

microtech DESIGNS EL00IG Wireless Vehicle Detection System Instruction Manual

<u>Home</u> » <u>microtech DESIGNS</u> » microtech DESIGNS EL00IG Wireless Vehicle Detection System Instruction Manual [™]

microtech DESIGNS EL00IG Wireless Vehicle Detection System Instruction Manual



Contents

- 1 Specifications
- **2 Wireless Vehicle Detection**

System

- 3 Fitting e-LOOP
- 4 Calibrate e-LOOP
- 5 Documents / Resources
 - **5.1 References**

Specifications

• Frequency: 433.39 MHz

• Security: 128-bitAESencryption

• Range: up to 30 metres

• Battery life: up to 10years

• Battery type: 14000 mAbattery

Wireless Vehicle Detection System

STEP 1:

Coding e-LOO Pintoe-Trans 50


Short range coding with magnet

 Powerup the e-TRANS50, then press and release theCODEbutton. TheblueLEDonthee-TRANS50 will light up, now place the magnet on the CODE recesson the e-Loop, the yellow LED willflash, and theblue LED on the e-TRANS50 willflash3 times. The systems are now paired, and you can remove the magnet

NOTE: For coding e-TRANS-200 LCD transceivers, refer to e-TRANS-200 manual

Long range coding with magnet

Powerup the e-TRANS50, then place the magnet on the code recess of the e-Loop, the yellow code LED will
flash once now remove magnet and the LED come on solid, now walk overto the e-TRANS 50 and press and
release the CODE button, the yellow LED will flash and the blue LED on the e-Trans50 willflash 3 times, after15
seconds the e-loop code LED will turn off



Changing mode using magnet (EL0OIG-RAD only)

Note: e-loop comes preset in presence m


- 1. Place a magnet on the MODE recess until the yellow starts LED flashing indicating presence mode, to change to exit mode place the magnet on the SET recess, the red LED will start flashing, to change to parking mode place the magnet on the MODE recess, the Yellow LED will come onsolid.
- 2. Wait 5 seconds until all LED's flash, we have now entered the confirmation menu, move to Step 3 or wait a further 5 seconds until all LED's flash 3 times to exit menu.
- 3. Confirmation mode. Once in the confirmation menu the red LED will be on solid meaning confirmation is not enabled, to enable place magnet on code recess, the yellow LED and red LED will be on, confirmation is now enabled, wait 5 seconds and both LED's willflash 3 times indicating menu has now been exited.

Fitting e-LOOP

(Referto diagram below)

1. Drill a 89-92mm hole, 65-70mm deep. Neurocoeles clean and dry before fitting. 2. Measure down before in sorting thee-LOOP to ensure it will fit flush with the drive way surface, then pour sikaflex or similar compound into the base of hole. 3. Insert the e-LOOP by pushing down until flush or slightly above the driveway surface. (Never push below the driveway surface)

NOTE: Ensure e-LOOP is fitted in a well drained area, as water over the e-LOOP can effect the radar detection system.



Calibrate e-LOOP

- 1. Move any metal objects away from the e-LOOP.
- 2. Place Magnetin to the SET button recess on the e-LOO Untethered LED flash Estwick, then remove the magnet.
- 3. Thee-LOOP will take about 5second stocalib rate and once complete, the red LED will flash 3times.

ERROR2: No radio connection yellow and red LED flashes 3 times before red LED flashes 3 times

Uncalibrate e-LOOP

Uncalibrate e-LOOP 1. Place magnet into the SET button recess until red LEDflashes4 times .e-LOOP is now uncalibrated.

Changing mode You can change the mode by using thee-TRANS-200 LCD transceiver or diagnostic remote EDOOR- refer to manual.

NOTE: This menu cannot be accessed via the e-TRANS-50 Transceiver. Thee-LOOPELOOIG is set-to EXIT mode (this can't be changed).

Parameters that can be altered:

- 1. Activation detection level
- 2. X. Y. Z axis sensitivity.

Parameters that can be altered on ELOOIG-RAD:

1. Mode is set to PRESENCE but can be changed to EXIT mode.

NOTE: do not use presence modes personal safety device.

- 2. Activation detection level
- 3. X, Y, Z axis sensitivity
- 4. Radar read time
- 5. Release trip point
- 6. Start lens detection range
- 7. Measure lens detection range
- 8. Radar trip sensitivity
- 9. Radar confirm ON/OFF

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the

FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna. -- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
- 1. This device may not cause harmful interference, and
- 2. this device must accept any interference received, including interference that may cause undesired operation.

Microtech Designs

enquiries@microtechdesigns.com.au





microtech DESIGNS EL00IG Wireless Vehicle Detection System [pdf] Instruction Manual EL00IG Wireless Vehicle Detection System, EL00IG, Wireless Vehicle Detection System, Vehicle Detection System, Detection System

References

- Monday Micro-Tech Designs, Inc.
- <u>Microtech Designs</u>
- User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.