



## Milesight UC50x Series LoRaWAN Controller User Guide

[Home](#) » [Milesight](#) » Milesight UC50x Series LoRaWAN Controller User Guide 

### Milesight UC50x Series LoRaWAN Controller User Guide



## Contents

- 1 Safety Precautions
- 2 Declaration of Conformity
- 3 Revision History
- 4 Product Introduction
  - 4.1 Overview
  - 4.2 Features
- 5 Hardware Introduction
  - 5.1 Packing List
  - 5.2 Hardware Overview
  - 5.3 Internal Interfaces
  - 5.4 Dimensions (mm)
- 6 Hardware Switch
- 7 Operation Guide
  - 7.1 Log in the ToolBox
  - 7.2 LoRaWAN Settings
  - 7.3 Interface Settings
  - 7.4 Maintenance
- 8 Installation
- 9 Milesight IoT Cloud Management
- 10 Device Payload
- 11 Documents / Resources
  - 11.1 References
- 12 Related Posts

## Safety Precautions

Milesight will not shoulder responsibility for any loss or damage resulting from not following the instructions of this operating guide.

- The device must not be remodeled in any way.
- Do not place the device close to objects with naked flames.
- Do not place the device where the temperature is below/above the operating range.
- Make sure electronic components do not drop out of the enclosure while opening.
- When installing the battery, please install it accurately, and do not install the reverse or wrong model.
- Make sure both batteries are newest when install, or battery life will be reduced.
- The device must never be subjected to shocks or impacts.

## Declaration of Conformity

UC50x series is in conformity with the essential requirements and other relevant provisions of the CE, FCC, and RoHS



All information in this guide is protected by copyright law. Whereby, no organization or individual shall copy or reproduce the whole or part of this user guide by any means without written authorization from Xiamen Milesight



For assistance, please contact

Milesight technical support:  
Email: [iot.support@milesight.com](mailto:iot.support@milesight.com)  
Tel: 86-592-5085280  
Fax: 86-592-5023065  
Address: Building C09, Software ParkIII,  
Xiamen 361024, China

## Revision History

Date	Doc Version	Description
Jan. 20, 2021	V 1.0	Initial version
Nov.26, 2021	V 1.1	Description Update
Dec. 9, 2021	V 2.0	Update based on 2.0 hardware

## Product Introduction

### Overview


UC50x series is a LoRaWAN® controller used for data acquisition from multiple sensors. It contains different I/O interfaces such as analog inputs, digital inputs, digital outputs, serial port and so on, which simplify the deployment and replacement of LoRaWAN® networks. UC50x series can be easily and quickly configured by NFC or wired USB port. For outdoor applications, it provides solar or built-in battery power supply and is equipped with IP67-rated enclosure and M12 connectors to protect itself from water and dust in harsh environments.

### Features

- Easy to connect with multiple wired sensors through GPIO/AI/RS232/RS485 interfaces
- Long transmission distance up to 15 km with line of sight
- Waterproof design including IP67 case and M12 connectors
- Solar powered and built-in battery optional
- Quick wireless configuration via NFC
- Compliant with standard LoRaWAN® gateways and network servers
- Quick and easy management with Milesight IoT Cloud solution


## Hardware Introduction

### Packing List




**!** If any of the above items is missing or damaged, please contact your sales Representative.

## Hardware Overview




## Data Interface 1:



Pin	Description
1	5V/9V/12V OUT (Switchable)
2	3.3V OUT
3	GND
4	Analog Input 1
5	Analog Input 2
<a href="#">612</a>	5-24V DC IN

Data Interface 2:




Pin	Description	
1	5V/9V/12V OUT (Switchable)	
2	3.3V OUT	
3	GND	
4	GPIO1	
5	GPIO2	
6	RS232/RS485 (Switchable)	
7		
8	Reserved	
Pin	RS232	RS485
6	TXD	A
7	RXD	B

1. When both DC external power and batteries are connected, external power will be the preferred power supply

option.

2. For UC502, the DC interface can't be to charge battery

### Internal Interfaces



### DIP Switch:

Interface	DIP Switch
Power Output	12V: 1 on 2 off 3 off 9V: 1 off 2 on 3 off 5V: 1 off 2 off 3 on
Analog Input	4-20mA ADC: 1 off 2 on 3 on 0-10V ADC: 1 on 2 off 3 off
RS485	Add 120 $\Omega$ resistor between A and B: 1 on 2 off 3 off Add 1k $\Omega$ pull-up resistor on A: 1 off 2 on 3 off Add 1k $\Omega$ pull-down resistor on B: 1 of 2 off 3 on


### Note:

1. Analog inputs are set to 4-20mA by default, power outputs are set to 12V by default.
2. Power output on interface 1 is used for powering analog devices, power output on interface2is used for powering serial port devices.

### Power Button:

Function	Action	LED Indication
Turn On	Press and hold the button for more than 3s.	Off → <b>On</b>
Turn Off	Press and hold the button for more than 3s.	<b>On</b> → Off
Reset	Press and hold the button for more than 10s.	Blinks.
Check On/Of Status	Quickly press the power button.	<b>Light On</b> : Device is on.
		Light Off: Device is off.

#### Dimensions (mm)




#### Hardware Switch

When using the analog input or power output of UC50x series, please follow the steps to switch the working mode of hardware interface:

1. Remove the screw caps and take off the roof cover.
2. Change DIP switches that are related analog inputs and power outputs as shown in **Section 2.3**.
3. Put back the roof cover and screw the screws.

**Note: turn off the device before changing DIP switches.**



## Operation Guide

### Log in the ToolBox

UC50x series can be configured via NFC or Type-C port. Please select one of them to complete configuration.

### NFC Configuration

1. Download and install “Milesight ToolBox” App from Google Play or Apple App Store.
2. Enable NFC on the smart phone and launch Milesight ToolBox.
3. Attach the smart phone with NFC area to the device to read device information.
4. Basic information and settings of the device will be shown on ToolBox App if it's recognized successfully. You can read and configure the device by tapping the Read/Write device on the App. In order to protect the security of the device, password validation is required when first configuration. The default password is **123456**.




### Note

1. Ensure the location of smart phone NFC area and it's recommended to take off phone case.
2. If the smart phone fails to read/write configurations via NFC, keep the phone away and backto try again.
3. UC50x series can also be configured by dedicated NFC reader, which can be purchased from Milesight IoT.

### USB Configuration



1. Download ToolBox software from **Milesight IoT website**.
2. Open the case of UC50x and connect the UC50x to computer via type-C port.



3. Open the ToolBox and select type as “General”, then click password to log in ToolBox. (Default password: **123456**)

A screenshot of the 'ToolBox Settings' dialog box. It has a blue header with the title 'ToolBox Settings' and a close button. The settings are as follows:

Type	General
Serial port	COM4
Login password	
Baud rate	115200
Data bits	8
Parity bits	None
Stop bits	1

At the bottom, there are two buttons: 'Save' and 'Cancel'.

4. After logging in the ToolBox, you can click “Power On” or “Power Off” to turn on/off device and change other settings.

A screenshot of the ToolBox main interface. On the left is a dark sidebar with three icons: 'Status', 'General', and 'LoRaWAN Settings'. The 'Status' icon is selected. The main area has a header 'Status >' and a 'Power On' button. Below is a table of device information:

Model:	UC501-915
Serial Number:	6412A4304414
Firmware Version:	01.01
Hardware Version:	2.1
Device Status:	Off
Join Status:	-
RSSI/SNR:	-
Battery:	-
Channel Mask:	-
Uplink Frame-counter:	-
Downlink Frame-counter:	-

## LoRaWAN Settings

LoRaWAN settings is used for configuring the transmission parameters in LoRaWAN® network.

### Basic LoRaWAN Settings:

Go to “LoRaWAN -> Basic” of ToolBox software or “Setting -> LoRaWAN Settings” for ToolBoxApp to configure join type, App EUI, App Key and other information. You can also keep all settings by default.

Device EUI	<input type="text" value="24E1244102404123"/>
App EUI	<input type="text" value="24E124C0002A0001"/>
Application Port	<input type="text" value="85"/>
Join Type	<input type="text" value="OTAA"/>
Application Key	<input type="text" value="*****"/>
Spread Factor	<input type="text" value="SF12-DR0"/>
Confirmed Mode	<input checked="" type="checkbox"/>
Rejoin Mode	<input checked="" type="checkbox"/>
Set the number of packets sent	<input type="text" value="32"/> packets
ADR Mode	<input type="checkbox"/>
TXPower	<input type="text" value="TXPower0-16 dBm"/>

Parameters	Description
Device EUI	Unique ID of the device which can also be found on the label.
App EUI	Default App EUI is 24E124C0002A0001.
Application Port	The port used for sending and receiving data, default port is 85. Note: RS232 data will be transmitted via another port.
Working Mode	UC501: Class A and Class C are available; UC502: Class A.
Join Type	OTAA and ABP mode are available.
Application Key	Appkey for OTAA mode, default is 5572404C696E6B4C6F52613230313823.
Device Address	DevAddr for ABP mode, default is the 5th to 12th digits of SN.
Network Session Key	Nwkskey for ABP mode, default is 5572404C696E6B4C6F52613230313823.
Application Session Key	Appskey for ABP mode, default is 5572404C696E6B4C6F52613230313823.
Spread Factor	If ADR is disabled, the device will send data via this spread factor.
Confirmed Mode	If the device does not receive ACK packet from network server, it will resend data 3 times at most.
Rejoin Mode	Reporting interval $\leq 30$ mins: the device will send specific mounts of LoRaMAC packets to check connection status every 30 mins; If no reply after specific packets, the device will re-join.
	Reporting interval $> 30$ mins: the device will send specific mounts of LoRaMAC packets every to check connection status every reporting interval; If no reply after specific packets, the device will re-join.
ADR Mode	Allow network server to adjust datarate of the device.
Tx Power	Tx power of the device.

**Note:**

1. Please contact sales for device EUI list if there are many units.
2. Please contact sales if you need random App keys before purchase.
3. Select OTAA mode if you use Milesight IoT cloud to manage devices.
4. Only OTAA mode supports rejoin mode

**LoRaWAN Frequency Settings:**

Go to “**LoRaWAN -> Channel**” of ToolBox software or “Setting -> **LoRaWAN Settings**” for ToolBox APP to select supported frequency and select channels to send uplinks. Make sure the channels match the LoRaWAN® gateway

<input type="checkbox"/>	Index	Frequency/MHz	Max Datarate	Min Datarate
<input checked="" type="checkbox"/>	0	868.1	5-SF7BW125	0-SF12BW125
<input checked="" type="checkbox"/>	1	868.3	5-SF7BW125	0-SF12BW125
<input checked="" type="checkbox"/>	2	868.5	5-SF7BW125	0-SF12BW125
<input type="checkbox"/>	3	0	5-SF7BW125	0-SF12BW125
<input type="checkbox"/>	4	0	5-SF7BW125	0-SF12BW125
<input type="checkbox"/>	5	0	5-SF7BW125	0-SF12BW125
<input type="checkbox"/>	6	0	5-SF7BW125	0-SF12BW125

If frequency is one of CN470/AU915/US915, you can enter the index of the channel that you want to enable in the input box, making them separated by commas.

**Examples:**

- 1, 40: Enabling Channel 1 and Channel 40
- 1-40: Enabling Channel 1 to Channel 40
- 1-40, 60: Enabling Channel 1 to Channel 40 and Channel 60
- All: Enabling all channels
- Null: Indicates that all channels are disabled

Channel Index	Frequency/MHz	Channel Spacing/MHz	BW/kHz
0 - 15	915.2 - 918.2	0.2	125
16 - 31	918.4 - 921.4	0.2	125
32 - 47	921.6 - 924.6	0.2	125
48 - 63	924.8 - 927.8	0.2	125
64 - 71	915.9 - 927.1	1.6	500

**Note:**

For -868M model, default frequency is EU868;

For -915M model, default frequency is AU915.

### Interface Settings

UC50x series support data collection by multiple interfaces including GPIOs, analog input and serial ports. Besides, it can also power the terminal devices by power output interfaces. Basic settings are as follows: Go to "General -> Basic" of ToolBox software or "Setting -> General Settings" page to change the reporting interval.

Reporting Interval	<input type="text" value="10"/> s
The device returns to the power supply state	<input type="text" value="Last working status"/> ▼
Interface 2 (Pin2) 3V3 Output	<input type="checkbox"/>
Interface 1 (Pin2) 3V3 Output	<input type="checkbox"/>
Change Password	<input type="checkbox"/>

Parameters	Description
Reporting Interval	Reporting interval of transmitting data to network server. Default: 20 mins, Range: 1-1080 mins. <b>Note:</b> RS232 transmission will not follow the reporting interval.
The device returns to the power supply state	If the device loses power and return to power supply, the device will be on or off according to this parameter.
Interface 1/2 3V3 Output	Enable 3.3V power output. After enabled, the power output will supply power <b>continuously</b> .
Change Password	Change the password for ToolBox APP or software to read/write this device.

## RS485 Settings

1. Connect RS485 device to RS485 port on interface. If you need UC50x to power the RS485 device, please connect the power cable of RS485 device to 5V/9V/12V power output on interface 2.
2. Go to "General -> Serial" of ToolBox software or "Setting -> Serial Setting" to enable RS485 and configure serial port settings. Serial port settings should be the same as RS485 terminal devices.

Enable	<input checked="" type="checkbox"/>
Interface Type	RS485 (Modbus Master) ▼
Interface 2 (Pin1) 5/9/12V Output	<input type="checkbox"/>
Baud Rate	9600 ▼
Data Bit	8 bits ▼
Stop Bit	1 bits ▼
Parity	None ▼
Execution Interval	50 ms
Max Resp Time	500 ms
Max Retry Times	3
Modbus RS485 bridge LoRaWAN	<a href="#">?</a> <input type="checkbox"/>

Parameters	Description
Interface 2(Pin 1) 5V /9V/12V	Enable 5V/9V/12V power output of interface 2 to supply power to RS485 terminal devices. It's 12V by default and you can change <a href="#">DIP switches</a> to change voltage.
Power Output Time Before Collect	UC50x will power the RS485 terminal devices for a period of time before collecting data for terminal device initialization.
Baud Rate	1200/2400/4800/9600/19200/38400/57600/115200 are available.
Data Bit	8 bit is available.
Stop Bit	1 bit/2 bit are available.
Parity	None, Odd and Even are available.
Execution Interval	The execution interval between each Modbus command.
Max Resp Time	The maximum response time that the UC50x waits for the reply to the command. If it does not get a response after the max response time, it is determined that the command has timed out.
Max Retry Time	Set the maximum retry times after device fails to read data from RS485 terminal devices.
Modbus RS485 bridge LoRaWAN	If this mode is enabled, UC50x will transparent Modbus RTU commands from network server to RS485 terminal devices and send Modbus reply originally back to network server. <b>Port:</b> Select from 2-84, 86-223.

**Note:** When you use power output to power RS485 Modbus slave devices, it only supplies power when reporting interval is coming. It's suggested to power slave devices with external power during the PoC test.

- Click  to add Modbus channels, then save configurations

Channel Settings Fetch

Channel ID	Name	Slave ID	Address	Quantity	Type	Sign	Value
1	Temperature	1	0	1	Input Register(INT16)	<input type="checkbox"/>	

Save Fetch ✕ + Up to 16 channels

Parameters	Description
Channel ID	Select the channel ID you want to configure, 16 channels selectable.
Name	Customize the name to identify every Modbus channel.
Slave ID	Set Modbus slave ID of terminal device.
Address	The starting address for reading.
Quantity	Set read how many digits from starting address. It fixes to 1.
Type	Select data type of Modbus channels.
Sign	The tick indicates that the value has a plus or minus sign.

**Example:** If you configure as following picture, UC50x will send Modbus read command to terminal device regularly: 01 03 00 00 00 01 84 0A

Channel ID	Name	Slave ID	Address	Quantity	Type	Sign	Decimal Place	Value
1	Temperature	1	0	1	Holding Register(INT16)	<input type="checkbox"/>	0	

4. For ToolBox software, click “Fetch” to check if UC50x can read correct data from terminal devices. You can also click “Fetch” on the top of list to fetch all channel data.

Channel ID	Name	Slave ID	Address	Quantity	Type	Sign	Value
1	1	1	16	1	Input Register(INT16)	<input checked="" type="checkbox"/>	554
2	2	2	12	1	Holding Register(INT16)	<input type="checkbox"/>	
3	1	1	17	1	Input Register(INT16)	<input type="checkbox"/>	

**Note:** Please do not click “Fetch” frequently since response time to reply is differ for every terminal device.

For ToolBox App,

- a. Tap every Modbus channel, click “Collect” and attach smart phone to device to make device collect data.



←

Temperature

\* Name

Temperature

Slave ID

-

1

+

Address

-

0

+

Quantity

1

Type

Holding Register(INT16)

Sign

☐

Value

-

Collect

b. Click “Fetch” and attach smart phone to make APP read the data. You can also tap “Collect All” and “Fetch All” to fetch all channel data.

## RS232 Settings

1. Connect RS232 device to RS232 port on interface If you need UC501 to power the RS232 device, connect the power cable of RS232 device to 5V/9V/12V power output on interface 1.
2. Go to “**General -> Serial**” of ToolBox software or “**Setting -> Serial Setting**” to enable RS232 and configure serial port settings. Serial port settings should be the same as RS232 terminal devices.

Enable

☒

Interface Type

RS232

Interface 2 (Pin1)  
5/9/12V Output

☐

Baud Rate

9600

Data Bit

8 bits

Stop Bit

1 bits

Parity

None

Port

86

Parameters	Description
Interface 2(Pin 1) 5V/9V/12V	Enable 5V/9V/12V power output of interface 2 to supply power to RS232 terminal devices <b>continuously</b> . Only UC501 supports this feature. <b>Note:</b> Power output is 12V by default and you can change <a href="#">DIP switches</a> to change voltage.
Baud Rate	300/1200/2400/4800/9600/19200/38400/57600/115200 are available.
Data Bit	8 bit is available.
Stop Bit	1 bit/2 bit are available.
Parity	None, Odd and Even are available.
Port	The port used for RS232 data transmission.

## GPIO Settings

1. Connect devices to GPIO ports on interface 2.
2. Go to **“General -> GPIO”** of ToolBox software or **“Setting -> GPIO Setting”** to enable GPIOport

Interface Name

GPIO 1

Enable

☒

Interface Type

Digital Input1

Digital Input

Status

Fetch

Interface Name

GPIO 2

Enable

☒

Interface Type

Digital Input2

Digital Input

Status

Fetch

Save

3. Select GPIO type according to your requirements.

- Digital Input: detect high or low status of devices;
- Digital Output: Send voltage signal to trigger devices;
- Counter: pulse counter.


### Digital Input:

Select initial status of digital input. If pull up is selected, falling edge will be triggered; if pull down is selected, rising edge will be triggered. After selection, click “Fetch” to check current status of digital input.

Interface Name	GPIO 1		
Enable	<input checked="" type="checkbox"/>		
Interface Type	Digital Input1		
Digital Input		Pull Down	
Status	Low		Fetch

### Digital Output:

Click “Switch” to check if UC50x can trigger devices by digital output or click “Fetch” to check current status of digital output

Interface Name	GPIO 1		
Enable	<input checked="" type="checkbox"/>		
Interface Type	Digital Output1		
Status	Low		Fetch Switch

### Pulse Counter:

Interface Name	GPIO 1		
Enable	<input checked="" type="checkbox"/>		
Interface Type	Counter		
Digital Input		Pull Down	
Digital Filter		<input checked="" type="checkbox"/>	
keep last value when power off	<input checked="" type="checkbox"/>		
Counter values	0	Refresh	Start Clear

Parameters	Description
Digital Input	Initial status of counter. Pull Down: Increase 1 when detecting rising edge Pull Up/None: Increase 1 when detecting falling edge
Digital Filter	It's recommended to enable when pulse period is greater than 250 us.
Keep last value when power off	Keep the counted values when the device powers off.
Start/Stop	Make the device start/stop counting. <b>Note:</b> UC50x will send non-changable counting values if you do not click "Start".
Refresh	Refresh to get latest counter values.
Clear	Count the value from 0.

## AI Settings

1. Connect analog device to analog input ports on interface 1. If you need UC50x to power the analog device, connect the power cable of analog device to 5V/9V/12V power output on interface 1.
2. Go to **"General -> AI"** of ToolBox software or **"Setting -> AI Setting"** to enable analog input.

Interface 1 (Pin1)  
5/9/12V Output ☒

Power Output Time Before Collect  s

Interface Name

Enable ☒

Analog Input Signal Type

Status

Interface Name

Enable ☒

Analog Input Signal Type

Status

3. Select analog input type according to analog device type. Note: Ensure **DIP switches** has changed before

changing “Analog Input Signal Type” to 0-10V.

4. Enable “Interface 1 (Pin 1) 5V/9V/12V” and configure “Power Output Time Before Collect”, UC50x will power the analog devices for a period of time before collecting data.




Interface 1 (Pin1)  
5/9/12V Output ☒

Power Output Time Before Collect  s

**Note:** When you use power output to power analog devices, it only supplies power when reporting interval is coming. It's suggested to power slave devices with external power during the PoC test.


5. For ToolBox software, click “Fetch” to check if UC50x can read correct data from analog devices.



Interface Name Analog Input 2


Enable ☒

Analog Input Signal Type

Status   [Fetch](#)

For ToolBox App,

- a. Click “Collect” and attach smart phone to device to make device collect data.
- b. Click “Fetch” and attach smart phone to make APP read the data.



AI Settings ^

Interface 2(Pin 1) 5/9/12V ☐

Analog Input 1 ☒

Analog input Signal Type

Status - mA [Collect](#)

## Maintenance

## Upgrade

### ToolBox Software:

1. Download firmware from [www.milesight-iot.com](http://www.milesight-iot.com) to your PC.
2. Go to “Maintenance -> Upgrade” of ToolBox software, click “Browse” to import firmware and upgrade the

device. You can also click “Up to Date” to search for the latest firmware of the device and upgrade.

Upgrade

Backup and Reset

Model:

UC502-868M

Firmware Version:

01.07

Hardware Version:

2.1

Domain:

Beijing Server

FOTA:

Up to date

Update Locally

Browse

Upgrade

### ToolBox App:

1. Download firmware from [www.milesight-iot.com](http://www.milesight-iot.com) to your smart phone.
2. Open ToolBox App and click “Browse” to import firmware and upgrade the device.

### Note:

1. Operation on ToolBox is not supported during the upgrade.
2. Only Android version ToolBox supports the upgrade feature.

Status

Setting

Maintenance

SN

6412B3029235

Model

UC501-868M

Firmware Version

V1.2

Hardware Version

V2.0

Manual Upgrade

Browse

### Backup

UC50x devices support configuration backup for easy and quick device configuration in bulk. Backup is allowed only for devices with the same model and LoRa frequency band. Please select one of following methods to backup device:

### ToolBox Software:

1. Go to “Maintenance -> Backup and Reset”, click “Export” to save current configuration as json format backup file.

2. Click “Browse” to select backup file, then click “Import” to import the configurations.

The screenshot shows a software interface with a top navigation bar containing two tabs: 'Upgrade' and 'Backup and Reset'. The 'Backup and Reset' tab is currently selected. Below the navigation bar, there are three main sections. The first section is labeled 'Config Backup' and contains a blue 'Export' button. The second section is labeled 'Config File' and contains a text input field, a blue 'Browse' button, and a blue 'Import' button. The third section is labeled 'Restore Factory Defaults' and contains a blue 'Reset' button.

### ToolBox App:

1. Go to “Template” page on the App and save current settings as a template. You can also edit the template file.
2. Select one template file which saved in the smart phone and click “Write”, then attach to another device to write configuration.

The screenshot shows the 'Template' page of the ToolBox App. At the top, there is a blue header with the word 'Template'. Below the header, there is a search bar and a list of templates. One template is visible: 'EM500-UDL-868M\_20201124' with a subtext 'Last Modified Time: 2020-11-24 17:06:26'. A modal dialog box titled 'New Template' is open in the center. It contains the text 'Please enter template name' and a text input field with the value 'UC500-915M\_20201228'. Below the input field are two buttons: 'Cancel' and 'OK'. At the bottom of the screen, there is a blue button labeled 'Save as a New Template'. The bottom navigation bar has two icons: 'Device' and 'Template', with 'Template' being the active icon.

### Reset to Factory Default

Please select one of following methods to reset device:

**Via Hardware:** Open the case of UC50x and hold on power button more than 10s.

**Via ToolBox Software:** Go to “**Maintenance -> Backup and Reset**” to click “Reset”.

Upgrade

Backup and Reset

Config Backup

Export

Config File

Browse

Import

Restore Factory Defaults

Reset

**Via ToolBox App:** Go to “Device -> Maintenance” to click “Reset”, then attach smart phone with NFC area to UC50x to complete reset.

Status

Setting

Maintenance

SN

6412B3029235

Model

UC501-868M

Firmware Version

V1.2

Hardware Version

V2.0

Manual Upgrade

Browse

Restore Factory Default


Reset

## Installation

UC50x series support wall mounting or pole mounting. Before installation, make sure you have the mounting bracket, wall or pole mounting kits and other required tools.

### Wall Mounting:


1. Fix the wall plugs into the wall, then fix the mounting bracket to the wall plugs with screws.
2. Put the device on the mounting bracket, then fix the bottom of the device to the bracket with a fixing screw.





## Pole Mounting:


1. Straighten out the hose clamp and slide it through the rectangular rings in the mounting bracket, wrap the hose clamp around the pole. After that use a screwdriver to tighten the locking mechanism by turning it clockwise.
2. Put the device on the mounting bracket, then fix the bottom of the device to the bracket with a fixing screw.



## Milesight IoT Cloud Management

UC50x series can be managed by Milesight IoT Cloud platform. Milesight IoT cloud is a comprehensive platform that provides multiple services including device remote management and data visualization with the easiest operation procedures. Please register a Milesight IoT Cloud account before operating following steps.

1. Ensure Milesight LoRaWAN® gateway is online in Milesight IoT Cloud. For more info about connecting gateway to cloud please refer to gateway's user guide.



2. Go to “My Devices” page and click “+New Devices”. Fill in the SN of UC50x and select associated gateway.

**Add Device**

\* SN: 6412A5196409


\* Name: UC501

\* Associated Gateway: UG Gateway

\* Device EUI: 24e124412A519640

\* Application Key: 5572404c696e6b4c6f52613230313823

Cancel Confirm

3. For UC501, click  and go to “Basic Settings” to change class type the same as device settings.

Devices / UC501 / Basic Settings

Basic Settings Interface Settings Maintenance Log

\* Name: UC501

\* Application Key: 5572404c596e6b4c52613230313823

LoRaWAN Class: classC

Description:

\* Reporting Interval: 20 min

4. After UC50x is online in Milesight IoT Cloud, click  and go to “Interface Settings” to select used interfaces and customize the name, sign and formulas.

**Note:** Modbus channel settings should be the same as the configuration in ToolBox.

Dashboard

My Devices

Map

Triggers

Reports

Event Center

Sharing Center

Me

Devices / UC501 / Interface Settings

Basic Settings Interface Settings Maintenance Log

Enable	Name	Type	Custom Name	Current Value	Alarm Threshold
<input checked="" type="checkbox"/>	GPIO_1	Digital Input	Low High	-	Disable
<input checked="" type="checkbox"/>	GPIO_2	Digital Output	Low High	-	Disable

Enable	Name	Type	On	Off	Unit	Current Value	Alarm Threshold
<input type="checkbox"/>	AI_1	4 - 20mA	20	mA	mA	0.00 - 0.01 Min - 0.01 Max - 0.01 Avg - 0.01	0
<input type="checkbox"/>	AI_2	4 - 20mA	20	mA	mA	0.00 - 0.01 Min - 0.01 Max - 0.01 Avg - 0.01	0

Channel ID	Channel Name	Type	Sign	Raw Data	Formula	Value	Unit	Alarm Threshold	Operation
1	Temperature			HEX DEC				0	



## Device Payload

UC50x Series use the standard Milesight IoT payload format based on IPSO. Please refer to the UC50x Series Communication Protocol; for decoders of Milesight IoT products please **click here**.

[www.milesight-iot.com](http://www.milesight-iot.com)



## Documents / Resources

<div><div><div>Milesight</div><div>LoRaWAN® Controller</div><div>UC50x Series</div><div>User Guide</div></div><div></div></div>	<p><a href="#">Milesight UC50x Series LoRaWAN Controller</a> [pdf] User Guide</p> <p>UC50x Series, LoRaWAN Controller, UC50x Series LoRaWAN Controller, UC501, UC502</p>
<div><div><div>Milesight</div><div>LoRaWAN® Controller</div><div>UC50x Series</div><div>User Guide</div></div><div></div></div>	<p><a href="#">Milesight UC50x Series LoRaWAN Controller</a> [pdf] User Guide</p> <p>UC50x Series, UC50x Series LoRaWAN Controller, LoRaWAN Controller, Controller</p>

References

-  [Milesight IoT - LoRaWAN, 5G & AIoT](#)