



Milesight WS558 Smart Light Controller User Guide

[Home](#) » [Milesight](#) » [Milesight WS558 Smart Light Controller User Guide](#) 

Contents

- [1 Milesight WS558 Smart Light Controller](#)
- [2 Safety Precautions](#)
- [3 Hardware Introduction](#)
- [4 Operation Guide](#)
- [5 Installation](#)
- [6 Device Payload](#)
- [7 Documents / Resources](#)
 - [7.1 References](#)
- [8 Related Posts](#)



Milesight WS558 Smart Light Controller



Safety Precautions

Milesight will not shoulder responsibility for any losses or damages resulting from not following the instructions of this operating guide.

- The device must not be modified in any way.
- To protect the security of the device, please change device the password when first configuration. The default password is 123456.
- The installation and maintenance must be conducted by a qualified service person and should strictly comply with the electrical safety regulations of the local region.
- Ensure power is off during the installation.
- For the LN model, do not reverse the Live Wire (L) and Neutral (N) wire.
- To get the best data transmission, ensure the device is within the signal range of the LoRaWAN® gateway and keep it away from metal objects and obstacles.
- Do not overload the maximum capacity to avoid damage to the device.
- The device is intended only for indoor use. Do not place the device where the temperature is below/above the operating range.
- Do not place the device close to objects with naked flames, heat source (oven or sunlight), cold source, liquid and extreme temperature changes.
- Keep the device away from water to prevent electric shock.
- Use the device only in a clean environment. Dusty or dirty environments may prevent the proper operation of this device.
- Do not drop the device or subject it to physical shocks and strong vibration.

Product Introduction

Overview

WS558 is a LoRaWAN® Smart Light Controller for the monitoring and control of lights. With 2 circuit types and 8 switches, WS558 can fit in different rooms without the need for re-wirings and reduce the renovation costs. Besides LoRaWAN®, WS558 can be controlled without a gateway via Milesight D2D communication protocol, which sets up a connection quickly. WS558 can be widely used for wireless control of indoor lights, fans, heaters, machines, etc. Power data and switch status are transmitted via LoRaWAN® protocol, and LoRaWAN® technology enables encrypted radio transmissions over long distances while consuming very little power. Also, users can check visualized data through Milesight IoT Cloud or the user's own Application Server.

Features

- LN type or switch type optional, controls up to 8 circuits of lights, adopts different indoor wiring
- Support local switch button control, able to test the lamp status without networking
- Collect data on current, voltage, electrical consumption
- Up to 15 km communication range
- Easy configuration via NFC
- Standard LoRaWAN® technology
- Compatible with Milesight IoT Cloud and Milesight ToolBox
- Support Milesight D2D protocol to enable ultra-low latency control without gateway
- Support multicast for control in bulk


Hardware Introduction

Packing List



1 ×

WS558 Controller



4 ×

Wall Mounting Kits



1 ×

Quick Guide




1 ×

Warranty Card

If any of the above items is missing or damaged, please contact your sales representative.


Hardware Overview




All circuits/switches are open with their LED indicator off by default. You can press the button beneath their LED indicator to close a circuit/switch, and the LED indicator will be lit on as the lamp connected to this circuit/switch.

Wiring Diagram


LN Model:



Switch Model:



Dimensions (mm)




Operation Guide

ToolBox Login

WS558 can be configured via NFC or Type-C port. Please select one of them to complete the configuration.

NFC Configuration

1. Download and install "Milesight ToolBox" App from Google Play or Apple App Store.
2. Enable NFC on the smartphone and launch Milesight ToolBox.
3. Attach the smartphone with the NFC area to the device to read device information. Basic information and settings of the device will be shown on ToolBox App if it's recognized successfully. You can read and configure the device by tapping the Read/Write device on the App. To protect the security of the device, password validation is required when first configuration. The default password is **123456**.




Note:

1. Check the NFC area of your smartphone and it's recommended to remove the phone case.
2. If the smartphone fails to read/write configurations via NFC, move the phone away and back to try again.
3. WS558 can also be configured on ToolBox via a dedicated NFC reader provided by Milesight IoT.

USB Configuration

1. Download ToolBox software from www.milesight-iot.com.
2. Connect the device to a computer via the Type-C port. Please note that do not touch the power interface, switches and other wirings to avoid electric shock.



3. Open the ToolBox and select type as “General”, then click password to log into the **ToolBox**. (Default password: **123456**)

A screenshot of a software window titled "ToolBox Settings" with a close button (X) in the top right corner. The window contains several configuration options, each with a label and a dropdown menu or text field. At the bottom are "Save" and "Cancel" buttons.

Label	Value
Type	General
Serial port	COM4
Login password	
Baud rate	115200
Data bits	8
Parity bits	None
Stop bits	1

4. After logging into the ToolBox, you can check device status and change device

Model:	WS558-915M
Serial Number:	6756C22186300001
PN:	LN
Device EUI:	24e124756c221863
Firmware Version:	01.01-a3
Hardware Version:	2.0
Device Status:	On
Join Status:	De-Activate
RSSI/SNR:	0/0
Voltage:	222V
Total Current:	5mA
Power Consumption:	0kWh
Channel Mask:	0000000000000000ff00
Uplink Frame-counter:	0
Downlink Frame-counter:	0

Reset

LoRaWAN Settings

LoRaWAN settings are used to configure the data transmission parameters in the LoRaWAN® network.

Basic Settings

WS558 supports basic configurations like join type, App EUI, App Key and other information. You can also keep all settings by default.

Device EUI	<input type="text" value="24E124756C221863"/>
App EUI	<input type="text" value="24E124C0002A0001"/>
Application Port	<input type="text" value="85"/>
Join Type	<input type="text" value="OTAA"/>
Application Key	<input type="text" value="*****"/>
RX2 Data Rate	<input type="text" value="DR8 (SF12, 500k)"/>
RX2 Frequency	<input type="text" value="923300000"/>

Spread Factor	<input type="text" value="SF8-DR2"/>
Confirmed Mode	<input type="checkbox"/>
Rejoin Mode	<input checked="" type="checkbox"/>
Set the number of packets sent	<input type="text" value="32"/> packets
ADR Mode	<input checked="" type="checkbox"/>
TXPower	<input type="text" value="TXPower0-22 dBm"/>

Parameters	Description
Device EUI	Unique ID of the device which can also be found on the label.
App EUI	Default App EUI is 24E124C0002A0001.
Application Port	The port used for sending and receiving data, default port is 85.
Join Type	OTAA and ABP modes are available.
Application Key	Appkey for OTAA mode, default is 5572404C696E6B4C6F52613230313823.
Device Address	DevAddr for ABP mode, default is the 5th to 12th digits of SN.
Network Session Key	Nwkskey for ABP mode, default is 5572404C696E6B4C6F52613230313823.
Application Session Key	Appskey for ABP mode, default is 5572404C696E6B4C6F52613230313823.
RX2 Data Rate	RX2 data rate to receive downlinks or Milesight D2D commands.
RX2 Frequency/MHz	RX2 frequency to receive downlinks or Milesight D2D commands.
Spread Factor	If ADR is disabled, the device will send data via this spread factor.

Confirmed Mode	If the device does not receive the ACK packet from network server, it will resend data once.
Rejoin Mode	<p>Reporting interval ≤ 30 mins: the device will send a specific number of LinkCheckReq MAC packets to the network server every 30 mins to validate connectivity; If there is no response, the device will re-join the network.</p> <p>Reporting interval > 30 mins: the device will send a specific number of LinkCheckReq MAC packets to the network server every reporting interval to validate connectivity; If there is no response, the device will re-join the network.</p>
ADR Mode	Allow the network server to adjust the data rate of the device.
Tx Power	Transmit power of the device.

Note:

1. Please contact your sales representative for device EUI list if there are many units.
2. Please contact your sales representative if you need random App keys before purchase.
3. Select OTAA mode if you use Milesight IoT Cloud to manage devices.
4. Only OTAA mode supports rejoin mode.

Frequency Settings

Select supported frequency and channels to send uplinks. Make sure the channels match the LoRaWAN® gateway.

Basic

Channel

Support Frequency : EU868

<input type="checkbox"/>	Index	Frequency/MHz	Max Datarate	Min Datarate
<input checked="" type="checkbox"/>	0	868.1	5-SF7BW125	0-SF12BW125
<input checked="" type="checkbox"/>	1	868.3	5-SF7BW125	0-SF12BW125
<input checked="" type="checkbox"/>	2	868.5	5-SF7BW125	0-SF12BW125
<input type="checkbox"/>	3	0	5-SF7BW125	0-SF12BW125
<input type="checkbox"/>	4	0	5-SF7BW125	0-SF12BW125
<input type="checkbox"/>	5	0	5-SF7BW125	0-SF12BW125
<input type="checkbox"/>	6	0	5-SF7BW125	0-SF12BW125

If the device frequency is one of CN470/AU915/US915, you can enter the index of the channel that you want to enable in the input box, making them separated by commas.

Examples:

- 1, 40: Enabling Channel 1 and Channel 40
- 1-40: Enabling Channel 1 to Channel 40
- 1-40, 60: Enabling Channel 1 to Channel 40 and Channel 60
- **All**: Enabling all channels
- **Null**: Indicates that all channels are disabled

Support Frequency : AU915

Enabled Channel Index: ? 0-71

Channel Index	Frequency/MHz	Channel Spacing/MHz	BW/kHz
0 - 15	915.2 - 918.2	0.2	125
16 - 31	918.4 - 921.4	0.2	125
32 - 47	921.6 - 924.6	0.2	125
48 - 63	924.8 - 927.8	0.2	125
64 - 71	915.9 - 927.1	1.6	500

Note

- For -868M model, the default frequency is EU868;
- For -915M model, the default frequency is AU915.

Multicast Settings

WS558 supports setting up several multicast groups to receive multicast commands from network servers and

users can use this feature to control devices in bulks.

1. Enable Multicast Group on WS558, set a unique multicast address and keys to distinguish other groups. You can also keep these settings by default.

Multicast Group 1

☒

Multicast Address

?

11111111

Multicast McAppSKey

Multicast McNetSKey

Multicast Group 2

☐

Multicast Group 3

☐

Multicast Group 4

☐

Parameters	Description
Multicast Address	Unique 8-digit address to distinguish different multicast groups.
	32-digit key. Default values:
Multicast McAppSkey	Multicast Group 1: 5572404C696E6B4C6F52613230313823 Multicast Group 2: 5572404C696E6B4C6F52613230313824 Multicast Group 3: 5572404C696E6B4C6F52613230313825
	Multicast Group 4: 5572404C696E6B4C6F52613230313826
	32-digit key. Default values:
Multicast McNetSkey	Multicast Group 1: 5572404C696E6B4C6F52613230313823 Multicast Group 2: 5572404C696E6B4C6F52613230313824 Multicast Group 3: 5572404C696E6B4C6F52613230313825
	Multicast Group 4: 5572404C696E6B4C6F52613230313826

2. Add a multicast group on the network server. Take Milesight UG6x gateway as example, go to “**Network Server -> Multicast Groups**”, click “**Add**” to add a multicast group.

Status

Packet Forwarder

Network Server

Network

General

Applications

Profiles

Device

Multicast Groups

Gateway Fleet

Packets

Multicast Groups

Add

Search

Multicast Address	Group Name	Number of Devices	Operation
No matching records found			

Fill in the multicast group information the same as **WS558** settings, and select the devices which you need to control, then click **“Save”**.

Group Name

WS558 Control

Multicast Address

11111111

Multicast Network Session Key

5572404C696E6B4C6F526132

Multicast Application Session Key

5572404C696E6B4C6F526132

Class Type

Class C

Datarate

DR0 (SF12, 125 kHz)

Frequency

505300000

Hz

Frame-counter

0

Selected Devices

WS558

General

Applications

Profiles

Device

Multicast Groups


Gateway Fleet

Packets

Multicast Groups

Add

Search

Multicast Address	Group Name	Number of Devices	Operation
11111111	WS558 Control	2	 

3. Go to **“Network Server -> Packets”**, select the multicast group and fill in the downlink command, click **“Send”**.
The network server will broadcast the command to devices which belong to this multicast group.

Note: ensure all devices’ application ports are the same.

Status

Packet Forwarder

Network Server

Network

System

Maintenance

APP

General

Applications

Profiles

Device

Multicast Groups

Gateway Fleet

Packets

Send Data To Device

Device EUI	Type	Payload	Port	Confirmed	
0000000000000000	ASCII		85	<input type="checkbox"/>	<div>Send</div>

Send Data to Multicast Group

Multicast Group	Type	Payload	Port	
WS558 Control	hex	#31##	85	<div>Send</div>

send success

General Settings

Reporting Interval min

The device returns to the power supply state

Change Password ☐

Parameters	Description
Reporting Interval	The interval of reporting switch status and electrical parameters. Default: 20 mins, Range: 1 – 1080 mins
The device returns to the power supply state	If the device loses power and returns to power supply, all switches or outputs status will change according to this parameter.
Change Password	Change the configuration. password of the device for ToolBox App or software

Milesight D2D Settings

Milesight D2D protocol is developed by Milesight and used for setting up transmission among Milesight devices without a gateway. When the Milesight D2D setting is enabled, WS558 can work as Milesight D2D agent device to receive commands from Milesight D2D controller devices.

1. Ensure the RX2 datarate and RX2 frequency in LoRaWAN settings are the same as the Milesight D2D controller device.
2. Enable the Milesight D2D feature, and define a unique Milesight D2D key to be the same as the setting in Milesight D2D controller device. (Default Milesight D2D Key: 5572404C696E 6B4C6F52613230313823)
3. Define a 2-byte hexadecimal control command (0x0000 to 0xffff) and command action. For example, you can configure a control command 0001 to inverse Output channel 2 as below. WS558 supports at most 16 control commands.

Basic

LoRa D2D Settings

LoRa D2D

LoRa D2D Key:

LoRa D2D Action settings

1. Control Command	0000	Action Object	Output channel 1	Action Status	Close	⊗
2. Control Command	0001	Action Object	Output channel 2	Action Status	Inverse	⊗
3. Control Command	0002	Action Object	Action Group	Action Status	Open	+ ⊗

4. These control commands can be configured in Milesight D2D controller device. When Milesight D2D controller device is triggered, it will send the pre-defined control command to control the circuits/switches of **WS558** to on, off or inverse status.

Maintenance

Upgrade

ToolBox Software:

1. Download firmware from www.milesight-iot.com to your PC.
2. Go to “**Maintenance -> Upgrade**” of ToolBox software, click “**Browse**” to import firmware and upgrade the device. You can also click “**Up to Date**” to search for the latest firmware of the device and upgrade.

Maintenance >

Upgrade

Backup and Reset

Model:

WS558-915M

Firmware Version:

01.01-a3

Hardware Version:

2.0

Domain:

Beijing Server

FOTA:

Up to date

Local Upgrade

Browse

Upgrade

ToolBox App:

1. Download firmware from www.milesight-iot.com to your smartphone.
2. Open ToolBox App and click “**Browse**” to import firmware and upgrade the device.

Note:

1. Operation on ToolBox is not supported during the upgrade.
2. Only the Android version ToolBox supports the upgrade feature.




Backup

WS558 supports configuration backup for easy and quick device configuration in bulk. Backup is allowed only for devices with the same model and LoRaWAN® frequency band.


ToolBox Software:

1. Go to “**Maintenance -> Backup and Reset**” of ToolBox software, click “**Export**” to backup the device configuration.
2. Click “**Browse**” to import the backup file, then click “Import” to load the configuration.








ToolBox App:

1. Go to “**Template**” page on the App and save current settings as a template. You can also edit the template file.
2. Select one template file saved in the smartphone and click “**Write**”, then attach it to another device to write configuration.



Note: Slide the template item to the left to edit or delete it. Click the template to edit the configurations.

Template		
<input type="text"/>		
	EM500-UDL-868M_20201124	
	Last Modified Time: 2020-11-24 17:06:26	
	EM300-TH-915M_20210112	
	Last Modified Time: 2021-01-12 14:35:12	
	UC512-DI-868M_20210128	
	Last Modified Time: 2021-01-28 16:57:20	
	UC501-470M_20210201	
	Last Modified Time: 2021-02-01 11:29:43	
	M_20210208	
	Last Modified Time: 2021-02-08 16:44:37	
	Edit	Delete

Reset to Factory Default

Please select one of the following methods to reset the device:


Via ToolBox Software: Go to "Maintenance -> Backup and Reset" of ToolBox software, click "Reset" to complete.

Via ToolBox App: Go to "Device -> Maintenance" to tap "Reset", then attach smartphone with NFC area to the device to complete.

Installation


Wall Mounting

Fix the wall plugs into the wall, then fix the device to the wall plugs with screws.



DIN Rail Mounting

Fix the device to DIN rail via the groove on the back of the device.



Device Payload

All data are based on the following format (HEX), the Data field should follow little endian:

Channel1	Type1	Data1	Channel2	Type2	Data2	Channel 3	...
1 Byte	1 Byte	N Bytes	1 Byte	1 Byte	M Bytes	1 Byte	...

For decoder examples you can find at <https://github.com/Milesight-IoT/SensorDecoders>.

Basic Information

WS558 reports basic information of the device whenever it joins the network.

Channel	Type	Description
ff	01 (Protocol Version)	01 => V1
	09 (Hardware Version)	01 40 => V1.4
	0a (Software Version)	01 14 => V1.14
	0b (Power On)	Device is on
	0f (Device Type)	00: Class A, 01: Class B, 02: Class C
	16 (Device SN)	16 digits
	26 (Power Consumption)	00-disabled, 01-enabled

Example:

ff0bff ff0101 ff166756c22186300001 ff090200 ff0a0101 ff0f02 ff2601					
Channel	Type	Value	Channel	Type	Value
ff	0b (Power On)	ff (Reserved)	ff	01 (Protocol Version)	01(V1.0)
Channel	Type	Value	Channel	Type	Value
ff	16(Device SN)	6756c22186 300001	ff	09 (Hardware Version)	0200 (V2.0)

Channel	Type	Value	Channel	Type	Value
ff	0a (Software Version)	0101 (V1.1)	ff	0f (Device Type)	02=>Class C
Channel	Type	Value			
ff	26 (Power Consumption)	01=>Enabled			

Sensor Data

WS558 reports switch status and electrical data according to reporting interval (20 mins by default). For Switch model, it only uploads switch status.

Channel	Type	Description
03	74 (Voltage)	UINT16, Unit: V Resolution: 0.1V
04	80 (Active Power)	UINT32, Unit: W
05	81 (Power Factor)	UINT8, Unit: %
06	83 (Power Consumption)	UINT32, Unit: Wh
07	c9 (Total Current)	UINT16, Unit: mA
08	31 (Switch Status)	Byte 1: 00 Byte 2: indicate every switch status per bit, 0=close, 1=open

Example:

1. Periodic package:

08310001 058164 07c90200 0374b208 068301000000 048001000000					
Channel	Type	Value	Channel	Type	Value
08	31 (Switch Status)	Byte 1: 00 Byte 2: 01= 00000001 => L1 open and others close	05	81 (Power Factor)	64=> 100%
Channel	Type	Value	Channel	Type	Value
07	c9 (Current)	02 00=>00 02=2mA	03	74(Voltage)	b2 08=>08 b2=2226 Voltage=2226 *0.1=222.6V
Channel	Type	Value	Channel	Type	Value
06	83(Power Consumption)	01 00 00 00=>00 00 00 01=1 Wh=0.001 kWh	04	80 (Active Power)	01 00 00 00=>00 00 00 01=1 W

2. When any switch changes status:

08310060		
Channel	Type	Value
08	31 (Switch Status)	Byte 1: 00 Byte 2: 60= 0110 0000 => L6, L7 open and others close

3. When LN model device detects the current over 13A for more than 30s, all switches will close and upload alarm package:

07c9413f 08310000					
Channel	Type	Value	Channel	Type	Value
07	c9 (Current)	41 3f=>3f 41=16193 mA=16.193 A	08	31 (Switch Status)	Byte 1: 00 Byte 2: 00 =>All close

Downlink Commands

WS558 supports downlink commands to configure the device. The application port is **85** by default.

Channel	Type	Description
08	—	Byte 1: every switch control status per bit, 0=not allow control, 1=allow control Byte 2: every switch status per bit, 0=close, 1=open
ff	03 (Set Reporting Interval)	2 Bytes, unit: s
	10 (Reboot Device)	ff
	32 (Add Delay Task)	Byte 1: 00 Byte 2-3: delay time, unit: s Byte 4: every switch control status per bit, 0=not allow control, 1=allow control Byte 5: every switch status per bit, 0=close, 1=open Note: WS558 supports adding only one task. Later command will cover previous command.
	23 (Delete Delay Task)	00 ff
	26 (Power Consumption)	00-disable, 01-enable

	27 (Reset Power Consumption)	ff
	28 (Enquire Electrical Status)	ff

Example:

1. Close L1 and open **L6**.

082120		
Channel	Type	Command
08	—	Byte 1: 21=0010 0001 =>L1 and L6 allow control Byte 2: 20 = 0010 0000 => L1 close, L6 open

2. Close all switches.

08ff00		
Channel	Type	Command
08	—	Byte 1: ff=1111 1111 =>All switches allow control Byte 2: 00 = 0000 0000 =>All switches close

3. Set reporting interval as 20 minutes.

ff03b004		
Channel	Type	Value
ff	03 (Set Reporting Interval)	b0 04=>04 b0=1200s =20 minutes

4. Add a delay task: close L6 after 1minute

ff32003c002000		
Channel	Type	Value
ff	32 (Add Delay Task)	Byte 1:00 Byte 2-3: 3c 00=>00 3c=60s=1min Byte 4: 20=>Bit6=1=>Control L6 Byte 5: 00=>Bit6=0=>L6 close

5. Delete the delay task

ff2300ff		
Channel	Type	Value
ff	23(Delete Delay Task)	00ff

6. Disable the collection and upload of power consumption.

Channel	Type	Value
ff	26 (Power Consumption)	00 = disable

7. Reset power consumption

ff27ff		
Channel	Type	Value
ff	27(Reset Power Consumption)	ff (Reserved)

Declaration of Conformity

WS558 is in conformity with the essential requirements and other relevant provisions of the CE, FCC, and RoHS.

For assistance, please contact Milesight technical support:

- **Email:** iot.support@milesight.com Tel: 86-592-5085280
- **Fax:** 86-592-5023065
- **Address:** Building C09, Software Park III, Xiamen 361024, China



Copyright © 2011-2022 Milesight. All rights reserved.

All information in this guide is protected by copyright law. Whereby, no organization or individual shall copy or reproduce the whole or part of this user guide by any means without written authorization from Xiamen Milesight IoT Co., Ltd.

Revision History

Date	Doc Version	Description
July 20, 2022	V 2.0	Initial version

Documents / Resources

	Milesight WS558 Smart Light Controller [pdf] User Guide WS558, Smart Light Controller, WS558 Smart Light Controller
	Milesight WS558 Smart Light Controller [pdf] User Guide 2AYHY-WS558, 2AYHYWS558, WS558, Smart Light Controller, WS558 Smart Light Controller, Light Controller, Controller

References

-  [Milesight IoT - LoRaWAN, 5G & AIoT](#)
-  [GitHub - Milesight-IoT/SensorDecoders](#)
-  [Download Center | Milesight - AIoT Solution Provider](#)

Manuals±.