



moa MC10D Multi Cooker Instruction Manual

[Home](#) » [moa](#) » moa MC10D Multi Cooker Instruction Manual 

Contents

- 1 moa MC10D Multi Cooker
- 2 Product Information
- 3 Product Usage Instructions
- 4 FUNCTION LIST
- 5 SAFETY INSTRUCTIONS
- 6 OPERATION
- 7 COOKING RICE
- 8 QUICK RICE COOKING
- 9 COOKING GRAIN
- 10 COOKING HOT CEREALS
- 11 STEAM COOKING
- 12 START TIME SELECTION
- 13 CLEANING AND CARE
- 14 Documents / Resources
 - 14.1 References
- 15 Related Posts

moa

moa MC10D Multi Cooker



Product Information

The Multi Cooker MC10D is a versatile kitchen appliance that allows you to cook a variety of dishes with ease. It comes with multiple functions and features to make your cooking experience convenient and efficient. The cooker has a time display with control lamp for hours and minutes, allowing you to track the cooking time accurately. It also has a switch on and switch off function, as well as a keep warm feature to ensure your food stays warm until you're ready to serve. The cooker also includes a delay start function, which allows you to set a specific time for the cooking process to begin.

Product Usage Instructions

1. To cook white rice with a preset cooking time of 45 minutes, select function 1.
2. To cook white rice with a preset cooking time of 35 minutes, select function 2.
3. To cook whole grain rice or grain with a preset cooking time of 60 minutes, select function 3.
4. To cook hot cereals with an adjustable cooking time ranging from 5 minutes to 5 hours, select function 4.
5. To steam cook using the steamer insert for up to 30 minutes, select function 5.

Before using the Multi Cooker MC10D, it is important to read and understand the safety instructions provided in the user manual. Some key safety instructions include:


1. Include this instruction manual with the appliance if it is passed on to other people.
2. Ensure the appliance is used for domestic purposes only and not operated outside.
3. Verify that the type of current and supply voltage matches the specifications on the rating plate.
4. Avoid touching the rice cooker or power plug with wet or damp hands.
5. Use a dedicated power outlet for the rice cooker and do not connect it to outlets used for other devices.
6. Operate the rice cooker only when monitored and for its intended purpose.
7. Supervise children aged 8 years and above when using the appliance and ensure they understand the hazards involved.
8. Do not use the rice cooker with an external timer or separate remote control system.
9. Place the rice cooker on a heat-resistant, level, and stable surface, away from hot stoves, gas flames, or other

heat sources.

10. Avoid placing objects under or on the unit during operation.

These are just a few of the safety instructions. Please refer to the user manual for the complete list of safety guidelines and instructions on cleaning and maintenance.

FUNCTION LIST



1. To cook white rice with preset cooking time (45 minutes).
2. To cook white rice with preset cooking time (35 Minutes).
3. To cook whole grain rice or grain with preset cooking time (60 minutes).
4. To cook hot cereals with adjustable cooking time (between 5 minutes and 5 hours).
5. To steam cook while using the steamer insert (up to 30 minutes).
6. To cook pre-packaged rice mixes, soups, stews that will be heated and then simmered at temperatures below 100°C with adjustable cooking time (between 5 minutes and 5 hours).
7. Time display with control lamp for hours and minutes.
8. Switch on and switch off function / keep warm.
9. Use to delay the start time.

IMPORTANT INFORMATION

Only connect the appliance to an earthed wall socket. Please read through these operating instructions carefully prior to operating the rice cooker for the first time and store it in a safe place. Pay particular attention, in your own interest, to the safety information in order to avoid accidents and malfunctions. Improper use, application or insufficient cleaning and care can impair safety and result in danger for the user. MOA cannot accept any responsibility for injuries or damage attributed to improper use.

SAFETY INSTRUCTIONS

1. Include this instruction manual with the appliance if it is passed on to other people.
2. If the appliance is used or handled in an inappropriate manner, we cannot be held responsible for any ensuing damage. This appliance is intended for domestic use only. Do not operate this appliance outside.
3. Start by verifying that the type of current and supply voltage is as specified on the rating plate.
4. Do not touch either the rice cooker or the power plug with wet or damp hands.
5. Do not use a power outlet that is already used to power other devices.
6. The rice cooker may only be operated when monitored and used for the intended purpose.

7. This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Cleaning and user maintenance shall not be made by children.
8. Children should be supervised to ensure that they do not play with the device.
9. Never operate this device with an external timer or a separate remote control system.
10. Only operate the rice cooker on a sufficiently water and heat resistant, level and stable surface and not in the vicinity of hot stoves, gas flames or other sources of heat as well as under wall-cupboards. Make sure that there is enough space next to and above the rice cooker.
11. **Caution:** The device is hot when in use and steam escapes!
12. Do not place any objects under or on the unit during operation.
13. Never carry or move the rice cooker as long as it is in operation or while it still is hot.
14. **Pull the power plug after each use and:**
 - in case of faults during operation,
 - each time you clean the device.

Always pull on the plug from the outlet before removing the cable from the unit.
15. Do not allow the power cord to dangle and place the device in a way that no one can fall over the cord.
16. Check the power cord for damage prior to each use. Prevent it from becoming pinched or kinked, coming into contact with warm or hot surfaces, or from chafing against sharp edges. The cable must be replaced in any case if it is damaged.
17. Never immerse the appliance, the cord or the plug in water or other liquids. Do not clean the appliance in the dishwasher.
18. Never use the appliance if you discover damage, if water has penetrated the housing or if the appliance has been dropped.
19. Never attempt to open or repair the appliance yourself. In the event of a malfunction, have the appliance repaired by qualified experts only! Contact your authorised dealer whenever the appliance is in need of repairs.
20. Only use the original accessories.

BEFORE USING FOR THE FIRST TIME

- Start by carefully reading the instructions for use and the safety instructions.
- Then remove all packaging material and dispose of it properly.
- Please only wipe off the housing with a soft cloth (slightly damp, if necessary). The non-stick coated pot, the steamer insert, the measuring cup and the spoon can be cleaned with a mild detergent and warm water.
Caution: Do not use aggressive or abrasive cleaners during cleaning. Do not clean these parts in the dishwasher.
- Then dry off completely.

OPERATION

- Place the rice cooker on a sufficiently water and heat resistant, level and stable surface.
- **Caution:** Please ensure that the power cord does not touch any hot surfaces of the housing.
- Ensure that the condensation container on the back of the device is always in-stalled and the steam valve is always placed properly in the according opening on the lid.

- Ensure that there are no foreign bodies (like rice grains) in the heating bowl or on the outer side of the non-stick pot.
- Always keep the outside of the pot clean and dry. Handle the pot carefully. If the bottom is bent or has dents, the heat transfer does not work correctly.
- Place the pot into the heating bowl. Assure the correct placement by turning it slightly to the right or left side. This must be very smooth.
- Never place liquids or food directly into the appliance. Fill the pot only to the top mark to prevent overflow. Do not use any foaming food stuffs like milk, cream, eggs. Do not use vinegar for cooking.
- Ensure that the lid is completely locked before switching on the appliance.
- Only use wooden or heat resistant plastic kitchen utensils. Pay attention that the food stuffs do not overflow. In that case wipe off immediately with slightly damp cloth.

Attention: Never carry, move or tilt the rice cooker while in operation or still hot. Hot steam may evaporate from the valve.

- Hot steam escapes while opening the lid and hot condensate water can leak out of the condensate container. Dry it off immediately.

COOKING RICE

1. Measure the rice with the measuring cup, wash the rice as needed and add it to the pot with non-stick coating. Add the liquid up to the mark on the inside of the pot.

1 Measuring cup of rice – fill with liquid up to 1 CUP mark.

2 Measuring cup of rice – fill with liquid up to 2 CUP mark.

Attention: The 10 CUP mark in the pot must not be exceeded.

2. Check to ensure that the non-stick pot is seated correctly in the heating bowl and close the lid.
3. Connect the cable to the appliance and insert mains plug in a suitable socket.
4. If all of the control lamps are blinking, select the desired program.
Then the relevant control lamp blinks and the time appears in the display. After a few seconds, the control lamp and the time illuminate continuously and the appliance begins cooking.

Note: If you have not made a selection within 15 seconds, the appliance switches off. Press the START / WARM button to switch on the appliance.

5. The cooking time presetting of 45 minutes is shown in the display. However, this can vary depending on the amount of rice and liquid. Empty the condensate container on the back side of the appliance as needed.
6. A signal tone is sounded when the rice is finished cooking. Then the cooker switches automatically to a lower temperature to keep the rice warm. The time that this mode has been active is displayed, up to a maximum of 12 h.

After 12hours, the appliance switches off automatically.

TIPS:

- The indicated ratio between the food and liquid is a guidelines value which can be adjusted as needed. Vary this ratio according to your taste. Further information is also provided on the food package.

- For creamier rice, we recommend keeping the rice warm for 10 – 15 minutes after the cooking process is finished.

QUICK RICE COOKING

1. Measure the rice with the measuring cup, wash the rice as needed and add it to the pot with non-stick coating. Add the liquid up to the mark on the inside of the pot.
1 Measuring cup of rice – fill with liquid up to 1 CUP mark.
2 Measuring cup of rice – fill with liquid up to 2 CUP mark.
Attention: The 10 CUP mark in the pot must not be exceeded.
2. Check to ensure that the non-stick pot is seated correctly in the heating bowl and close the lid.
3. Connect the cable to the appliance and insert mains plug in a suitable socket.
4. If all of the control lamps are blinking, press the RISOTTO button. Then the relevant control lamp blinks and the time appears in the display. After a few seconds, the control lamp and the time illuminate continuously and the appliance begins cooking.
Note: If you have not made a selection within 15 seconds, the appliance switch-es off. Press the Start / Warm button to switch on the appliance.
5. The cooking time presetting of 35 minutes is shown in the display. However, this can vary depending on the amount of rice and liquid. Empty the condensate container on the back side of the appliance as needed.
6. A signal tone is sounded when the risotto is finished cooking. Then the cooker switches automatically to a lower temperature to keep the rice warm. The time that this mode has been active is displayed, up to a maximum of 12 h.

After 12 hours, the appliance switches off automatically.

COOKING GRAIN

1. Measure the grain with the measuring cup, wash the grain as needed and add it to the pot with non-stick coating. Add the appropriate amount of liquid:
Barley, wheat, sorghum: 1 measuring cup of grain – 3 measuring cups of liquid
Millet: 1 measuring cup of grain – 2 measuring cups of liquid
Quinoa: 1 measuring cup of grain – 1 measuring cup of liquid
Attention: The 10 CUP mark in the pot must not be exceeded.
2. Check to ensure that the non-stick pot is seated correctly in the heating bowl and close the lid.
3. Connect the cable to the appliance and insert mains plug in a suitable socket.
4. If all of the control lamps are blinking, press the VOLLKORN REIS / WHOLE GRAIN button. Then the relevant control lamp blinks and the time appears in the display. After a few seconds, the control lamp and the time illuminate continuously and the appliance begins cooking.
Note: If you have not made a selection within 15 seconds, the appliance switches off. Press the START / WARM button to switch on the appliance.
5. The cooking time presetting of 60 minutes is shown in the display. However, this can vary depending on the amount of rice and liquid. Empty the condensate container on the back side of the appliance as needed.
6. A signal tone is sounded when the grain is finished cooking. Then the cooker switches automatically to a lower temperature to keep the grain warm. The time that this mode has been active is displayed, up to a maximum of

12 h. After 12 hours, the appliance switches off automatically.

TIPS:

- The indicated ratios between the food and liquid are guidelines values which can be adjusted as needed. Vary these ratios according to your taste. Further information is also provided on the food package.
- Very small grain types, such as teff or amaranth, should not be cooked in the rice cooker.

COOKING HOT CEREALS

1. Measure the grain with the measuring cup, wash the grain as needed and add it to the pot with non-stick coating. Add the liquid in a 1:3 ratio.
1 measuring cup of grain – 3 measuring cups of liquid
Attention: The 10 CUP mark in the pot must not be exceeded.
2. Check to ensure that the non-stick pot is seated correctly in the heating bowl and close the lid.
3. Connect the cable to the appliance and insert mains plug in a suitable socket.
4. If all of the control lamps are blinking, press the HOT CEREALS button. Then the relevant control lamp blinks and 5 appears in the display as the shortest cooking time. Press and hold the HOT CEREALS button to adjust the cooking time. The time can be adjusted in increments of one minute for up to 90 minutes and then in increments of one hour for up to a maximum cooking time of 5 hours. Observe the control lamps for minutes and hours.
5. After a few seconds, the control lamp and the time illuminate continuously and the appliance begins cooking.
Note: If you have not made a selection within 15 seconds, the appliance switches off. Press the START / WARM button to switch on the appliance.
6. ON appears in the display during the heating process. The countdown begins once the liquid boils.
7. After the adjusted time expires, the rice cooker switches automatically to a lower temperature to keep the food warm. The time that this mode has been active is displayed, up to a maximum of 12 h. After 12 hours, the appliance switches off automatically.

TIP:

The indicated ratio between the food and liquid is a guidelines value which can be adjusted as needed. Vary this ratio according to your taste. Further information is also provided on the food package.

STEAM COOKING

1. Add the liquid to the pot with non-stick coating (min. 1 cup mark; max. 3 cup mark) and place the pot in the heating bowl. Check to ensure that the non-stick pot is seated correctly in the heating bowl.
2. Hang the steam insert with the food in the non-stick pot and close the lid.
3. Connect the cable to the appliance and insert mains plug in a suitable socket.
4. Press the STEAM COOKING button while the control lamps are blinking. Press and hold the button to adjust the cooking time (max. 30 minutes).
5. ON appears in the display while the appliance is heating up. The remaining time appears in the display once the steaming process begins.
6. An acoustic signal sounds if the water has evaporated completely and the time in the display blinks. In order to resume the cooking process, add water within 3 minutes. Otherwise the appliance switches off.

TIPS:

- Do not overfill the steam insert so that the lid can close completely.
- Only foods with a similar cooking time should be steamed together.
- You can compensate for different cooking times by cutting harder foods into smaller pieces and softer foods into larger pieces.
- The more food you add to the steam insert, the longer the cooking time. · Small pieces cook faster than larger pieces.
- You can cook rice and steam other food at the same time. Cook the rice as described under COOKING RICE. Place the steam insert in the non-stick pot when the remaining cooking time of the rice equals the cooking time for the food to be steamed.
- Select the appropriate program depending on the type of rice.

SIMMER

1. Add the liquid and food to the non-stick pot.
2. Check to ensure that the non-stick pot is seated correctly in the heating bowl and close the lid.
3. Connect the cable to the appliance and insert mains plug in a suitable socket.
4. Press the SIMMER button while the control lamps are blinking. 5 appears in the display. To adjust the cooking time, press and hold the SIMMER button. The time can be adjusted in increments of one minute for up to 90 minutes and then in increments of one hour for up to a maximum cooking time of 5 hours. Observe the control lamps for minutes and hours.
5. After a few seconds, the control lamp and the time illuminate continuously and the appliance begins cooking.
Note: If you have not made a selection within 15 seconds, the appliance switches off. Press the START / WARM button to switch on the appliance.
6. ON appears in the display during the heating process. The countdown begins once the liquid boils.
7. After the adjusted time expires, an acoustic signal sounds and the appliance switches automatically to a lower temperature to keep the food warm. The time that this mode has been active is displayed, up to a maximum of 12 h. After 12 hours, the appliance switches off automatically.

START TIME SELECTION

1. Add the food and liquid to the non-stick pot.
2. Check to ensure that the non-stick pot is seated correctly in the heating bowl and close the lid.
3. Connect the cable to the appliance and insert mains plug in a suitable socket.
4. Press the button for the desired program.
5. Press the button for the start time selection, then press it again to select the start time (1 – 15 hours). The rice cooker starts the countdown after 5 seconds.
6. The selected time appears in the display. The cooking process starts automatically after this time has expired.
7. After the adjusted time expires, the rice cooker switches automatically to a lower temperature to keep the food warm. The time that this mode has been active is displayed, up to a maximum of 12 h. After 12 hours, the appliance switches off automatically.

TIPS:

- Press the START / WARM button to correct the adjusted time. The appliance is switched off. Select the appropriate program, then adjust the start time.

AFTER USE

- First, pull the plug out of the outlet and then pull the cable out of the device.
- After each use, remove the condensation container attached to the rear, empty and clean it, and set it back.

CLEANING AND CARE

- Always pull out the power cord before cleaning and allow the appliance to cool down.
- Do not use any sharp or pointed objects, benzene, solvents, scrubbing brushes or abrasive cleaning agents for cleaning.
- Only clean the housing with a dry or lightly dampened cloth.
- Only clean the inner side of the rice cooker with a dry or lightly dampened cloth.
- Do not clean the rice cooker in the dish washer. Do not immerse into water or any other liquids.
- The non-stick coated pot, the steamer insert, the measuring cup and the spoon can be cleaned with a mild detergent and warm water. Please do not clean the parts in the dishwasher.
- For easy cleaning the steam valve can be removed from the lid and disassembled.
- Then dry off completely.

Customer service: 0341 741 041

Only intended for household use! Do not immerse in liquids!

220–240V | 50/60 Hz | 700 Watt


WARRANTY

We cover this device with a warranty of 2 years from the purchase date. Damages due to normal wear, unauthorized use, improper treatment, incorrect use, lack of care and cleaning, willful destruction, transport or accident, and repair by unauthorized persons are excluded from this warranty. Contact us in case of warranty claim. The warranty can only be honored if the device is accompanied by the sales slip/receipt.

DISPOSAL/RECYCLING

According to the Electric and Electronic Equipment Act this product may not be disposed of in normal household garbage at the end of its useful life. For this reason, please take it to a free communal collection point (e.g. recycling depot) for the recycling of electric and electronic devices. Translation are made in good faith. We do not assume any liability for translation errors.

Documents / Resources

 <p>Multi Cooker MC10D Instruction Manual MC10D Multi Cooker, MC10D, Multi Cooker, Cooker</p>	<p>moa MC10D Multi Cooker [pdf] Instruction Manual MC10D Multi Cooker, MC10D, Multi Cooker, Cooker</p>
--	--

References

-  [MOA](#)

Manuals+.