



Modules Dual Mode Bluetooth (SPP+BLE) Module User Manual

[Home](#) » [Modules](#) » Modules Dual Mode Bluetooth (SPP+BLE) Module User Manual

Modules Dual Mode Bluetooth (SPP+BLE) Module User Manual

Dual Mode Bluetooth (SPP+BLE) Module

JDY-32 Bluetooth User Manual



Version

| Version | Date | Description |
|---------|------------|-----------------|
| V1.0 | 2018-05-08 | Release version |

Contents [[hide](#)]

- [1 1. Product introduction:](#)
- [2 2. Applications:](#)
- [3 3. Pin function description](#)
- [4 4. Serial AT instruction set](#)
- [5 Documents / Resources](#)
- [6 Related Posts](#)

1. Product introduction:

JDY-32 dual-mode Bluetooth is based on Bluetooth 3.0 SPP + Bluetooth 4.2 BLE design, which can support Windows, Linux, iOS, android data transmission, working frequency 2.4GHZ, modulation mode GFSK, maximum transmission power 5db, maximum transmission distance 40 meters, Support users to modify the device name, baud rate and other commands through the AT command, which is convenient and quick to use.


2. Applications:


JDY-32 is a classic Bluetooth protocol that can communicate with Bluetooth-enabled computers (desktops, notebooks) and mobile phones (android). Can be applied

- Windows computer Bluetooth serial port transparent transmission
- Android Bluetooth serial port transparent transmission
- Smart home control
- Automotive ODB testing equipment
- Bluetooth toy
- Share mobile power, share weight
- Medical equipment

| | |
|---------------------------|--|
| Model | JDY-32 |
| Working frequency | 2.4GHZ |
| Communication Interface | UART |
| Operating Voltage | 1.8-3.6V (3.3V recommended) |
| Operating temperature | -40 ° C - 80 ° C |
| Antenna | Built-in PCB antenna |
| Transmission distance | 40 m |
| Master-slave support | Slave |
| Module size | 19.6 * 14.94 *1.8 mm (length, width, height) |
| Bluetooth version | Bluetooth 4.2 BLE/Bluetooth 3.0 SPP |
| SMT soldering temperature | <260° C |
| Broadcast current | 4.4mA |
| BLE connected current | 3.8mA |
| SPP connected current | 12mA |
| Transmit power | 5db (maximum) |
| Receiving sensitivity | -97dbm |

3. Pin function description





| | |
|-------|--|
| STATE | Connection status pin (not connected low, high level after connection) |
| RXD | Serial input pin (TTL level) |
| TXD | Serial output pin (TTL level) |
| GND | Power ground |
| VCC | Power supply (support 3.6-6V) |
| EN | Vacant |

| PIN | Pin Function | Pin function description |
|-----|--------------|-------------------------------|
| 1 | TXD | Serial output pin (TTL level) |
| 2 | RXD | Serial input pin (TTL level) |
| 3 | CTS | |
| 4 | RTS | |
| 5 | NULL | |
| 6 | NULL | |
| 7 | NULL | |
| 8 | NULL | |
| 9 | SWI | |

| | | |
|----|--------|--|
| 10 | NULL | |
| 11 | RST | Reset (active low) |
| 12 | VCC | Power supply (1.8–3.6V) |
| 13 | GND | Ground |
| 14 | EN | |
| 15 | ALED | Broadcast status pin (not connected to flash, output high level after connection) |
| 16 | STAT | Connection status pin (not connected low level, output high level after connection) |
| 17 | SELECT | AT command pin (only valid after connection, low level enters AT command mode after connection, high level is transparent mode), no state of SELECT pin in unconnected state |
| 18 | NULL | |
| 19 | NULL | |
| 20 | NULL | |
| 21 | NULL | |
| 22 | NULL | |
| 23 | NULL | |
| 24 | NULL | |
| 25 | NULL | |

4. Serial AT instruction set

JDY-32 module serial port send AT command must be added run

| Num. | Command | Function | Default |
|------|------------|---|-------------|
| 1 | AT+VERSION | Version number | JDY-32-V1.0 |
| 2 | AT+RST | Soft reset | |
| 3 | AT+DISC | AT command disconnected | |
| 4 | AT+MAC | Query the MAC address of BLE | |
| 5 | AT+MACS | Query the MAC address of the SPP | |
| 6 | AT+BAUD | Baud rate | 9600 |
| 7 | AT+NAME | BLE broadcast name settings and queries | JDY-32-LE |
| 8 | AT+NAMES | SPP broadcast name setting and query | JDY-32-SPP |
| 9 | AT+TYPE | SPP password connection type | 2 |
| 10 | AT+PIN | SPP connection password | 1234 |
| 11 | AT+DEFAULT | Reset | |

1. Query the version number Command

| Command | Response | Parameter |
|------------|----------------------|-----------|
| AT+VERSION | +VERSION=JDY-19-V1.0 | NO |

2. Reset

| Command | Response | Parameter |
|---------|----------|-----------|
| AT+RST | OK | NO |

3. Disconnect

| Command | Response | Parameter |
|---------|----------|-----------|
| AT+DISC | OK | NO |

4. BLE Bluetooth MAC Address

| Command | Response | Parameter |
|---------|-------------------|-----------|
| AT+MAC | +MAC=1334ab52de8c | NO |

5. SPP Bluetooth MAC address

| Command | Response | Parameter |
|---------|-------------------|-----------|
| AT+MACS | +MAC=1334ab52de8c | NO |

6. Baud rate setting / query

| Command | Response | Parameter |
|----------------|----------|---|
| AT+BAUD<Param> | +OK | Param: (1 to 4) |
| AT+BAUD | | 1:9600 2:19200 3:38400 4:57600 5:115200 |

7. BLE broadcast name setting / query

| Command | Response | Parameter |
|----------------|---------------|--|
| AT+NAME<Param> | OK | Param: BLE broadcast name Longest: 18 bytes Default broadcast name: JDY-32-LE |
| AT+NAME | +NAME=<Param> | |

8. SPP Broadcast name setting / query

| Command | Response | Parameter |
|----------------|---------------|---|
| AT+NAME<Param> | OK | Param: BLE broadcast name Longest: 18 bytes Default broadcast name: JDY-32-SPP |
| AT+NAME | +NAME=<Param> | |

9. SPP password pairing type

| Command | Response | Parameter |
|----------------|---------------|--|
| AT+TYPE<Param> | OK | Param: (0-2) 0: No password is required for connection 1: You need to enter a password for each connection. 2: The first connection requires a password |
| AT+TYPE | +TYPE=<Param> | |


10. SPP connection password

| Command | Response | Parameter |
|---------------|--------------|--|
| AT+PIN<Param> | OK | Param: The password is 4 digits. Default password: 1234 |
| AT+PIN | +PIN=<Param> | |

11.Reply to factory configuration

| Command | Response | Parameter |
|------------|----------|-----------|
| AT+DEFAULT | OK | NO |

Documents / Resources

| | |
|---|--|
|  <p>Dual Mode Bluetooth (SPP+BLE) Module</p> | <p>Modules Dual Mode Bluetooth (SPP+BLE) Module [pdf] User Manual</p> <p>Dual Mode Bluetooth SPP BLE, Module, JDY-32 Bluetooth</p> |
|---|--|