



MOTOROLA SOLUTIONS MN007868A01-AE Portable Two Way Radios User Guide

[Home](#) » [Motorola Solutions](#) » **MOTOROLA SOLUTIONS MN007868A01-AE Portable Two Way Radios User Guide**

Contents

- 1 MOTOROLA SOLUTIONS MN007868A01-AE Portable Two-Way Radios
- 2 Product Information
- 3 Product Usage Instructions
- 4 Frequently Asked Questions
- 5 Legal and Support
- 6 Activation Overview
- 7 Initial Activation Process
- 8 Troubleshooting
- 9 Documents / Resources
 - 9.1 References



MOTOROLA SOLUTIONS MN007868A01-AE Portable Two-Way Radios



Product Information

Specifications

- **Product Name:** MOTOTRBOTM R7 Portable Two-Way Radios
- **Device Type:** Land Mobile Radio (LMR)
- **Activation Requirement:** One-time activation for software features and services
- **Connectivity:** Wi-Fi for access point setup
- **Software Tools:** RadioCentral Server, Radio Management (RM), Customer Programming Software (CPS) 2.0

Product Usage Instructions

Activation Overview

MOTOTRBOTM R7 is an advanced cloud-ready Land Mobile Radio (LMR) device. It requires a one-time activation to enable the software features and services purchased with the radio.

Initial Activation Process

1. Set up Wi-Fi Access Point: Follow the instructions provided to connect the radio to a Wi-Fi network for initial setup.
2. Activation and Firmware Update: Activate the device to obtain specific software features and settings from the RadioCentral Server. Ensure that the radio downloads the latest firmware for updated software features and security patches.
 - **Best Practices:** Refer to the user manual for best practices during the activation and firmware update process.

Troubleshooting

If you encounter any issues during the activation process or while using the device, refer to the troubleshooting section in the user manual for guidance on resolving common problems.

Frequently Asked Questions

Q: What should I do if my device fails to activate?

A: If your device fails to activate, ensure that you have a stable internet connection and follow the activation steps carefully. If issues persist, contact Motorola Solutions support for assistance.

Q: Can I use the radio without activating it?

A: The radio needs to be activated to access software features and services. Failure to activate may limit the functionality of the device.

Q: How can I update the firmware of MOTOTRBOTM R7?

A: The firmware updates are automatically downloaded during the activation process. Ensure your device is connected to a reliable Wi-Fi network to receive the latest firmware updates.

Legal and Support

Intellectual Property and Regulatory Notices

Copyrights

- The Motorola Solutions products described in this document may include copyrighted Motorola Solutions computer programs. Laws in the United States and other countries preserve for Motorola Solutions certain exclusive rights for copyrighted computer programs. Accordingly, any copyrighted Motorola Solutions computer programs contained in the Motorola Solutions products described in this document may not be copied or reproduced in any manner without the express written permission of Motorola Solutions.
- No part of this document may be reproduced, transmitted, stored in a retrieval system, or translated into any language or computer language, in any form or by any means, without the prior written permission of Motorola Solutions, Inc.

Trademarks

- MOTOROLA, MOTO, MOTOROLA SOLUTIONS, and the Stylized M Logo are trademarks or registered trademarks of Motorola Trademark Holdings, LLC, and are used under license. All other trademarks are the property of their respective owners.

License Rights

- The purchase of Motorola Solutions products shall not be deemed to grant either directly or by implication, estoppel or otherwise, any license under the copyrights, patents, or patent applications of Motorola Solutions, except for the normal non-exclusive, royalty-free license to use that arises by operation of law in the sale of a product.

Open Source Content

- This product may contain Open Source software used under license. Refer to the product installation media for full Open Source Legal Notices and Attribution content.

European Union (EU) and United Kingdom (UK) Waste of Electrical and Electronic Equipment (WEEE) Directive

- The European Union's WEEE directive and the UK's WEEE regulation require that products sold in EU countries and the UK must have the crossed-out wheellie bin label on the product (or the package in some cases).
- As defined by the WEEE directive, this crossed-out wheellie bin label means that customers and end-users in EU and UK countries should not dispose of electronic and electrical equipment or accessories in household waste.
- Customers or end-users in EU and UK countries should contact their local equipment supplier representative or service center for information about the waste collection system in their country.

Disclaimer

- Please note that certain features, facilities, and capabilities described in this document may not apply to or be licensed for use on a specific system, or may be dependent upon the characteristics of a specific mobile subscriber unit or the configuration of certain parameters. Please refer to your Motorola Solutions contact for further information.

Activation Overview

- MOTOTRBO™ R7 is an advanced cloud-ready Land Mobile Radio (LMR) device.
- R7 requires a one-time activation to enable the software features and services purchased with the radio. The radio connects to RadioCentral Server which is a cloud-based application to obtain the specific software features and settings for a particular model and region (regional codeplug). The radio also downloads the latest firmware (if available) to ensure that your radio has the latest software features and security patches.
- After the one-time activation, your radio can be activated and configured with Radio Management (RM) or Customer Programming Software (CPS) 2.0 software.

Wi-Fi Access Point Setup

- Your radio connects to the secure cloud application through Wi-Fi. All radios come with Wi-Fi as standard or as software upgradable options and are capable of connecting to Wi-Fi for this initial download.

Table 1: Requirements for Preconfigured Wi-Fi Access Point

Item	Description
SSID	MOTOTRBO
Password	Radio Management
Security type	WPA2-PSK
Frequency	2.4 GHz and 5 GHz
Channel	1 to 11 (2.4 GHz)
Recommended download speed per radio	7 Mbps

Activation and Firmware Update

The section explains the typical package size and the duration of the activation process.

Table 2: Activation

Item	Description
Typical package size	0.5 MB
Activation process time	Two to three minutes

Table 3: Activation and Firmware Upgrade

Item	Description
Typical package size	30 MB
Activation process time	Eight to ten minutes

Best Practices

Motorola Solutions offers best practices for the security and operation of the Wi-Fi network for your radio. For more information, refer to the MOTOTRBO™ Best Practices for Device Activation, MN008921A01 at <https://learning.motorolasolutions.com>.



Initial Activation Process


The radio connects automatically to the preconfigured Wi-Fi access point and activates after the radio is turned on.



NOTE:

- For full keypad (FKP), you can refer to the Radio Display as well as the LED and Tone Indication columns in the following tables.
- For non-keypad (NKP), you can refer to the LED and Tone Indication column in the following tables.
- You can also check the Wi-Fi status announcement by pressing the 3-Dot Programmable Feature button.



Stage 1: Wi-Fi Connection


Radio Display (FKP only)	LED and Tone Indication (FKP and NKP)	Status
	LED : Solid Green Tone : Power Up	Radio powers on and shows the Motorola Solutions launch screen.
	LED : - Tone : Continuous Unprogrammed	Radio is in the unprogrammed state.

Radio Display (FKP only)	LED and Tone Indication (FKP and NKP)	Status
	LED : Blinking Yellow Tone : Momentary Valid	Radio connects to a Wi-Fi network.

Icon	Description
	Radio is connected to a Wi-Fi network.
	Wi-Fi network is not available.

Stage 2: Radio Connects to Server for Package Download





Radio Display (FKP only)	LED and Tone Indication (FKP and NKP)	Status
	LED : Blinking Yellow Tone : Momentary Valid	Radio connects to the server and check for radio updates.
	LED : Blinking Yellow Tone : Momentary Valid	Radio downloads the packages from the server if there are updates required. NOTE: <ul style="list-style-type: none"> If the software in the radio has the latest version, the radio only downloads the regional information. If the software in the radio is not the latest, the radio upgrades and download the regional information.

Radio Display (FKP only)	LED and Tone Indication (FKP and NKP)	Status
	LED : Blinking Yellow Tone : Momentary Valid	Radio unpacks the downloaded updates.

NOTE: Your radio restarts after the server update process is complete.

IMPORTANT: Ensure a stable network connection at all times.

Stage 3: Installation









Radio Display (FKP only)	LED and Tone Indication (FKP and NKP)	Status
	LED : Solid Yellow Tone : Momentary Valid	Radio must be on during the installation process.  NOTE: Turning off radio at this stage can cause update failures.
	LED : Solid Yellow Tone : Momentary Valid	Radio is updating.
Radio Display (FKP only)	LED and Tone Indication (FKP and NKP)	Status
	LED : - Tone : Momentary Update Complete	The update is complete.




Troubleshooting








This section explains the basic troubleshooting process.




NOTE:



- You are recommended to start the troubleshooting steps with a full keypad radio.
- The maximum number of concurrent radios supported depends on the number of active clients that your access point supports but it is recommended to troubleshoot 20 radios at a time.
- In case of a power failure, the radio resumes at the previous stage.
- **IMPORTANT:** Ensure stable network connection at all times.

Problem	LED and Tone Indication	Solution														
<p>Radio is unable to connect to Wi-Fi</p> 	<p>LED: Blinking Yellow</p> <p>Tone: -</p>	<p>Perform one of the following actions:</p> <ol style="list-style-type: none">1. Verify that the Wi-Fi feature is enabled. <p> NOTE: You are recommended to use a Wi-Fi modem or router.</p> <table><tr><th>Icon</th><th>Description</th></tr><tr><td></td><td>Your radio is connected to a Wi-Fi network.</td></tr><tr><td></td><td>Wi-Fi network is not available.</td></tr></table> <ol style="list-style-type: none">2. Check if the access point is configured correctly: <table><tr><th>Item</th><th>Description</th></tr><tr><td>SSID</td><td>MOTOTRBO</td></tr><tr><td>Password</td><td>Radio Management</td></tr><tr><td>Security Type</td><td>WPA2-PSK</td></tr></table> <ol style="list-style-type: none">3. Ensure that the radio is powered on within the range of the access point. You can verify by connecting to the MOTOTRBO access point by using a smart-phone.	Icon	Description		Your radio is connected to a Wi-Fi network.		Wi-Fi network is not available.	Item	Description	SSID	MOTOTRBO	Password	Radio Management	Security Type	WPA2-PSK
Icon	Description															
	Your radio is connected to a Wi-Fi network.															
	Wi-Fi network is not available.															
Item	Description															
SSID	MOTOTRBO															
Password	Radio Management															
Security Type	WPA2-PSK															

Problem	LED and Tone Indication	Solution
Radio remains in Unprogrammed channel 	LED: - Tone: Continuous Unprogrammed	4. Check the distance of the radio and the access point. Check the signal of the SSID by using a smartphone.  NOTE: Ensure that the sleep feature is turned off for iPhone access point. Enable maximum compatibility. Perform one of the following actions: 1. If the Wi-Fi is connected, check if the access point has internet connection. 2. Connect to the access point by using a smartphone. a. If the Wi-Fi is connected, check the Wi-Fi icon  in an unprogrammed channel. If the Wi-Fi signal has more than three bars, connect to the SSID by using a smartphone. Go to https://www.motorolasolutions.com/ b. If https://www.motorolasolutions.com/ is not accessible through your smartphone, contact your network administrator. This process requires an internet connection. 3. If the radio shows Connecting, and eventually shows Unprogrammed, perform the following actions: a. Check the access point and password. b. If the Wi-Fi is unavailable, use your smartphone to connect to the SSID using the password stated. 4. If the radio shows Checking for Updates, and eventually shows Unprogrammed, perform the following actions: a. If the Wi-Fi is connected, test the internet connectivity by using a smartphone. b. If the internet connection is working properly, power cycle the radio to restart the provisioning process. 5. If you hear these tones: <ul style="list-style-type: none"> • Continuous unprogrammed tone • Momentarily valid tone wait for one to two minutes for the radio to find the Update Job and perform one of the following actions: <ul style="list-style-type: none"> • If a job is found, the radio proceeds to the provisioning process.


Problem	LED and Tone Indication	Solution
		<ul style="list-style-type: none"> If no job is found, power cycle the radio. <p> NOTE: If the issues persist, contact Motorola Customer Service.</p>
Update Not Available 	LED: Blinking Red Tone: Continuous Un-programmed	Perform the following actions: <ol style="list-style-type: none"> 1. Verify that the Wi-Fi is connected by pressing the 3-Dot Programmable Feature button. 2. Check the router firewall configuration. 3. To retry the activation process, power cycle the radio. <p> NOTE: If the Wi-Fi is connected, contact Motorola Customer Service.</p>
Update Failed 	LED: Blinking Red Tone: Continuous Un-programmed	Perform the following actions: <ol style="list-style-type: none"> 1. Verify that the Wi-Fi is connected by pressing the 3-Dot Programmable Feature button. 2. If there is a low battery alert tone, charge the radio and continue until the tone stops. 3. Power cycle the radio and redo the whole process. <p> NOTE: If the issues persist, contact Motorola Customer Service.</p>
Missing Certificates 	LED: Solid Red Tone: Continuous Un-programmed	Contact Motorola Customer Service. <p> NOTE: If the radio connects to the Wi-Fi before receiving the error message, the radio shows the Wi-Fi icon. If you receive the error message before connecting to the Wi-Fi, the radio does not show the Wi-Fi icon.</p>
Device Not Found in RC	LED: Solid Red Tone:	Contact Motorola Customer Service.

Problem	LED and Tone Indication	Solution
	Continuous Un-programmed	
Job Not Found in RC 	LED: Solid Red Tone: Continuous Un-programmed	Contact Motorola Customer Service.
Install Failed Restarting 	LED: Flashing Red Tone: Momentary Invalid	Wait for the radio to power cycle.
Staging Error	LED: Solid Red Tone: Continuous Un-programmed	Contact Motorola Customer Service.

Problem	LED and Tone Indication	Solution
		
Committing Error 	LED: Solid Red Tone: Continuous Un-programmed	Contact Motorola Customer Service.

• © 2024 Motorola Solutions, Inc. All Rights Reserved

Documents / Resources

	MOTOROLA SOLUTIONS MN007868A01-AE Portable Two Way Radios [pdf] User Guide MN007868A01-AE, MN007868A01-AE Portable Two Way Radios, MN007868A01-AE, Portable Two Way Radios, Two Way Radios, Way Radios, Radios
-------------------------------------------------------------------------------------	-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.