



MOXA AWK-1161C Industrial Wireless AP-Bridge-Client Installation Guide

[Home](#) » [MOXA](#) » MOXA AWK-1161C Industrial Wireless AP-Bridge-Client Installation Guide 

MOXA AWK-1161C Industrial Wireless AP-Bridge-Client Installation Guide



Contents

- 1 Overview
- 2 Hardware Setup
- 3 Package Checklist
- 4 Optional Mounting Accessories (Sold Separately)
- 5 Panel Layout of the AWK-1161C/AWK-1161A
- 6 Mounting Dimensions
- 7 DIN-rail Mounting
- 8 Wall Mounting (Optional)
- 9 Wiring Requirements
- 10 Read and Follow These Guidelines:
- 11 Terminal Block Pin Assignment
- 12 Communication Connections
- 13 LED Indicators
- 14 Specifications
- 15 Software Setup
- 16 First-time Quick Configuration
- 17 Appendix
 - 17.1 Federal Communication Commission Interference Statement
 - 17.2 Canada, Innovation, Science and Economic Development Canada (ISED) Notices
 - 17.3 [NCC statements]
- 18 Documents / Resources
 - 18.1 References

Overview

The AWK-1161C and AWK-1161A Series are industrial-grade Wi-Fi clients and APs with IEEE 802.11ax technology. These Series feature dual-band Wi-Fi data transmissions up to 574 Mbps (2.4 GHz mode) or 1,201 Mbps (5 GHz mode), meeting the speed and flexibility requirements for industrial applications. In addition, the built-in dual band pass filter and the wide temperature design ensure reliability and uninterrupted operation in harsh environments. Meanwhile, backwards compatibility with 802.11a/b/g/n/ac makes the AWK-1161C/AWK-1161A Series the ideal solution for constructing a versatile wireless data transmission system.

Hardware Setup

This section covers the hardware setup for the AWK-1161C/AWK-1161A.

Package Checklist

Moxa's AWK-1161C/AWK-1161A is shipped with the following items. If any of these items is missing or damaged, please contact your customer service representative for assistance.


- 1 x AWK-1161C wireless client or AWK-1161A wireless AP
- 2 x 2.4/5 GHz antennas: ANT-WDB-ARM-0202
- DIN-rail kit (pre-installed)
- Quick installation guide (printed)
- Warranty card

Optional Mounting Accessories (Sold Separately)


- Wall-mount kit including 4 screws (M2.5×4)

Panel Layout of the AWK-1161C/AWK-1161A


Top Panel View



Bottom Panel View




Front Panel View





Rear Panel View

Side Panel View (Label Side)



Side Panel View (Wall mount Side)







1. Reset button
2. Antenna connector 1
3. Antenna connector 2
4. **System LEDs:** PWR, WLAN, SYSTEM
5. USB host (type A for ABC-02)
6. Console port (RS-232, RJ45)
7. LAN port
(10/100/1000BaseT(X), RJ45)
8. Terminal blocks for PWR (V+,
9. Functional Ground) Model name
10. Screw holes for wall-mounting kit
11. DIN-rail mounting kit

Mounting Dimensions

AWK-1161C/A Standard Models



AWK-1161C/A Wide Temperature (-T) Models



DIN-rail Mounting



When shipped, the metal DIN-rail mounting kit is fixed to the back panel of the AWK-1161C/AWK-1161A. Mount the AWK-1161C/AWK1161A on to a corrosion-free mounting rail that adheres to the EN 60715 standard.

STEP 1:

Insert the upper lip of the DIN-rail kit into the mounting rail.

STEP 2:

Press the AWK-1161C/AWK-1161A towards the mounting rail until it snaps into place.




To remove the AWK-1161C/AWK-1161A from the DIN rail, do the following:

STEP 1:

Pull down the latch on the DIN-rail kit with a screwdriver.

STEP 2 & 3:

Slightly pull the AWK-1161C/AWK1161A forward and lift it up to remove it from the mounting rail.




Wall Mounting (Optional)

For some applications, it may be more convenient to mount the AWK1161C/AWK-1161A to a wall, as illustrated below.


STEP 1:

Remove the aluminum DIN-rail attachment plate from the AWK1161C/AWK-1161A, and then attach the wall-mounting plates with M2.5×4 screws, as shown in the adjacent diagrams.



STEP 2:

Mounting the AWK-1161C/AWK-1161A to a wall requires 2 screws. Use the AWK-1161C/AWK-1161A device, with wall-mounting plates attached, as a guide to mark the correct locations of the 2 screws on the wall. The heads of the screws should be less than 6.0 mm in diameter, the shafts should be less than 3.5 mm in diameter, and the screw length should be at least 15 mm, as shown in the figure on the right.




Do not drive the screws in all the way—leave a space of about 2 mm to allow room for sliding the wall-mounting panel between the wall and the screws.

NOTE : Test the screw head and shank size by inserting the screws into one of the keyhole shaped apertures of the wall-mounting plates before they are fixed to the wall.

STEP 3:

Once the screws are fixed into the wall, insert the screw heads through the large opening of the keyhole-shaped apertures, and then slide the AWK-1161C/AWK-1161A downwards, as indicated to the right. Tighten the screws for added stability.



WARNING

- This equipment is intended to be used in a Restricted Access Location, such as an enclosed machine cabinet or chassis where only authorized service personnel or users can gain access. Such personnel must be

instructed about the fact that the metal chassis of the equipment can be extremely hot and may cause burns.

- Service personnel or users have to pay special attention and take special precautions before handling this equipment.
- Only authorized, well-trained professionals should be allowed to access the restricted access location. Access should be controlled by the authority responsible for the location with lock and key or a security identity system.
- **External metal parts are hot!!** Pay special attention or use special protection before handling the equipment.

Wiring Requirements



WARNING

Safety First!

Be sure to disconnect the power cord before installing and/or wiring your AWK-1161C/AWK-1161A.

Calculate the maximum possible current in each power wire and common wire. Observe all electrical codes that dictate the maximum current allowed for each wire size. If the current goes above the maximum ratings, the wiring could overheat, causing serious damage to your equipment.

Read and Follow These Guidelines:

- Use separate paths to route wiring for power and devices. If power wiring and device wiring paths must cross, make sure the wires are perpendicular at the crossing point.

NOTE Do not run signal or communications wiring and power wiring in the same wire conduit. To avoid interference, wires with different signal characteristics should be routed separately.

- You can use the type of signal transmitted through a wire to determine which wires should be kept separate. The rule of thumb is that wiring that shares similar electrical characteristics can be bundled together.
- Keep input wiring and output wiring separated.
- For future reference, you should label the wiring used for all of your devices.

NOTE The product is intended to be supplied by a UL Listed Power Unit marked “L.P.S.” (or “Limited Power Source”) and is rated 9-30 VDC, 1.57-0.47 A min, Tma min. 75°C. If you need further assistance with purchasing the power source, please contact Moxa for further information.

NOTE If using a Class I adapter, the power cord must be connected to a socket-outlet with an earthing connection.



ATTENTION

Make sure the external power adapter (includes power cords and plug assemblies) provided with the unit is certified and suitable for use in your country or region.


Grounding the AWK-1161C/AWK-1161A

Grounding and wire routing help limit the effects of noise due to electromagnetic interference (EMI). Run the ground connection from the functional ground input on the terminal block to the grounding surface prior to connecting devices.



ATTENTION

This product is intended to be mounted to a well-grounded mounting surface, such as a metal panel. The potential difference between any two grounding points must be zero. If the potential difference is NOT zero, the product could be permanently damaged.




Arrester Accessories

- SA-NMNF-02: Surge arrester, N-type (male) to N-type (female)
- SA-NFNF-02: Surge arrester, N-type (female) to N-type (female)

Terminal Block Pin Assignment

The AWK-1161C/AWK-1161A comes with a 3-pin terminal block located on the front panel of the device. The terminal block contains the power input and functional ground. Refer to the following figure and table for the detailed pin assignment.



Pin	Definition
1	Functional GND
2	DC Power Input 1
3	

NOTE Before connecting the AWK-1161C/AWK-1161A DC power inputs, make sure the DC power source voltage is stable.

- The wiring for the input terminal block shall be installed by a skilled person.
- Wire type: Cu
- Only use 16-24 AWG wire size.
- Use only one conductor in a clamping point between the DC power source and the power input.



ATTENTION

If the AWK-1161C/AWK-1161A is connected to a motor or other similar type of equipment, be sure to use power isolation protection. Before connecting the AWK-1161C/AWK-1161A to the DC power inputs, make sure the DC power source voltage is stable.


Communication Connections

10/100/1000BaseT(X) Ethernet Port Connection

The 10/100/1000BaseT(X) ports located on the AWK-1161C/AWK-1161A's front panel are used to connect to Ethernet-enabled devices.

MDI/MDI-X Port Pinouts


Pin	1000BaseTMDI/MDI-X	10/100BaseT(X)MDI	10/100BaseT(X)MDI-X
1	TRD(0)+	TX+	RX+
2	TRD(0)–	TX-	RX-
3	TRD(1)+	RX+	TX+
4	TRD(2)+	–	–
5	TRD(2)-	–	–
6	TRD(1)-	RX-	TX-
7	TRD(3)+	–	–
8	TRD(3)-	–	–



RS-232 Connection

The AWK-1161C/AWK-1161A has one RS-232 (8-pin RJ45) console port located on the front panel. Use either an RJ45-to-DB9 or RJ45-to-DB25 cable to connect the AWK-1161C/AWK-1161A's console port to your PC's COM port. You may then use a console terminal program to access the AWK-1161C/AWK-1161A for console configuration.

Pin	Description
1	DSR
2	NC
3	GND
4	TXD
5	RXD
6	NC
7	NC
8	DTR



LED Indicators

The front panel of the AWK-1161C/AWK-1161A contains several LED indicators. The function of each LED is described in the table below:

LED	Color	State	Description
Front Panel LED Indicators (System)			
PWR	Green	On	Power is being supplied.
		Off	Power is not being supplied.
SYSTEM	Red	On	System initialization failure, configuration error, or system error. Refer to the AWK-1161C/AWK-1161A Series User Manual for more details.
	Green	On	System startup completed and is operating normally.
WLAN	Green	On	Client/Client-Router/Slave has established a Wi-Fi connection to an AP/Master with a SNR value of 35 or higher.
		Blinking	Data is being transmitted over the WLAN interface.
	Amber	On	Client/Client-Router/Slave has established a Wi-Fi connection to an AP/Master with a SNR value of less than 35.
		Blinking	Data is being transmitted over the WLAN interface.
LAN LED Indicators (RJ45 Port)			
LAN	Green	On	LAN port's 1000 Mbps link is active .
		Blinking	Data is being transmitted at 1000Mbps.
		Off	LAN port's 1000 Mbps link is inactive .
	Amber	On	LAN port's 10/100 Mbps link is active .
		Blinking	Data is being transmitted at 10/100Mbps.
		Off	LAN port's 10/100 Mbps link is inactive .

Specifications

Input Current	9 to 30 VDC, 1.57 to 0.47 A
Input Voltage	9 to 30 VDC
Power Consumption	14 W (max.)
Operating Temperature	Standard Models: -25 to 60°C (-13 to 140°F) Wide Temp. Models: -40 to 75°C (-40 to 167°F)
Storage Temperature	-40 to 85°C (-40 to 185°F)

NOTE To meet the standard for IP30 protection, all unused ports should be covered with the protective caps.



ATTENTION

The AWK-1161C/AWK-1161A is NOT a portable mobile device and should be located at least 20 cm away from the human body.

The AWK-1161C/AWK-1161A is NOT designed for the general public. To ensure that your AWK-1161C/AWK-1161A wireless network is safe and configured correctly, consult a well-trained technician to assist with the installation process.



ATTENTION

Use the appropriate antennas for your wireless setup: Use 2.4 GHz antennas when the AWK-1161C/AWK-1161A is configured for IEEE 802.11b/g/n. Use 5 GHz antennas when the AWK-1161C/AWK-1161A is configured for IEEE 802.11a/n/ac. Make sure that the antennas are located in an area with a lightning and surge protection system installed.

ATTENTION

Do not locate the antenna near overhead power lines or other electric light or power circuits, or where it can come into contact with such circuits. When installing the antenna, take extreme care not to come into contact with such circuits, because they may cause serious injury or death. For proper installation and grounding of the antenna, refer to national and local codes (for example, U.S.: NFPA 70; National Electrical Code (NEC) Article 810; Canada: Canadian Electrical Code, Section 54).

NOTE For installation flexibility, you can use either antenna 1 or antenna 2. Make sure the antenna connection matches the antennas configured in the AWK-1161C/AWK-1161A web interface.

interface.

To protect the connectors and RF module, all radio ports should be terminated by either an antenna or a terminator. We strongly recommend using resistive terminators for terminating the unused antenna ports.

Software Setup

This section covers the software setup for the AWK-1161C/AWK-1161A.

How to Access the AWK

Before installing the AWK device (AWK), make sure that all items in the package checklist are provided in the product box. You will also need access to a notebook computer or PC equipped with an Ethernet port.

Step 1: Connect the AWK to an appropriate DC power source.

Step 2: Connect the AWK to the notebook or PC via the **AWK's LAN port**.

The LED indicator on the AWK's LAN port will light up when a connection is established.



NOTE If you are using an Ethernet-to-USB adapter, follow the instructions in the user manual provided with the adapter.

- **Step 3:** Set up the computer's IP address.

Choose an IP address for the computer that is on the same subnet as the AWK. Since the AWK's default IP address is **192.168.127.253**, and the subnet mask is **255.255.255.0**, set the IP address to **192.168.127.xxx**,

where xxx is a value between 1 and 252.


- **Step 4: Access the homepage of the AWK.**

Open your computer's web browser and type <https://192.168.127.253> in the address field to access the AWK's homepage. If successfully connected, the AWK's interface homepage will appear. Click **NEXT**.



- **Step 5: Choose your country or region.**

Select your country or region from the drop-down list and click **NEXT**.



- **Step 6: Create a user account and password.**

Enter the username, password, and email address for your user account and click **CREATE**.

NOTE The username and password are case-sensitive.



MOXA®

Create your administrator account

Username *

At least 4 characters 0 / 32

New Password *

At least 4 characters 0 / 63

Confirm Password *

At least 4 characters 0 / 63

Email

0 / 318

BACK CREATE

Copyright © 2022 Moxa, Inc. All Rights Reserved.

After creating your account, you will be automatically redirected to the login screen.



- **Step 7: Log in to the device.**

Enter your username and password and click **LOG IN**. The device will start initializing, this may take several seconds. Once the warning message has disappeared, you can log in using your username and password.




First-time Quick Configuration

After successfully accessing the AWK, refer to the appropriate subsection below to quickly set up a wireless network.

NOTE Ensure that there are no IP address conflicts when you configure more than one AWK on the same subnet.


AP/Client Mode



Configuring the AWK as an AP (AWK-1161A Series Only)

- **Step 1: Set the operation mode of the AWK to AP mode.** Go to Wi-Fi Wireless Settings and select AP from

the Operation Mode drop-down list.



- **Step 2: Set up the AWK as an AP.**

Click the ADD icon to create a new SSID.



On the settings page, configure the **SSID Status**, **SSID**, **RF Band**, **RTS/CTS Threshold**, and **Transmission Rate** for the 5 GHz or 2.4 GHz band. When finished, click **NEXT**.

Configure SSID Settings

1

2

SSID Status *

Enabled

SSID *

MOXA

At least 1 character

4 / 32

RF Band

5 GHz

RTS / CTS Threshold

2346

32 - 2346

byte

Transmission Rate: 5 GHz

Data Transmission Rate

Auto

Min. Data Transmission Rate

0

0 - 54

Mbps

Broadcast/Multicast Data Trans...

36 Mbps

Management Transmission Rate

36 Mbps

CANCEL

NEXT

On the second SSID Settings screen, configure the SSID

Broadcast Status and Security type. From here, you can also copy the configuration over to the second SSID.

When finished, click CONFIRM.

Configure SSID Settings

2

SSID Broadcast Status *

Enabled

Security

Open

Copy Config to SSIDs


BACK

CONFIRM


Configuring the AWK as a Client (AWK-1161C Series Only)

Set the operation mode of the AWK to Client mode.

Go to **Wi-Fi Wireless Settings** and select Client from the Operation Mode drop-down list, set the SSID, and click **Apply**. For more detailed configurations, refer to the **AWK-1161C/AWK-1161A Series User Manual**.




Master/slave Mode



Configuring the AWK as a Master (AWK-1161A Series Only)

- **Step 1:** Set the operation mode of the AWK to Master mode. Go to Wi-Fi Wireless Settings and select Master from the Operation Mode drop-down list.



- **Step 2: Set up the AWK as a Master.**

Click the **ADD** icon  to create a new SSID.



On the settings page, configure the **SSID Status**, **Master/AP** (select Master), **SSID**, **RF Band**, **RTS/CTS Threshold**, and **Transmission Rate** for the 5 GHz or 2.4 GHz band. When finished, click **NEXT**.

Configure SSID Settings

1
2

SSID Status *
Enabled

Master / AP
Master

SSID *
MOXA

RF Band
5 GHz

At least 1 character 4 / 32

RTS / CTS Threshold
2346

32 - 2346 byte

Transmission Rate: 5 GHz

Data Transmission Rate
Auto

Min. Data Transmission Rate
0

0 - 54 Mbps

Broadcast/Multicast Data Trans...
36 Mbps

Management Transmission Rate
36 Mbps

CANCEL
NEXT

On the second SSID Settings screen, configure the **SSID Broadcast Status** and **Security** type. From here, you

can also copy the configuration over to the second **SSID**. When finished, click **CONFIRM**.

2

SSID Broadcast Status *

Enabled

Security

Open

Copy Config to SSIDs

BACK

CONFIRM

Configure SSID Settings

Configuring the AWK as a Slave (AWK-1161C Series Only) Set the operation mode of the AWK to Slave mode.

Go to **Wi-Fi Wireless Settings** and select **Slave** from the Operation Mode drop-down list, set the SSID, and click **Apply**. For more detailed configurations, refer to the **AWK-1161C/AWK-1161A Series User Manual**.

Search for function

Device Summary

System

Wi-Fi

Wireless Settings

Connection Check and Recovery

Roaming

Ports

Layer 2 Switching

IP Configuration

Routing and NAT

Firewall

Security

Wireless Setting

General

Operation Mode

Slave

SSID Settings ^

SSID *

Moxa

4 / 32

Security Settings >

RF Settings >

Advanced Settings >

APPLY

Appendix

Federal Communication Commission Interference Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

CAUTION

Any changes or modifications not expressly approved by the grantee of this device could void the user's authority to operate the equipment.

This device is restricted to indoor use.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20 cm between the radiator & your body.

Canada, Innovation, Science and Economic Development Canada (ISED) Notices

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

This device may not cause interference.

This device must accept any interference, including interference that may cause undesired operation of the device.

Avis du Canada, Innovation, Sciences et Développement économique Canada (ISED)

Radio Frequency (RF) Exposure Information

The radiated output power of the Wireless Device is below the Innovation, Science and Economic Development Canada (ISED) radio frequency exposure limits. The Wireless Device should be used in such a manner such that the potential for human contact during normal operation is minimized.

This device has also been evaluated and shown compliant with the ISED RF Exposure limits under mobile exposure conditions. (antennas are greater than 20 cm from a person's body).

This radio transmitter [IC: 9335A-AWK1160] has been approved by Innovation, Science and Economic Development Canada to operate with the antenna types listed below, with the maximum permissible gain indicated. Antenna types not included in this list that have a gain greater than the maximum gain indicated for any type listed are strictly prohibited for use with this device.

Antenna Type	Model Number	Antenna Gain(dBi)	
		2.4 GHz	5 GHz
Dipole	ANT-WDB-ARM-02	2	2
Dipole	ANT-WDB-ARM-0202	2	2
Dipole	ANT-WSB-AHRM-05-1.5m	5	—
Dipole	MAT-WDB-CA-RM-2-0205	2	5
Dipole	MAT-WDB-DA-RM-2-0203-1m	2	3

the device for operation in the band 5150-5250 MHz is only for indoor use to reduce the potential for harmful interference to co-channel mobile satellite systems;

[NCC statements]



[KC statements]

[ANATEL statements]

ANATEL – <https://www.gov.br/anatel>



Documents / Resources

<div><div>AWK-1161C/AWK-1161A Series</div><div>Quick Installation Guide</div><div>Moxa Articles</div><div>Version 1.0, January 2024</div><div>Technical Support Contact Information</div><div>www.moxa.com/support</div><div></div><div></div></div>	<div><div>MOXA AWK-1161C Industrial Wireless AP-Bridge-Client [pdf] Installation Guide</div><div>AWK-1161C Industrial Wireless AP-Bridge-Client, AWK-1161C, Industrial Wireless AP-Bridge-Client, Wireless AP-Bridge-Client, AP-Bridge-Client, Client</div></div>
--	---

References

- [M Moxa - Support](#)
- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.