

MOXA MGate 5119 Series Modbus TCP Gateway Installation Guide

Home » MOXA » MOXA MGate 5119 Series Modbus TCP Gateway Installation Guide 1



Contents

- 1 MOXA MGate 5119 Series Modbus TCP
- **Gateway**
- 2 Overview
- 3 Package Checklist
- **4 Hardware Introduction**
- **5 Dimensions**
- **6 Reset Button**
- 7 Hardware Installation Procedure
- 8 Wall-mount:
- 9 Software Installation Information
- 10 Pin Assignments
- 11 Ethernet Port (RJ45)
- 12 Specifications
- 13 Documents / Resources
 - 13.1 References
- **14 Related Posts**



MOXA MGate 5119 Series Modbus TCP Gateway



Overview

The MGate 5119 Series is an Ethernet gateway designed for the power industry to integrate Modbus, DNP3, IEC 60870-5-101/104 devices to an IEC 61850 MMS network.

Package Checklist

Before installing the MGate 5119, verify that the package contains the following items:

- 1 MGate 5119 gateway
- 1 serial cable: CBL-RJ45F9-150
- Quick installation guide (printed)
- · Warranty card

Please notify your sales representative if any of the above items is missing or damaged.

Optional Accessories (can be purchased separately)

- CBL-F9M9-150: DB9-female-to-DB9-male serial cable, 150 cm
- CBL-F9M9-20: DB9-female-to-DB9-male serial cable, 20 cm
- CBL-RJ45F9-150: RJ45-to-DB9-female serial cable, 150 cm
- CBL-RJ45SF9-150: RJ45-to-DB9-female serial shielded cable, 150 cm
- Mini DB9F-to-TB DB9: Female-to-terminal-block connector
- WK-36-02: Wall-mounting kit, 2 plates with 6 screws
- CBL-PJTB-10: Non-locking barrel plug to bare-wire cable

Hardware Introduction


LED Indicators

| LED | Color | Description |
|---------------------|-------|--|
| Ready | Off | Power is off or a fault condition exists |
| | Green | Steady: Power is on, and the MGate is functioning normally |
| | Red | Steady: Power is on, and the MGate is booting up |
| | | Blinking slowly: Indicates an IP conflict, or the DHCP or BOOTP server is not re sponding properly |
| | | Flashing quickly: the microSD card failed |
| MB/101/ 104/DNP3 | Off | No communication with a Modbus/101/104/DNP3 device |

| Green | Normal Modbus/101/104/DNP3 communication in progress |
|-------|---|
| Red | When the MGate 5119 acts as a Modbus master: |
| | Received an exception code from the slave device Received a framing error (parity error, checksum error) Timeout (the master sent a request but no response was received) |
| | When the MGate 5119 acts as an IEC 60870-5- 101/104/ DNP3 master: |

| LED | Color | Description |
|-----|-------|---|
| | | Received an outstation exception (format error, checksum error, invalid data, outstation responds are not supported) Timeout (the master sent a command, but no response was received) |
| 850 | Off | No communication with the IEC 61850 system |
| | Green | Normal IEC 61850 communication in progress |
| | Red | When the MGate 5119 acts as an IEC 61850 server: 1. Received an abnormal package (wrong format, unsupported function code) 2. Failed to establish an IEC 61850 connection 3. Disconnected the IEC 61850 connection |

Dimensions




Reset Button

Restore the MGate to factory default settings by using a pointed object (such as a straightened paper clip) to hold the reset button down until the Ready LED stops blinking (approximately five seconds).

Pull-high, Pull-low, and Terminator for RS-485

Beneath the MGate 5119's top cover, you will find DIP switches to adjust each serial port's pull-high resistor, pull-low resistor, and terminator.




Hardware Installation Procedure


- 1. Connect the MGate 5119's terminal block to the power supply, which could provide 12 to 48 VDC.
- 2. Use a serial or Ethernet cable to connect the MGate to the Modbus RTU/ASCII/TCP, DNP3 Serial/TCP, IEC60870-5-101/104 device.
- 3. Use an Ethernet cable to connect the MGate to the IEC 61850 MMS system.

4. The MGate 5119 is designed to be attached to a DIN rail or mounted on a wall. For DIN-rail mounting, push down the spring and properly attach it to the DIN rail until it "snaps" into place. For wall mounting, install the wall-mount kit (optional) first and then screw the device onto the wall. An M3 screw is suggested, and the minimum length of the screw should be 10 mm.


The following figure illustrates the two suggested mounting options:



The following figure illustrates how to attach screws to the mounting kits: **DIN Rail:**



Wall-mount:



NOTE The equipment is intended to be supplied by the external power source (UL listed/ IEC 60950-1/ IEC 62368-1), which output complies with ES1/SELV, PS2/LPS, output rating is 12 to 48 VDC, 0.455 A min., an ambient temperature 75°C minimum.

NOTE Before connecting the Equipment to DC power inputs, make sure DC power source voltage is stable

- The wiring of input terminal block shall be installed by skilled person.
- Wire type: Cu
- Only use 28-18 AWG wire size, torque value 0.5 N-m.
- One individual conductor in a clamping point.

NOTE If you are using a Class I adapter, the power cord should be connected to an outlet with an earthing connection

Software Installation Information

You can download the User's Manual and Device Search Utility (DSU) from Moxa's website: www.moxa.com. Please refer to the User's Manual for additional details on using the DSU.


The MGate 5119 also supports login via a web browser.

Default IP address: 192.168.127.254

Default account: admin Default password: moxa

Pin Assignments

Serial Port (Male DB9)




| Pin | RS-232 | RS-422/ RS-485 (4W) | RS-485 (2W) |
|-----|--------|---------------------|-------------|
| 1 | DCD | TxD-(A) | _ |
| 2 | RXD | TxD+(B) | _ |
| 3 | TXD | RxD+(B) | Data+(B) |
| 4 | DTR | RxD-(A) | Data-(A) |
| 5* | GND | GND | GND |
| 6 | DSR | _ | _ |
| 7 | RTS | _ | _ |
| 8 | CTS | _ | _ |
| 9 | _ | _ | _ |


Ethernet Port (RJ45)

Ethernet Port (RJ45)

| Pin | Signal |
|-----|--------|
| 1 | Tx+ |
| 2 | Tx- |
| 3 | Rx+ |
| 6 | Rx- |




Power Input and Relay Output Pinouts



Specifications

| Power Requirements | | | |
|---------------------------|---|--|--|
| Power Input | 12 to 48 VDC | | |
| Input Current | 455 mA max. | | |
| Operating Temperature | -40 to 75°C (-40 to 167°F) | | |
| Ambient Relative Humidity | 5 to 95% (non-condensing) | | |
| Dimensions | 36 x 120 x 150 mm (1.42 x 4.72 x 5.91 in) | | |
| Reliability | | | |
| Alert Tools | Built-in buzzer and RTC | | |
| MTBF | 1,180,203 hrs. | | |

Documents / Resources



References

- Moxa Your Trusted Partner in Automation
- M Moxa Support

Manuals+,