



## moxee Mobile Hotspot K779HSDL User Manual

[Home](#) » [Moxee](#) » [moxee Mobile Hotspot K779HSDL User Manual](#) 

### moxee Mobile Hotspot K779HSDL






#### Contents

- [1 Display Layout and Icons](#)
- [2 Device Overview](#)
- [3 Charging your device](#)
- [4 Setting up Wi-Fi connection](#)
- [5 Troubleshooting](#)
- [6 Documents / Resources](#)
- [7 Related Posts](#)

### Display Layout and Icons



Icon	Description
	Signal and Roaming status icon
	Network mode icon
	Data flow icon
	Wi-Fi signal and number of access users
	The number of unread messages; maximum is 100
	Battery capacity icon; if battery is lower than 25% then this icon is red
	WPS status indicator
	Download and upload data speed

## Device Overview



1. Menu button
2. Signal and Roaming status icon
3. Network mode icon
4. Wi-Fi signal icon
5. Unread message icon
6. Battery icon
7. Power button
8. MicroUSB port
9. Battery cover
10. Notch for removing back cover

## Charging your device

Your device comes with a charger. To charge, plug one end of the charger into an electrical outlet and the other end into the device's MicroUSB port.

## Setting up Wi-Fi connection

Press and hold the Power Button for 3 seconds until the welcome logo appears on the display.

1. After a few seconds, the Wi-Fi signal icon will appear on the display.
2. Look for the network (SSID) "**Moxee HotspotXX\_2.4G**" or "**Moxee HotspotXX\_5G**", where XX are the last two digits of the device IMEI.
3. Click "Connect" and enter the default password found on your device. Your Wi-Fi SSID and password information can be found on your device's "**Wi-Fi Info**" screen or on the SSID label located underneath the battery cover.

**Note:** This device will search for software updates periodically and may result in a small amount of data usage.

## Troubleshooting

If you are having trouble with the device, here are a few troubleshooting tips:

1. If the device is not responsive, restart it by pressing the Power Button for 8 seconds.
2. If restarting the device does not solve the issue, try restoring the device to its default factory settings.

### Q: What do I do if I see the SSID but failed to connect?

A: Check if the password you entered is the correct one.

– Check if WPS security is enabled on your PC. If so, check the device to see if it is expecting a WPS action from your PC.

### Q: What if there's no service?

A: The possible reasons are an unstable network signal or a hardware problem. You can try the following solutions:

- If you are inside a building or near a structure that may be blocking the signal, change the position or location of the device. For example, try moving the device close to a window.
- Check the hardware for any loose parts or damage.

### Q: What if I have forgotten my Wi-Fi Password?

A: You can find the Wi-Fi Password in the Wi-Fi Info page on the LCD.

– You can also reset the device to factory defaults by pressing the reset button for 5 seconds. The default password is listed on the SSID label under the back cover of the device and is also the last 8 digits of your hotspot's IMEI. The IMEI can be found on the device label located underneath the removable battery. Be sure to power your device off before removing the battery.

## Documents / Resources

	<p><a href="#">moxee Mobile Hotspot K779HSDL</a> [pdf] User Manual Hotspot, K779HSDL</p>
---	--