




Netatmo QSG1-NTH-V9 Smart Thermostat User Guide

[Home](#) » [Netatmo](#) » Netatmo QSG1-NTH-V9 Smart Thermostat User Guide



QSG1-NTH-V9 Smart Thermostat User Guide



Smart Thermostat

Replacing a wall-mounted thermostat




Read these instructions carefully before starting the installation.
The Netatmo Thermostat must be installed according to applicable standards.
Before any intervention, make sure the power is turned off.
The Netatmo Thermostat cannot control electric converters.

To replace a wall-mounted thermostat, you can watch an installation tutorial video online at the following address: netatmo.com/video1


Contents [[hide](#)

- [1 Pack contents](#)
- [2 Plug the Relay](#)
- [3 Identify the wires](#)
- [4 Replace](#)
- [5 Test the Thermostat](#)
- [6 Download the Netatmo Energy mobile app](#)
- [7 Installation troubleshooting](#)
- [8 Documents / Resources](#)
 - [8.1 References](#)
- [9 Related Posts](#)


Pack contents




1. Thermostat



2. Mobile stand*




3. Relay




4. Boiler adaptor*




5. Wall-bracket



6. Wall mounting plate



7. Color Adhesives




8. Mains adaptor



9. Tape*



10. 3 AAA batteries




11. 4 screws
4 screw anchors

* Not used or optional in this setup

Plug the Relay

①




Plug the mains adaptor into the **Relay**.

②




Plug the **Relay** into a wall socket in the same room as your existing thermostat.

③



The LED of the **Relay** will blink.


④



Switch off the power supply.

Identify the wires


1. Remove the cover of your old thermostat.
Take a picture of the wiring.
- 2.



Control wires

Power supply wires


- If there are only two wires, they are the control wires and are useful in this setup.
 - If there are more than two wires, identify the two control wires with the help of the following diagram. They are usually connected to the COM/NO ports.
- The other wires have to be safely insulated.




See the Installation Troubleshooting p. 24 for more help.

Replace


1. Disconnect your old thermostat. Remove it from the wall.



2. Pass the wires through the wall bracket and screw it to the wall. To hide potential scratches and holes left behind, you can put the wall mounting plate first.




3. Screw the control wires previously identified into the wiring terminals of the wall bracket (no polarity). Insulate the unused wires. Screw the protection cover onto the wiring terminals.




Customize your Thermostat


1. You can choose to customize your Thermostat by using one of the color adhesives.



2. Take off the outer frame of the adhesive.




3. Stick it on the back of your Thermostat.




Set the Thermostat


1. Insert the batteries in the Thermostat ensuring the positive and negative ends correspond.




2. Set the Thermostat on the wall bracket.




3. Switch the power supply back on.



4. The Thermostat will display the start screen and search for the Relay.




5. When the Thermostat has found the Relay, it displays the setpoint temperature and the room temperature.




See the Installation Troubleshooting p. 24 for more help.

Test the Thermostat


1. Push the top of the Thermostat until it displays « MAX ». The Thermostat switches the boiler on.




2. Push the bottom of the Thermostat until it displays « OFF ». The Thermostat switches the boiler off.



Download the Netatmo Energy mobile app



🏠 Netatmo webapp



To remotely control your Thermostat from your smartphone or tablet, download the app on: therm.netatmo.com

Installation troubleshooting

Page	Problem	Possible causes	Solutions
p 10	I cannot identify the control wires of my boiler.		Please send a picture to photo@netatmo.com and our support team will help you identify the right wires.
p 18 p20	The Thermostat displays the 1" symbol.	The Thermostat hasn't found the Relay.	TM:evren:ohset lal?nYdcwtteur nTitthhee symbol disappears.
	The Thermostat doesn't switch on and off the boiler.	The control wires have been in correctly wired.	Check your wiring using the picture of your old Thermostat's wiring to identify the right control wires.
2	The boiler does the opposite of the thermostat (the thermostat displays MAX).	The polarity of the Thermostat	Change the polarity of the Thermostat once you will have finished the setup, in the advanced settings of the app.



support.netatmo.com



QSG1-NTH

Copyright Netatmo © 2020 All rights reserved. Reproduction and distribution prohibited without written authorization from Netatmo Apple and the Apple logo are trademarks of Apple Inc., registered in the U.S. and other countries. App Store is a service mark of Apple Inc., registered in the U.S. and other countries. Google Play and the Google Play logo are trademarks of Google Inc




Documents / Resources

	Netatmo QSG1-NTH-V9 Smart Thermostat [pdf] User Guide QSG1-NTH-V9, Smart Thermostat, QSG1-NTH-V9 Smart Thermostat
--	--

References

- 🏠 [Netatmo: same home, just smarter](#)
- 🏠 [Netatmo : same home, just smarter](#)
- 🏠 [Netatmo Helpcenter](#)

-  [Netatmo : same home, just smarter](#)

[Manuals+](#), [home](#) [privacy](#)