

NEXSENS
technology
**X2-CB Buoy Mounted
Data Logger**



NEXSENS X2-CB Buoy Mounted Data Logger User Guide

[Home](#) » [NEXSENS](#) » NEXSENS X2-CB Buoy Mounted Data Logger User Guide 

Contents

- [1 NEXSENS X2-CB Buoy Mounted Data Logger](#)
- [2 Overview](#)
- [3 What's Included?](#)
- [4 Sensor Configuration](#)
- [5 Documents / Resources](#)
 - [5.1 References](#)



NEXSENS X2-CB Buoy Mounted Data Logger



IMPORTANT – BEFORE FIELD DEPLOYMENT

Completely configure new X2-CB systems with sensors and a direct connection to the CONNECT software in a nearby work area. Operate the system for several hours and ensure correct sensor readings. Use this test run to become familiar with the features and functions.

Overview

The X2-CB buoy-mounted data logger has five sensor ports that provide industry-standard protocols including SDI-12, RS-232, and RS-485. The Solar/COM port offers direct communication (serial to PC) and power input. The X2-CB is powered by the CB-Series buoy's solar rechargeable battery reserve.

CONNECT is a software utility that enables users to interface directly with any NexSens X2-Series data logger using a UW6-USB-485P cable. It supports a growing number of diagnostic and configuration tools to facilitate system setup and troubleshooting.

What's Included?

- (1) X2-CB buoy-mounted data logger
- (5) Sensor port plugs, (3) spare rings
- (1) Power port plug, (2) spare rings
- (1) Oring grease
- (2) Spare sensor port plugs
- (1) Quick start guide

Sensor Configuration

1. Visit the following link on the NexSens Knowledge

Base to download the CONNECT software and establish a connection with the X2. nexsens.com/connst

- Remove the SOLAR/COM blank plug from the 6-pin port and insert the UW6-USB-485P between the logger and the PC.
- The device will beep once when powered. Power will be coming from the internal buoy batteries.

Note: If a System Integration Guide is included with the order, the sensor programming is complete, and steps 2-4 can be skipped.

2. Use the following link to ensure the proper scripts are enabled for each sensor. nexsens.com/conncss .Power down the X2 and remove the USB cable connection.

- Remove one blank sensor plug from an 8-pin port (i.e., P0, P1, or P2) for each sensor.
- Connect all sensors to the desired ports.

Note: Ensure that all SDI-12 and RS-485 sensors have unique addresses.


3. Provide 12V power to the X2 and wait up to 5-10 minutes for sensor detection

- Reconnect the USB cable to the X2 and open CONNECT.

4. Once in CONNECT, visit the following article to confirm the X2 sensor configuration and directly download the first few data points. nexsens.com/conndu

For additional information, please reference the X2-CB & CONNECT software resource libraries on the NexSens Knowledge Base. nexsens.com/x2cbkb | nexsens.com/connug
[937-426-2703 www.nexsens.com](https://nexsens.com)

Documents / Resources

	<p>NEXSENS X2-CB Buoy Mounted Data Logger [pdf] User Guide X2-CB Buoy Mounted Data Logger, X2-CB, Buoy Mounted Data Logger, Mounted Data Logger, Data Logger, Logger</p>
---	--

References

- [Configure Sensor Scripts - NexSens](#)
- [Direct Data Upload - NexSens](#)
- [CONNECT Setup - NexSens](#)
- [NexSens Technology Inc. - Better Data. It's what we do](#)
- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.