



NICOLAUDIE ARCHITECTURAL SLESA-U11 Smart DMX Interface Instruction Manual

[Home](#) » [NICOLAUDIE ARCHITECTURAL](#) » NICOLAUDIE ARCHITECTURAL SLESA-U11 Smart DMX Interface Instruction Manual 

Contents

- [1 NICOLAUDIE ARCHITECTURAL SLESA-U11 Smart DMX Interface](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
- [4 Overview](#)
- [5 Key Features](#)
- [6 Technical Data](#)
- [7 Setting up the Controller](#)
- [8 Basic Operation](#)
- [9 Remote Control Over Local Network](#)
- [10 Troubleshooting](#)
- [11 Documents / Resources](#)
 - [11.1 References](#)
- [12 Related Posts](#)



NICOLAUDIE ARCHITECTURAL SLESA-U11 Smart DMX Interface



Product Information

The SLESA-U11 is a smart DMX interface that combines the latest innovations from Nicolaudie Architectural. It can be programmed using ESA Pro 2 software or Arcolis and features the new Nicolaudie Stand Alone engine (NSA) for powerful performance. The interface has multi-zone capabilities, extended triggers, and 16-bit channels management. It also has an intuitive backlit keyboard with 10 presets and zone selection. The SLESA-U11 can be controlled using Arcolis Remote Pro or Arcolis Remote apps from a smartphone or tablet. It is compatible with Windows, Mac OS, iOS, and Android.

Key Features:

- Input Power: 5-5.5V DC 0.6A
- Output Protocol: DMX512
- Programmability: Windows, Mac OS, iOS, Android
- Connections: Type C USB, XLR3, Ethernet, 20-Pin (2×10) Male IDC Socket, battery
- Memory: microSD SD & SDHC (32Gb Max)
- Buttons: 10 buttons for direct access, 2 buttons to change scene, 1 button to change zone
- Dimensions: 160x90x45mm
- Weight: 268g
- OS Requirements: Mac OS X 10.13 onwards, Windows 8.1 64bit onwards
- Standards: EC, EMC, ROHS

Optional Accessories: POWER1_EU/UK/US 5V ACDC PSU with EU/UK/US plug

Product Usage Instructions

To use the SLESA-U11 interface with a computer, connect it to the software. The controller will output DMX directly from the software and display "LI" on the screen. If using ESA PRO 2018, navigate to the "BAR" menu and select options such as Edit, Display, or About. The software allows you to control different areas, rooms, and lights. You can also create scenarios/sequences and apply various effects. For live use, the SLESA-U11 can be controlled using Arcolis Remote Pro or Arcolis Remote apps from a smartphone or tablet. Simply connect the interface to an Ethernet connection or use Wi-Fi for wireless control. For more information and technical details,

refer to the [official product page](#) or consult the product's technical datasheet.

Overview

- The new SLESA-U11 is built on the latest generation of lighting controllers from Nicolaudie Architectural and combines all our recent innovations.
- Programmable with ESA Pro 2 software or with Arcolis, the SLESA-U11 features the new Nicolaudie Stand Alone engine (NSA) offering incredible power with multi-zone, extended triggers and 16-bit channels management.
- Intuitive backlit keyboard with 10 presets and zone selection. With an Ethernet connection and Wifi, the SLESA-U11 can be controlled using Arcolis Remote Pro or Arcolis Remote apps from a smartphone or tablet.
- <http://www.nicolaudie.com/slesa-u11.htm>.

Key Features

- 2x DMX512 universes in live mode (computer/tablet)
- 2x DMX512 universes in stand alone mode
- Expandable from 2 to 4 DMX512 universes
- Intuitive backlit keyboard with 10 presets
- 99 scenes (total) across 5 zones
- USB & Ethernet for programming/control
- Multi-zone microSD memory
- 16 dry contact trigger ports via 20-Pin IDC Socket
- Clock and calendar with Sunrise/Sunset triggering
- Network communication. Control lighting remotely
- OEM customization
- Windows/Mac software to set dynamic colors/effects
- Phone/iPad/Android remote and programming apps
- Metal bracket, mount to a wall or under a desk
- DMX in or out. RDM ready.
- Extended triggering possibilities (TCA)
- Smart Upgrade Technology (SUT)

Technical Data

- **Input Power:** 5-5.5V DC 0.6A
- **Output Protocol:** DMX51
- **Programmability:** Windows, Mac OS, iOS, Android
- **Connections:** Type C USB, XLR3, Ethernet, 20-Pin (2×10) Male IDC Socket, battery
- **Memory:** microSD SD & SDHC (32Gb Max)
- **Environment:** IP20. 0°C – 50°C
- **Buttons:** 10 buttons for direct access 2 buttons to change scene + 1 button to change zone
- **Dimensions:** 160x90x45mm 268

- **OS Requirements:** Mac OS X 10.13 onwards Windows 8.1 64bit onwards
- **Standards:** EC, EMC, ROHS


Live use with a computer


- When connected to software the controller will output DMX directly from the software and will display LI on the screen.



Stand Alone or live use with a smartphone/tablet

- The controller will start in Stand Alone Mode when powered on. It will look for a project stored on the microSD card and then begin playing scenes. A01 indicates Scene 1 from zone A is playin








Setting up the Controller

Programming the Controller


The controller can be programmed from a PC, Mac, iOS (Apple) or Android device using the software listed below. Refer to the corresponding software manual for more information. Firmware and settings can be updated using Hardware Manager (installed with PC/Mac programming software) or with Hardware Tools (Android / iOS, compatibility). Refer to the SUT page in HardwareManager for a full list of software licences.

Windows / Mac Programming Software

- 
 ESA Pro 2 Software (Windows/Mac) – Multi-zone nicolaudie.com/esapro2.htm.
- 
 ESA2 Software (Windows/Mac) – Single Zone nicolaudie.com/esa2.htm.
- 
 Hardware Manager (Windows/Mac) – Firmware, clock <https://eu-tools-n-g.co/Release/HardwareManager.dmg>. <https://eu-tools-n-g.co/Release/HardwareManagerBeta.exe>.

Apple iOS and Android Apps

Arcolis Designer

- 
 Multi-zone programming from a tablet or smartphone

Hardware Tools



Update firmware, set clock, settings, etc.


Basic Operation

Your controller comes pre-programmed with a demo RGB show with 8 scenes (A01-08). This demo show can be rewritten at any time using HardwareManager. In most cases you will want to create your own show for your specific fixtures using our software.

- Download ESA Pro 2 or ESA2 from nicolaudie.com/download.htm. or Arcolis Designer from the Android Playstore or iOS App Store.
- Connect the controller with USB or ETHERNET to a network.
- Arcolis can connect with Wifi or with USB (Android only)
- Connect your lights to the DMX1 or DMX2 connectors
- Use app to program your controller (refer to manual / tutorials)
- Use the controller in stand alone mode with USB power
- Trigger the scenes with the remote apps, dry contacts, internal clock/calendar, UDP messages or the 10 buttons keypad

Dry Contact Port Triggering

Port triggering is possible using the 20-Pin (2×10) Male IDC Socket on the right hand side of the controller. You will need to remove a plastic protective cover to access it.



To activate a port, a brief contact of at least 1/25 second must be established between the ports (1...16) and the ground (GND) using the external HE20 connector. A suitable IDC cable can be found by searching for 'IDC 20 Pins Connector Flat Ribbon Cable Female Connector 2.54mm Pitch'. If making your own cable you will need '20 Way Flat Ribbon Cable, Pitch 1.27mm'. To connect cable to a screw terminal breakout board, search for 'IDC20 2×10 Pins Male Header Breakout Board'.

Mount Controller

- A metal bracket for mounting against a wall is available upon request.

Remote Control Over Local Network

Free apps are provided to allow remote control over a local area network when running in stand alone mode. Connect the controller to a Wifi network. The apps will find all compatible devices on the network using multicast / broadcast messages. Use Hardware Manager to configure the network settings for your controller.

Arcolis Remote – A simple interface provides the easiest way to control your device (iOS / Android)

Arcolis Remote Pro Create a customized remote controller with buttons, faders and color control (iOS / Android)

UDP Network Triggering Refer to User Manuals > Siudi11 Dina1 & 2 Remote Control document at nicolaudie.com/download.htm.

SUT Licence Upgrades

- Extra hardware features (e.g. extra DMX512 universes) and software compatibility can be unlocked at : store.nicolaudie.com/my_interfaces.
- Click + Register a new Interface and download the SUT driver software. Follow the on-screen prompts.
- Once registered, select your interface on the left. You can buy new features and software compatibility, change the device name or transfer the device to a new owner. 30 day software trials available.
- Any licence changes will be automatically synchronised the next time you connect your interface to almost any Nicolaudie Group software while connected to the internet.
- **Note:** The Artnet upgrade allows live output from software only (Daslight, Sunlite etc). The SIUDI-11A cannot output Artnet when operating in Standalone mode.

Display Messages

- 000 022 at startup -> means serial number 1 000 022
- A01 to E99 -> Stand Alone OK (Zone A-E + Scene No. displayed)
- USB/Eth PC -> connected to a Windows software (live mode)
- USB/Eth nAC -> connected to a MacOS software (live mode)
- USB/Eth LI -> connected to a Linux software (live mode)
- USB/Eth APP -> connected to another OS app (live mode)
- See Trouble Shooting section for other messages.

Troubleshooting

The controller is not detected by the computer

- Be sure that the latest software version is installed from our website
- Connect by USB and open the Hardware Manager (found in the software directory). If it is detected here, try to update the firmware. If it is not detected, try the method below.
- Bootloader Mode Sometimes the firmware update may fail and the device may not be recognised by the computer. Starting the controller in 'Bootloader' mode forces to the controller to start at a lower level and in some cases allows the controller to be detected and the firmware to be written. To force a firmware update in Bootloader Mode :

1. Power off your interface
2. Start HardwareManager on your computer
3. Activate Bootloader by holding down the 3 buttons under the screen (A-B-C, < , >) while connecting power. If successful, your interface will appear in HardwareManager with the suffix _BL.

4. Update your firmware

'8.8.8.' is flashing on the display

The controller is in bootloader mode. This is a special 'startup mode' which is run before the main firmware loads. Try re-writing the firmware with the latest hardware manager available from the downloads section of our website.

The lights are not responding

- Check the DMX +, – and GND are connected correctly
- Check that the driver or lighting fixture is in DMX mode
- Be sure that the DMX address has been set correctly
- Check there are no more than 32 devices in the chain
- Check that the red DMX LED is flickering. There's one by each XLR
- Connect with the computer and open Hardware Manager (found in the software directory). Open the DMX Input/Output tab and move the faders. If your fixtures respond here, it is possibly a problem with the show file

What do the LED's on the controller signify?

- Yellow: The device is receiving power
- Red: Flickering indicates DMX activity
- Green: USB activity

Displayed error messages

You may see one of the following messages on the LCD display

no LIC: no licences found on device. See information below this table.

- **no SD**: no SD card detected. insert an SD card.
- **no Sho**: no show files detected on the SD card. write a show using our software.
- **bAd Sho**: invalid show found on SD card. write a new show using our software
- **err drl drive fail**: – make sure the microSD is formatted to FAT16 or FAT32 and 32Gb or less in capacity – try replacing microSD, if faulty
- **err CHA**: too many channels in the show files. Reduce number of channels in your show or purchase channel upgrade if an extra DMX port is available. max 4 universes, 2048 channels
- **err PIN**: try rewriting your show Contact support with error number
- **err XXX**: error code number XXX. send support code.
- **HDF XXX**: hardware fault number XXX. send support code


no LIC

- This message means no licences found on device. The devices should come pre-registered with licences installed. If you see this message try :
 - connecting your device to a computer with an internet connection








- open latest version of HardwareManager from our website
- select the controller on the left
- If this does not solve it, try completely disabling your firewall or create a rule which allows our software to communicate through your firewall, then repeat the steps above. If this does not solve it, contact support with your device serial number. The serial number is displayed when it first powers on; see display messages.

© Nicolaudie Group 1989-2022. All rights reserved. We reserve the right without notice to amend the technical information and specifications.

Documents / Resources

	<p>NICOLAUDIE ARCHITECTURAL SLESA-U11 Smart DMX Interface [pdf] Instruction Manual SLESA-U11 Smart DMX Interface, SLESA-U11, Smart DMX Interface, DMX Interface, Interface</p>
---	--

References

-  [Nicolaudie lighting control software, USB DMX 512 controller : download DMX software](#)
-  [Easy Stand Alone 2 DMX lighting software for Mac and PC](#)
-  [ESA Pro 2 lighting control software for DMX interfaces](#)
-  [Nicolaudie Store - Sign in](#)
-  [SLESA-U11: Programmable DMX lighting controller with a backlit keyboard](#)
-  eu-tools.n-g.co/Release/HardwareManager.dmg
-  eu-tools.n-g.co/Release/HardwareManagerBeta.exe