Optoelectronics 2A9WC-BT002-Remote Control logo





# **Optoelectronics 2A9WC-BT002 Remote Control Instructions**

Home » Optoelectronics » Optoelectronics 2A9WC-BT002 Remote Control Instructions

#### **Contents**

- 1 Optoelectronics 2A9WC-BT002 Remote Control
- 2 Specifications
- **3 FCC STATEMENT**
- 4 FAOs
- 5 Documents / Resources
  - **5.1 References**

# **Optoelectronics**

**Optoelectronics 2A9WC-BT002 Remote Control** 



#### **Product Information**

# **Specifications**

• Model: Model2A9WC-BT002

• Remote Control Function: Fan operation

• Battery Type: 2 AAA batteries (not included)

• Wireless Transmission Frequency: 433.92MHz

• Dimensions:

Length: 20mmWidth: 59mmHeight: 59mm

## **Product Usage Instructions**

## **Product Description**

- 1. To operate the fan, install 2 AAA batteries in the handheld remote control transmitter
- 2. If not used for a long time, remove the battery to prevent damage to the transmitter. Store the remote control away from high temperatures and humidity.



	Fan off
	Light on/off (light memory after 10 seconds) CCT switch (fast click to switch)
1-6	Fan speed
OFF	Fan on/off
$\approx$	Natural wind
	Forward or reverse rotation
命	Safe mode(anti-theft mode)
<b>⊘</b>	Delayed off Fan and light will turn off after 5 minutes.
□X	Remote controller mute
1H 4H 8H	Fan stop after 1 hour Fan stop after 4 hours Fan stop after 8 hours

# **Remote Controller Pairing**

The remote controller can be used to control multiple ceilng fans.

1. For the ceiling fans you want to pair, turn the main power switch off for at least 1 minute.

2. Turn on the main power switch, then press and hold the



3. Wait for the fan receiver to make a beeping sound, then release the button.

If the pairing process is unsuccessful, please repeat the above steps. The wireless transmission frequency is: 433.92MHz

#### **Installing Batteries**

- 1. Open the battery compartment on the back of the handheld remote control transmitter.
- 2. Insert 2 AAA batteries into the compartment, ensuring correct polarity.
- 3. Close the battery compartment securely.

#### Operating the Fan

- 1. Point the remote control toward the fan.
- 2. Press the desired fan function buttons (e.g., speed settings, timer) to operate the fan.

#### **Maintenance**

If the remote control will not be used for an extended period:

- 1. Remove the batteries from the transmitter to prevent damage.
- 2. Store the remote control in a cool, dry place away from high temperatures and humidity.

#### **FCC STATEMENT**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1. this device may not cause harmful interference, and
- 2. This device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. Suppose this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on. In that case, the user is encouraged to try to correct the interference by one or more of the following measures:

- 1. Reorient or relocate the receiving antenna.
- 2. Increase the separation between the equipment and receiver.
- 3. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- 4. Consult the dealer or an experienced radio/TV technician for help.ct.

The device has been evaluated to meet the general RF exposure requirement.

#### **FAQs**

# Q: What should I do if the remote control is not working?

Check the battery polarity and replace the batteries if necessary. Ensure there are no obstructions between the remote control and the fan.

# Q: How can I change the wireless transmission frequency?

The wireless transmission frequency is preset and cannot be changed manually.

#### **Documents / Resources**



Optoelectronics 2A9WC-BT002 Remote Control [pdf] Instructions 2A9WC-BT002, 2A9WC-BT002 Remote Control, Remote Control

#### References

• User Manual

#### Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.