



orolia FemtoStepper 100fs Resolution Phase Stepper User Manual

[Home](#) » [orolia](#) » orolia FemtoStepper 100fs Resolution Phase Stepper User Manual 

Contents

- 1 cecotec EssentialVita Hyden 600 Electric Lever Juicer
- 2 FemtoStepper System Description
- 3 FemtoStepper System Description
- 4 FemtoStepper Installation
- 5 System Control
- 6 RS232 Commands
- 7 Mechanical
- 8 Documents / Resources
 - 8.1 References
- 9 Related Posts



cecotec EssentialVita Hyden 600 Electric Lever Juicer



FemtoStepper System Description

The FemtoStepper provides a highly stable MHz signal, available on four outputs, that is adjustable in phase and frequency with an extremely high resolution. In addition to the MHz outputs, the micro-stepper provides a one pulse per second (PPS) signal available on four outputs generated from the MHz output. The FemtoStepper provides a MHz signal that is derived from a high performance, ultra low phase noise crystal oscillator which is

phase locked to an external MHz reference input. It allows for adjusting the outputs in phase and frequency without disturbing the reference signal source, and precautions are taken to minimize added noise. The design is based on a double heterodyne architecture where a first structure is used for positive phase/frequency adjustment and the second structure for negative adjustment. The device is controlled remotely through an RS-232 serial link, which provides a prompt with a defined list of commands. All commands are parsed for correct syntax and operational range prior to execution. Commands that contain errors are rejected.

FemtoStepper Installation

Safety

Ensure proper safety precautions are taken during installation and use of the FemtoStepper system.

Environmental Responsibility

Follow environmental regulations and guidelines for the disposal of the FemtoStepper system.

Unpacking

When unpacking the FemtoStepper system, carefully remove all components and verify that everything is included as per the product documentation.

Electrical & Indicator Interfaces

Refer to the product documentation for detailed information on the electrical and indicator interfaces of the FemtoStepper system.

Connections

Make the necessary connections as specified in the product documentation to ensure proper functioning of the FemtoStepper system.

Recommendations

Follow the recommendations provided in the product documentation for optimal performance and longevity of the FemtoStepper system.

System Power-Up|

Refer to the product documentation for instructions on how to power up the FemtoStepper system.

System Control

Control the FemtoStepper system remotely using RS-232 commands. Refer to section 4 of the user manual for a list of available commands and their usage.

RS232 Commands

Command	Description
Frequency Adjustment	Adjust the frequency offset of the output MHz OCXO
Phase Adjustment	Adjust the output phase with picosecond resolution
Microprocessor control and PPS (pulse per second) facility	Control the FemtoStepper functions and manage the PPS signal

Mechanical

Refer to the product documentation for detailed mechanical information about the FemtoStepper system.

FemtoStepper System Description

The FemtoStepper provides a highly stable ~MHz, available on four outputs, that is adjustable in phase and frequency with an extremely high resolution. In addition to the ~MHz outputs, the micro-stepper provides a one pulse per second (~PPS) available on four outputs generated from the ~MHz output.

The FemtoStepper provides a ~MHz signal that is derived from a high performance, ultra low phase noise crystal oscillator which is phase locked to an external ~MHz reference input. It allows to adjust the outputs in phase and frequency without disturbing the reference signal source and precautions are taken in order to minimize the added noise.

The design is based on a double heterodyne architecture where a first structure is used for positive phase / frequency adjustment and the second structure for negative adjustment.

The device is controlled remotely through an RS-485 serial link. which provides a prompt with a defined list of commands. All commands are parsed for correct syntax and operational range prior to execution. Commands that contain errors are rejected.




Figure 1- Application Diagram




Figure 2- Block Diagram

Frequency Adjustment

The frequency offset is applied to the output ~MHz OCXO through the double heterodyne structure in order to increase the resolution.

$$F_{out} = F_{in} + \frac{\Delta f}{G}$$

Where :

G : Heterodyne Gain of ~.

Δf is managed by the microprocessor.

The relationship between the output frequency and the input frequency is the following : Where :

N : Frequency offset by ~ steps.

The frequency offset is always the absolute value from the ~MHz input.

The output range is limited nearly x ~)

$$F_{out} = \frac{F_{in}}{1 - \frac{N}{10^{17}}}$$

Phase Adjustment

The output phase is adjustable with ~ 1 picosecond resolution over a maximum range of in order to cover an entire period of the ~ 10 MHz output signal. The phase adjustment is performed under microprocessor control.

Microprocessor control and PPS (pulse per second) facility

The microprocessor is controlling the functions. It is clocked by the ~ 10 MHz_{out}. A division by $\sim 10^6$ is made, providing the PPS_{out}. The PPS_{out} can be aligned to a reference PPS_{ref} within ~ 100 ns when the command AL \sim is issued. .




Figure 3 – The microprocessor and its surrounding




Figure 4 – The PPS_{out} can be aligned to the PPS_{ref}.

FemtoStepper Installation

Safety

- Use proper ESD precautions
- Ensure that all cables are properly connected

Handling the product in a reasonably foreseeable conditions do not cause any risk for human health, exposure to the SVHC (substances of very high concern) would require grinding the component up.

Environmental Responsibility

- The equipment contains materials, which can be either re-used or recycled.
- Do not deposit the equipment as unsorted municipal waste. Leave it at an authorized local WEEE collection point or return to Orolia Switzerland SA to ensure proper disposal.
- To return the appliance :
 - Download and fill up the RMA form (from www.orolia.com) and send it to clocksupport@orolia.com
 - Once the RMA is approved, we will contact you with shipment process details.

Unpacking

Unpack and carefully inspect the unit. Check for physical damage. If physical damage is observed, then immediately contact SpectraTime.

Unit Supply:

- FemtoStepper Rack
- Cable SUB-D pins male/female
- Euro power cable
- Brackets for rack mount (only with standard version)
- Connector for Backup DL power supply

Electrical & Indicator Interfaces





Fig. 3 Interfaces

N°	In/ Out	Designation	Type		Pin	Designation		
J1	In	230VAC primary power	Schurter KM00.11OS.11	J2	1	GND VDC backup power		
J2	In	+24VDC backup power	Jaeger S306004006	J2	2	+24 VDC backup power		
J3	In/ Out	COM Interface	Sub-D-9P-FEM	J2	3	+24 VDC backup power		
J4	–	Ground connection	Screw M4	J2	4	GND VDC backup power		
JS	In	10 MHz reference signal	SMA	<div>Table 2: Backup Power Connector</div> <div></div>				
J6	In	PPS reference signal	SMA					
J7-J10	Out	4x PPS output	SMA					
J11-J14	Out	4x 10MHz output	SMA					
S1	–	On/Off switch						
F1	–	Primary power supply fuse – T 3,1SA						
F2	–	Backup power supply fuse – T 1,6A						
L1	–	Primary power indicator	Green					
L2	–	Backup power indicator	Green					
L3	–	Alarm indicator	Red					
L4	–	Running indicator	Green					
LS	–	Initialization indicator	Yellow					

Connections

- Connect the 10MHz input reference to the FemtoStepper unit (J).
- Connect, if PPS functionality is desired, the PPSref signal (J').
- Connect the male SUB-D- to the unit (J') and female SUB-D- to the computer.
- Connect the primary power cable (230VAC) to the unit (J).
- Connect the backup power cable (+24VDC) to the unit (J).
- Optionally, connect the device to ground (J).
- Switch on the unit (S).

Recommendations

- Warm-up FemtoStepper several hours before to start any applications.
- To reduce warm-up time, keep FemtoStepper powered-up at all times even when an input reference signal is not available.
- To ensure a continuous operation, connect a uninterruptible backup $\geq 5V$ power source.
- Avoid locations of the unit with variable air flow and temperature changes.
- Avoid to place FemtoStepper close to vibration environment and high magnetic fields changes.

System Power-Up

- Switch on the unit (S⁺).
- If the primary power is connected, L⁺ indicator is green.
- If the backup power is connected, L_b indicator is green.
- The alarm indicator (L⁻) is red while warming-up.
- During the first five seconds, the microprocessor is performing an initialization. At the end of the initialization sequence, L switches on.
- After approximately fifteen minutes, the alarm (L⁻) indicator have to switch off. If still red, check if an input reference is connected (J).
- When ready to operate the running indicator (L) becomes green.
- When a frequency offset is applied, the running indicator (L) is blinking.

System Control

The device is controlled remotely through an RS-485 serial link. which provides a prompt with a defined list of commands. All commands are parsed for correct syntax and operational range prior to execution. Commands that contain errors are rejected.

The RS-485 protocol is :

bits/s

data bits

No parity

stop bit

No handshake

FemtoStepper accepts the following basic ASCII commands: Data is in decimal ASCII code.

Command name	Syntax command	Data field (if any)	Response syntax	Response data (if any)
Identification	ID CR LF	–	TNTMPS-aaa/rr/s.ss CR LF	aaa: OO1 rr: revision number s.s s: software version
Serial number	SN CR LF	–	xxxxxx CR LF	xxxxxx : 6 digits serial nbr

Status	ST CR LF	–	yyxx CR LF	yy : always OO (for future use) xx : HEX ASCII Bit signification : Bit 7 :- Bit 6 :backup power active Bit 5 :primary power active Bit 4 :frequency drift not O Bit 3 :frequency offset not O Bit 2 :stepping activity Bit 1 : OOL – Bit 0 : OOL +
Single Phase Step	PSs CR LF	s= + : Positive Step s= – : Negative Step	s CR LF	s: signe s= + : Positive Step s= – : Negative Step
Packet Phase Step	PSsdddddd CR LF	s=+ : Positive Packet Step s=- : Negative Packet Step dddddd: number	sdddddd CR LF	s:signe s=+ : Positive Packet Step s=- : Negative Packet Step ddddd: value
Actual phase offset	PH CR LF		sdddddd CR LF	s:signe s=+ : Positive Packet Step s=- : Negative Packet Step ddddd: value From 000000 To 000000
Frequency offset	FAsdddddd CR LF	s= + : Positive offset s= – : Negative offset dddd: number	sdddddd CR LF	s= + : Positive offset s= – : Negative offset dddd: value
Actual frequency offset	FR CR LF		sdddddd CR LF	s= + : Positive offset s= – : Negative offset dddd: value
Frequency drift	FDsdddd CR LF	s= + : Positive drift s= – : Negative drift	sdddd CR LF	s= + : Positive drift s= – : Negative drift dddd : value in 1E-17/day frequency drift
Align PPSO UT to PPSREF	ALd CR LF	d= 1 : align d= ? : alignment status	d CR LF	d= 0: ready for alignment d= 1: alignment in progress d= 2 : no PPSREF

Set PPSOUT delay (rounded to 200 ns)	DEdddddddd CR LF	dddddddd=delay in ns. Max 999999800 ???????? :interrogation	dddddddd=delay in ns. Max 999999800 ???????? :interrogation	dddddddd=delay in ns. Min 000000000 Max 999999800
Send information every second	BTx CR LF	x= 0 : Stop to send x= 3 : PPSRef position x = S : Status	x= 3 : aaaaaaaaaa sbbb CR LF x= S : yyxx CR LF	aaaaaaaa= PPSOUT vs PPSREF delay in ns . sbbb= fine phase comparator value in approx. ns yyxx= see ST command

RS232 Commands

ID[] : Identification

Answer : TNTMPS-aaa/rr/s.ss

aaa : 001

rr : revision number

s.ss : software version

Example : ID answers TNTMPS-001/01/1.00

Serial number

SN[] : Serial number

Answer : xxxxxx xxxxxx : 6 digits serial number

Example : SN answers 000015

Status

ST[] : Status

Answer : yyxx yy : always 00 (reserved for future use) xx : HEX ASCII status : bit 7 :– bit 6 : backup power active
bit 5 : primary power active bit 4 : frequency drift not 0 bit 3 : frequency of set not 0 bit 2 : stepping activity bit 1 :
OOL negative loop bit 0 : OOL positive loop

Example : ST answers 0068 (backup and primary power active, frequency of set applied, no frequency drift, system locked)

Note : BT5 send status once per second in the same format.

Single Phase Step

PSs[] : Single phase step

s = +: 1 positive phase step of 10-13 second

– : 1 negative phase step of 10-13 second

Answer : s s : sign of the single phase step

Example : PS+ answers +

Note : Phase adjustment are not absolute value.

Packet phase step

PSsdddd[] : Packet phase step

s = +: positive phase adjustment

– : negative phase adjustment

dddddd : phase adjustment in 10-13 second

000000 to 500000

000001 : minimum phase adjustment ($\pm 1 \times 10^{-13}$ s)

500000 : maximum phase adjustment ($\pm 5 \times 10^{-9}$ s)

000000 : no phase adjustment

Answer : sdddddd sdddddd : phase adjustment value

Example : PS+000100 answers +000100 (a positive phase adjustment of 10-11 second is asked)

Note : Phase adjustment are instantaneous phase changes and are cumulative with previous phase changes.

Actual Phase Adjustment PH[]

Actual phase adjustment Answer : sdddddd

s = +: positive phase adjustment

– : Negative phase adjustment

dddddd : phase adjustment value in 10-13 second step

Example : PH answers -000020 (an total actual negative phase adjustment of 2×10^{-12} second has been applied)

Note : The actual phase is the accumulated phase changes from the starting of the system. A frequency of set different from 0 reset the phase adjustment to 0.

Example : At To the command PS+000002 has been sent, At T1 the command PS-000007 has been sent, At T2 the command PS+000009 has been sent, At T3 the command PH answers +000004 which corresponds to the total accumulated phase adjustment applied until T3 ($2-7+9=4 \times 10^{-13}$ second)

Frequency Off set

FAssddddddd[] : Frequency of set

s = +: positive frequency of set

– : Negative frequency of set

ddddddd : frequency of set in 10-17 step

00000000 to 10000000

00000001 : minimum frequency of set ($\pm 1 \times 10^{-17}$)

99999999 : maximum frequency of set ($\pm 9.9999999 \times 10^{-10}$)

00000000 : no frequency of set

Answer : sddddddd sddddddd : frequency of set value

Example : FA+00010000 answers +00010000 (a positive frequency of set of 10-13 relative to input reference frequency is asked)

Note : Frequency of set are absolute value from input reference frequency. A new frequency of set overwrite the previous one.

Actual Frequency Of set

FR[] : Actual frequency of set

Answer : sddddddd

s = +: positive frequency of set

– : negative frequency of set

ddddddd : frequency of set in 10-17 step

Example : FR answers -00100000 (a negative frequency of set of 10-12 relative to input reference frequency is applied)

Note : Frequency of set are absolute value from input reference frequency. A new frequency of set overwrite the previous one.

Example : At To the command FA+00600000 has been sent, At T1 the command FA-00020000 has been sent, At T2 the command FR answers -00020000 which is the actual frequency of set (it corresponds to the last frequency of set command applied before T2.)

Frequency Drift

FDsddddCR[LF] : Change the frequency during time

s : positive frequency drift

– : negative frequency drift

dddddd : frequency drift in E/dayno drift

?????? interrogation

Answer: sdddddd : just asked drift or drift actually active

Example: FD??????CR answers . The frequency is increased seconds and this value can be read back with the command FR.

Pulse Per Second Alignment

ALdCR[LF] : PPSOUT alignment to PPSREF

d : align

? : interrogation

Answer : dCRLF

ready for alignment

alignment in progress

no PPSREF

Example : answers

Notes: While the command is in progress, an internal PPSLOCAL is aligned to PPSREF. This can take up to seconds.

The alignment is done within ns.

After an alignment DE???????? answers

This command has no influence on the MHz output.

PPSOUT Delay

DEdddddddddCR[LF] : Set a PPSOUT delay

ddddddddd : delay in ns

no delay

minimum delay

maximum delay

????????? : interrogation

Answer : ddddddddCRLF

ddddddddd : just asked delay

Example : DE?????????CR answers CRLF

Notes : After power on / Reset, the PPSOUT position is random.

After the command AL, the PPSOUT is aligned to PPSREF and the delay is settled to .

This command has no influence on the MHz output.

Information Every Second

BTxCR[LF] : send information once per second on the serial port

x : stop to send

Answer : none

x : PPSOUT vs PPSREF position

Answer : aaaaaaaaa sbbbCRLF once per second

aaaaaaaaa : raw PPSOUT vs PPSREF position in ns, rounded to ns steps

PPSOUT aligned to PPSREF

minimum value

maximum value

????????? : no PPSREF

sbbb : s : sign +/- ; bbb : analog ne PPS comparator value in approximately ns. PPSLOCAL vs PPSREF.

PPSLOCAL and PPSREF are perfectly aligned.

lowest value

highest value


Remark : the command ALCRLF must be sent first to bring the PPSLOCAL in the PPS phase comparator working range.

x : Status

Answer : yyxxCRLF once per second

See Status command for details

Mechanical



29 November 2022. Patented FemtoStepper
 Specifications subject to change or improvement without notice
 © 2022 Orolia

www.orolia.com
sales@orolia.com

Documents / Resources

	<p>orolia FemtoStepper 100fs Resolution Phase Stepper [pdf] User Manual FemtoStepper 100fs Resolution Phase Stepper, 100fs Resolution Phase Stepper, Resolution Phase Stepper, Phase Stepper, Stepper</p>
--	--

References

- [Safran | Navigation and Timing - The World Leader in Resilient PNT](#)