



PATLITE SF08 Multi-Function Beacons Instruction Manual

[Home](#) » [PATLITE](#) » PATLITE SF08 Multi-Function Beacons Instruction Manual 

Contents

- 1 PATLITE SF08 Multi-Function Beacon
- 2 Notice to Customer
- 3 Safety Precautions
- 4 Model Number Configuration
- 5 Part Names
- 6 Accessory List
- 7 Installation
- 8 Installation Dimensions
 - 8.1 Wiring
- 9 Removal
- 10 Specifications
- 11 Conformity Standards
- 12 Documents / Resources
 - 12.1 References
- 13 Related Posts

PATLITE®

PATLITE SF08 Multi-Function Beacon



Notice to Customer

- Request the installation and wiring be performed by a professional contractor if construction work is involved.
- Prior to installation, read this manual thoroughly before using this product to ensure correct use.
- In addition, please store this manual for future reference when performing maintenance, repairs or inspections.
- For options and repair parts, please visit our website (<https://www.patlite.com>).
- If there are any questions concerning this product, refer to the contact information at the end of this document and contact your nearest PATLITE Sales Representative.

Safety Precautions


- To prevent from short-circuits or damage, observe the following:
- Be sure the power is disconnected before replacement or repair, including the replacement of the fuse.
- Use this product in a properly maintained condition. (Replace or repair if the globe, case, etc. are damaged.)
- If installing this product requires construction work, ask a specialist in order to avoid fire, or personal injury.
- When this product is used for security purposes, it should be inspected daily. In case a malfunction should occur, it is recommended that you use this product together with other security products.
- After installation, do not use this product to climb up onto the equipment with. Failure to comply will result in product damage and/or falling off the machinery.

Caution


- Be sure to put a fuse in the wiring circuit between the power source and equipment for protection. If a fuse is not added, it may result in product and/or equipment failure.
- Be sure to prevent electrostatic damage due to discharge when working with this product for wiring, exchanging units, setting up parameters, etc. by discharging static electricity on your body, etc.
- Do not disassemble or detach during operation.

Model Number Configuration

SF • SL Models




SK Model




Part Names

Cable type



Terminal block type



Accessory List

| Model | Name | QTY |
|-----------------------------|------------------------------------|-----|
| SF00-00KT/SL00-00KT | Mounting Bracket, Waterproof Sheet | 1 |
| SF08-00J/SL08-00J/SKS Model | M4 Nut, Plain Washer | 3 |
| SF10-00J/SL10-00J/SKH Model | M5 Nut, Plain Washer | 3 |
| SL15-00J/SKP Model | M8 Nut, Plain Washer | 3 |


Installation

Notice

- Ensure that the product is installed in an environment that meets the following conditions:
 - Where excessive vibration is not present.
 - On a sturdy surface.
 - On a level surface.
- When it is necessary to waterproof the backside of the installation surface;
- Provide a sealant coating around the nuts of the backside of the installation

- surface.
- Waterproof the cable mounting area.
- Ensure that the product is mounted upright when installed outdoors.
- Ensure that the speaker is facing forward when installing the buzzer models.
- Depending on your operating environment, additional waterproofing may be required on the Terminal Block openings for SKH-M□T models.

Screw Mounting Type



Insert the bolts of the beacon into the holes of the mounting surface. Use the nuts and washer (accessory) to secure in place.

Maximum Board Thickness of Mounting Surface

| Model | Maximum Board Thickness |
|---------------|-------------------------|
| SF08/SL08/SKS | 9 mm |
| SF10/SL10/SKH | 8 mm |
| SL15/SKP | 10 mm |


Installation Dimensions

Refer to the “Installation Manual”.

point Hole Type Mounting (SF • SL Models)/point Hole Type Mounting (SL15 Model Only)

2-point Hole Type Mounting

3-point Hole Type Mounting



1. Use the screws or bolts, nuts. to secure the mounting bracket(accessory) to the mounting surface. (Installation screws and nuts are not included with this product. Binding head screws or pan head screws are recommended.)
2. Check that the O-ring is not twisted.

| Model | Screw Hole Depth of Mounting Bracket | Nominal Diameter |
|-----------|--------------------------------------|------------------|
| SF08/SL08 | 4.4 mm | M4 |
| SF10/SL10 | 5.7 mm | M5 |
| SL15 | 4.8 mm | M8 |

3. Align the main unit of the product with the positioning Indicator and turn it clockwise to lock it.

Installation Example

Installation Dimensions

Refer to the "Installation Manual".

Wiring

1. Make sure the power is OFF before wiring. A short circuit may damage internal circuits.
2. Ensure the proper working voltage is used. Any mistake in wiring may result in damage.
3. Do not pull the wire, or stuff it inside of this case.
4. Be sure the wiring is done properly. Any mistake in wiring may result in damage. In the M2 model, do not perform blinking control by turning the power supply ON / OFF. Any mistake in wiring may result in damage.
5. Do not apply a voltage to the common wire. (M1 type)
6. Do not apply a voltage to any wire other than the power supply wire. (M2 type) Failure to comply will result in product damage.(except buzzer wire of SKH-M1) Do not expose the wiring from the device. If tension is applied to the wiring, the wiring may be disconnected, resulting in a short circuit or an electric shock.
7. Use either a Contact Switch or Contact Relay for External Contact that power supply wire of SF, SL, SK Aodels and buzzer wire of SK Model. Failure comply may result in fire, product malfunction.

Notice

1. The protection rating does not include the Cabtyre Cable ends.
2. If the ends of it are in contact with water or exposed to dew or condensation, refer to the indications below to dress the wire ends for water resistance.
3. – Connect it ends in a location that will not expose the ends to water.
– Use Fillers, such as silicon, etc., to seal the ends.

[External contact capacity of power supply wire]

| | M1 | M2 |
|-----------------------|------------|------------|
| Current Capacity (Is) | 3A or more | 1A or more |

| | M1 | M2 |
|------------------------|----------------|----------------|
| Current Capacity (Is) | 10 mA or more | 10 mA or more |
| Withstand Voltage (Vs) | 20 V or more | 20 V or more |
| Leakage Current* (IL) | 0.1 mA or less | 0.1 mA or less |

| | M1 | M2 |
|------------------------|---------------|---------------|
| Current Capacity (Is) | 0.5 A or more | 0.5 A or more |
| Withstand Voltage (Vs) | 35 V or more | 20 V or more |


Wire Type / Wire Gauge

- Wire Type: UL2464
- Wire Gauge: M1 AWG22
- Power Supply Wire AWG18


- Excluding Power Supply Wire AWG24

Wiring Example


Refer to the “Installation Manual”.



Removal



Pull out the lead wire.



Terminal Block Wiring

Specifications

| Model | Rated Voltage |
|-------------------------|---------------------------|
| SF08-M1/SF10-M1 | 12 – 24 V DC (Non-polar) |
| SF08-M2/SF10-M2 | 100 – 240 V AC (50/60 Hz) |
| SL08-M1/SL10-M1/SL15-M1 | 12 – 24 V DC (Non-polar) |
| SL08-M2/SL10-M2/SL15-M2 | 100 – 240 V AC (50/60 Hz) |
| SKS-M1J/SKH-M1J/SKP-M1J | 12 – 24 V DC (Non-polar) |
| SKS-M2J/SKH-M2J/SKP-M2J | 100 – 240 V AC (50/60 Hz) |
| SKH-M1T | 12 – 24 V DC (Non-polar) |
| SKH-M2T | 100 – 240 V AC (50/60 Hz) |

Conformity Standards

- EMC Directive (EN61000-6-4, EN61000-6-2)
- RoHS Directive (EN50581)
- UL508, CSA-C22.2 No.14 (File No. E215660)
- FCC Part 15 Subpart B Class A

This product conforms to EN standards and shows the CE Marking.


This product has been tested and found to comply with the limits for a Class A device, pursuant to EMC DIRECTIVE. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This product must not be used in residential areas. This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. The equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

(Note) Dimensions and specifications may change without notice due to PATLITE and the PATLITE logo is a trademark or registered trademark of the PATLITE Corporation of Japan and each country.

(Importer for EU)

PATLITE Europe GmbH Am Soeldnermoos 8, D-85399 Hallbergmoos, Germany

Documents / Resources

| | |
|---|---|
|  | PATLITE SF08 Multi-Function Beacons [pdf] Instruction Manual SF08, Multi-Function Beacons, SF08 Multi-Function Beacons, SF10, SL08, SL10, SL15, Flashing Beacons |
|---|---|

References

-  [PATLITE - New Frontiers in Safety, Security and Comfort.](#)

Manuals+.