



# PCE Instruments PCE-AM 45 Anemometer User Manual

[Home](#) » [PCE Instruments](#) » PCE Instruments PCE-AM 45 Anemometer User Manual 

## Contents

- 1 [PCE Instruments PCE-AM 45 Anemometer](#)
- 2 [Safety notes](#)
- 3 [Specifications](#)
- 4 [Delivery scope](#)
- 5 [Device description](#)
- 6 [Switching the meter on and off](#)
- 7 [Making a measurement](#)
- 8 [Volume flow measurement](#)
  - 8.1 [The lowest, highest, and average measured value](#)
- 9 [Software](#)
- 10 [Contact](#)
- 11 [PCE Instruments' contact information](#)
- 12 [Documents / Resources](#)
  - 12.1 [References](#)



**PCE Instruments PCE-AM 45 Anemometer**



## Safety notes

- Please read this manual carefully and completely before you use the device for the first time. The device may only be used by qualified personnel and repaired by PCE Instruments personnel. Damage or injuries caused by non-observance of the manual are excluded from our liability and not covered by our warranty.
- The device must only be used as described in this instruction manual. If used otherwise, this can cause dangerous situations for the user and damage to the meter.
- The instrument may only be used if the environmental conditions (temperature, relative humidity, ...) are within the ranges stated in the technical specifications. Do not expose the device to extreme temperatures, direct sunlight, extreme humidity or moisture.
- Do not expose the device to shocks or strong vibrations.
- The case should only be opened by qualified PCE Instruments personnel.
- Never use the instrument when your hands are wet.
- You must not make any technical changes to the device.
- The appliance should only be cleaned with a damp cloth. Use only pH-neutral cleaner, no abrasives or solvents.
- The device must only be used with accessories from PCE Instruments or equivalent.
- Before each use, inspect the case for visible damage. If any damage is visible, do not use the device.
- Do not use the instrument in explosive atmospheres.
- The measurement range as stated in the specifications must not be exceeded under any circumstances.

- Non-observance of the safety notes can cause damage to the device and injuries to the user. We do not assume liability for printing errors or any other mistakes in this manual.
- We expressly point to our general guarantee terms which can be found in our general terms of business.
- If you have any questions please contact PCE Instruments. The contact details can be found at the end of this manual.

## Specifications

Unit	Measurement range	Resolution	Accuracy
<b>Wind speed</b>			
m/s	0.3.... 45.0 m/s	0.01 m/s	±3 % ±0.1 m/s of reading
ft/min	60 ... 8800 ft/min	0.01, 0.1, 1 ft/min	±3 % ±20 ft/min of reading
knots	0.6.... 88.0 knots	0.01 knots	±3 % ±0.2 knots of reading
km/h	1.0.... 140.0 km/h	0.01 km/h	±3 % ±0.4 km/h of reading
mph	0.7 ... 100 mph	0.01 mph	±3 % ±0.2 mph of reading
<b>Wind direction</b>			
	0 ... 360 °	1 °	
<b>Volume flow</b>			
CMM (m³/min)	0 ... 999900 m³/min	0.001 ... 100 m³/min	
CFM (FT³/min)	0 ... 999900 ft³/min	0.001 ... 100 m³/min	
<b>Temperature measurement</b>			


°C	0 ... 45 °C	0.1 °C	±1.0 °C
°F	32 ... 113 °F	0.18 °F	±1.8 °F
<b>Humidity measurement</b>			
% RH	10 ... 90 % RH	0.1 % RH	±5 % RH
<b>Further specifications</b>			
Probe length	270 ... 540 mm / 10.63 ... 21.26“, telescopic		
Probe aperture	Ø65 mm / 2.5"		
Interface	Micro USB		
Data memory	960 measured values		
Power supply	4 x 1.5 V AAA battery		
Power consumption	15 ... 20 mA without backlight 20 ... 25 mA with backlight 0 ... 8 µA standby		
Flat battery indicator	<4.5 V		
Operating conditions	0 ... 50 °C / 32 ... 122 °F, 40 ... 80 % RH, non-condensing		
Storage conditions	-20 ... 60 °C / -4 ... 140 °F, < 80 % RH, non-condensing		

Dimensions	70 x 194 x 35 mm / 2.7 x 7.6 x 1.3"
Weight	400 g / 14.1 oz

### Delivery scope

- 1 x handheld anemometer PCE-AM 45
- 1 x micro USB cable
- 1 x carrying case
- 4 x 1.5 V AAA battery
- 1 x user manual

### Device description




No.	Description

1	<p>Shift key between:</p> <p><b>MAX:</b> highest measured value</p> <p><b>AVG:</b> average measured value</p> <p><b>MIN:</b> lowest measured value</p> <p>Numeric keypad digit: 1</p>
2	<p>Enter key (ENTER) 2/3 V Max key</p> <p>Wind direction calibration key</p> <p>Numeric keypad digit: 2</p>
3	<p>Freeze display (HOLD)</p> <p>Numeric keypad digit: 3</p>
4	<p>Select between wind speed and volume flow</p> <p>Numeric keypad digit: 4</p>
5	<p>Unit shift key (UNIT) (short press)</p> <p>Switching the key tone on and off (long press)</p> <p>Numeric keypad digit: 5</p>
6	<p>On/off switch (long press)</p> <p>Numeric keypad digit: 6</p>

7	Setting the temperature unit (short press) Select between temperature and humidity display (long press) Numeric keypad digit: 7			
8	Setting the area for volume Setting the storage interval (SAMPLE) Numeric keypad digit: 8	flow	measurement	(AREA)
9	Opening the memory menu (read, save, record) Numeric keypad digit: 9			
10	Save a measured value Opening the recording menu Numeric keypad digit: 0			
11	Clear memory Numeric keypad digit:			
12	USB interface for data transfer			
13	LC display			

14	Connection for the flow sensor
15	Connection cable of the flow sensor
16	The handle of flow sensor
17	Telescopic arm of the flow sensor
18	Flow sensor

### Display description





No.	Meaning
1	2/3 of the maximum display for volume flow measurement
2	Display of the highest measured value
3	Display of the average reading
4	Display of the lowest measured value
5	Display of the saved measured value
6	Measured value is saved
7	Clearing the memory
8	Data connection with a PC has been established
9	Battery voltage too low
10	Measured value frozen
11	Beaufort scale
12	Units for speed display

13	When displayed, the flow value is shown
14	Displayed measured value must be multiplied by 100
15	When displayed, the volume flow is shown
16	Measured value
17	Unit: CFM (FT <sup>3</sup> /min)
18	Unit: CMM (m <sup>3</sup> /min)
19	Display for temperature, area and memory
20	Unit
21	Angle display
22	Unit: relative humidity
23	Compass direction E: East W: West S: South N: North ES: Southeast EN: Northeast WS: Southwest WN: Northwest
24	The indication that there is no saved data

## Numeric keypad

It may happen that a number has to be entered; for example, when entering the memory interval. To enter this function, each key changes its function to a specific numerical key. All four cells must always be completed for each entry. A comma key is also available for volume flow measurement.


## Switching the meter on and off

To switch the meter on and off, press and hold the on/off key for at least two seconds.

## Automatic power off

If no entry is made within five minutes after switching on, the meter switches itself off. To deactivate this function, hold down the Enter key when switching on and switch on the meter. The display shows “no”. The automatic power-off function is now deactivated. Now release all keys to make a measurement. The automatic power off function reactivates whenever the meter is switched off.

## Making a measurement



To make a measurement, align the flow sensor with the flow direction. An arrow inside the sensor indicates the orientation in relation to the wind flow. Wait for at least two seconds for the reading to stabilise.

## Beaufort scale

The Beaufort scale is always active and shows the current wind force category

Wind force	Designation of the wind force	Designation of the sea state (wind sea)
0	Calm	A completely calm, smooth sea
1	Light air	Calm, rippled sea
2	Light breeze	Mildly agitated sea
3	Gentle breeze	Mildly agitated sea
4	Moderate breeze	Slightly agitated sea
5	Fresh breeze	Moderately agitated sea
6	Strong breeze	Rough sea
7	Near gale	Very rough sea
8	Gale	Moderately high seas
9	Strong gale	High seas
10	Storm	Very high seas
11	Violent storm	Heavy sea

12	Hurricane	Exceptionally heavy sea
----	-----------	-------------------------

### Setting the flow unit

- To set the unit of the flow velocity, press the “UNIT” key. You can choose between m/s, km/h, ft/min, knots and mps. The default setting is m/s.

### Setting the temperature unit

- To set the temperature unit displayed, press and release “°C/°F” once. You can choose between °C and °F. The default setting is °C.

### Volume flow measurement

- For a volume flow measurement, first press the “VEL/FLOW” key to select between velocity and volume flow measurement. This is signaled by “VEL” (speed measurement) and “FLOW” (volume flow measurement) on the display.
- Depending on the entered area and the measured wind flow, the measured value can also be significantly higher than it is possible to display. In this case, “x100” or “x10” is displayed next to the measured value. The measured value in the display must then be multiplied by 100 or 10 accordingly.

### Setting the unit of the volume flow measurement

- To select the unit  $\text{FT}^3$  or  $\text{m}^3$ , press and release the “UNIT” key once.

### Hint:



- The function also has an effect on the area specification.

### Area specification for volume flow measurement



- In order to perform a volume flow measurement, it is mandatory to perform an area measurement of the flow. To do this, press the “AREA/SAMPLE” key in volume flow mode. Now enter the area. The unit of measurement m2 or FT2 flashes next to the display. Set the corresponding unit of measurement before entering the area.
- During the volume flow measurement, it is possible to display 2/3 of the maximum volume flow. To do this, press the “ENTER” key. 2/3 MAX” appears on the display. Only 2/3 of the maximum measured value will be displayed. Press the “ENTER” key again to exit the mode.



#### **The lowest, highest, and average measured value**

For velocity and volume flow measurement, the lowest / highest and the average measured value can be displayed by pressing a key. To use these functions, repeatedly press the “MAX/MIN” key until you have reached your desired function.

#### **Highest measured value**

When displaying the highest measured value, only the highest measured value is displayed after activating this function. When “MAX” is displayed, this function is active. When the function is changed, the value expires.



#### **Average reading**

When the average reading is displayed, the average of the last 10 seconds is displayed. When “AVG” is displayed, this function is active. When the function is changed, the value expires.

#### **Lowest measured value**

When the lowest measured value is displayed, it is only the lowest measured value that is displayed. When “MIN” is displayed, this function is active. When the function is changed, the value expires.




## Wind direction

- For wind direction measurement, there is an additional gyroscope in the wind speed sensor.
- The wind direction can be determined via this sensor. To do this, hold the sensor vertically to the airflow.
- Pay attention to the marking inside the sensor for the flow direction.
- The display shows the current angle degree and the compass direction as letters:
- **E**: East
- **W**: West
- **S**: South
- **N**: North
- **ES**: Southeast
- **EN**: Northeast
- **WS**: Southwest
- **WN**: Northwest

## Calibrating the wind direction

The wind direction should be calibrated when the meter is first put into operation, when it is located in a different region and at regular intervals. To do this, switch on the meter and then align the sensor vertically. Now press and hold the “ENTER” key until the wind direction indicator flashes “- -”. Now rotate the sensor vertically around its own axis twice for 8 seconds each. Then press the “Enter” key. The calibration is complete.



## Freezing the measured value

To freeze and hold the currently displayed reading, press and release the “HOLD” key once. The reading is now held. HOLD” appears on the display. Press the “HOLD” key again to resume the measurement.



## Recording the measured values

- To record individual measured values, the storage interval must be set to “0000” seconds. The storage interval can only be set when the air velocity measuring function VEL” is set. To do this, press the “SAMPLE” key and now set the storage interval accordingly. Then press the “REC” key whenever you want to save the current measured value. The memory location used is shown on the lower display and the “REC” display flashes once briefly above the display.
- For continuous recording, set a desired storage interval with the “SAMPLE” key. You can select between 1 ... 9999 seconds. Then press the “REC” key once. The lower display briefly shows the storage interval. REC” is shown above the display. This signals that the measured values are being recorded.
- To interrupt saving, keep the “REC” key pressed.
- If you press the “REC” key again, recording will be restarted.
- Date and time are only saved when recording with the software.

## Read out data memory

To read out the data memory on the meter, press and release the “READ” key once. “READ” is now shown above the display. All readings displayed are now those from the memory. Each time you press the “READ” key, the next memory value is displayed. Now press the “AREA/SAMPLE” key and type in the memory location you want to read out. To return to normal measuring mode, keep the “READ” key pressed until “READ” disappears from the display.

## Delete data

The meter has a memory with 960 measuring points. As soon as the memory is full, “FULL” is shown on the display.

To delete the measurement data on the meter, press and hold the “DEL” key for at least two seconds until “CLA” is displayed and “DEL” lights up. All saved data have now been deleted.

### Hint:

Only the entire memory can be cleared.













## Software

To install the software, first go to the page: [https://www.pce-instruments.com/english/download-win\\_4.htm](https://www.pce-instruments.com/english/download-win_4.htm) where you can download and install the latest software. Then connect the meter to the PC and open the software with administrator rights. As soon as the meter is connected to the PC, the automatic power off function is deactivated.






Button	Function
"Real Time Measure	Live view of the measurement
"Device Storage"	<p>Reading out the memory of the meter.</p> <p>The window for viewing the saved readings on the meter has an identical structure.</p>
"Erase Storage"	<p>Clearing the memory of the meter.</p> <p>As soon as you click on this button, all measured values are immediately deleted. There is no warning in advance.</p>

Icon	Function
 Start Measure	Start live measurement
 Stop	Stop live measurement
 Import	Import a saved live measurement. File format XLS
 Export	Export a current live measurement. The data is saved as XLS.
 Config	Entry of a company name, author and comment
 Open	Open an anemometer file: File format .ane and .xls
 Save	Save an anemometer file File format .ane and .xls This function is <b>only available when reading out the meter.</b>
 Close RT-Measure	Close window
 Clear	Delete all displayed measured values
 Quit	Close programme
<input type="checkbox"/> Zoom all	The scaling of the current graph is adjusted so that all measured values in the current measurement period are visible in one window.


The exported data is saved in XLS format. This could look like this, for example:

	A	B	C	D	E	F	G	H
1	PCE							
2	Wind Velocity	Wind Flow	Temperature	Humidity	Area	Direction/Angle	Time	Date
3	0,00m/s	0,00CMM	23,1°C	42,2%RH	5555M²	W S 245°	13:02:25	10-06-2021
4	0,99m/s	329967,00CMM	23,1°C	42,2%RH	5555M²	W S 206°	13:02:26	10-06-2021
5	5,92m/s	1973136,00CMM	23,1°C	42,3%RH	5555M²	S 197°	13:02:27	10-06-2021
6	6,07m/s	2023131,00CMM	23,1°C	42,9%RH	5555M²	S 186°	13:02:28	10-06-2021
7	4,48m/s	1493184,00CMM	23,1°C	43,8%RH	5555M²	E S 154°	13:02:29	10-06-2021
8	2,78m/s	926574,00CMM	23,1°C	44,1%RH	5555M²	E S 156°	13:02:30	10-06-2021
9	4,75m/s	1583175,00CMM	23,1°C	44,2%RH	5555M²	S 163°	13:02:31	10-06-2021
10	2,70m/s	899910,00CMM	23,1°C	44,5%RH	5555M²	S 160°	13:02:32	10-06-2021
11	3,27m/s	1089891,00CMM	23,1°C	44,6%RH	5555M²	S 164°	13:02:33	10-06-2021
12	5,53m/s	1843149,00CMM	23,1°C	44,4%RH	5555M²	W 270°	13:02:34	10-06-2021
13	2,57m/s	856581,00CMM	23,1°C	44,3%RH	5555M²	W 270°	13:02:35	10-06-2021
14								
15	Author: ME			File Comments: test				
16								

After you have selected “Real Time Measure”, a new window opens for live measurement on the PC. From here, the measurement data is transferred directly to the PC.



To set the read interval, click on “Option” and then select “Read interval(sec)”. In the next window, you can set the interval in seconds.



Below the window, you can see whether a meter is connected. In addition, the current window can be printed. A print preview can be started before printing. There is also a status bar for the current status of importing a file.



## Contact

If you have any questions, suggestions or technical problems, please do not hesitate to contact us. You will find the relevant contact information at the end of this user manual.

## Disposal

- For the disposal of batteries in the EU, the 2006/66/EC directive of the European Parliament applies. Due to the contained pollutants, batteries must not be disposed of as household waste. They must be given to collection points designed for that purpose.
- In order to comply with the EU directive 2012/19/EU we take our devices back. We either re-use them or give them to a recycling company that disposes of the devices in line with law.
- For countries outside the EU, batteries and devices should be disposed of in accordance with your local waste regulations.

- If you have any questions, please contact PCE Instruments.

## **PCE Instruments' contact information**

### **Germany**

- PCE Deutschland GmbH
- Im Langel 26
- D-59872 Meschede

### **Deutschland**

- Tel.: +49 (0) 2903 976 99 0
- Fax: +49 (0) 2903 976 99 29 [info@pce-instruments.com](mailto:info@pce-instruments.com)
- [www.pce-instruments.com/deutsch](http://www.pce-instruments.com/deutsch)

### **United Kingdom**

- PCE Instruments UK Ltd
- Unit 11 Southpoint Business Park Ensign Way, Southampton Hampshire
- United Kingdom, SO31 4RF
- Tel: +44 (0) 2380 98703 0
- Fax: +44 (0) 2380 98703 9
- [info@pce-instruments.co.uk](mailto:info@pce-instruments.co.uk)
- [www.pce-instruments.com/english](http://www.pce-instruments.com/english)
- The Netherlands
- PCE Brookhuis B.V. Institutenweg 15
- 7521 PH Enschede
- Nederland
- Telefoon: +31 (0)53 737 01 92
- [info@pcebenelux.nl](mailto:info@pcebenelux.nl)
- [www.pce-instruments.com/dutch](http://www.pce-instruments.com/dutch)
- France
- PCE Instruments France EURL
- 23, rue de Strasbourg
- 67250 Soultz-Sous-Forets
- France
- Téléphone: +33 (0) 972 3537 17 Numéro de fax: +33 (0) 972 3537 18
- [info@pce-france.fr](mailto:info@pce-france.fr)
- [www.pce-instruments.com/french](http://www.pce-instruments.com/french)
- Italy
- PCE Italia s.r.l.
- Via Pesciatina 878 / B-Interno 6 55010 Loc. Gragnano
- Capannori (Lucca)

## Italia

- Telefono: +39 0583 975 114
- Fax: +39 0583 974 824
- [info@pce-italia.it](mailto:info@pce-italia.it)
- [www.pce-instruments.com/italiano](http://www.pce-instruments.com/italiano)
- United States of America
- PCE Americas Inc.
- 1201 Jupiter Park Drive, Suite 8 Jupiter / Palm Beach
- 33458 FL
- USA
- Tel: +1 (561) 320-9162
- Fax: +1 (561) 320-9176
- [info@pce-americas.com](mailto:info@pce-americas.com)
- [www.pce-instruments.com/us](http://www.pce-instruments.com/us)


## Spain

- PCE Ibérica S.L.
- Calle Mayor, 53
- 02500 Tobarra (Albacete) España
- Tel. : +34 967 543 548
- Fax: +34 967 543 542
- [info@pce-iberica.es](mailto:info@pce-iberica.es)
- [www.pce-instruments.com/espanol](http://www.pce-instruments.com/espanol)

## Turkey

- PCE Teknik Cihazları Ltd.Şti. Halkalı Merkez Mah.
- Pehlivan Sok. No.6/C
- 34303 Küçükçekmece – İstanbul Türkiye
- Tel: 0212 471 11 47
- Faks: 0212 705 53 93
- [info@pce-cihazlari.com.tr](mailto:info@pce-cihazlari.com.tr)
- [www.pce-instruments.com/turkish](http://www.pce-instruments.com/turkish)

## Documents / Resources



[PCE Instruments PCE-AM 45 Anemometer](#) [pdf] User Manual  
PCE-AM 45, PCE-AM 45 Anemometer, Anemometer

## References

- [France.fr : Actualités, destinations et infos du tourisme en France](#)
- [iberica.es](#)
- [Make an offer on the domain instruments.co.uk - Domains.co.uk](#)
- [Computer Instruments | Home](#)
- [Discover Italy: Official Tourism Website - Italia.it](#)
- [Industrial Measurement Products and Solutions | PCE Instruments](#)
- [PCE Deutschland GmbH Prüfgeräte vom Hersteller | PCE Instruments](#)
- [PCE Brookhuis B.V. | PCE Instruments](#)
- [PCE Americas Inc. : Test Instruments | PCE Instruments](#)
- [PCE Iberica S.L. Instrumentación | PCE Instruments](#)
- [PCE Instruments France | PCE Instruments](#)
- [PCE Italia s.r.l. / Strumenti di Misura | PCE Instruments](#)
- [PCE Teknik Cihazlar Paz. Tic. Ltd.Şti. | PCE Instruments](#)
- [PCE Americas Inc. : Test Instruments | PCE Instruments](#)
- [Download | PCE Instruments](#)
- [PCE Americas Inc. : Test Instruments | PCE Instruments](#)