




Photonic Universe MWM Series Module Wind Turbine Controller User Manual

[Home](#) » [Photonic Universe](#) » Photonic Universe MWM Series Module Wind Turbine Controller User Manual 

Photonic Universe MWM Series Module Wind Turbine Controller User Manual



**Product Model
HCM3000-48-240**

Contents

- [1 Important Safety Warning](#)
- [2 Basic Information](#)
- [3 Product Installation](#)
- [4 Operation Interface](#)
- [Introduction](#)
- [5 Trouble Shooting](#)
- [6 Technical Parameters](#)
- [7 Warranty](#)
- [8 Documents / Resources](#)
 - [8.1 References](#)
- [9 Related Posts](#)

Important Safety Warning

Before Using the controller, please read all instructions and cautionary markings on the unit and this manual. Store the manual where it can easily be accessed.

This manual includes all safety warnings, installation, and operation guidance of MWM wind controllers.

- Before installing and using this controller, read all instructions and cautionary markings on the controller and all appropriate sections of this guide.
- Do not use the machine in the place where has flammability and explosive gas/articles. Beware of flames and sparks.
- Please Contact our after-sales person if the machine doesn't work.
- Do not change the electrical components and parts yourself, or we will not be responsible for the warranty items and related duties.
- Please disconnect the AC input and DC output from controller before install or maintain the machine. Besides, do not touch the controller in 5 mins after disconnection.
- Please install the machine indoor to avoid the rain water enter the controller inside.
- Please keep good ventilation and heat dissipation.
- Please install a circuit breaker outside the controller if conditions are allowed.
- Please use copper cable for line connection, and choose the right diameter of cable according to the actual current.
- To avoid a risk of fire and electric shock, make sure the existing wiring is in good condition and that the wire is connected tightly.
- Do not restart the controller immediately when it alarms. Please analyze the fault reasons and repair them at first.

Basic Information


2.1 Introduction and Features

The MWM series wind power generation controller is the controller which integrates MPPT control and charge and discharge control. The power curve can be set by setting the wind turbine voltage and current, which can ensure the wind turbine work with the best power output all the time.

Features:

- Can be applied to grid-tied system, off-grid system and grid-tied energy storage system. Charge function is optional.
- MPPT track point settable
- Complete protection function
- Electrical components and parts in high quality.
- Several functions are optional, such as PV control function, wind speed measure function, rotational speed control function and temperature compensation function.
- RS232/RS485/RJ45/GPRS optional.

2.2 Product Structure



1	Battery terminal	5	Manual brake switch
2	Dump load terminal	6	Browse button
3	Wind turbine terminal	7	LCD display
4	Communication device port	8	Unload indicator light




Chart3: Dump Load with different power

Product Installation

3.1 Installation Notes

- 1. The machine should be kept indoors and well ventilated;
- 2. Environment temperature: -20 +40℃; Humidity: <=95% no condensing
- 3. Altitude should not be more than 4000m (1000 m derating according to the GB/T3859.2 regulations).
- 4. Avoid using the machine in direct sunlight, sun exposure, rain, humidity, acid fog, and dust.
- 5. The machine can only charge for the battery in the rated voltage range.
- 6. The machine can only be connected to the wind turbine and PV with allowed power and voltage.

3.2 Installation and Wiring

3.2.1 Installation Steps




Chart 4: Installation Overview

3.2.2 Installation Steps




Chart5: Installation Steps

3.2.3 Electrical Connection




Chart 6: System Overview


Please connect those parts according to the order of ①②③, and notice the following items.

1. Connect Dump load to the controller terminal “DUMPLoad” by using copper conductor cable.
2. Connect the battery bank to the controller by the terminal which marks “DC Bus”. (do not reversed the connection of positive and negative terminals)
3. When wind turbine is still or running in a low speed, connects its output cable to the “WIND INPUT” terminal on the controller.
4. Check all the connection to make sure they are connected rightly and tightly.








Operation Interface Introduction

4.1 LCD Display

After the power is connected, the whole screen is in a browsing status. It shows battery voltage, and can be changed to the following information by press related buttons.



4.2 LCD Information Define

Name	Icon	Status
Wind Turbine		Rotate means wind turbine works normally
		Brake by hand
Battery		Charging
		Fully charged. flickering for over voltage, stop flickering when it recover from over voltage
		Flickering means over -discharge
Browse button		Press it to enter next LCD display. Press it for 5s to enter the brake status Press it for another 5s to recover charging status.
Dump load indicator light		Red light is on means the machine is on unload status or brake status. The light is off when it works normally.

Trouble Shooting

Fault Type	Description	Possible reasons and solutions
No display on LCD	The connection between the battery and the controller is not tight	Check the wiring, and reconnect it.
	DC breaker is not on between battery and controller	Turn on the breaker
	Low battery voltage	The system parameters are not matched correctly. Recheck the label and parameters on the machine.
		The battery doesn't work. Change a new one.
	Battery is connected in wrong polarity to battery input terminals.	Need change the internal fuse in controller, and reconnect the battery.
No charging	The connection cable between wind turbine and controller is loose.	Reconnect and fix the cables.
	Wind turbine output voltage hasn't reached the charging voltage,	Check whether the system voltage is reasonable.
	Wind turbine is in "Brake" status	Wait the wind turbine recover if it brakes automatically. Press the button for 5s to release the brake status if it brakes by hand.
	Battery is already fully charged.	Check if the battery voltage has reached its output overvoltage.

Technical Parameters

Model	HCM3000-48-240
Type	Buck

Wind Turbine Input	
Rated input power	3kW
Rated input voltage	240V
Input voltage range	0~320V
Start charge voltage	60Vdc (factory default,40Vdc~320Vdc settable)
Rated input current	13A
Brake by hand	Keep press the button for 5s to unload completely, and then recover by hand.
	Switch "ON" the brake switch
Brake by over current	13Adc (factory default,0~15A settable)Unload completely when reached the set current, and recover automatically after working 10mins.
Brake by overvoltage	320Vdc (Factory default), PWM unload step by step once reached the set unload voltage, and it will unload completely if the voltage rise 20Vdc more.
Charge Parameters	
Rated battery voltage	48V
Start unload voltage	56Vdc (factory default,44Vdc~64Vdc settable)
Complete unload voltage	58Vdc(factory default, add 2V to the start unload voltage)
Max. Output current	63A
General Parameters	
Rectifier mode	Uncontrolled rectifier
Display mode	LCD
Display information	DC output voltage, wind turbine voltage/current/power." For those with charge control function, Battery voltage is showed as well.


Monitoring mode	RS232
Monitoring Contents	Real-time display: DC output voltage, wind turbine voltage/current/power. For those with charge control function, Battery voltage is showed as well.
	Parameter setting: Output overvoltage point, wind turbine over current point, wind turbine start voltage, and wind turbine manual brake button.
Lightning protection	YES

Conversion efficiency	≥92%
Static loss	5W
Ambient temperature	-20℃ +40℃
Humidity	0~90%, No condensing
Noise	≤65dB
Cooling mode	Forced air cooling
Installation mode	Wall-mounted
Cover protection class	IP42
Product dimension (W*H*D)	360×440×195mm
Product net weight	15.5kg
Dump load dimension (W*H*D)	400×390×210mm
Dump load net weight	13kg
Note: Part of parameters can be adjusted according to customer's specific demand.	

Warranty

The product shall be in warranty for one year from production. Please take contract as the final one if it has special terms on warranty.

Documents / Resources

	<p>Photonic Universe MWM Series Module Wind Turbine Controller [pdf] User Manual WWS30A-48-L00-S00, HCM3000-48-240, HCM3000-48-240 Module Wind Turbine Controller, HCM3000-48-240, Module Wind Turbine Controller, Wind Turbine Controller, Turbine Controller, Controller</p>
-----------------------------------------------------------------------------------	------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

References

- [User Manual](#)

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.