



Home » Power Dynamics » Power Dynamics PD800 UHF Wireless In Ear Monitoring System Instruction Manual 75

Power Dynamics PD800 UHF Wireless In Ear Monitoring System Instruction Manual



Congratulations to the purchase of this Power Dynamics product. Please read this manual thoroughly prior to using the unit in order to benefit fully from all features.

Read the manual prior to using the unit. Follow the instructions in order not to invalidate the warranty. Take all precautions to avoid fire and/or electrical shock. Repairs must only be carried out by a qualified technician in order to avoid electrical shock. Keep the manual for future reference.

- Prior to using the unit, please ask advice from a specialist. When the unit is switched on for the first time, some smell may occur. This is normal and will disappear after a while.
- The unit contains voltage carrying parts. Therefore do NOT open the housing.
- Do not place metal objects or pour liquids into the unit

This may cause electrical shock and malfunction.

- Do not place the unit near heat sources such as radiators, etc. Do not place the unit on a vibrating surface. Do not cover the ventilation holes.
- The unit is not suitable for continuous use.
- Be careful with the mains lead and do not damage it. A faulty or damaged mains lead can cause electrical shock and malfunction.
- When unplugging the unit from a mains outlet, always pull the plug, never the lead.
- Do not plug or unplug the unit with wet hands.
- If the plug and/or the mains lead are damaged, they need to be replaced by a qualified technician.
- If the unit is damaged to such an extent that internal parts are visible, do NOT plug the unit into a mains outlet and DO NOT switch the unit on. Contact your dealer.
- To avoid fire and shock hazard, do not expose the unit to rain and moisture.
- All repairs should be carried out by a qualified technician only.
- Connect the unit to an earthed mains outlet (220- 240Vac/50Hz) protected by a 10-16A fuse.
- During a thunderstorm or if the unit will not be used for a longer period of time, unplug it from the mains. The rule is: Unplug it from the mains when not in use.
- If the unit has not been used for a longer period of time, condensation may occur. Let the unit reach room temperature before you switch it on.
- Never use the unit in humid rooms or outdoors.
- To prevent accidents in companies, you must follow the applicable guide lines and follow the instructions.
 - Do not repeatedly switch the fixture on and off. This shortens the life time.
- Keep the unit out of the reach of children. Do not leave the unit unattended.
- Do not use cleaning sprays to clean switches. The residues of these sprays cause deposits of dust and grease. In case of malfunction, always seek advice from a specialist.
- Do not force the controls.
- This unit is with speaker inside which can cause magnetic field. Keep this unit at least 60cm away from computer or TV.
- If this product have a built-in lead-acid rechargeable battery. Please recharge the battery every 3 months if you are not going to use the product for a long period of time. Otherwise the battery may be permanently damaged.

- If the battery is damaged please replace with same specifications battery. And dispose the damaged battery environment friendly.
- If the unit has fallen, always have it checked by a qualified technician before you switch the unit on again.
- Do not use chemicals to clean the unit. They damage the varnish. Only clean the unit with a dry cloth.
- Keep away from electronic equipment that may cause interference.
- Only use original spares for repairs, otherwise serious damage and/or dangerous radiation may occur.
- Switch the unit off prior to unplugging it from the mains and/or other equipment.
 Unplug all leads and cables prior to moving the unit.
- Make sure that the mains lead cannot be damaged when people walk on it. Check the mains lead before every use for damages and faults!
- The mains voltage is 220-240Vac/50Hz. Check if power outlet match. If you travel, make sure that the mains voltage of the country is suitable for this unit.
- Keep the original packing material so that you can transport the unit in safe conditions.

This mark attracts the attention of the user to high voltages that are present inside the housing and that are of sufficient magnitude to cause a shock hazard.

This mark attracts the attention of the user to important instructions that are contained in the manual and that he should read and adhere to.

The unit has been certified CE. It is prohibited to make any changes to the unit. They would invalidate the CE certificate and their guarantee!

NOTE: To make sure that the unit will function normally, it must be used in rooms with a temperature between 5°C/41°F and 35°C/95°F.

Electric products must not be put into household waste. Please bring them to a recycling centre. Ask your local authorities or your dealer about the way to proceed. The specifications are typical. The actual values can slightly change from one unit to the other. Specifications can be changed without prior notice.

Do not attempt to make any repairs yourself. This would invalid your warranty. Do not

make any changes to the unit. This would also invalid your warranty. The warranty is not applicable in case of accidents or damages caused by inappropriate use or disrespect of the warnings contained in this manual. Power Dynamics cannot be held responsible for personal injuries caused by a disrespect of the safety recommendations and warnings. This is also applicable to all damages in whatever form.

Contents [hide]

- 1 UNPACKING INSTRUCTION
- 2 POWERSUPPLY
- **3 TRANSMITTER**
- 4 DISPLAY
- **5 RECEIVER**
- 6 INSERT BATTERIES IN THE RECEIVER
- 7 TECHNICAL SPECIFICATION
- 8 Documents / Resources
 - 8.1 References
- 9 Related Posts

UNPACKING INSTRUCTION

CAUTION! Carefully unpack the box upon receipt. Check the contents to ensure that all parts are present and have been received in good condition. Notify the shipper immediately and retain packaging material if any parts appear damaged from shipping or the package itself shows signs of mishandling. Save the package and all packaging materials. If the product must be returned, it is important that the product is returned in the original factory box and packaging.

If the device has been exposed to drastic temperature fluctuation (e.g. after transportation), do not switch it on immediately. The arising condensation water might damage your device. Leave the device switched off until it has reached room temperature.


POWERSUPPLY

On the label on the backside of the product is indicated on this type of power supply

must be connected. Check that the mains voltage corresponds to this, all other voltages than specified, the light effect can be irreparably damaged. The product must also be directly connected to the mains and may be used. No dimmer or adjustable power supply.

Always connect the device to a protected circuit (circuit breaker or fuse). Make sure the device has an appropriate electrical ground to avoid the risk of electrocution or fire.

TRANSMITTER



1. Headphones Jack

2. Phones output Control

Controls the headphone volume, turn left to decrease the audio level, turn right to increase.

3. **Input level**

Controls the volume of input.

- 4. LCD Screen
- 5. Up / Set / Down Button
- 6. Infrared signal emission window (IR window)

7. Power On/Off & exit button

This button is to be used as a power On/Off switch and as any setting exit key. When the PD800 transmitter power is off, press this button long until the power is turned on. When the power is on, the LCD display will light up. While the power is on and trying to turn off the power, press this button steadily until the power is turned off.

8. BNC Antenna Jack

9. PAD Switch

Use to adjust output gain. To cut gain, set to (-12dB). To leave gain unaffected leave set the switch to (0dB).

10. Left In-/Output


Combo connector for signal input via XLR or 6.3mm (1/4") jack or use the output connector to connect for example active monitor speaker.

11. Right In-/Output

Combo connector for signal input via XLR or 6.3mm (1/4") jack or use the output connector to connect for example active monitor speaker.

12. **12VDC Input**

DISPLAY



1. Left / Right AF signal icon

2. Frequency

This six-character display is used to show the frequency menu.

3. Group Display

Display the selected frequency group for the PD800 transmitter.

4. Channel Display

Display the selected frequency channel for the PD800 transmitter.

5. Audio mode

Display of Mono or Stereo audio mode.

6. Lock icon


The lock icon indicates whether mode is on or off. When the lock function is enabled, the PD800 transmitter is locked in the menu.

7. Power mode

8. Menu icons

The menu icons include the following functions: group select, channel select, mode select, power select, lock select and exit setup.

RECEIVER



- 1. LED Indicator
- 2. LCD display
- 3. Infrared signal window
- 4. Up / Down button
- 5. Set / Sync button
- 6. Battery compartment (2xAA batteries)
- 7. Battery compartment cover
- 8. Lock button / Release button
- 9. Antenna
- 10. Earphone jack
- 11. Belt clip
- 12. On/Off switch and volume control
- 13. **Rf signal icon**
- 14. Audio mode
- 15. Lock icon

The "Lock" icon is used to indicate that the lock function is enabled (Lock Icon light on) or disabled (Lock Icon light off). When the lock function is enabled, the PD800 receiver is locked the menu operations.

16. Battery-level meter

This is used to indicate the battery power level. When the battery power level is below a predetermined level, this battery level meter will start to blink and the batteries need to be replaced immediately.

17. **Group display**

This display is used to show the current frequency group setting.


18. Channel display

This display is used to show the current frequency channel setting.

19. **Frequency**


This six-character display is used to show the frequency or to show lock menu.

Channel adjustment




- 1. The "CHANNEL SELECT" icon is used to adjust the transmitter frequency channel.
- 2. In the main menu, press the "SET" button to the "CHANNEL SELECT" icon.
- 3. When the "CHANNEL SELECT" icon is displayed, press the "UP" button to increase the channel number or "DOWN" button to decrease the channel number. When the "UP"/"DOWN" button is pressed longer time, the channel number will be increased / decreased in a fast manner until the button is released.
- 4. Once the desired frequency channel is reached, press the "SET" button to save and go to the next menu, if have no any operation in 5 seconds, the receiver will exit to the main status. If press the "POWER" button to exit to the main status without saving.

Audio Mode adjustment




- 1. The "MODE SELECT" icon is used to adjust the transmitter audio inputs mode.
- 2. In the main menu, press the "SET" button to the "MODE SELECT" icon.
- 3. When the "MODE SELECT" icon is displayed, press the "UP" button to select "STEREO" mode and "DOWN" button to select "MONO" mode.
- 4. Once the desired frequency group is reached, press the "SET" button to save and go to the next menu, if have no any operation in 5 seconds, the receiver will exit to the main status. If press the "POWER" button to exit to the main status without save.

Power Mode Adjustment



- 1. The "POWER SELECT" icon is used to adjust the transmitter radiated power.
- 2. In the main menu, press the "SET" button to the "POWER SELECT" icon.
- 3. When the "POWER SELECT" icon is displayed, press the "UP" button to select "H" mode for higher radiant power and "DOWN" button to select "L" mode for lower radiant power.
- 4. Once the desired frequency group is reached, press the "SET" button to save and go to the next menu, if have no any operation in 5 seconds, the receiver will exit to the main status. If press the "POWER" button to exit to the main status without save.

Lock Adjustment



- 1. The "LOCK SELECT" icon is used to lock all the transmitter settings.
- 2. In the main menu, press the "SET" button to the "LOCK SELECT" icon.
- 3. When the "LOCK SELECT" icon is displayed, press the "UP" button to select "LOCK OFF" mode and "DOWN" button to select "LOCK ON" mode.
- 4. Once the desired frequency group is reached, press the "SET" button to save and go to the next menu, if have no any operation in 5 seconds, the receiver will exit to the main status. If press the "POWER" button to exit to the main status without save.

INSERT BATTERIES IN THE RECEIVER

Insert two 1.5V AA batteries to control the receiver. Open the receiver's front cover and insert the batteries as shown in the battery compartment. The display shows the capacity of the batteries: When the battery indicator flashes, the batteries are empty and the receiver will automatically switch off shortly after. If the receiver is not used for a long period (approx. 1-2 weeks), remove the batteries to protect the device from possible leakage.

TECHNICAL SPECIFICATION

Input connections: 6.3mm Jack, XLR (3-pin)

Output connections: 6.3mm Jack

Frequency range: 863.000 - 865.000 MHz

Frequency response: 40Hz – 16KHz

Signal-to-noise ratio: >105dB

Batteries: 3V (2x AA)

Power supply: 100-240VAC 50/60Hz (12V Adapter)

Power consumption: 0.05 - 0.023A

Dimensions: Receiver: 210 x 170 x 45 mm

Dimensions: Body pack: 120 x 62 x 23 mm

Weight: 2.30 kg

Weight: Receiver: 1.00 kg

Weight: Body pack: 0.12 kg

The specifications are typical. The actual values can slightly change from one unit to the other. Specifications can be changed without prior notice.

The products referred to in this manual conform to the European Community Directives to which they are subject:

European Union

Tronios B.V.,

Bedrijvenpark Twente Noord 18,

7602KR Almelo, The Netherlands

ϵ

2014/35/EU

2014/30/EU

2011/65/EC

2014/53/EU

United Kingdom

Tronios Ltd., 130 Harley Street,

London W1G 7JU, United Kingdom



S.I. 2016:1101

S.I. 2016:1091

S.I. 2012:3032

S.I. 2017:1206

Specifications and design are subject to change without prior notice.

www.tronios.com

Copyright © 2024 by Tronios The Netherlands



Documents / Resources



Power Dynamics PD800 UHF Wireless In Ear Monitoring System [pdf]

Instruction Manual

PD800, PD800 UHF Wireless In Ear Monitoring System, UHF Wireless In Ear Monitoring System, Wireless In Ear Monitoring System, In Ear Monitoring System, Monitoring System

References

- Samen zijn we open. Samen staan we sterk. Stichting OPEN
- Sound & Light distributor Tronios.com
- Mecycle Wecycle Wecycle
- Homepage Wecyle Wecycle
- User Manual

Related Posts

Power Dynamics PD800 In Ear Monitoring System UHF Instruction Manual



PD800 In Ear Monitoring System UHF Instruction Manual PD800 In Ear Monitoring System UHF Congratulations to the purchase...



SBS Power Bank Wireless Instructions

SBS Power Bank Wireless Product Information Specifications Manufacturer: SBS Compliance: RED directive 2014/53/EU, RoHS 2011/65/EU, WEEE

2012/19/EU Maximum...



xtorm FS400UC5 Magnetic Wireless Power Bank User
Manual

xtorm FS400UC5 Magnetic Wireless Power Bank specification charge your device installation battery

pecentage



SIEMENS SENTRON Portfolio for Power Monitoring
Instructions

SENTRON Portfolio for Power Monitoring SENTRON & SIMATIC software solutions for power monitoring and

energy management SENTRON powerconfig...

Power

Dynamics

▶ In-Ear Monitoring System, Monitoring System, PD800, PD800 UHF Wireless In Ear Monitoring System, Power Dynamics, UHF Wireless In Ear Monitoring System, Wireless In-Ear Monitoring System

—Previous Post

Power Dynamics PDC90 Media Player Amplifier Instruction Manual Next Post—

Power Dynamics 100.044 In Outdoor IPX5 Speaker Set Instruction Manual

Leave a comment

Comment *
Name
Email
Website
website
☐ Save my name, email, and website in this browser for the next time I comment.
Post Comment
Search:
e.g. whirlpool wrf535swhz
Manuals+ Upload Deep Search Privacy Policy @manuals.plus YouTube

Your email address will not be published. Required fields are marked *

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.