



PowerA XP7-X Plus Moga Bluetooth Controller for Mobile and Cloud Gaming User Manual

[Home](#) » [PowerA](#) » PowerA XP7-X Plus Moga Bluetooth Controller for Mobile and Cloud Gaming User Manual 



XP7.X+ Bluetooth Controller for Mobile & Cloud Gamin USER MANUAL





Contents

[1 PLAYING IN STANDARD MODE](#)

[2 USING THE GAMING STAND](#)

[3 INSTRUCTIONS](#)

[4 Documents / Resources](#)

[4.1 References](#)

[5 Related Posts](#)

PLAYING IN STANDARD MODE



USING THE GAMING STAND



INSTRUCTIONS

CONTENTS

- MOGA XP7-X+ controller
- Detachable gaming stand
- One 6.6 ft. (2m) micro USB to standard USB
- One 11.8 in. (30 cm) Micro USB to USB Type-C/Micro USB
- User manual


SETUP

For best results, fully charge the controller and power bank prior to first use.


CHARGING CONTROLLER + POWER BANK



- Using the included 6.6ft (2m) USB Cable, connect the Micro-USB end to the port at the top of the controller, and connect the Standard USB end to any powered USB source.
- When charging, four LEDs will display the charging level from 25-50-75-100%.

CHARGE LEVEL INDICATOR

Check the battery charge level by pressing the battery status button  on the front lower left of the controller. The LEDs will indicate the current charge level from 25-100% even when the controller is off.


WIRELESS MODE

Move the Wireless/Wired switch on the front center of the controller to BT  which indicates the wireless mode.


1. If the controller is off, press the Xbox button  to turn it on (LED will illuminate).
2. Press and hold the Bluetooth sync button  on the back of the controller for 5 seconds to enter pairing mode (LED will flash rapidly).
3. Enter the Bluetooth settings on your device and choose the MOGA controller. The pairing LED will turn solid when connected.

NOTE: A previously paired device will automatically pair to the controller when powered on.

POWERING OFF

Hold the Xbox button  for 5 seconds to turn the controller off and save battery capacity.

WIRED MODE

Move the Wireless/Wired switch on the front center of the controller to USB  which indicates the wired mode.

- Connect the Micro-USB end of the 11.8" (30 cm) or 6.6ft (2 m) cable to the port at top of the controller, and connect another end to your gaming device.
- Gaming device input ports (Standard USB, Micro-USB, USB-C) will determine whether you use the shorter or longer micro-USB cable for wired gaming.
- This MOGA controller supports Direct Input by default but also supports XInput mode. If the initial wired connection is unsuccessful, switch modes by pressing Menu + View for three seconds. Three LED flashes to indicate mode was changed and retained in memory. Repeat process to switch back.

STANDARD MODE

The XP7-X+ lets you insert your phone into the middle of the controller, allowing for a convenient way to game on the go.

1. Remove the detachable gaming stand from the middle of the controller by sliding it up.
2. Pull the two grips on the controller away from each other to extend the middle of the controller.
3. Place your phone between the extended grips so that it rests on the ledge of the middle part.
4. Slowly release the grips until they press against the phone, holding it tightly in place.
5. To remove your phone simply pull the grips apart and remove your device.

GAMING STAND

A detachable mobile gaming stand is included for Tabletop Mode.

1. Remove the gaming stand from the middle of the controller by sliding it up.
2. Raise the top of the stand to your preferred viewing angle, the stand rotation clicks through several different positions.
3. Place the stand down on a sturdy surface.
4. Place your device in the grooves on the bottom of the stand and rest it against the back of the stand.

WIRELESS INTEGRATED POWER BANK

A Wireless Power Bank built into the controller allows you to charge your phone during gameplay or while the controller is off.

- Make sure you are using a phone that has wireless charging capability while in standard mode.
- During gameplay, move the Power Bank switch, located on the top left of the controller, to the right (On) to start charging.
- Your mobile device will display charge status once connected. If charging does not begin, the power bank battery may be too low. Recharge controller.
- The amount of charge available for your phone depends on how much battery capacity remains on the controller when charging begins.

ASSIGNING THE ADVANCED GAMING BUTTONS

1. Press the Green Program Button on the bottom of the controller for 2 seconds. The LED Connection Indicator will flash, signaling the controller is in Assign Mode.
2. Press one of the following buttons (A/B/X/Y/LB/RB/LT/RT/Left Stick Press/Right Stick Press/Dpad) to re-assign. Then press the Advanced Gaming Button (Right or Left) that you wish to assign.
The LED connection indicator will stop flashing, signaling the Advanced Gaming Button has been set.
3. Repeat for the remaining Advanced Gaming Button.

NOTE: Advanced Gaming Button assignments will remain in memory even after being disconnected.


RESETTING THE ADVANCED GAMING BUTTONS

1. Hold the Program Button down for 2 seconds. The LED Connection Indicator will slowly flash, signaling the controller is in Assign Mode.
2. Press the previously assigned button for 5 seconds, and the function will be cleared.


FAQS

For the latest FAQs, visit PowerA.com/support

PROBLEM: My controller will not power on.

SOLUTION: Confirm the controller is fully charged by pressing the battery status button  front lower left of the controller. Plug into recharge as needed.

PROBLEM: I don't see my MOGA controller listed in the mobile device's Bluetooth settings.

SOLUTION: Press and hold the Bluetooth sync button  on the back of the controller for 2 seconds to enter pairing mode (LED will flash rapidly).

PROBLEM: The wireless power bank is not functioning.

SOLUTION: Confirm the controller has more than 25% charge and the Power Bank button is switched on.

BATTERY WARNING – CAUTION

- Don't attempt to replace the rechargeable battery yourself. There is a serious risk of explosion if the battery is incorrectly replaced.
- The lithium-ion battery in your device should be serviced or recycled by PowerA, or an authorized provider and must be recycled or disposed of separately from household waste. Dispose of batteries according to your local environmental laws and guidelines.
- Disposal of a battery or a controller that contains batteries into a fire, or mechanically crushing or cutting of a battery can result in an explosion.
- Leaving a battery or a controller that contains batteries in an extremely high-temperature environment can result in an explosion or leakage of flammable liquid or gas.
- A battery or controller that contains batteries that are subjected to extremely low air pressure may result in an

explosion or leakage of flammable liquid or gas.

- Don't use the rechargeable battery in a location where there is a lot of static electricity, as the internal safety functions may be damaged, causing a dangerous situation.
- In case any electrolytes get into the eyes due to battery leakage, do not rub your eyes! Instead, immediately rinse your eyes with clean running water and seek medical attention right away.
- If the battery gives off an odor, generates heat, or in any way appears abnormal during use, recharging, or storage, immediately remove the controller from the battery charger and place it in a secure container such as a metal box.

MOTION WARNING

Playing video games can make your muscles, joints, skin, or eyes hurt. Follow these instructions to avoid problems such as tendinitis, carpal tunnel syndrome, skin irritation, or eyestrain:

- Avoid excessive play. Take a 10 to 15-minute break every hour, even if you don't think you need it. Parents should monitor their children for appropriate play.
- If your hands, wrists, arms, or eyes become tired or sore while playing, or if you feel symptoms such as tingling, numbness, burning, or stiffness, stop and rest for several hours before playing again.
- If you continue to have any of the above symptoms or other discomforts during or after play, stop playing and see a doctor

FCC STATEMENT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. this device may not cause harmful interference, and
2. this device must accept any interference received, including interference that may cause undesired operation.

WARNING: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/ TV technician for help.

RF EXPOSURE COMPLIANCE

This equipment complies with FCC/IC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter

CAN ICES-003(B)/NMB-003(B)

This device contains license-exempt transmitter(s)/receiver(s) that comply with Innovation, Science, and Economic Development Canada's license-exempt RSS(s). Operation is subject to the following two conditions:

1. This device may not cause interference;
2. This device must accept any interference, including interference that may cause undesired operation of the device

MANUFACTURED BY

ACCO Brands USA LLC.

4 Corporate Way, Lake Zurich, IL 60047 | POWERA.com

CONTACT/SUPPORT

For support with your authentic PowerA accessories, please visit PowerA.com/support.

WARRANTY

2-Year Limited Warranty: Visit PowerA.com/support for details.

AUSTRALIAN WARRANTY STATEMENT

This product comes with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. If purchased within Australia or New Zealand, this product comes with a one-year warranty from the date of purchase. Defects

in the product must have appeared within one year from the date of purchase, in order to claim the warranty. All warranty claims must be facilitated back through the retailer of purchase in accordance with the retailer's return policies and procedures. Any expenses incurred, as a result of returning the product to the retailer of purchase are the full responsibility of the consumer.

AU WHOLESALE DISTRIBUTOR

Level 2, 2 Darling Street South Yarra, Australia VIC 3141 bluemouth.com.au | Email: support@bluemouth.com.au | +61 (3) 9867 2666

ADDITIONAL LEGAL

MOGA, the PowerA logo, and the MOGO by PowerA logo are trademarks of the ACCO Brands Corporation. TM & © ACCO Brands Corporation. Microsoft, Xbox, Xbox Series X|S, Xbox One, Xbox One Elite, Xbox One Elite Series 2, and Windows are trademarks of the Microsoft group of companies. All other trademarks are the property of their respective owners.

REGIONAL COMPLIANCE SYMBOLS

More information is available via web-search of each symbol name.

The WEEE (Waste of electrical and electronic equipment) symbol requires battery disposal outside of other household waste per local regulations. Contact your city office, waste disposal service, or retailer for guidance.

CE is a certification mark that indicates conformity with health, safety, and environmental protection standards for products sold within the European Economic Area.

The UKCA (UK Conformity Assessment) mark is a declaration from the manufacturer that the product meets applicable UK Regulations for health, safety, and environmental protection.

The Regulatory Compliance Mark is a visible indication of a product's compliance with all applicable ACMA (Australian Communications and Media Authority) regulatory arrangements, including all technical and record-keeping requirements regarding electrical safety and/ or electromagnetic compatibility (EMC).

DECLARATION OF CONFORMITY

TRADE NAME: Power A | MODEL NO.: 1510706-01

US COMPANY NAME: ACCO Brands USA LLC.

ADDRESS: 14 Corporate Way, Lake Zurich, IL 60047

INTERNET CONTACT INFORMATION: POWERA.com

Hereby, ACCO Brands USA LLC at 4 Corporate Way, Lake Zurich, IL 60047 USA, declares that this wireless controller is in compliance with Directive 2014/30/EU. The full text of the EU Declaration of Conformity is available at the following internet address: PowerA.com/compliance

WIRELESS RATING FOR EU COMPLIANCE

BLUETOOTH: 2402-2480 MHz | MAX E.I.R.P.: < 10dBm (for EU compliance)

WIRELESS CHARGER: 110.417-145.513 kHz


MAX POWER TRANSMITTED: 3.88 dBuA/m @10m distance (for EU compliance)
INPUT: 5v, 500 mA | OUTPUT: 5V, 1000 mA | OPERATIONAL TEMPERATURE: 50-113°F (10-45° C)



CONTENTS

MOGA XP7-X+ controller | Detachable phone stand | One 6.6 ft. (2m) micro USB to standard USB | One 11.8 in. (30 cm) micro USB to USB type-c/micro USB | User manual
2-YEAR LIMITED WARRANTY / VISIT [POWERA.COM/SUPPORT](https://www.powera.com/support) FOR DETAILS
Garantie de deux ans : consultez [PowerA.com/Support](https://www.powera.com/support)
Garanzia limitata di due anni, visita la pagina [PowerA.com/Support](https://www.powera.com/support)
Garantia limitada de dois anos – visita [PowerA.com/Support](https://www.powera.com/support)
ACCO BRANDS USA LLC, 4 CORPORATE WAY, LAKE ZURICH, IL 60047
1510706-01

Documents / Resources

	PowerA XP7-X Plus Moga Bluetooth Controller for Mobile and Cloud Gaming [pdf] User Manual XP7-X Plus, Moga Bluetooth Controller for Mobile and Cloud Gaming, XP7-X Plus Moga Bluetooth Controller for Mobile and Cloud Gaming
---	--

References

- [BDA Home](#)
- [bluemouth.com.au](https://www.bluemouth.com.au)
- [PowerA | PowerA](#)
- [Declaration of Conformity | PowerA](#)
- [Support | PowerA](#)