




**Contents** [ [hide](#) ]

- [1 REDTIGER F77 Dual IMX678 Dash Cam](#)
- [2 Product Specifications](#)
- [3 Package Contents](#)
- [4 Appearance](#)
- [5 Buttons and Functions](#)
- [6 Touch Screen Function](#)
- [7 User Interface Overview](#)
- [8 Function Overview](#)
- [9 App and Wi-Fi Function](#)
- [10 Installation](#)
- [11 Troubleshooting](#)
- [12 Customer Service Center](#)
- [13 Documents / Resources](#)
  - [13.1 References](#)



**REDTIGER**

**REDTIGER F77 Dual IMX678 Dash Cam**



## Notice

- Please read this manual carefully before operation and keep it for future reference. It will be helpful should you encounter any operational problems.
- Non-original parts or improper installation will void the manufacturer's warranty. The installation instructions do not apply to all types of vehicles and are written as guidelines to assist in installing the system.
- Consult with an experienced technician if you are not comfortable installing the device on your own.
- Please make sure to read and understand local laws and regulations regarding cameras and their use in a vehicle. Laws may vary by state.
- Do not obscure the view of the road ahead or obstruct the deployment of any airbags in the event of an accident.
- When not in use, please disconnect the car adapter from both the 12/24V DC outlet in your vehicle and the device itself.
- Only clean the device with a soft dry cloth, for tough dirt, apply some neutral detergent diluted in 5 to 6 parts water on a soft cloth.
- Note that alcohol, thinner, benzene, etc. could cause damage to the paint or coatings on the device.
- Avoid making contact with the lens as this may cause damage.
- The video recordings made by this device are intended for personal use only.
- While driving, do not adjust the controls of your device, as it may draw your attention from your surroundings.

## Product Specifications

|                       |  |                 |                              |
|-----------------------|--|-----------------|------------------------------|
| Item Name             | F77 Dash Cam   | Video Format    | MP4                          |
| Screen Size           | 4" IPS Screen  | Photo Format    | JPG                          |
| Recording Resolution  | Front 4K@30fps+Rear 4K@30fps Front 2.5K@60fps+Rear 4K@30fps Front 2.5K@30fps+Rear 4K@30fps<br>Front 4K@30fps / Front 2.5K@60fps / Front 2.5K@30fps |                 |                              |
| Input                 | DC 5V-2.5A   | Lens            | Front cam F1.8 Rear cam F1.8 |
| Operating Temperature | -4°F~158°F   |                 |                              |
| eMMC Storage          | 128GB  | Warranty Period | 18 months                    |

### Note:


If you have any problems during use, we will provide free device replacement within 18 months of purchase, in addition to lifetime technical support.

### Extended Warranty Service:


You may also receive an additional 6 months of extended warranty service by registering your device on our website.

URL: <https://www.redtigercam.com/pages/warranty-form>


## Package Contents




• F77 4K Dash Cam




• 4K Rear Camera



• Power Supply Cable  
with Car Charger



• Rear Cam Cable



• USB Type-C Data  
Cable



• Adhesive



• Electrostatic  
Sticker



• Cable Clips\*5





• User Manual



• Tool

## Appearance



## Buttons and Functions

### Power Button

- **Recording Mode:**

Short press-to Switch screen

Long press-to Turn off the Camera

- **Setup Mode:**

Short press-to Turn on/off screen

- **Playback Mode:**

Short press-to Delete/Lock/Unlock the specific file

## **Menu Button**

- **Recording Mode:**

Short press to Enter main menu

- **Setup Mode:**

Short press-to Return to the previous screen

- **Playback Mode:**

Short press-to Return to the previous screen

## **Left Button**

- **Recording Mode:**

Short press-to Lock/Unlock the recording file

Long press-to Turn on/off Wi-Fi

- **Setup Mode:**

Short press-to Select the previous function

- **Playback Mode:**

Short press-to Select the previous file

Short press-to Fast rewind while video is being played



**Power Button**



**Menu Button**



**Left Button**

## **Right Button**

- **Recording Mode:**

Short press-to Turn on/off audio recording

- **Setup Mode:**

Short press-to Select the next function

- **Playback Mode:**

Short press-to Select the next file

Short press-to Fast forward while video is being played

## **OK Button**

- **Recording Mode:**

Short press-to Take a snapshot

Long press-to Turn on/off video

- **Setup Mode:**


Short press-to Enter/Confirm specific settings

- **Playback Mode:**

Short press-to Play the specific file




**Right Button**



**OK Button**


## Touch Screen Function

### Video Mode




You can manually click the icon  at the top of the screen to choose whether to record audio during video recording.

You can manually click the icon  at the top of the screen to choose whether to turn on Wi-Fi.


You can manually click the icon  at the top of the screen to choose whether to turn on the key sound.


You can manually click the icon  at the top of the screen to choose whether to turn on the Voice control.

### Playback Mode




Swipe up and down on the playback interface to turn pages.


You can manually click the icon  to choose whether to copy the contents of the eMMC to the memory card.

You can manually click the icon  to choose whether to delete files.

You can manually click the icon  to choose whether to lock files.


You can manually click the icon  to choose whether to select multiple files.

## Setting Mode



Swipe up and down on the setting interface to turn pages.  
 You can manually click the icon to enter the selected function interface.

**Voice Control Function**

Fast control through simple voice commands  
 If the icon is white , it means the function can be used normally.

You have two ways to enable this feature.

1. Tap on the icon to turn the feature on or off.
2. Enter the setting mode-vioce control-on/off.

|                   |                    |
|-------------------|--------------------|
| lock the video    |                    |
| take picture      |                    |
| turn on audio     | turn off audio     |
| turn on screen    | turn off screen    |
| turn on wifi      | turn off wifi      |
| turn on recording | turn off recording |


show front camera

show rear camera













**Note:** You can see the specific commands in setting-vioce control.

## User Interface Overview

### Recording Mode




| Icon | Description  |
|------|--|
|      | Fatigue driving function is on                                     |
|      | G-Sensor sensitivity   |
|      | Front camera resolution  |
|      | Loop recording in 1 min/3 mins/5 mins per file                     |
|      | Whether to connect the hardwired kit and set up parking monitoring |
|      | Voice control  |


| Icon  | Description                         |
|---|-------------------------------------|
|    | GPS status                          |
|    | Wi-Fi status                        |
|    | Camera system sound status          |
|    | Voice recording statusd             |
|    | Which camera is being displayed     |
|    | Recording status and recording time |
|    | Emergency recording is on           |
|  | Date and time of the camera         |
|  | Settings                            |
|  | Emergency recording                 |
|  | Turn on or off recording            |
|  | Photograph                          |

## Playback Mode

1. Press the M button to enter Playback mode.
2. Press the Left or Right button to select the folder you want to play, then press the OK button to enter.

























3. Press the OK button to watch the recorded video.
4. Short press the power button to edit your recorded videos.











## Function Overview

Short press M button to enter settings menu, where you can adjust various functions and parameters of the entire machine.

| Icon  | Function           | Option/Description   |
|---|--------------------|--|
|    | Resolution         | Front 4K@30fps+Rear 4K@30fps /<br>Front 2.5K@60fps+Rear 4K@30fps/<br>Front 2.5K@30fps+Rear 4K@30fps/<br>Front 4K@30fps/Front 2.5K@60fps/<br>Front 2.5K@30fps |
|    | Audio              | ON/OFF   |
|    | Recording Duration | 1/3/5mins  |
|    | G-sensor           | Off/Low/Medium/High  |
|    | Fatigue Reminder   | A Reminder Will be Made During<br>1h/2h/3h/OFF   |
|    | Wi-Fi              | OFF/2.4GHz/5.8GHz  |
|   | Click Tone         | ON/OFF   |
|  | Screen Saver       | OFF/10s/30s/2mins,<br>Screen goes off after the set time   |
|  | Voice Control      | ON/OFF/Voice Command   |
|  | Mirror Flip        | Horizontal Flip Your Rear View<br>*Need to connect rear camera   |

| Icon  | Function        | Option/Description   |
|---|-----------------|--|
|    | Rear Cam Flip   | Vertical Flip Your Rear View<br>*Need to connect rear camera |
|    | Parking Monitor | Please connect the ACC hardwire kit                          |
|    | GPS             | Display GPS signal strength                                  |
|    | TimeWatermark   | ON/OFF   |
|    | Speed Stamp     | ON/OFF   |
|    | GPS Stamp       | ON/OFF   |
|    | Speed Units     | KM/H / MPH   |
|  | Language        | Choose Your Preferred Language                               |
|  | Clock Settings  | Update With GPS  |
|  | Time Format     | 12h/24h  |
|  | Time Zone       | Choose Your Time Zone  |
|  | DST             | Daylight Saving Time ON/OFF                                  |

| Icon  | Function        | Option/Description                                  |
|---|-----------------|---|
|    | Flicker         | 60Hz/50Hz   |
|    | Format Reminder | Reminder to Clear Data                              |
|    | Format          | Format eMMC or memory card.All data will be deleted |
|    | Card Speed      | Card Speed Detection                                |
|    | Default Setting | Reset All Settings                                  |
|    | APP             | A QR Code for redtiger app                          |
|   | Version         | Software Version                                    |
|  | Help Center     | Scan the QR code to contact us                      |

## Note

- In order to a Clean, Smooth, Comfortable using experience, we suggest you format your eMMC storage once a month.
- When you turn off Click Tone, the startup and shutdown sounds will also be turned off.

## App and Wi-Fi Function

### How to connect Wi-Fi?

#### 1. Download the app

You can download the app from:

- Official Website: <https://www.redtigercam.com/pages/app>
- QR Code located on your dash cam (may be located on the right side)
- Search “Redtiger” in the Apple App Store or Google Play Store


2. Turn on the Wi-Fi on the dash cam, the Wi-Fi and SSID and password will appear on the display.
3. Open Redtiger App> jump to the Wi-Fi connection interface according to the steps> find the Wi-Fi of the dash cam> enter the password to connect.  
(The default password is 12345678)
4. After successfully connecting to Wi-Fi, return to the App to use it.



### **View/Download/Delete/Share Video**

1. Click the icon on the main interface to view video and image files.
2. Long press the video file to select it, then choose whether you would like to download or delete it.
3. Return to the App home page and select the Album> Open and watch/share it.

### **App Home**



|  |    |                            |
|--|----|----------------------------|
| 1 Native Wi-Fi Name                      | 2  | Turn on/off recorded sound |
| 3 Switch recording screen                | 4  | GPS information            |
| 5 Video play window                      | 6  | Mirror Flip                |
| 7 Rotate the video screen left and right | 8  | Map                        |
| 9 Dash cam file                          | 10 | Pause/start recording      |
| 11 Take pictures                         | 12 | Dash cam settings          |

## Over-The-Air Updates

**Note:** Please update the Redtiger App to the latest version to use this function.

1. To perform an over-the-air update, disconnect your phone from the dash cam's Wi-Fi

network. Connect your phone to LAN (not the dash cam's Wi-Fi) for 5 seconds, then disconnect. Reconnect to the dash cam's Wi-Fi network.

2. Once Wi-Fi connection is successful, open the Redtiger App to start using it. If new software is detected, the App page will indicate the availability of an update.
3. To perform the update, click on "Upgrade Now". The Redtiger app will prompt you to download the update package.
4. Connect the dash cam to send the update package. Do not power off the dash cam during the upgrade process. Once the upgrade is completed, the app will display the upgrade success message, and the dash cam will automatically restart.

### **How to Play Video on Computer**

We recommend using REDTIGER Player as the correct video player to watch/play videos. It can also view Google Maps.

You can Download it for free on Mac or Windows from the following link:



<https://www.redtigercam.com/pages/gps-player>


You can choose different playback modes in Settings > Video Playback Mode. You can set playback speed, language, map, and various other functions.

### **TIPS:**

Data can be output from the main unit to a personal computer using a USB cable.

Alternatively, you can insert a memory card into the dash cam and copy data from the eMMC, transfer data by using a card reader.





1. Video play window (Front)
2. Video play window (Rear)
3. Map and track display
4. Play control panel
5. Speed and driving state indication
6. Play list

### Note:

If the video files of front and rear road tracks are recorded synchronously and loaded into the playing list at the same time, they can be played separately in split left and right screens.

When you find the desired video file, hold down the left mouse button and drag the desired files to the video play window to play it.

## Installation

## WARNING

Please make sure to connect all cameras and wires before powering on the camera screen, otherwise the camera will not work properly. Please follow the instructions below for the first-time installation of the Redtiger dash cam.

Scan the QR code on the right to view the installation tutorial video.




### **eMMC Storage**

The dash cam comes with built-in 128GB eMMC (Embedded Multi Media Card) storage, eliminating the need for additional purchase and installation of a memory card, allowing for immediate recording upon startup.

### **Insert Memory Card (Optional Operation)**



F77 also support using memory cards to copy the videos you need. You can do this in the playback folder by clicking “Copy Current” or “Copy Selected.”

**Tips:** Video is not saved directly to the memory card. Insert the memory card into the dash cam, ensuring that it is oriented correctly so that the gold contacts are facing towards the screen of the dash cam. Push the memory card until it clicks into the slot.




### **Front camera installation**

Peel off the electrostatic sticker on the cellophane and transfer it to where you want to stick it. Attach the front camera to the electrostatic sticker and press to make it firmer.




### Wire Layout In The Vehicle

1. The car charger is connected to the cigar socket.
2. Connect the other end of the car charger to the dash cam.
3. Use the crowbar to run the power cable along the front windshield and the roof, and hide the cable down the A-pillar, so as not to block the driver's sight and cause danger.





4. Connect the interface of the rear cable with the interface of the rear cam cable.
5. Hide the rear cam cable along the gaps between the front windshield and the ceiling, between the car body and the ceiling on the side of the passenger seat, and between the rear seats and the ceiling.



### **Rear camera installation**

Peel off the electrostatic sticker on the rear camera and transfer it to where you want to stick it. Attach the camera to the electrostatic sticker and press to make it firmer.



## Troubleshooting

### Why is the machine running normally but there are no files in the memory card?

The eMMC (Embedded Multi Media Card) is built into the dash cam for storage. The memory card does not automatically save files, but you can manually copy files to the memory card.

### Why is there no GPS signal?

1. Disconnect and clean the cable and port of any dust that may have accumulated around the dash cam. Check for any interference in your car, like metal film on the windshield, a radio antenna, or radar detector.
2. Move your car to an open area. Observe if the GPS icon on the screen turns green and displays GPS information.
3. Once the GPS locks on to a signal, a satellite icon will appear at the bottom left of the screen. Green indicates positioning, while white indicates no positioning.

### How to turn off the on/off music of dash cam?

Please go to Settings > Click Tone > Off.

When the click tone is turned off, the power on and off music will also be turned off.

### **Why does my dash cam prompt “Card Error” or “Please Format Memory Card” occasionally?**

Please follow the steps below to check:

1. Please go to Settings > Format Reminder to check whether the regular format reminder is enabled.
2. Format the Memory Card.
3. Restore factory settings and restart the dash cam.
4. Update the firmware.

### **Device restarts repeatedly/no boot?**

1. Ensure you're using the included charger/cables.
2. Remove the memory card, camera cable, and car charger and reinstall them. Check if an issue was caused by the accessories.
3. Reset the device using the button at the bottom of the camera.
4. If the issue persists, connect the dash cam to a computer using a USB cable. If the device powers on, the issue may be caused by the car charger cable. If it does not power on while connected, there may be an issue with the dash cam itself.
5. Please go to the official website to update the firmware.
6. If it is not resolved, please contact our dedicated customer service for a replacement.

### **Why “Mass storage” appears on the screen?**

“Mass storage” happens when you use a USB cable with data transfer mode causing the dash cam to enter transfer mode. In this mode, data can only be transferred; no other functions work. For best results, use the original car charger or a USB cable without data transfer mode.

### **Why can't I connect to Wi-Fi?**

1. Check the working distance of Wi-Fi, about 15ft.
2. Check the SSID and password of the Wi-Fi, or whether there are other devices

connected to the Wi-Fi.

3. Turn off mobile data, security software, and VPN on your phone.
4. If the issue persists, please contact customer support for assistance.

### Why is the time setting incorrect?

The dash cam features built-in GPS. It automatically adjusts time based on your location and time zone, eliminating the need for manual time changes. And you can adjust the time through Settings > Time Zone/DST.

## Customer Service Center

If you have any problems with the function or installation of your dash cam, please feel free to reach out to us.



Help Center



WhatsApp


### For more information:

**After-sales:** [help@redtigercam.com](mailto:help@redtigercam.com)

Business Cooperation: [contact@redtigercam.com](mailto:contact@redtigercam.com)

Customer Phone Service: +1 888 966 8028 (US)

## Documents / Resources

|   |   |
|---|---|
|  | <p><a href="#">REDTIGER F77 Dual IMX678 Dash Cam [pdf]</a> User Manual</p> <p>F77 Dual IMX678 Dash Cam, F77, Dual IMX678 Dash Cam, Dash Cam</p> |
|---|---|

## References

- [REDTIGER® Official Site - 4K UHD Smart Car Dash Cam with WiFi & GPS](#)
- [APP](#)
- [REDTIGER® Official Site - 4K UHD Smart Car Dash Cam with WiFi & GPS](#)
- [Warranty Form](#)
- [User Manual](#)

 Dash Cam, Dual IMX678 Dash Cam, F77, F77 Dual IMX678 Dash Cam,

 Redtiger redtiger

—Previous Post

**REDTIGER Dash Cam App User Guide**

Next Post—

**REDTIGER VisionSync 10 Dash Camera User Manual**

---

## Leave a comment

Your email address will not be published. Required fields are marked \*

Comment \*

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

**Post Comment**

## Search:

e.g. whirlpool wrf535swhz

**Search**

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.