

**RICE LAKE**  
**HID Long Range**  
**Reader**



## RICE LAKE HID Long Range Reader User Guide

[Home](#) » [RICE LAKE](#) » RICE LAKE HID Long Range Reader User Guide 

### Contents

- [1 RICE LAKE HID Long-Range Reader](#)
- [2 Product Usage Instructions](#)
- [3 HID Reader/Interface Board Installation](#)
- [4 Mounting the New Mounting Plate](#)
- [5 FCC Compliance](#)
- [6 FAQs](#)
- [7 Documents / Resources](#)
  - [7.1 References](#)
- [8 Related Posts](#)

**RICE LAKE**

RICE LAKE HID Long-Range Reader



### Specifications:

- **Model:** HID Long-Range Reader
- **Connection:** Wiegand Converter Box
- **Terminal Descriptions:**
  - P1-1 Beeper Input (BEEP)
  - P1-2 LED Input (GRN)
  - P1-3 Ground (GND)
  - P1-4 +VDC
  - P1-5 Unused (DRAIN)
  - P1-6 LED Input (RED)
  - P1-7 Hold Input (HOLD)

### Product Usage Instructions

#### Wiring Connection:

The HID Long Range Reader connects to an indicator through a Wiegand Converter Box.

#### Wiring Schematic:

Refer to Figure 1 for the HID Long Range Reader Wiring Schematic.

#### Reader Connections:

Wiegand Terminal	HID Terminal	Description
P2-1	GPIO4	RS485-Y / TXA


#### Wiegand Converter Box Wiring:

For detailed wiring connections, refer to Figure 3 of the manual.

## HID Reader/Interface Board Installation

The HIS Signo™ Reader offers a secure, standards-based, flexible platform that stores and retrieves data, using a special card/ badge. This reader will replace the RFID reader currently installed in the kiosks.

**WARNING:** To avoid shock or serious injury, consult a licensed electrician for electrical installation procedures



**Figure 1. HID Reader/Interface Board Kit (PN 176451)**

Use the following directions to install the HID reader kit.

### Remove Old HID Reader (if needed)

1. Remove the existing reader from the kiosk panel.
2. Remove the screw from the bottom of the HID Reader.
3. Pull the back plate from the HID Reader.

### Mounting the New Mounting Plate

1. Align new back plate with the existing holes, if possible. Holes can to be adjusted, or new holes created for mounting.




Figure 2. Mount Back Plate

- If mounting on or near metal, spacers are recommended for optimal read performance.
  - Use supplied screws to ensure the correct fitting and to avoid damaging the reader or mounting plate.
2. Attach the plate to the kiosk panel, using the four screws included in the kit.

### Terminal Strip Wiring



Terminal No.§	Description§
1§	+5VDC
2§	Ground §
3§	Data 1 / Clock / RS-485-A§
4§	Data 0 / Date / RS-485-B§
5§	LED Input (GRN)§
6§	Beeper Input§
7§	Hold Input / LED Input (Blue)§
8§	LED Input (Red)§
9§	Tamper 2 (RLY2§
10§	Tamper 1 (RLY1)§

Figure 3. Install HID Reader

Connecting up the reader incorrectly may permanently damage the reader.

### Secure the Reader to the Mounting Plate

1. Hook the top of the reader on the top of the mounting plate.
2. Align the bottom of the reader with the bottom of the mounting plate.
3. Secure the reader to the mounting plate using the supplied 0.138-32 x 0.375" screw.



*Figure 4. Secure Reader to Mounting Plate*


#### **Power and Test Reader**

1. Power on the reader. The reader will beep and the LED will flash.
2. Test the reader with a credential. The reader will beep and the LED will flash.




*Figure 5. Power up and Test the Reader*

If located elsewhere on the panel, use the adhesive spacers.



Using Standoffs and Screws



Using Spacers




Figure 6. Install Interface Card

3. Wire connections as shown below and in Figure 7.




Figure 7. Install Interface Board and Wire




Figure 8. Interface Board Wiring Diagram (Reference)

## FCC Compliance

### United States

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

### Canada

This digital apparatus does not exceed the Class B limits for radio noise emissions from digital apparatus set out in the Radio Interference Regulations of the Canadian Department of Communications.

### Approvals

© Rice Lake Weighing Systems Specifications subject to change without notice

Rice Lake Weighing Systems is an ISO 9001 registered company.

230 W. Coleman St. • Rice Lake, WI 54868 • USA

U.S. [800-472-6703](tel:800-472-6703) • Canada/Mexico [800-321-6703](tel:800-321-6703) • International [715-234-9171](tel:715-234-9171) • Europe +31 (0)26 472 1319


[www.ricelake.com](http://www.ricelake.com)

## FAQs

### Q: How do I connect the HID Long Range Reader to power?

A: Connect the HID READER to a customer-supplied 120 VAC power source as shown in the wiring diagram.

## Documents / Resources



[RICE LAKE HID Long Range Reader](#) [pdf] User Guide

HID Long Range Reader, HID, Long Range Reader, Range Reader, Reader

## References

-  [Rice Lake Weighing Systems](#)
- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.