


# RICE LAKE SCT-1SX-Ethernet Indicators and Controller User Guide

Home » RICE LAKE » RICE LAKE SCT-1SX-Ethernet Indicators and Controller User Guide 🖫



#### **Contents**

- 1 Electrical Schematic
- 2 Key Functions
- **3 Indicator Light Descriptions**
- **4 Configuration Menu**
- **5 Maximum Scale Capacity, Increment and Decimal Point**

**Settings** 

- **6 Theoretical Calibration**
- 7 Zero Mechanical Tare (pre-tare zeroing)
- 8 Calibration with Sample Weight
- 9 Load Cells Diagnostics (μV/V)
- 10 Input Settings
- 11 Output Settings
- 12 Fieldbus Settings
- 13 Weight Filter
- **14 Programming Errors**
- 15 Ethernet/IP
- 16 Documents / Resources
  - 16.1 References
- **17 Related Posts**

#### **Electrical Schematic**


Load cells excitation: 5 V. Load cells output: 6 mV/V max.

INPUT: 12 to 48 Vdc

OUTPUT: 48Vac or 60Vdc, 0.5 A max

For UL approved models: equipment to be powered by 12 to 24 Vdc LPS or Class 2 power source.

CONSUMPTION: 4 W max. (without load cells).



Manuals are available from Rice Lake Weighing Systems at <a href="https://www.ricelake.com/manuals">www.ricelake.com/manuals</a>
Warranty information is available at <a href="https://www.ricelake.com/warranties">www.ricelake.com/warranties</a>


## **Key Functions**



Configu	Configuration menu			
•	Decreases digit / Scrolls down.			
	Increases digit / Scrolls up.			
•	Enters the setup. Selects digit to modify.			
4	Enters a step / Confirms.			
С	Clears / Exits a step (no save).			

Weighir	Weighing mode			
•	Clears the displayed gross weight.			
<b>A</b>	Short press: executes semiautomatic tare. Long press: allows to enter known tare.			
•	Activates / deactivates the function.			
4	Short press executes data transmission on the printer serial port. Long press: Setpoint configuration.			
С	ON/Standby of the instrument.			


## **Indicator Light Descriptions**



1	Weight on zero.	
2	Unstable weight.	
3	A tare is active.	
4	A function is active.	
5	Digital output 1 is active.	
6	Digital output 2 is active.	

## **Configuration Menu**


- 1. Reboot the weight transmitter
- 2. Press the ▶ key when display shows the 88888 message:



#### HOW TO EXIT THE MENU AND SAVE YOUR CONFIGURATION

1. Press **C** key repeatedly until <sup>5AUE?</sup> appears; press ← to save or press **C** to exit without saving.

#### **Maximum Scale Capacity, Increment and Decimal Point Settings**



#### **Examples:**

For a 60000 lb scale, with 2 lb increment:

d 1U.dEC = 2

CAPAC = 60000

For a 10000 g scale, with 0.1 g increment:

 $d_{1}U_{1}, dEC = 0.1$ 

CRPRC = 10000.0


For a 3000 lb scale, with 0.05 lb inc rement:

 $d \cdot U \cdot dEC = 0.05$ 


CAPAC = 3000.00

- \*1 Increment = the amount that the scale will increment by as weight is added or removed.
- \*2 Maximum capacity = the maximum weight that can be measured using the scale you are creating.

#### **Theoretical Calibration**




## Zero Mechanical Tare (pre-tare zeroing)




This functionality allows to zero the weigh of the scale structure (e.g. empty silo, conveyor, etc.) without changing the calibration in memory.

## **Calibration with Sample Weight**




## Load Cells Diagnostics (μV/V)




It allows to verify signal of each channel. It must be included into the range 0 to 3 mV/V. Signal have to be stable and it have to increase by increasing the weight on the scale.


## **Input Settings**




## **Output Settings**




#### 11.1 HOW TO PROGRAM SETPOINTS




## **Fieldbus Settings**



#### Set the IP address:



## Weight Filter



The active weight filter is displayed, alternating with the weight value.

Press ▲ and ▼ keys to scroll through the available filters (from slowest to fastest, F1 to F11).

## **Programming Errors**

MESSAGE	DESCRIPTION	SOLUTION		
PrEC.	Calibration error	First calibrate the zero point (zero), then proceed with sample weight acquisition (sp n) (section 9).		
Err.Pnt	Calibration error	Check the connection of the load cell. Verify the load cell signal is stable, valid and greater than the previously ac quired point.		
Er 11	Calibration error	Increase the calibration weight.		
Er 12	Calibration error	Check the signal from the load cell increases when weig ht is incremented on the scale.		
Er 37	Calibration error	Repeat calibration and verify capacity and division have been correctly set.		
Er 39	Instrument not configured	Transmitter needs to be configurated.		
C.Er. 36	Calibration error	Verify the signal from the load cell is not negative.		
C.Er. 37	Calibration error	Verify the signal from the load cell is not negative.		
ErrNot	Weight unstable	Check in AdC.uU parameter that the signal is stable. If the connection of the cells is with 4 wires, check that the sense jumpers are inserted.		
AdC.Err	A/D converter error	Converter failure. Reboot the instrument.		
CEL.Err	Global load cell error	Signal anomaly: check the load cells connection.		

## Ethernet/IP

## 15.1 ETHERNET/IP REGISTERS

Data	Byte	DESCRIPTION		
	0 (MSB)			
Goss weight	1	Bytes 1, 2, 3 and 4 contain the Gross Weight value.		
Goss weight	2	bytes 1, 2, 3 and 4 contain the Gross weight value.		
	3 (LSB)			
	4 (MSB)			
	5			
Notweight	6	Dutas E. C. 7 and O contain the Net Weight union		
Net weight	7 (LSB)	Bytes 5, 6, 7 and 8 contain the Net Weight value.		

		Bit 15 (msb) Bit 14 Bit 13		annel. on. on. on.			
	8 (MSB)	Bit 12 Bit 11 Bit 10 Bit 9 Bit 8 ( Isb)		Bit 15	Bit 14	Active Channel	
				0	0	Channel 1	
Input status regi				0	1	Channel 2	
ster				1	0	Channel 3	
				1	1	Channel 4	
	9 (LSB)	Bit 7( msb) Bit 6 Bit 5 Bit 4 Bit 3 Bit 2 Bit 1 Bit 0 ( Isb)	<ul> <li>1 = Scale unloaded (gross weight = 0). Tare PT (1 = PT tare is active).</li> <li>Tare (1 = Tare is active).</li> <li>Overload condition (0 = No; 1 = Overload). Underload condition (0 = No; 1 = Underload). Weight Stability (0 = Unstable; 1 = Stable).</li> <li>Gross Weight Polarity (0 = "+"; 1 = "-"). Net Weight Polarity (0 = "+"; 1 = "-").</li> </ul>				
	10 (MSB)	Last re	ceived con	nmand.			
Command statu s register	11 (LSB)	Bit 7(msb) Bit 6 Bit 5 Bit 4 Bit 3 Bit 2 Bit 1 Bit 0 (lsb)	Last command result. Last command result. Last command result. Last command result. Counting of processed commands. Counting of processed commands. Counting of processed commands. Counting of processed commands.				
	12 (MSB)	No Fun	o Function.				
Output status re gister	13 (LSB)	Bit 7( msb)  Bit 2 Bit 1 Bit 0(l sb)	No function No function. Digital output 2 status (0 = OFF; 1 = ON). Digital output 1 status (0 = OFF; 1 = ON).				
Selected page	14 (MSB) 15 (LSB)	Shows	the value	of the select	ed page (30	001).	
	16 (MSB)						

$\mu V$ 17 (LSB) $\mu V$ value.	
---------------------------------	--

## 15.2 ETHERNET/IP REGISTERS FOR COMMAND SENDING

Data	Byte	DESCRIPTION					
Not used	0	Always 0.					
		Main available commands:					
		Value Command					
		00 Hex No command					
		01 Hex Scale zeroing					
Command	1	02 Hex Tare					
Command		03 Hex Preset Tare					
		OA Hex Setpoint 1 setting					
		OB Hex Setpoint 2 setting					
		19 Hex Digital output setting					
		22 Hex Reboot the weight transmitter					
	2 (MSB)						
Parameter 1	3	First parameter of the command.  Parameter is always expressed in absolute mode (no decimals, no sign).					
raiaillelei i	4						
	5 (LSB)						
	6 (MSB)						
Parameter 2	7	Second parameter of the command.  Parameter is always expressed in absolute mode (no decimals, no sign).					
raiaillelei 2	8						
	9 (LSB)						
	10(MSB)						
		Used in advanced configuration, refer to the complete Fieldbus manual for furthe information.					
	31 (LSB)						

#### **EXAMPLE 1**

For zeroing the weight on the scale:

2. Set the command in byte 2

Byte	Value
1	00 Hex
2	01 Hex

#### **EXAMPLE 2**

For setting a preset tare of 1000 lb:

- 1. Set the tare value in parameter 1 (byte 3, 4, 5, 6)
- 2. Set the command in byte 2

Byte	Value
1	00 Hex
2	03 Hex
3(MSB)	00 Hex
4	00 Hex
5	03 Hex
6(LSB)	E8 Hex

No



230 W. Coleman St. • Rice Lake, WI 54868 • USA USA: 800-472-6703 • International: +1-715-234-9171 © Rice Lake Weighing Systems Content subject to change without notice.

www.ricelake.com PN 219716 Rev A September 29, 2023

#### **Documents / Resources**



RICE LAKE SCT-1SX-Ethernet Indicators and Controller [pdf] User Guide SCT-1SX-Ethernet Indicators and Controller, SCT-1SX-Ethernet, Indicators and Controller, and Controller, Controller

#### References

User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.