



Robertshaw RS8210 Non-Programmable Multi-Stage 2H-1C Wall Thermostat User Manual

[Home](#) » [Robertshaw](#) » Robertshaw RS8210 Non-Programmable Multi-Stage 2H-1C Wall Thermostat User Manual 



RS8210 Operation Manual




Caution

DO NOT SWITCH SYSTEM TO COOL IF THE TEMPERATURE IS BELOW 50°F (10°C). THIS CAN DAMAGE THE AIR CONDITIONING SYSTEM AND CAUSE PERSONAL INJURY.

Contents

- [1 THERMOSTAT OPERATION](#)
- [2 THERMOSTAT QUICK REFERENCE](#)
- [3 PROGRAMMING](#)
- [4 INSTALLER SETUP MENU](#)
- [5 TERMINAL DESIGNATIONS](#)
- [6 Documents / Resources](#)
 - [6.1 References](#)
- [7 Related Posts](#)

THERMOSTAT OPERATION



1. LCD Screen
2. Fan Switch
3. System Switch
4. Temperature Set-Point Buttons
5. User Buttons

1. LCD Screen

See page 4 for details about this display read out.

2. Fan Switch



Select ON or AUTO. ON will run the fan continuously. AUTO will cycle the fan on only when the heating or cooling system is running.

3. System Switch

Selects the HEAT or COOL for your HVAC system. Selecting HEAT turns on the heat mode. Selecting COOL turns on the cool mode. Selecting OFF turns both heating and cooling off.

Selecting EMH (for heat pumps with auxiliary heat) will lockout the compressor and control emergency/auxiliary heat.


4. Temperature Set-Point Buttons

Press the  or  to select the desired temperature.

5. User Buttons

Use these buttons to set up programming options.

THERMOSTAT QUICK REFERENCE




Caution:




When the battery icon appears, replace the alkaline AAA batteries immediately to avoid damage to your HVAC system. Freezing or overheating could occur

Battery Door Information



Press the lower portion of the thermostat to open the easy access battery door.




Install two AAA Alkaline batteries into battery compartment. Be sure to match positive (+) ends of batteries with positive (+) battery terminals in the battery compartment.

Filter Change Reminder

The thermostat can be configured to remind you when the air filter needs to be changed. The filter change reminder can be adjusted to up to 2000 hours in 50 hour increments.





If the installer configured the thermostat to issue this reminder, FILTER will be displayed when it is time to change the air filter. When FILTER is displayed, you should change the air filter and reset the Filter Change Reminder by holding down the second button from the top left side of the thermostat for 3 seconds.

Hold down button for
3 seconds to reset
filter reminder.



PROGRAMMING

Set Time



1. Press the MENU button.
2. Press SET TIME.
3. Day of the week will be flashing. Use  or  to select the current day of the week.
4. Press NEXT STEP.
5. The current hour will be flashing. Use  or  to select the current hour. Note the correct a.m. or p.m. indicator is selected.

6. Press NEXT STEP.

7. The minutes will be flashing. Use  or  to select the current minutes.

8. Press DONE when completed.

Set temperature

1. Use  or  to select set temperature.

INSTALLER SETUP MENU

1. Press MENU.







2. Press and hold TECH SET for 3 seconds.

3. Configure the installer options as desired using the table below.

4. Use + and – to change settings and the NEW STEP or PREV STEP to move from one option to another.

Note: Only press DONE when you want to exit the Installer Setup Options.

Feature	Filter Change Reminder	Room Temperature Calibration	Minimum Compressor On Time	Compressor Short Cycle Delay	Cooling Differential	Heating Differential
Adjustment Options	The filter change reminder can be adjusted from OFF to 2000 hours in 50 hour increments.	The room temperature display can be adjusted to read 3° above or below the factory calibrated temperature.	The minimum compressor run time can be adjusted from OFF to 3, or 5 4, minutes. 4 ff 3, , or 5 ls selected, the compressor will run for at least the selected time before turning off (although the fan may continue to run for a short time).	The compressor short cycle delay setting can be removed by selecting OFF.	The cooling differential setting is adjustable from 0.2°F to 2°F	The heating differential setting is adjustable from 0.2°F to 2°F.

Feature	Filter Change Reminder	Room Temperature Calibration	Minimum Compressor On-Time	Compressor Short Cycle Delay	Cooling Differential	Heating Differential
Factory default settings	OFF	0°F	OFF	On	0.5°F	0.4°F
Feature Description	This setting will flash FILT in the display after the elapsed run time to remind the user to change the filter. The OFF setting will disable this feature.	This setting allows the installer to change the calibration of the room temperature display so that, for example, the thermostat would read 72°F instead of 70°F.	The installer can select the minimum run time for the compressor to help protect the compressor from short-cycling.	The compressor short cycle delay setting will not allow the compressor to be turned on for 5 minutes after it was last turned off in order to protect the compressor.	The cooling differential is factory preset at 0.5°. This means that whenever the room temperature heats by 0.5° full degree from the temperature setting, the cooling system will turn on. If the cooling system turns on too often, increase the temperature differential setting. the	The heating differential is factory preset at 0.4°. This means that whenever the room temperature cools by 0.4° from the temperature heating system will turn on. If the heating system turns on too often, increase the temperature differential.
LCD will show						

FILTER Setting: Display SE FI, flashing 1000 (the default value 1000 hours), select from 50-2000 hours.

Temperature Calibration: Display CAL and flashing 0°F (the default value 0), select from -3-3°F.

Minimum compressor on time: Display AN ON and flashing OFF (default setting), select from OFF, 3, 4 or 5 minutes.

Compressor Delay Time Setting: Display CO OF and flashing ON (default setting), select from ON or OFF.

Cooling Differential Setting: Display df CO and flashing 0.6, choose from 0.2-2.0 (factory default setting: 0.6°F).

Heating Differential Setting: Display df HE and flashing 0.5, choose from 0.2-2.0 (factory default setting: 0.5°F).

°F/°C Selection: Setting F (Fahrenheit) or C (Celsius).

24H/12H Selection: Setting the 24 hour or 12 hour time format.

ELEC/GAS Selection: Select the ELEC or GAS.

TERMINAL DESIGNATIONS

W2 Auxiliary heat relay
Y Compressor relay
G Fan relay
O Heat pump reversing valve energized in cooling
RH 24VAC Power
C Common wire (if applicable)
B Heat pump reversing valve energized in heating
E Emergency heat relay

Note:

In many systems with no emergency heat relay, a jumper can be installed between E and W2.



Customer Service +1.800.304.6563

Technical Service +1.800.445.8299


HVACCustomerService@robertshaw.com

www.robertshaw.com • 352-00301-001

352-00310-001 Rev. B

© 2021 Robertshaw Controls Company.

Robertshaw ® is a trademark of Robertshaw Controls Company.




<https://qrstud.io/9ni5j5m>

6 Year Limited Warranty

Use Phone to Scan for Warranty Info

Documents / Resources

 The image shows the cover of the Robertshaw RS8210 Operation Manual. It features the Robertshaw logo at the top, followed by the model number "RS8210" and the text "Operation Manual" below it.	<p>Robertshaw RS8210 Non-Programmable Multi-Stage 2H-1C Wall Thermostat [pdf] User Manual</p> <p>RS8210 Non-Programmable Multi-Stage 2H-1C Wall Thermostat, RS8210, Non-Programmable Multi-Stage 2H-1C Wall Thermostat, Multi-Stage 2H-1C Wall Thermostat, Wall Thermostat, Thermostat</p>
--	--

References

-  [Robertshaw | Electronic controls, switches and valves](#)