



# RODSUMWIRELESS AC-RW-R120 Aroco WiFi Bridging Device User Manual

[Home](#) » [RODSUMWIRELESS](#) » RODSUMWIRELESS AC-RW-R120 Aroco WiFi Bridging Device User Manual 

## Contents

- [1 RODSUMWIRELESS AC-RW-R120 Aroco WiFi Bridging Device](#)
- [2 Instructions](#)
  - [2.1 Specification](#)
- [3 Function](#)
- [4 WiFi Configuration](#)
- [5 Documents / Resources](#)
- [6 Related Posts](#)

**RODSUM**WIRELESS

**RODSUMWIRELESS AC-RW-R120 Aroco WiFi Bridging Device**



## **Instructions**

AC-BW-R120 is WIFI client bridging device for receiving RF Beacon information. The device will send the beacons information to application server through the existing WIFI network. User can build own server to receive MQTT protocol data, or use existing Rodsum server with web interface.

## **Purpose**


This document will introduce the Device, provide the Specification, Functional, and WiFi reporting configuration method. MQTT protocol will not be included in this document. Please go to our website to download: <https://www.rodsum.com/downloads> to download protocol manual.

## **Specification**

|                                 |  |
|---------------------------------|--|
| <b>Mechanics Data</b>           |  |
| Size                            | Approx. 97.9 x 55.7 x 25.5 mm  |
| Weight                          | Approx. 69 grams   |
| Casing                          | PC/ABS Case  |
| <b>Electrics Data</b>           |  |
| Bluetooth Chip                  | Nordic nRF52840  |
| Bluetooth Frequency             | 2.4GHz   |
| Memory                          | 256kB Ram, 1MB Flash   |
| BLE Version                     | Bluetooth 5 compatible iBeacon compatible<br>BT4.2 Advertise Mode supported<br>Long Range (PHY Coded) Mode supported |
| BLE Transmission Range          | Up to 200m (with Long Range PHY Coded Mode)  |
| WiFi Transmission               | 802.11 bgn   |
| WiFi Frequency                  | 2.4GHz   |
| Power Input                     | 5VDC Input (with 1.1 meters USB Cable) 9-36VDC Input Port Reserved   |
| <b>Environmental Conditions</b> |  |
| Operating Temperature           | -25°C to +75°C   |
| Waterproof Rating               | IP68   |
| Material Resistance             | UV resistance  |

## Function


AC-BW-R120 Device will scan bluetooth normal or Coded PHY data, and report to server by MQTT protocol with ibeacon format or all type raw data, according device setting.



### AC-RW-R120

User can use the existing USB Cable Type A Connector to connect PC/ notebook or other 5VDC power supplier for device Power Input. 5V500mA or higher current supplier is recommended. Device has 3 LED indicators in the case to show the current working status.

**Green Circle:** LED Indicators (LED 3, LED 2, LED 1)



### Indicator LED Description


| LED          | Description       | Flashing 100ms<br>On 400ms Off) | Flashing 50ms<br>On 450ms Off | Flashing 150ms<br>On 350ms Off | Flashing 100ms<br>On 900ms Off |
|--------------|-------------------|---------------------------------|-------------------------------|--------------------------------|--------------------------------|
| LED1 (Red)   | Bluetooth Status  | Bluetooth Scanning              | –                             |                                |                                |
| LED2 (Green) | WiFi Connection   | –                               | No Connection                 | Connecting                     | Connected                      |
| LED3 (Blue)  | Server Connection | –                               | No Connection                 | Connecting                     | Connected                      |

### Enter Configuring Mode

- Unscrew the screw by Philips screwdriver. Open the cover



- Power On Device
- Press and Hold the Config button SW1 while the device Power On until LED 1 and LED 2 Flashing intermittently
- Use Mobile/PC to enable WiFi Network. SSID "ABW\_xxxxxxxxxxx" will be shown on the current searching list (xxxxxxxxxxx is the WiFi Module MAC Address).
- Connect the WiFi. Password: 12345678
- After the WiFi network connected, use the web browser to 192.168.4.1 to the Configuring page



- Blue Circle: SW1 Config Button
- Orange Circle: Reset Button
- Device only can enter configuring mode when power just On. User might need to press “RESET” button to reset the device and press and Hold SW1 button immediately.
- Mobile Connected Mobile Network might stop the configuring page access.



## WiFi Configuration

 192.168.4.1 15

# AROCO BT-WIFI V89

WiFi SSID:  (6-31 chars)

WiFi PSK:  (8-31 chars)

MQTT Server:  (5-63 chars)

MQTT Port:  (1-65535)

Username:  (0-31 chars)

Password:  (0-31 chars)

Report Topic:  (3-31 chars)

Device ID:  (6-31 chars)

NTP Server:  (empty or max 5-63 chars)

Expire Interval(s):  (3-604800)

Adv. report mode: ☐

Adv. raw data: ☐

Use Coded PHY: ☐

- WiFi SSID (6-31 chars)
- If new SSID length not in the range, the notice will be shown as below after press
- “Submit” button. SSID parameter cannot be updated. “Setting saved” notice will be shown if there is any other item updated correctly at the same time.

### SSID length incorrect

- Default: “wifissid”
- WiFi PSK: WiFi Password (8-31 chars)
- If new WiFi PSK length not in the range, the notice will be shown as below after press
- “Submit” button. WiFi PSK parameter cannot be updated. “Setting saved” notice will be shown if there is any other item updated correctly at the same time.

### PSK length incorrect

- Device cannot connect WiFi Network and report data to server if SSID or/and PSK parameter is incorrect
- Default: "12345678"
- MQTT Server: Report Server IP/domain (5-63 chars)
- If new MQTT Server length not in the range, the notice will be shown as below after press "Submit" button. MQTT Server parameter cannot be updated. "Setting saved" notice will be shown if there is any other item updated correctly at the same time.

### **SRV length incorrect**

- Default: "enter-your.server.com"
- MQTT Port: Report Server Port (1-65535)
- Server & Port cannot be empty
- If new MQTT Server value in the range, the notice will be shown as below after press
- "Submit" button. MQTT Server parameter cannot be updated. "Setting saved" notice will be shown if there is any other item updated correctly at the same time.

### **Port must be 1-65535**

- Default: "1883"
- Username: Data User name (0-31 chars)
- Default: empty
- Device will cut off to 31 chars and saved data if the new data user name length over 31 chars
- Password: Data Password (0-31 chars)
- Default: empty
- Device will cut off to 31 chars and saved data if the new data password length over 31 chars
- Report Topic: Data Topic (3-31 chars)
- If new Report Topic length not in the range, the notice will be shown as below after press "Submit" button. Report Topic parameter cannot be updated. "Setting saved" notice will be shown if there is any other item updated correctly at the same time.

### **Topic length incorrect**

- Default: "iotdata"
- Device ID: WiFi bridging Device ID (6-31 chars)
- If new Device ID length not in the range, the notice will be shown as below after press "Submit" button. Device ID parameter cannot be updated. "Setting saved" notice will be shown if there is any other item updated correctly at the same time.

### **DEV.ID length incorrect**

- Default: 16 chars Wifi bridge MAC address
- NTP SRV: Network Time Protocol Server for Device report data time (empty or max 5-63 chars)
- If new NTP Server length not in the range, the notice will be shown as below after press "Submit" button. NTP Server parameter cannot be updated. "Setting saved" notice will be shown if there is any other item updated



correctly at the same time.

### **NTP length incorrect**

- Default: "pool.ntp.org"
- Expire Interval(s): Data Expiry Interval (3-604800)
- If new Expire Interval value not in the range, the notice will be shown as below after press "Submit" button.  
Expire Interval parameter cannot be updated. "Setting saved" notice will be shown if there is any other item updated correctly at the same time.

### **Exp(s) not correct**

- Device will not report new scanned data to server if new data packet include MAC address, UUID, Major, Minor, battery level is scanned within the pre-set expiry interval (default: 5s).
- Adv. report mode: Report Mode Check Box.
- Device will report all scanned data to server without expiry filter checking when this function Enable.
- Adv. raw data: Raw Mode Check Box.
- Device will report all RAW data to server when this function is Enable
- Device will not report non iBeacon data to server when RAW function is Disable
- Use Coded PHY: Coded PHY check Box
- Device will scan Coded PHY (Long Range) data only when this function is Enable
- Device will scan BT4.2 Advertise data only when this function is Disable
- Submit: Submit button to update the configuration.
- Device will check all the setting
- "Setting saved" notice will be shown if there is any item updated correctly.

### **Settings saved**

- Parameter will be updated individually and shown related notice if any new parameter is not correct
- Default: Default button to set all configurations to default value.
- Device will set all configurations to default and reboot immediately. "REBOOT IN PROGRESS" message will be shown
- Reboot: Reboot button to reboot device back to normal operation
- Device will reboot immediately. "REBOOT IN PROGRESS" message will be shown

### **Leave Configuring Mode**

Press Reboot Button on the configuration page to reboot the device after all parameters set. Device will restart as normal mode to function.

### **Documents / Resources**

|   |  |
|---|--|
| <div data-bbox="142 107 272 302"><div data-bbox="142 107 183 123"></div><div data-bbox="142 129 272 156">Aroco AC-RW-R120 WiFi Bridging Device User Manual</div><div data-bbox="164 183 252 248"></div><div data-bbox="189 275 226 302">Aroco AC-RW-R120<br/>WiFi Bridging Device<br/>User Manual</div></div> | <div data-bbox="316 152 1473 264"><p><a href="#">RODSUMWIRELESS AC-RW-R120 Aroco WiFi Bridging Device</a> [pdf] User Manual<br/>AC-RW-R120, Aroco WiFi Bridging Device, WiFi Bridging Device, WiFi Bridging, AC-RW-R120, Bridging Device</p></div> |
|---|--|