



# Ruijie RG-RAP2260 Reyee Access Point User Guide

[Home](#) » [RuiJie](#) » Ruijie RG-RAP2260 Reyee Access Point User Guide 

## Contents

- 1 Ruijie RG-RAP2260 Reyee Access Point
- 2 Obtaining Technical Assistance
- 3 Related Documents
- 4 Documentation Conventions
- 5 Product Overview
- 6 Technical Specifications
  - 6.1 RG-RAP2260(G) Technical Specifications
  - 6.2 Hardware Installation and Reference Guide
- 7 Product Image
  - 7.1 Appearance of RG-RAP2260(G)
- 8 LED Indicator and Button
- 9 Power Sources
- 10 Cooling Solution
  - 10.1 The AP features a fanless design
- 11 Preparing for Installation
- 12 Installation
- 13 Movement
- 14 EMI
- 15 Ventilation
- 16 Temperature and Humidity
  - 16.1 Required Temperature and Humidity for the RG-RAP2260(G)
- 17 Cleanness
- 18 Power Supply
- 19 Technical Specifications of the DC Connector
- 20 Installation Tools
- 21 Unpacking the Access Point
  - 21.1 Package Contents
- 22 Installing the Access Point
- 23 Installation Flowchart
- 24 Before You Begin
- 25 Installing the Access Point
  - 25.1 Ceiling Mount
  - 25.2 Attaching the Mounting Bracket on the Ceiling/Wall
- 26 Connecting the Ethernet Cable to the LAN Port
- 27 Fastening the AP
- 28 Removing the Access Point
- 29 Connecting Cables
- 30 Bundling Cables

30.1 Bundling Steps
31 Checking after Installation
31.1 Checking the Cabinet
31.2 Checking Cable Connection
31.3 Checking the Power Supply
32 System Debugging
32.1 Setting up a Debugging Environment
32.2 Setting up the Environment
33 Powering up the AP
33.1 Checking before power-up
33.2 Checking after power up recommended
34 Monitoring and Maintenance
34.1 Monitoring
34.2 Hardware Maintenance
35 Troubleshooting
35.1 Troubleshooting Flowchart
35.2 LED does not light up after the AP is powered on
35.3 Ethernet port is not working after the Ethernet port is connected
35.4 Wireless client cannot find the AP
36 Appendix A Connectors and Media
36.1 1000BASE-T/100BASE-TX/10BASE-T
36.2 1000BASE-T Connection
36.3 100BASE-TX/10BASE-T Pin Assignments
36.4 Wiring of straight-through and crossover cables for 100BASE-TX/10BASE-T A-2 100BASE-TX/10BASE-T Connection
37 Appendix B Cabling Recommendations
38 Required Minimum Cable Bend Radius
38.1 Precautions for Cable Bundling
39 Cutting off Excess Cable Tie
40 Do Not Tie Cable Ties within the Bend
41 Fastening Cable Lugs
42 Documents / Resources
42.1 References
43 Related Posts



**Ruijie RG-RAP2260 Reyee Access Point**



Documents	Description
Configuration Guide	Describes network protocols and related mechanisms that supported by the product, with configuration examples.
Command Reference	Describes the related configuration commands, including command modes, parameter descriptions, usage guides, and related examples.

## Documentation Conventions

The symbols used in this document are described as below



This symbol brings your attention to some helpful suggestions and references.



This symbol means that you must be extremely careful not to do some things that may damage the device or cause data loss

## Product Overview

Featuring leading 802.11ax and MU-MIMO, Ruijie RG-RAP2260(G) supports 2 spatial streams and delivers up to 574Mbps at 2.4G and 1201Mbps at 5G. The overall dual-radio dual-band performance speeds up to 1.775Gbps per device, totally eliminating Gigabit wireless bottlenecks. RG-RAP2260(G) adopts either local power supply or PoE+ power supply, and can be ceiling-mounted in indoor Wi-Fi coverage scenarios with large areas. RG-RAP2260(G) provides two Gigabit Ethernet ports, making it possible to connect a camera or switch device to adapt to challenges in a wide variety of deployment scenarios.

## Technical Specifications

### RG-RAP2260(G) Technical Specifications

<b>Model</b>	RG-RAP2260(G)
<b>RF</b>	Dual-band and dual-radio
<b>Transmission Protocol</b>	Support concurrent 802.11ax, 802.11ac wave2/wave1 and 802.11a/b/g/n.
<b>Operating Bands</b>	802.11b/g/n/ax: 2.4 GHz to 2.4835 GHz 802.11a/n/ac/ax: 5.15 GHz to 5.35 GHz, 5.725 GHz to 5.85 GHz
<b>Antenna</b>	Array antenna 2.4G: 3dBi, 5G: 3dBi

<b>Spatial Streams</b>	<p>2.4G: 2 x 2 MIMO</p> <p>5G: 2 x 2 MIMO</p>
<b>Max Throughput</b>	<p>2.4G: up to 574 Mbps 5G: up to 1201 Mbps</p> <p>Up to 1.775 Gbps per AP</p>
<b>Modulation</b>	<p>OFDM: BPSK6/9Mbps, QPSK12/18Mbps, 16QAM24Mbps, 64QAM48/54Mbps DSSS: DBP SK1Mbps, DQPSK2Mbps, CCK5.5/11Mbps</p> <p>MIMO-OFDM: BPSK, QPSK, 16QAM, 64QAM, 256QAM, 1024QAM</p> <p>OFDMA</p>

<b>Receive Sensitivity</b>	<p>11b: -96dBm(1Mbps), -93dBm(5Mbps), 89dBm(11Mbps)</p> <p>11a/g: -91dBm(6Mbps), -85dBm(24Mbps), 80dBm(36Mbps), -74dBm(54Mbps) 11n: 90dBm(MCS0), -70dBm(MCS7), -89dBm(MCS8), 68dBm(MCS15)</p> <p>11ac: 20MHz: 88dBm(MCS0), 63dBm(MCS9)</p> <p>11ac: 40MHz: 85dBm(MCS0), 60dBm(MCS9)</p> <p>11ac: 80MHz: 85dBm(MCS0), 60dBm(MCS9)</p> <p>11ax: 80MHz: -82dBm(MCS0), -57dBm(MCS9), -52dBm(MCS11)</p>
<b>Transmit Power</b>	≤100mw (20 dBm) (adjustable)
<b>Transmit Power Adjustment</b>	1 dBm
<b>Dimensions W x D x H</b>	194 mm x 194 mm x 35 mm 7.6 in. x 7.6 in. x 1.4 in excluding brackets

<b>Weight</b>	0.56 kg excluding brackets
<b>Service Ports</b>	

<b>Management Ports</b>	N/A
<b>LED</b>	1 LED green
<b>Power Supply</b>	Adapter: DC 12 V/1.5 A optional PoE: IEEE 802.3at compliant (compatible).
<b>Power Consumption</b>	< 15.3W
<b>Bluetooth 5.0</b>	Support



<b>Temperature</b>	Operating: 0°C to 40°C (32°F to 104°F)
	Storage: -40°C to 70°C -40°F to 158°F
<b>Humidity</b>	Operating: 5% to 95% RH non condensing
	Storage: 5% to 95% RH (non-condensing)
<b>Installation</b>	Ceiling/wall mounting
<b>Safety Standards</b>	GB4943 IEC 60950-1
<b>EMC Standards</b>	GB9254 EN301 489 EN50155 EN50121
<b>Mechanical Vibration</b>	IEC61373

<b>Radio</b>	China Radio Transmission Equipment Type Approval Certificate EN300 328 EN301 893
<b>MTBF</b>	> 400,000 H

**Hardware Installation and Reference Guide**

Weight refers to the weight of host.

**Product Image**

The AP provides two 10/100/1000Base-T Ethernet ports (LAN1/PoE port is PoE+-capable), one power port for an external power supply and one reset button.

**Appearance of RG-RAP2260(G)**



**LED Indicator and Button**

LED ator and Button	Indic State	Frequency	Meaning
LED Indicator	Off	N/A	The AP is NOT receiving power.
	Blinking	0.5Hz	Normal operation, but there are alarms.
	Fast blinking	10Hz	Possible cases: Restoring the factory settings Upgrading the firmware Restoring the image file Initializing the device
	Solid green	N/A	Normal operation.
Reset Button	Press for less than 2 seconds		Restart the device.
	Press for more than 5 seconds		Restore the factory settings.

## Power Sources

The AP can be powered either with a power adapter or through Power over Ethernet (PoE).

- Use DC power adapters with specifications recommended by Ruijie.
- The power adapter is customer-supplied.
- To use a PoE device, make sure that it supports the IEEE 802.3at standard.

## Cooling Solution

The AP features a fanless design

Leave sufficient space surrounding the AP when installing the AP to permit proper airflow for ventilation.

## **Preparing for Installation**

- To prevent device damage and physical injury.
- Recommendations do not cover all possible hazardous situations.

## **Installation**

The AP must be installed indoors. To ensure normal operation, the installation site must meet the following requirements.

- Install the AP in a well-ventilated environment. If it is installed in a closed room, make sure there is a good cooling system.
- Make sure the site is sturdy enough to support the AP and its accessories.
- Make sure the site has enough space for installing the AP and leave sufficient room around the AP for ventilation.
- Do not expose the AP to high temperature, dust, or harmful gases.
- Do not install the AP in an area prone to fire or explosions.
- Keep the AP away from EMI sources such as large radar stations, radio stations, and substations.
- Do not subject the AP to unstable voltage, vibration, and noises.
- Keep the AP at least 500 meters away from the ocean and do not face it towards the sea breeze.
- The installation site should be free from water including possible flooding, seepage, dripping, or condensation.
- The installation site should be selected according to network planning and communications equipment features, and considerations such as climate, hydrology, geology, earthquake, electrical power, and transportation.

## **Movement**

- Avoid frequently moving the device.
- Turn off all power supplies and unplug all power cables before you remove the device.

## **EMI**

- Please observe local regulations and specifications when performing electrical operations.
- Relevant operators must be qualified.
- Carefully check for any potential hazards in the working area such as damp/wet ground or floors.
- Find the location of the emergency power supply switch in the room before installation.
- Cut off the power supply first in case of an accident.
- Be sure to make a careful check before shutting down the power supply.
- Do not place the device in a damp/wet location. Do not let any liquid enter the chassis.
- Keep the AP far away from grounding or lightning protection devices for power equipment.
- Keep the AP away from radio stations, radar stations, high-frequency high-current devices, and microwave ovens.
- Any nonstandard and inaccurate electrical operation can cause an accident such as fire or electric shock, thus

causing severe even fatal damages to humans and devices.

- Direct or indirect contact with a wet object (or your finger) on the high voltage and power line can be fatal.

## Ventilation

For proper ventilation, leave sufficient space around the AP.

## Temperature and Humidity

To ensure the normal operation and equipment service life, maintain appropriate temperature and humidity levels in the equipment room. Improper room temperature and humidity can cause damage to the device.

- High relative humidity may affect insulation materials, resulting in poor insulation and even electrical leakage.
- Sometimes it may lead to changes in the mechanical properties of materials and corrosion of metal parts.
- Low relative humidity can dry and shrink insulation sheets and cause static electricity that can damage the circuitry.
- High temperatures greatly reduce device reliability and shorten service life.

### Required Temperature and Humidity for the RG-RAP2260(G)

Temperature	Relative Humidity
0°C to 40°C 32°F to 104°F	5% to 95%

## Cleanness

Maximum diameter $\mu\text{m}$	0.5	1	3	5
Maximum concentration Particles/ $\text{m}^3$	$1.4 \times 10^7$	$7 \times 10^5$	$2.4 \times 10^5$	$1.3 \times 10^5$

Dust poses a serious threat to device operation. Dust on the surface of the device can be absorbed onto metal contact points by static electricity causing poor contact. Electrostatic absorption of dust occurs more easily when the relative humidity is low, and might shorten the equipment service life and cause communication failures the maximum concentration and diameter of dust allowed in the equipment room.

Gas	Average mg/m <sup>3</sup>	Maximum mg/m <sup>3</sup>
SO <sub>2</sub>	0.2	1.5
H <sub>2</sub> S	0.006	0.03
NO <sub>2</sub>	0.04	0.15
NH <sub>3</sub>	0.05	0.15
Cl <sub>2</sub>	0.01	0.3

The amount of salt, acids and sulfides in the air are also strictly limited for the equipment room. These substances can accelerate metal corrosion and aging of some parts. Table 2-3 describes the limits of some hazardous gases such as SO<sub>2</sub>, H<sub>2</sub>S, NO<sub>2</sub> and Cl<sub>2</sub> in the equipment room.

## Power Supply

- DC power adapter:
- Input voltage: 12V
- Rated current: 1.5A
- PoE+ injector: IEEE 802.3at compliant

Inner Diameter	Outer Diameter	Insertion Depth	Conductor Impedance	Voltage endurance Impedance	Voltage endurance Insulator and Conductor	Polarity
2.10+/-0.05 mm	5.50+/-0.05 mm	9mm	5Ω	100MΩ	1000V	Inner pole: positive Outer pole: negative

## Technical Specifications of the DC Connector

The DC input power should be greater than the power actually consumed by the system. Use DC power adapters with specifications recommended by Ruijie. Please use Ruijie certified PoE injectors.

## Installation Tools

<b>Common Tools</b>	Phillips (crosshead) screwdriver, copper and fiber cables, bolts, diagonal pliers, cable ties
<b>Special Tools</b>	Wire stripper, crimping pliers, RJ-45 crimping pliers, punch down tool
<b>Meter</b>	Multimeter, bit error rate tester BERT

The tools listed above are customer supplied.

## Unpacking the Access Point

### Package Contents


<b>Items</b>	<p>Verify that all parts are installed and debugged. Screws</p> <p>Mounting brackets</p> <p>Product quick installation guide</p> <p>Q.C. certificate</p>
--------------	--

The above listed items are for general situations, and contents may vary in the actual shipment. The purchasing order shall prevail in any case. Please check each item carefully according to the packing list or purchasing order. If any item is damaged or missing, notify your sales representative.

## Installing the Access Point

The RG-RAP2260(G) series must be fixed and installed indoors.

### Installation Flowchart



## Before You Begin

Before installing the AP, verify that:

- The installation site provides sufficient ventilation for the AP.
- The installation site meets temperature and humidity requirements.
- The installation site is equipped with a proper power supply.
- Network cables are in place.
- The installation site meets all described requirements.
- The custom AP meets customer requirements.

## Precautions

To avoid damage to the AP, observe the following safety precautions:


- Do not power on the device during installation.
- Install the device in a well ventilated location.
- Do not subject the device to high temperatures.
- Keep away from high voltage cables.
- Install the device indoors.
- Do not expose the device in a thunderstorm or strong electric field.
- Keep the device clean and dust free.
- Disconnect the device before cleaning it.
- Do not wipe the device with a damp cloth.
- Do not wash the device with liquid.
- Do not open the enclosure when the AP is working.
- Fasten the device tightly.

## Installing the Access Point

### Ceiling Mount

Attach the mounting bracket on the ceiling or wall.


#### Attaching the Mounting Bracket on the Ceiling/Wall



Connect the Ethernet cable to the LAN port on the rear of AP


### Connecting the Ethernet Cable to the LAN Port





Align the square feet on the rear of the AP over the mounting holes on the bracket. Slide the AP into the holes until it clicks into place.

### **Fastening the AP**



- Install the Ethernet cables before mounting the AP on the bracket.
- The AP can be installed in any of four directions on the mounting bracket depending on how you route the Ethernet cable.
- The square feet should fit easily into the mounting slots.
- Do not forcibly push the AP into the slots.
- After installation, verify that the AP is securely fastened.

### **Removing the Access Point**

Hold the AP in your hands and push it upward and away from the bracket in the arrow direction.

### **Connecting Cables**

Connect the UTP/STP to the LAN1/PoE port on the AP. See Appendix A for the supported wiring for twisted pairs.

- Avoid bending the cable in a small radius close to the connector.
- Ruijie recommends that you do not use Ethernet cables with protective sleeves as they could make installation of Ethernet cables more difficult.

## **Bundling Cables**

### **Precautions**

- Make sure the cable bundles are neat and orderly.
- Bend twisted pairs naturally or in a large radius close to the connector.
- Do not over tighten a cable bundle as it may reduce cable life and performance.

### **Bundling Steps**

1. Bundle the drop UTP/STP cables and route them to the LAN/PoE port.
2. Attach the cables in the cable tray of the rack.
3. Extend the cables under the AP and run in a straight line.

## **Checking after Installation**

### **Checking the Cabinet**

- Make sure the external power supply matches the patch panel specifications for the cabinet.
- After installation, make sure that the front and rear cabinet doors easily close.
- Make sure the cabinet is stable and level.
- Make sure the device and all cables are securely fastened in the rack.

### **Checking Cable Connection**

- Make sure the UTP/STP cable matches the interface type.
- Make sure cables are properly bundled.

### **Checking the Power Supply**

- Make sure all power cables are properly connected and safe.
- Make sure the AP is operational after powering on.

## **System Debugging**

### **Setting up a Debugging Environment**

Use a power adapter or PoE to power the AP.

### **Setting up the Environment**

- Verify that the AP is properly connected to the power source.
- Connect the AP to a wireless controller through a twisted pair cable.
- When the AP is connected to a PC for debugging, verify that the PC and PoE switch are properly grounded.

## **Powering up the AP**

### **Checking before power-up**

- Verify that the power supply is properly connected.
- Verify that the input voltage matches the specification of the AP.

### **Checking after power up recommended**

After powering up, it is recommended that you check the following to ensure normal operation of the AP.

- Check if any message is displayed on the Web-based configuration interface for the wireless controller.
- Check if the LED works normally.

## **Monitoring and Maintenance**

### **Monitoring**


When RG-RAP2260(G) is operating, you can monitor its status by observing the LED indicator.

### **Hardware Maintenance**

If the hardware is faulty, please contact our Technical Assistance Center (TAC) for help.

## **Troubleshooting**

### **Troubleshooting Flowchart**



#### **LED does not light up after the AP is powered on**

- If you use PoE power supply, verify that the power source is IEEE 802.11at compliant; then verify that the cable is properly connected.
- If you use a power adapter, verify that the power adapter is connected to an active power outlet; then verify that the power adapter works properly.

#### **Ethernet port is not working after the Ethernet port is connected**

- Verify that the device at the other end of the Ethernet cable is working properly.
- And then verify that the Ethernet cable is capable of providing the required data rate and is properly connected.

#### **Wireless client cannot find the AP**

- First, follow the two steps above.
- Verify that the AP is correctly configured.
- Adjust the angle of the antennas.
- Move the client device to adjust the distance between the client and the AP.

## **Appendix A Connectors and Media**

## 1000BASE-T/100BASE-TX/10BASE-T

The 1000BASE-T/100BASE-TX/10BASE-T is a 10/100/1000 Mbps auto-negotiation port that supports auto MDI/MDIX. Compliant with IEEE 802.3ab, 1000BASE-T requires Category 5e 100-ohm UTP or STP (STP is recommended) with a maximum distance of 100 meters (328 feet). 1000BASE-T requires all four pairs of wires be connected for data transmission.

### 1000BASE-T Connection

Straight-Through		Crossover	
Switch	Switch	Switch	Switch
1 TP0+	←→ 1 TP0+	1 TP0+ ←→ 2 TP0-	1 TP0+
2 TP0-	←→ 2 TP0-	2 TP0- ←→ 1 TP0+	2 TP0-
3 TP1+	←→ 3 TP1+	3 TP1+ ←→ 6 TP1-	3 TP1+
6 TP1-	←→ 6 TP1-	6 TP1- ←→ 3 TP1+	6 TP1-
4 TP2+	←→ 4 TP2+	4 TP2+ ←→ 5 TP2-	4 TP2+
5 TP2-	←→ 5 TP2-	5 TP2- ←→ 4 TP2+	5 TP2-
7 TP3+	←→ 7 TP3+	7 TP3+ ←→ 8 TP3-	7 TP3+
8 TP3-	←→ 8 TP3-	8 TP3- ←→ 7 TP3+	8 TP3-

10BASE-T uses Category 3, 4, 5 100-ohm UTP/STP and 1000BASE-T uses Category 5 100-ohm UTP/STP for connections. Both support a maximum length of 100 meters. Table A-1 shows 100BASE-TX/10BASE-T pin assignments.

### 100BASE-TX/10BASE-T Pin Assignments

#### Wiring of straight-through and crossover cables for 100BASE-TX/10BASE-T A-2 100BASE-TX/10BASE-T Connection

Straight-Through		Crossover	
Switch	Switch	Switch	Switch
1 IRD+	←→ 1 OTD+	1 IRD+ ←→ 2 IRD-	1 IRD+
2 IRD-	←→ 2 OTD-	2 IRD- ←→ 1 IRD+	2 IRD-
3 OTD+	←→ 3 IRD+	3 OTD+ ←→ 6 OTD-	3 OTD+
6 OTD-	←→ 6 IRD-	6 OTD- ←→ 3 OTD+	6 OTD-

## Appendix B Cabling Recommendations

During installation, route cable bundles upward or downward along the sides of the rack depending on the actual situation in the equipment room. All cable connectors should be placed at the bottom of the cabinet rather than be exposed outside of the cabinet. Power cords should be routed upward or downward beside the cabinet close to the location of the DC power distribution cabinet, AC power outlet, or lightning protection box.


### Required Minimum Cable Bend Radius

- The minimum bend radius of a power, communication or flat cable should be 5 times the overall diameter of the cable. If the cable is constantly bent, plugged or unplugged, the bend radius should be 7 times the overall diameter.
- The minimum bend radius of a coaxial cable should be 7 times the overall diameter of the cable.

- If the cable is constantly bent, plugged or unplugged, the bend radius should be 10 times the overall diameter.
- The minimum bend radius of a high-speed cable, such as an SFP+ cable should be 5 times the overall diameter of the cable.
- If the cable is constantly bent, plugged or unplugged, the bend radius should be 10 times the overall diameter.



#### Precautions for Cable Bundling

Before bundling cables, correctly mark labels and stick the labels to cables where appropriate. Cables should be neatly and properly bundled.





- Route and bundle power, signal, ground cables separately. When the cables are close to each other, cross them.
- When power cables run parallel to signal cables, the distance between them must be greater than 30 mm.
- All cable trays and their accessories shall be smooth and free from sharp edges.
- Holes in metal, through which cables pass shall have smooth, well-rounded surfaces or be protected with insulating bushings.
- Use proper cable ties to bind cables together.
- Do not tie two or more cable ties to bind cables.
- Cut off excess cable tie cleanly with no sharp edges after bundling cables.

#### Cutting off Excess Cable Tie




If cables are to be bent, bind them first but do not tie cable ties within the bend to avoid stress on the cables, which may otherwise cause the wires inside to break.

### **Do Not Tie Cable Ties within the Bend**



- Wrap up unnecessary or excess cables and bind them to the appropriate rack position, where device operation is not affected and no damages occur to the device and cables during debugging.
- Do not bind power cords to the rails for moving parts.
- Leave a certain length of the cable connecting moving parts, such as the ground wire of the cabinet door, to avoid stress on the cable.
- When moving parts are in place, ensure the excess cable length shall not contact heat sources, sharp corners or edges.
- If heat sources are unavoidable, use high temperature cables instead.
- When using screws to fasten cable lugs, the bolts or nuts shall be tightened and prevented from loosening.

### **Fastening Cable Lugs**



1. Flat washer
2. Nut
3. Spring washer
4. Flat washer

- When using a stiff cable, fix it near the cable lug to avoid stress on the lug and cable.
- Do not use self-tapping screws to fasten terminals.
- Bundle cables of the same type and running in the same direction into groups.
- Keep cables clean and straight.
- Cables shall be tied according to the following table.

Diameter of Cable Bundle mm	Space between Bundles mm
10	80 to 150
10 to 30	150 to 200
30	200 to 300

Do not tie knots for cables or cable bundles. The metal parts of the cold-pressed terminal blocks, such as air circuit breakers, shall not be exposed outside of the blocks.

## Documents / Resources

	<a href="#">Ruijie RG-RAP2260 Reyee Access Point</a> [pdf] User Guide RG-RAP2260, Reyee Access Point, RG-RAP2260 Reyee Access Point
--	--

## References



- [!\[\]\(71ac35c616fd8bfda805d579390e24d8\_img.jpg\) csm](#)
- [!\[\]\(b10a8b91056068472be58f587e00cb47\_img.jpg\) csm](#)
- [!\[\]\(26a0aa65ffdf9b4c0922ec277970eeda\_img.jpg\) cn.bing.com/dict/clientsearch?mkt=zh-CN&setLang=zh&form=BDVEHC&ClientVer=BDDTV3.5.1.4320&q=%E8%80%90%E5%8E%8B](https://cn.bing.com/dict/clientsearch?mkt=zh-CN&setLang=zh&form=BDVEHC&ClientVer=BDDTV3.5.1.4320&q=%E8%80%90%E5%8E%8B)
- [!\[\]\(94aeee9c39a3a3d10654831c4bdd6b76\_img.jpg\) Ruijie Community](#)
- [!\[\]\(3e6c1aedeeaa8d5deb59d3ee4ab46da3\_img.jpg\) Ruijie Community](#)
- [!\[\]\(c902edf397a6ca641da2827a7619fb31\_img.jpg\) Support Center - Ruijie Reeye](#)
- [!\[\]\(2eeb38d109c7620c04b72105577a1616\_img.jpg\) Ruijie Networks | Network Devices and Solutions Provider](#)
- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.