




## RunCam Link Wasp Camera User Manual

[Home](#) » [RunCam](#) » RunCam Link Wasp Camera User Manual 



RunCam link Wasp




## RunCam Wasp Manual

### Contents

- [1 Introduction](#)
- [2 Connection](#)
- [3 Activation](#)
- [4 Linking](#)
- [5 Dimensions](#)
- [6 Documents / Resources](#)
  - [6.1 References](#)
- [7 Related Posts](#)

## Introduction


The RUNCAM LINK Digital FPV Air Unit is an advanced video transmission module that supports a 5.8 GHz digital video signal and 1280 x 720 60fps image transmission, with a transmission range of up to 4 km and a minimum end-to-end latency within 32 ms\*. The air unit can be mounted on a racing drone and used with DJI FPV Goggles or a remote controller to transmit video, control signals, and flight controller information wirelessly.



\* The end-to-end latency is the total time from camera input to screen display. The device is able to reach its minimum latency and maximum transmission distance (FCC) in a wide open area with no electromagnetic interference

## Connection

Refer to the illustration below to mount and connect the air unit to a racing drone.



	<b>RED:</b> Power (7.4-26.4 V)
	<b>BLACK:</b> Power GND
	<b>WHITE:</b> UART-RX (Connects to Flight Controller OSD TX, 0-3.3 V)
	<b>GRAY:</b> UART-TX (Connects to Flight Controller OSD RX, 0-3.3 V)
	<b>BLACK:</b> Signal GND
	<b>YELLOW:</b> DJI HDL (Connects to Flight Controller S.Bus, 0-3.3 V)

1. An electric soldering iron and soldering tin are required for connection. Make sure that there are no short

circuits or open circuits when soldering the cables.

2. There are up to eight channels for the air unit depending on the region (FCC: eight, CE/SRRC: four, MIC: three). Each channel has a bandwidth of 20 MHz. The public channel is 8, which is the default channel when the equipment is powered on. The channel can be changed manually to avoid interference from other devices.
3. The air unit may become hot during or after operation. DO NOT touch the air unit before it cools down.
4. DO NOT use the air unit for an extended period when the temperature is high or there is poor ventilation. Otherwise, the air unit may overheat and enter lowpower mode which will affect its performance. If the air unit enters low-power mode, restart it or wait for it to cool down and it will automatically return to normal.


## Activation

When powered on, connect the air unit to your computer and run DJI ASSISTANT™ 2 for activation. Download DJI Assistant 2 at <https://www.dji.com/fpv/downloads>

## Linking


The air unit support three linking methods: A, B, and A+B (Must link A before B).

A




1. Power on the air unit and the DJI FPV Goggles.
2. Press the link button on the air unit and the goggles.\*
3. The linking status indicator of the air unit turns solid green. The goggles stop beeping when successfully linked and the video display is normal.

B




1. Power on the air unit and the DJI FPV Remote Controller.
  2. Press the link button on the air unit, and then press the record button, C button, and right dial on the remote controller simultaneously.\*
  3. Both the linking status indicators turn solid green when successfully linked.
- \* When ready to link, the devices will give the following indication: Air unit: the linking status indicator turns solid red. Goggles: the goggles beep continually. Remote controller: the remote controller beeps continually and the status indicator blinks blue.

## Dimensions



## Documents / Resources



- [!\[\]\(27c3f183a8911a7dac26d53c513f13df\_img.jpg\) DJI Digital FPV System - Product Information - DJI](#)