



SALSIFY RC-100 Sensor Remote Programmer Instruction Manual

[Home](#) » [SALSIFY](#) » SALSIFY RC-100 Sensor Remote Programmer Instruction Manual 

SALSIFY RC-100 Sensor Remote Programmer Instruction Manual



Contents

- 1 SPECIFICATIONS
- 2 OVERVIEW
- 3 LED INDICATORS
- 4 BUTTON OPERATION
- 5 SETTING
- 6 Corridor Function
 - 6.1 Daylight Sensor Function
- 7 Documents / Resources
- 8 Related Posts

SPECIFICATIONS

Power supply	2 x AAA 1.5V battery, Alkaline preferred
Carrying case	RC-100 in carrying case
Upload range	Up to 15 m (50 ft.)
Op. temperature	0°C~50°C (32°F~122°F)
Dimensions	123 x 70 x 20.3 mm (4.84" x 2.76" x 0.8")



WARNING



Remove the batteries from compartment if the remote will not be used in 30 days.

OVERVIEW

The remote control Wireless IR Configuration Tool is a handheld tool for remote configuration of IR-enabled fixture integrated sensors. The tool enables device to modify via pushbutton without ladders or tools, and stores up to four sensor parameter modes to speed configuration of multiple sensors.

















The remote control uses bidirectional IR communication to send and receive sensor settings at mounting height up to 50 feet. The device can display previously established sensor parameters, copy parameters and send new parameters or store parameter profiles. For projects where identical settings may be desired across a large number of areas or spaces, this capability provides a streamlined method of configuration. Settings can be copied throughout a site, or in different sites.












LED INDICATORS

LED	DESCRIPTION	LED	DESCRIPTION
BRIGHTNESS	High end trim turning function(To Set the output level of connected lighting during occupancy)		To select the current surrounding lux value as the daylight threshold. This feature enables the fixture to function well in any real application circumstances.
SENSITIVITY	To set the occupancy sensing sensitivity of the Sensor		The daylight sensor stops working, and all motion detected could turn on the lighting fixture, no matter how bright the natural light is.
HOLD TIME	The time that the Sensor will turn off(if you choose stand-by level is 0) or dim the light to a low level after the area is vacated	STAND-BY DIM	To set the output level of connected lighting during vacancy. The sensor will regulate the lighting output at the set level. Setting the STAND-BY DIM level at 0 means light full off during vacancy.
DAYLIGHT SENSOR	To represents various thresholds of natural light level for the Sensor .	STAND-BY TIME	To represents the time that the Sensor will keep the light at low dim level after the HOLD TIME elapsed.

BUTTON OPERATION

BUTTON	DESCRIPTION	BUTTON	DESCRIPTION
--------	-------------	--------	-------------










 ON/ OFF	<p>Press the ON/OFF button, the light goes to permanent on or permanent off mode, and the sensor is disabled.</p> <p>(MUST press.  button to quit this mode for Setting.</p>	 AUTO	<p>Press.  button, the sensor starts to function and all settings remain the same as the latest status before the light is switched on/off.</p>
 DISP	<p>Display the current/latest setting parameters in LED indicators(the LED indicators will on for showing the setting parameters).</p>		<p>The button  is for testing purpose sensitivity only. after you choose sensitivity thresholds, then you press</p>
 RESE T	<p>Press  button, all settings go back to settings of dip Switch in sensor.</p>	 TEST 2s	<p> button, The sensor goes to test mode(hold time is only 2s) automatically ,meanwhile the stand-by period and daylight sensor are disabled. Press.  button to quit from this mode.</p>
 	<p>Enter in the setting condition, the parameter leds of remote control will flash to be selected. and Navigate to UP and Down for choose selected parameters in LED indicators.</p>	 	<p>Navigate to LEFT and RIGHT for choose selected parameters in LED indicators.</p>
 OK	<p>Confirm the selected parameters selected parameters in remote control.</p>		

 SEND	 Press  button, upload the current parameters to sensor(s), the led light which the sensor connects will on/off as confirm.		Open and close smart daylight Sensor . Press  or  Enter in the setting condition, the parameter leds of remote control will flash to be selected, Press  for open or close smart daylight Sensor.
   	4 Scene modes with preset parameters which are available to be changed and saved in modes.		

SETTING

The SETTING Content contains all available settings and parameters for remote sensors. It allows you to change the available control, parameters, and operation of the sensor from factory default or current parameters.

Change multiple settings of sensor(s)




1. Press  button, the remote control leds will show the latest parameters you set.
NOTE: if you push  button before, you must push  button to unlock the sensor.
2. Press  or  enter in the setting condition, the parameter leds of remote control will flash to be selected, navigate to the desired setting by pressing     to select the new parameters.
3. Press ok to confirm all setting and saving.
4. Aim at the target sensor and press to upload the new parameter, the led light which the sensor connects will on/off as confirm.










NOTE: the setting works key step is by Push  or  , enter in the setting condition.


NOTE: the led light which the sensor connects will on/off after getting the new parameter as confirm.









NOTE: If you press  button, the remote led indicators will show the latest parameters which were sent.

Change multiple setting of sensors with smart photocell sensor Open

1. Press  , the remote led indicators will show the latest parameters.
2. Press  or  enter in the setting condition, the parameter Led indicators of remote control will flash to be selected.

3. Press  ,2 led indicators will flash in daylight sensor settings ,select daylight    as setpoint to light on Automatically , select daylight    as setpoint to light off Automatically.
4. Press  to confirm all setting and saving
5. Aim at the target sensor and press  to upload the new parameter. The led light which the sensor connects will on/off.

NOTE:  is disabled by default

1. Open or close the smart daylight sensor by push  when remote control is in setting condition.
2. When the smart daylight sensor open, 2 Led indicators are flash in daylight sensor setting. select daylight    as setpoint to light on Automatically , select daylight    as setpoint to light off automatically. When smart daylight sensor close, 1 Led indicator is flash in the daylight sensor setting for choose daylight sensor threshold.
3. When the smart daylight sensor open, the stand-by time is only  .
4. Smart daylight sensor takes place of normal photocell sensor and works independently.


Corridor Function

This function inside the motion sensor to achieve tri-level control, for some areas which require a light change notice before switch-off. The sensor offers 3 levels of light: 100%—>dimmed light (natural light is insufficient) —>off; and 2 periods of selectable waiting time: motion hold-time and stand-by period; Selectable daylight threshold and freedom of detection area.


- With sufficient natural light, the light does not switch on when presence is detected.



- With insufficient natural light, the sensor switches on the light automatically when presence is detected.



- After hold-time, the light dims to stand-by level if the surrounding natural light is below the daylight threshold.



- Light switches off automatically after the stand-by period elapses.



Daylight Sensor Function

Open the daylight sensor by push  when remote control is in setting condition.

Settings on this demonstration

Hold-time: 30min
setpointtolighton: 50lux
Stand-by Dim: 10%
Stand-by period: $+\infty$

setpoint to light off: 300lux

(when the smart photocell sensor open, the stand-by time is only $+\infty$)


- The light switches on at 100% when there is movement detected.



- The light dims to stand-by level after the hold-time.




- The light remains in dimming level at night.




1 ↔ 3 goes in cycle
at night ...

100% on when movement
detected, and dims to 10%
in long absence.

- When the natural light level exceeds setpoint off to light, the light will turn off even if when the space is occupied.



- The light automatically turns on at 10% when natural light is insufficient (no motion).



Corridor Function VS Daylight Sensor Function





1. In corridor function, turn on the light **MUST** by natural light level lower daylight sensor setting and Occupancy. In smart daylight sensor function, turn on the light by natural light level lower daylight setpoint to light on even if vacancy.
2. In corridor function, turn off light by stand-by time finish if vacancy. In smart daylight sensor function, turn off the light by natural light level higher than daylight setpoint to light off even if occupancy.
3. In smart daylight sensor function, natural light level lighter/lower than daylight setpoint to light off/on **MUST** keep at least 1mintue,that will turn off/on the light automatically.

About RESET and MODE(1,2,3,4)





The remote control comes with 4 Scene MODES which are not default. You may make desired parameters and save as the new MODE(1,2,3,4) to configure the installed sensors.

RESET: all settings go back to settings of DIP Switch in sensor.

SCENE MODES(1 2 3 4)

MODE	BRIGHTNESS	SENSITIVITY	HOLD TIME	DAYLIGHT SENSOR	STAND-BY DIM	STAND-BY TIME
MODE1	70%	20%	10s		0%	+ ∞
MODE2	70%	20%	10s		0%	+ ∞
MODE3	70%	20%	10s		0%	+ ∞
MODE4	70%	20%	10s		0%	+ ∞






Change the MODES


1. press  /  /  /  button, the remote control Led indicators show existing parameters.
2. press to select the new parameters.
3. Press to confirm all parameters and saving in the mode.

UPLOAD


The upload function allows you to configure the sensor with all parameters in one operation. You may select CURRENT SETTING parameters or the MODE for uploading. Current setting parameters or the MODE are displayed in Remote control .

Upload the current parameters to sensor(s), and duplicate the sensor parameters from one to another

1. Press button or press  /  /  /  , all parameters are displayed in Remote control
Note: check if all parameters are correct , if not, change them.
2. Aim at the sensor and press  button , the light that sensor connects will be on/off as confirm.

Note: if other sensor need same parameters, just aim at the sensor and press  button.

Documents / Resources



[SALSIFY RC-100 Sensor Remote Programmer](#) [pdf] Instruction Manual
RC-100, Sensor Remote Programmer, RC-100 Sensor Remote Programmer