





SECURITY BRANDS 27-210 EDGE E1 Smart Keypad with Intercom Access Control System User Guide

[Home](#) » [SECURITY BRANDS](#) » SECURITY BRANDS 27-210 EDGE E1 Smart Keypad with Intercom Access Control System User Guide 



QUICK START GUIDE

EDGE E¹



Model 27-210, 27-21

1. Unpack the box and make sure you have all items shown here. (Screwdriver not shown.)



Edge Unit
(27-210 shown)



12-V AC/DC Adapter
(PS-12DC1)



Key




Carriage Bolt
(4x)




Hex Nut
(4x)

2. Unlock and open the front panel of the unit for mounting, wiring, and setup.



3. Mount unit to pedestal using included mounting hardware.

(This step may be completed later.)



WARNING



AUTOMATIC GATES CAN CAUSE SERIOUS INJURY OR DEATH!
ALWAYS CHECK THAT THE GATE PATH IS CLEAR BEFORE OPERATING
REVERSING OR OTHER SAFETY DEVICES SHOULD ALWAYS BE USED



CAUTION




Use all four carriage bolts when mounting the unit to a pedestal.
Leave the antenna in place.
Seal all openings created in the enclosure.
Failure to follow these instructions can damage the unit and/or cause it not to function properly.

What's what?

All important components labeled
Model 27-210 is shown

The unit is shown with the front panel open.
Wiring/cabling not shown for clarity



4. Connect wires.

Feed wires through the back of the unit, and connect as shown using included screwdriver. Excessive force can damage the unit!


Additional wiring diagrams can be found on Pages 5 and 6.



If the included 12-V AC/DC adapter will not be used, please go to Page 4 and follow the procedure.
Do not exceed 24 VAC/DC! Failure to choose a compatible power source can result in damage to the unit.

Edge Power, Relay, Event Terminals

Gate Operator / Door Opener



Using a Third-Party Power Source (Optional)

IMPORTANT

If you would like to use a third-party power source such as solar, verify that it conforms to the following specs:

Input

12-24 VAC/DC **no more than 10% beyond this range** Current Draw

less than 111 mA @ 12 VDC

less than 60 mA @ 24 VDC

4a Connect wires to the unit as shown in Step 4.

4b Connect wires to your power source, making sure you connect positive to positive and negative to negative.



Double-check that you have wired from positive on the Edge unit to positive on your power source and negative to negative. **Reverse polarity can damage the unit!**

5. The close front panel of the unit and lock it.





Before going forward, double-check all wiring and make sure the
Wiring diagrams for connecting to accessory devices can be found on
For connecting accessories not mentioned, please contact Technic
Make sure the gate or door path is clear before completing S

6. Add Access Code to Relay A.

(To add multiple codes, enter each of them before pressing the pound key.)



NOTE: The green arrow indicates a “good” tone on the Edge unit. By default, the following codes are reserved and cannot be used: 1251, 1273, 1366, 1381, 1387, 1678, 1752, and 1985.

7. Make sure the gate or door path is clear; then enter the access code on the keypad, and the confirm gate or door opens.




INSTALLATION COMPLETE!

Jump to **Page 7** to continue programming and download the Edge Smart Keypad app.

A Event Inputs

Wiring for accessories such as a request-to-exit device

Edge Power, Relay, Event Terminals



Event Input configuration instructions can be found on **Pages 10 and 11**.


Request-to-Exit Device

(58-RTE-P is shown)

B Digital Inputs


Wiring to various accessories

Edge Digital Input Terminals



Digital Inputs can be configured using the Edge Smart Keypad app.

© **Wiegand Device**
Wiring for a Wiegand device



If mounting a Wiegand card reader to the Edge unit front panel, remove the existing cover plate and hex nuts to reveal the mounting holes and wiring passthrough hole.



Disconnect power to the Edge unit before connecting Wiegand terminals.
Failure to disconnect power can damage the unit.

Downloading the Edge Smart Keypad App for iOS/Android



The Edge Smart Keypad app is for **ADMINISTRATOR USE ONLY** and is not intended for end users.

a Grab your smartphone or tablet. (These steps are optional. The unit can be fully programmed from the keypad.)

b Navigate to your app store, and search for "edge smart keypad."

c Find the Edge Smart Keypad app by Security Brands, Inc. and download it.



Edge Smart Keypad
Security Brands, Inc.



NEED HELP



You can find plenty of useful resources online to help you get your new Edge unit up and running.
Go to securitybrandsinc.com/edge/
If you need further assistance, please call
Technical Support at (972) 474-6390.

D Pairing Edge Unit

Connect your mobile device to your Edge unit for use with the app.

The app is available for administrators who want to use it. Nearly all functionality is available through direct programming via the keypad.



IMPORTANT! Make sure your Edge unit is powered on and that Bluetooth is enabled on your mobile device or pairing will not work.

Step 1 – Grab your mobile device and open the Edge Smart Keypad app.

If you do not have the app, follow the steps on this page for downloading it.

Step 2 – Fill out your account information and tap the “Sign Up” button.

If you have already created an account, you will log in instead.

Step 3 – On the Paired Keypads screen, tap the “Add Keypad” button.

Step 4 – On the Add Keypad screen, tap the Edge unit you want to pair.

If you do not see any Edge units listed, make sure your Edge unit is powered on and is in Bluetooth range.

Step 5 – Complete the procedure shown on your mobile device. These steps will be completed using the PIN pad on your Edge unit. **Step 6 – Enter the Master Code (default is 1251) on your mobile device.**

Step 7 – Enter the code shown on your mobile device at the Edge unit. This step must be completed within the time duration displayed.

Step 8 – Change your Master Code if you like.

This step is recommended, but optional, and can be done at a later time.

Your new Edge unit is now be paired and will appear on the Paired Keypads screen. Tapping on the Edge unit on this screen will give you access to relay control and full access control management of the Edge unit from within the app.




For more information and guidance, please go to securitybrandsinc.com/edge/ or call Technical Support at (972) 474-6390 for assistance.


E1 Direct Programming / Unit Configuration

Change Master Code

(Highly recommended for security purposes)



Change Sleep Code



The green arrow indicates a “good” tone on the unit.
Always wait for a good tone before moving on.

By default, these codes are unavailable for use: 1251, 1273, 1366, 1381, 1387, 1678, 1752, 1985.



For all programming not shown here, as well as reset procedures and the Smart Keypad app user guide, please visit our Edge start page at securitybrandsinc.com/edge/

Programming Sub Modes

1. Add Access Code(s) to Relay A
2. Delete Code (Non-Wiegand)
3. Change Master Code
4. – **3** Add Latch Code to Relay B
 - 4 – 4** Change Sleep Code
 - 4 – 5** Change Code Length (Non-Wiegand)
 - 4 – 6** Change Relay Trigger Time
 - 4 – 7** Enable/Disable Timers and Schedules
 - 4 – 8** Enable/Disable “3 Strikes, You’re Out”
 - 4 – 9** Configure Event Input 1
5. Add Latch Code to Relay A
6. Configure Wiegand Inputs
7. Add Access Code(s) to Relay B
8. Add Limited-Use Code
9. Delete All Codes and Timers

Things to Know

The Star Key (*)

If a mistake is made, pressing the star key deletes your entry. Two beeps will sound.


The Pound Key (#)

The pound key is good for one thing and one thing only: exiting the programming mode.


The green arrow indicates a “good” tone on the unit. Always wait for a good tone before moving on.

Change Code Length


❗ IMPORTANT! THIS WILL DELETE ALL NON-WIEGAND ACCESS AND LATCH CODES!



Change Relay Trigger Time



Enable/Disable Timers and Schedules



Enable/Disable “3 Strikes, You’re Out”


(When enabled, the unit will sound an alarm and go into a 90-second lockdown for 90 seconds when an incorrect code is entered three times.)



E3 Direct Programming / Unit Configuration

Toggle Silent Mode

(Toggles Silent Mode, which mutes all audible-tone feedback on the unit)



Configure Event Input 1

(Allows an external device to affect keypad operation or trigger a relay. To configure additional inputs, use the Edge Smart Keypad app.)

Mode 1 – Remote Open Mode

Triggers either Relay A or Relay B when event input state changes from normally open (N/O) to normally closed (N/C).

Mode 2 – Log Mode

Makes log entry of event input state when event input state changes from normally open (N/O) to normally closed (N/C).

Mode 3 – Remote Open and Log Mode

Combines Modes 1 and 2.

Mode 4 – Arming Circuit Mode


Enables either Relay A or Relay B when event input state changes from normally open (N/O) to normally closed (N/C). Otherwise, the selected relay is disabled.

Mode 5 – Remote Operation Mode

Triggers or latches either Relay A or Relay B when event input state changes from normally closed (N/C) to normally open (N/O).

Mode 0 – Event Input 1 Disabled

Modes 1, 3, and 4




E4 Direct Programming / Unit Configuration


Configure Event Input 1 (continued)

(Allows an external device to affect keypad operation or trigger a relay. To configure additional inputs, use the Edge Smart Keypad app.)


Mode 2



Mode 5




Disable Event/Digital Inputs (Mode 0)



E5 Direct Programming / Unit Configuration

Configure Wiegand Input

(Allows enabling or disabling of a Wiegand input and configuration of the Wiegand device type. For the tag reader type, use the Edge Smart Keypad app.)




Change Default Facility Code



F1 Direct Programming / Onboard Keypad


Add Access Code(s) to Relay B

(To add multiple codes, enter each of them before pressing the pound key)




F2 Direct Programming / Onboard Keypad


Add Latch Code to Relay A



Add Latch Code to Relay B




Delete Code (Non-Wiegand)



Add Limited-Use Code

(Access codes can be given a use or time restriction. For more advanced time restrictions, use the Edge Smart Keypad app.)




G1 Direct Programming / External Wiegand Keypad


Add Wiegand Keypad Access Code(s)

(Uses default facility code; to add multiple codes, enter each of them before pressing pound key)

On Both Wiegand Inputs



On Wiegand Input 1 or 2




Add Wiegand Keypad Manager Access Code(s)

(Uses default facility code; to add multiple codes, enter each of them before pressing pound key)

On Both Wiegand Inputs



On Wiegand Input 1 or 2




G2 Direct Programming / External Wiegand Keypad


Add Wiegand Keypad Latch Code(s)

(Uses default facility code; to add multiple codes, enter each of them before pressing pound key)

On Both Wiegand Inputs



On Wiegand Input 1 or 2




Delete Wiegand Keypad Code(s)


(Uses default facility code; to delete multiple codes, enter each of them before pressing pound key)

On Both Wiegand Inputs



On Wiegand Input 1 or 2





SECURITY BRANDS INC™
your *partner* in access control

Contents

- [1 NEED HELP](#)
- [2 Documents / Resources](#)
- [3 Related Posts](#)

NEED HELP


Call (972) 474-6390

Email techsupport@securitybrandsinc.com

We are available **Mon–Fri / 8 am–5 pm Central**

© 2021 Security Brands, Inc. All rights reserved

Documents / Resources



[SECURITY BRANDS 27-210 EDGE E1 Smart Keypad with Intercom Access Control System \[pdf\] User Guide](#)

27-210, 27-215, EDGE E1 Smart Keypad with Intercom Access Control System