

SENA 10C EVO Motorcycle Bluetooth Camera and Communication System User Guide

Home » Sena » SENA 10C EVO Motorcycle Bluetooth Camera and Communication System User Guide 🖺



Contents

- 1 SENA 10C EVO Motorcycle Bluetooth Camera and Communication **System**
- **2 Product Information**
- **3 Product Usage Instruction**
- **4 GETTING STARTED**
 - 4.1 How to Use This Guide
 - 4.2 Icon Legend
- **5 Product Details**
- 6 Installation
- 6.1 Sena Motorcycles App
- **7 Basic Operations**
 - 7.1 Music Controls
- 7.2 Camera Controls
- 7.3 Intercom
- **8 Headset Configuration Menu**
- 9 Troubleshooting
 - 9.1 QUICK REFERENCE
- 10 Documents / Resources
 - 10.1 References
- 11 Related Posts



SENA 10C EVO Motorcycle Bluetooth Camera and Communication System



Product Information

The SENA 10C EVO is a motorcycle communication device that comes with a 1.6 km (1.0 mile) intercom, an integrated UHD camera, four-way intercom, Smart Audio MixTM, Advanced Noise ControlTM, WiFi enabled, Audio MultitaskingTM, and Audio Source Priority. It has a camera button, phone button, jog dial, and status LED. The camera has a field of view of 125 degrees and an aperture of F/2.4. It also has a microSD card slot and a DC power charging and firmware upgrade port.

Getting Started

To get started with the SENA 10C EVO:

- 1. Refer to the Quick Start Guide for basic instructions. Download the full version of the User's Guide at sena.com.
- 2. Update the product firmware for free to access new features. Visit sena.com for instructions.
- 3. Follow SENA on social media for product updates and tips.

Installation

Refer to the installation diagrams in the Quick Start Guide for instructions on how to install the SENA 10C EVO on your motorcycle.

Mobile Apps

The SENA Camera App allows you to manage recorded videos and configure video settings using the built-in WiFi feature on the camera system. Download it from sena.com for Android and Apple operating systems.

The SENA Device Manager allows you to upgrade firmware and configure settings directly from your PC or Apple computer. Download it from <u>sena.com</u>.

Product Usage Instruction

Basic Operations

To perform basic operations on the SENA 10C EVO:

• To power on, hold the jog dial button for 1 second. To power off, tap the phone button once.

- To adjust volume, rotate the jog dial clockwise (right) for volume up and counterclockwise (left) for volume down.
- To check battery level visually, hold the phone button for 1 second. To check battery level audibly, hold the phone button for 5 seconds. The device will announce battery level as high, medium, or low.
- To pair with a mobile phone, hold the phone button for 5 seconds until the LED status alternates between blue and red flashing lights. Enter the PIN number to complete pairing.
- To answer a call, tap the phone button once. To end a call, tap the phone button once or hold for 2 seconds. To reject a call, hold the phone button for 2 seconds.
- To make a call with voice dialer, tap the phone button once.
- To control music playback, hold the camera button for 1 second to play/pause. Rotate the jog dial clockwise (right) to skip forward and counterclockwise (left) to skip backward.
- To control camera recording, refer to the camera controls section in the User's Guide.

RIDE CONNECTED

Blast your favorite tunes, talk over the intercom with your buddies, hear directions from your GPS and more, all through your headset. With built-in Bluetooth® capabilities, UHD camera, HD speakers and a microphone using Advanced Noise Control™, technology has never felt so minimal or freeing.



- · Bluetooth® Integrated
- 1.6 Km (1.0 Mile) Intercom
- UHD Camera Integrated
- · Four-Way Intercom
- Smart Audio Mix™
- Advanced Noise Control™
- WiFi Enabled
- Audio Multitasking™
- Audio Source Priority



GETTING STARTED


- This product comes with a Quick Start Guide, which is a basic version of the User's Guide. A FULL VERSION
 OF THE USER'S GUIDE CAN BE DOWNLOADED AT SENA.COM.
- 2. Update this product for free with the latest firmware to fully enjoy the new advanced features built into this product. Visit sena.com to see how to update your product.
- 3. Users can follow Sena on Facebook, YouTube, Twitter and Instagram to receive the most up to date information on products, helpful tips and all other announcements regarding Sena products.

How to Use This Guide


The legend and callouts are here to help you read the illustrations. New technology can be confusing, but we've created a simple way to perform actions using illustrations.



Buttons



Icon Legend









Rotate Jog Dial clockwise (right) or counterclockwise (left).







Rotate while Pressing Jog Dial clockwise (right) or counterclockwise (left).




"Hello"

Audible prompt

Product Details

Antenna




DC Power Charging & Firmware Upgrade Port

Phone Button

Speaker and Microphone Port

Installation



Sena Motorcycles App

- Android: Google Play Store > Sena Motorcycles
- iOS: App Store > Sena Motorcycles

Sena Camera App

The Sena Camera App allows you to see a live preview from the camera, manage recorded videos as well as configure the video settings using the built-in WiFi feature on camera system. When the camera and the Sena Camera App are connected, the camera is synchronized with the smartphone's date and time. Download the Sena Camera App for Android and Apple operating systems from sena.com.

Sena Device Manager

The Sena Device Manager allows you to upgrade the firmware and configure its settings directly from your PC or Apple computer. Download the Sena Device Manager from sena.com.

Basic Operations

Powering On









Powering Off









Volume Up







Volume Down








Checking the Battery Level

Visual Method



Audible Method











"Battery level high/medium/low"

Bluetooth Pairing (Phone, MP3, GPS)

Mobile Phone Pairing












LED STATUS

Alternating blue and red flashing lights indicate device is now discoverable.





PIN NUMBER

Mobile Phone

Answer a Call









Reject a call







End a Call













Make a Call with Voice Dialer







Music Controls

Play/Pause







Track forward







Track backward










Camera Controls

Camera On



Start Recording



Camera Off



Stop Recording



Taking Photos




Note:

If the video resolution is 2160p/30fps, you cannot take a photo during video recording.

Note:

- You cannot record videos without a microSD card.
- Your microSD card needs to be formatted before using the camera.
- MicroSD cards up to 128 GB and U3 or higher cards are compatible.

Format SD Card




Note:

IF YOUR SMARTPHONE OR REGION DOES NOT SUPPORT 5 GHz, YOU MUST CHANGE THE WIFI CHANNEL TO 2.4 GHz.

Intercom

Up to three other people can be paired with the headset for Bluetooth intercom conversations.

Pairing Headset A with Headset B



Start/End Intercom with Headset B



Headset Configuration Menu

Accessing the Headset Configuration Menu









Navigating Between Menu Options







Execute Menu Options







() =





Troubleshooting

Factory Reset

















Fault Reset




Note:

Fault Reset will not restore the headset to factory default settings.


QUICK REFERENCE







SENA Technologies, Inc.
Customer Support: sena.com.

Documents / Resources







References

• E The Best Motorcycle & Action Sport Bluetooth Devices | Sena

Manuals+,