

### **SENSIWATCH TGLA1-01-181 Cold Chain Monitoring Program User Guide**

Home » SENSIWATCH » SENSIWATCH TGLA1-01-181 Cold Chain Monitoring Program User Guide 🖺





**User Guide** 

#### **Contents**

- 1 TempTale GEO LTE Ordering Information
- 2 Registration One Time Action
- 3 SensiWatch Platform Log In and Log Out
- 4 Start a Trip
- **5 The Overview Page**
- 6 SensiWatch Platform Mobile App
- 7 Sensitech Contact Information
- 8 Documents / Resources
  - 8.1 References

#### TempTale GEO LTE Ordering Information

To order monitors, please contact a Sensitech Client Services representative. Email: sensitech.clientservices@carrier.com. Phone: +1 800-843-8367 TempTale LTE Custom Catalog Numbers



No minimum order quantity, 6 month shelf life.

Supplier Part Number: TGLA1-01-181
Description: TT GEO LTE SU — Subway

Product	Low	High	Graph Length	Startup Delay
Dairy and produce	32F	41F	7 days	5 miles

Supplier Part Number: TGL01-01-181


Description: TT GEO LTE EXT SU — Subway

Product	Low	High	Graph Length	Startup Delay
Fresh Meat	26F	36F	17 days	5 miles
Frozen meat, dough, and other froz en products	-15F	10F	17 days	5 miles

#### **Registration – One Time Action**

#### **Registration Email**

A new user added to the SensiWatch Platform will be sent an activation email. Click the Complete Registration (1) bar to initiate the registration process.



#### **Create Password**

Complete the New Password (2) and Confirm Password (3) fields.

Password Requirements:

8 to 32 characters,

- 1 uppercase letter,
- 1 lowercase letter,
- 1 numeric character,
- 1 non-alphanumeric character.



#### Password Successful | Login

When the password requirement is met, the Password created successfully message displays. Click Create Password (4).

Click Log In (5) to access SensiWatch Platform.



When prompted, click Accept and Continue to accept the End User License Agreement and Privacy Notice.

#### SensiWatch Platform Log In and Log Out

#### Login

Launch SensiWatch Platform: <a href="https://sensiwatch.com/">https://sensiwatch.com/</a>






#### Start a Trip

- · Search and Edit a Trip
- · Search and Edit a Trip
- · Create a New Trip
- Supplier Start & Placement Instructions


Set Up Search Results Columns —First Time Users Only

If this is your first time working with the SensiWatch platform Search, please set up your search results columns so that it is easier for your to find trips. Follow the instructions:



#### **Trip List with Modified Primary and Secondary Columns**

The trip results table is reloaded with the primary and secondary columns as configured in the Column Manager. The System remembers your selection and displays the Trip page with these columns every time you log in.



**Note:** while you type the Monitor ID number, the system verifies and displays the correct Monitor ID number next to the field. After the trip is created, follow the Supplier Start and Placement Instructions.

#### **Supplier Start and Placement Instructions**

**Note:** It is important that you enter trips details PRIOR to the monitor being started and placed on the load. After you have a trip in the SensiWatch Platform with the correct Monitor ID, follow the instructions to start and place the monitor.

- Fill Out The TempTale® GEO LTE's Label
   Write the PO Number on the TempTale LTE label with a permanent marker.
- 2. Start The TempTale GEO LTE Monitor

Press and hold the green Start (1) button until the Status LED (2) blinks rapidly for 30 to 60 seconds.



#### 3. Place The TempTale GEO LTE Monitor

Remove the protective paper from the adhesive strip on the back of the monitor and place it on the TOP of the last pallet loaded on the passenger side of the trailer. Place a green "Monitor Enclosed" label on the FRONT of the same pallet, facing the trailer door.



# © 2024 Carrier. All Rights Reserved. Alarm Notification and Acknowledgement Alarm Notification Email

You do not need to stop or download TempTale GEO LTE monitors; however, upon receipt, please store the monitors in a bright location as the monitors have light sensors and light sensor trigger is required to register the arrival of the monitors.


TempTale GEO LTE monitors do not have visible alarms. Email notifications are sent to the Supplier and DC contacts on file for in-transit alarms and arrived trips. The monitor type, monitor serial number, order number, trip status, larm status, origin, and the alarm type is displayed within the Subject line. All alarms must be acknowledged and corrective actions logged. Managing Carrier: The managing carrier is responsible for acknowledging the alarm in SensiWatch Platform within 1.5 hours of alarm.

To acknowledge an alarm click the Open Details link within the alarm notification email.

This will launch the Trip Detail page for the trip. View and Acknowledge alarms in the Trip Details page (next).



#### **Alarm Acknowledgement**




Other Functions in SensiWatch Platform


**The Overview Page** 



#### The Trips Page



#### The Trip Details Page




• Trip Actions could vary depending on the user role. For example, actions can include Edit Trip and Print


functions.

• Each action requires appropriate permissions assigned to your role by the Administrator.


## The Trip Details Page —Toolbar, Timeline, and Alarms Trip Toolbar



The Trip Details Page — Map and Multigraph Map Section



### The Trip Details Page —Trip Statistics and Trip Details Sections Trip Statistics section



SensiWatch Platform App is the companion mobile application to the core, desktop version of the SensiWatch Platform. Download SensiWatch Platform app from the Apple Store or Google Play.





Users can view trip list and a trip details page in the SensiWatch Platform Mobile App.







**Login** page uses the same login credentials as the web application.

The **Trips** page is where users can view a list of trips, filter the list by trip and alarm status, and find a specific trip.







**Trip Details** is a page from where users can view the map, graph, and other details of the trip such as trip status, origin, stops, and final destination. Users can also acknowledge alarms here.

#### **Sensitech Contact Information**

Request Category	Who to Contact?		
Order Placement for Monitors, Readers, Labels, Brackets, Return Systems	Sensitech Client Services Sensitech.clientservices@carrier.com +1 800-843-8367 +1 978-720-2650		
Monitor Evals / Post Validation Installation / Training Software Support	Sensitech Support Services Sensitech.support@carrier.com +1 800-843-8367		
Reports, Analysis Notifications Program Support	Katie Spurlock, Program Manager katherine.spurlock@carrier.com +1 978-288-6816 Genevieve Puccinelli, Account Manager genevieve.puccinelli@carrier.com +1 602-487-9371		

© 2024 Carrier. All Rights Reserved.

#### **Documents / Resources**



<u>SENSIWATCH TGLA1-01-181 Cold Chain Monitoring Program</u> [pdf] User Guide TGLA1-01-181 Cold Chain Monitoring Program, TGLA1-01-181, Cold Chain Monitoring Program, Chain Monitoring Program, Monitoring Program

#### References

- SensiWatch Platform
- User Manual

#### Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.