




SHARP 65BL2EA Android TV User Guide

[Home](#) » [Sharp](#) » SHARP 65BL2EA Android TV User Guide 

SHARP

androidtv



Quick start guide

Trademarks

	<p>The terms HDMI, HDMI High-Definition Multimedia Interface, and the HDMI logos are Administrator, Inc.</p>
	<p>The DVB logo is the registered trademark of the Digital Video Broadcasting – DVB – p</p>
	<p>Manufactured under license from Dolby Laboratories. Dolby, Dolby Audio, and the do</p>
	<p>For DTS patents, see http://patents.dts.com. Manufactured under license from DTS ol together, Virtual:X and the DTS Virtual:X logo are registered trademarks and/or trac countries. © DTS, Inc. All Rights Reserved.</p>
	<p>For DTS patents, see http://patents.dts.com. Manufactured under license from DTS ol together, DTS-HD, and the DTS-HD logo are registered trademarks and/ or tradem ies. © DTS, Inc. All Rights Reserved.</p>
	<p>The Wi-Fi CERTIFIED Logo is a certification mark of the Wi-Fi Alliance.</p>
<p>androidtv</p>	
	
	<p>Google, Android, YouTube, Android TV, and other marks are trademarks of Google LI</p>
	<p>The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth</p>

Contents

- 1 Important safety instructions
- 2 What is included in the box
- 3 Attaching the Stand
- 4 Wall mounting the TV
- 5 Connections
- 6 Getting started – initial setup
- 7 TV buttons*
- 8 TV Control Stick*
- 9 Choosing Mode Input/Source
- 10 TV Menu navigation
- 11 Electronic instruction manual
- 12 Remote control
- 13 Documents / Resources
 - 13.1 References
- 14 Related Posts

Important safety instructions



Please, read these safety instructions and respect the following warnings before the appliance is operated:



In order to prevent fire always keep candles and other open flames away from this product.

- Television sets with 43" size screens or more must be lifted and carried by at least two people.
- This TV does not contain any parts which could be repaired by the user.
In case of a fault, contact the manufacturer or the authorized service agent. Contact with certain parts inside the TV might endanger your life. The guarantee does not extend to faults caused by repairs carried out by unauthorized third parties.
- Do not remove the rear part of the appliance.
- This appliance is designed for the receiving and reproduction of video and sound signals. Any other use is strictly forbidden.
- Do not expose the TV to dripping or splashing liquid.
- To disconnect the TV from the mains please unplug the mains plug from the mains socket.
- If the supply cord is damaged, it must be replaced by the manufacturer, a service agent, or similarly qualified persons in order to avoid a hazard.
- The suggested distance to watch HD TV is approximately three times longer than the screen diagonal size. Reflections on the screen from other light sources can make the quality of the picture worse.
- Ensure the TV has sufficient ventilation and is not close to other appliances and other pieces of furniture.
- Install the product at least 5 cm from the wall for ventilation.

- Ensure that the ventilation openings are clear of items such as newspapers, tablecloths, curtains, etc.
- The TV set is designed to be used in a moderate climate.
- The TV set is designed exclusively for operation in a dry place. When using the TV outside, please, make sure it is protected against moisture (rain, splashing water). Never expose to moisture.
- Do not place any objects or containers filled with liquids, such as vases, etc. on the TV. These containers might get pushed over, which would endanger electric safety. Place the TV exclusively on flat and stable surfaces. Do not place any objects such as newspapers or blankets, etc. on or under the TV.
- Make sure the appliance does not stand on any power cables as they might get damaged. Mobile phones and other devices such as WLAN adapters, monitoring cameras with wireless signal transmission, etc. might cause electromagnetic interference and they should not be placed near the appliance.
- Do not place the appliance near heating elements or in a place with direct sunlight as it has a negative effect on the cooling of the appliance. Heat storage is dangerous and it can seriously reduce the lifetime of the appliance. In order to ensure safety, ask a qualified person to remove the dirt from the appliance.
- Try to prevent damage to the mains cable or mains adapter. The appliance can only be connected with the supplied mains cable/ adapter.
- Storms are dangerous for all-electric appliances. If the mains or aerial wiring is struck by lightning the appliance might get damaged, even if it is turned off. You should disconnect all the cables and connectors of the appliance before a storm.
- To clean the screen of the appliance use only a damp and soft cloth. Use only clean water, never detergents, and in no case use solvents.
- Position the TV close to the wall to avoid the possibility of it falling when pushed.
- **WARNING** – Never place a television set in an unstable location. A television set may fall, causing serious personal injury or death. Many injuries, particularly to children can be avoided by taking simple precautions such as:
 - Use cabinets or stands recommended by the manufacturer of the television set.
 - Only use furniture that can safely support the television set.
 - Ensure the television set is not overhanging the edge of the supporting furniture.
 - Not place the television set on tall furniture (for example, cupboards or bookcases) without anchoring both the furniture and the television set to a suitable support.
 - Not place the television set on cloth or other materials that may be located between the television set and supporting furniture.
 - Educate children about the dangers of climbing on furniture to reach the television set or its controls.
 - Ensure that children do not climb or hang onto the TV.
 - If your existing television set is being retained and relocated, the same considerations as above should be applied.
- The instructions shown below are a safer way to set up the TV, by fixing it to the wall and will avoid the possibility of it falling forwards and causing injury and damage.
- For this type of installation, you will need a fastening cord
 - A) Using one/both of the top wall-mounting holes and screws (the screws are already supplied in the wall mounting holes) fasten one end of the fastening chord/s to the TV.
 - B) Secure the other end of the fastening chord/s to your wall.
- The software on your TV and the OSD layout can be changed without notice.
- Note: In the case of electrostatic discharge (ESD) the apparatus may show incorrect function. In such a case,

switch the TV off and back on. The TV will work normally.

Warning:

- When turning off the set, use the standby button on the remote control. By long pressing of this button, the TV will turn off and enter the energy-saving standby mode to meet the eco-design requirements. This mode is the default one.
- Do not use the TV set directly after unpacking. Wait until the TV warms up to the room temperature before using it.
- Never connect any external devices to a live appliance. Switch off not only the TV but also the devices which are being connected! Plug the TV plug into the wall socket after connecting any external devices and the aerial!
- Always make sure there is free access to the TV mains plug.
- The appliance is not designed for use in a workplace fitted with monitors.
- The systematic use of headphones at high volume might lead to irreversible hearing damage.
- Ensure environmental disposal of this appliance and any components including batteries. When in doubt, please, contact your local authority for details of recycling.
- While installing the appliance, do not forget that furniture surfaces are treated with various varnishes, plastics, etc. or they might be polished. The chemicals contained in these products might have a reaction with the TV stand. This could result in bits of the material sticking to the furniture surface, which are difficult to remove, if not impossible.
- The screen of your TV has been produced under top quality conditions and was checked in detail for faulty pixels several times. Due to the technological properties of the manufacturing process, it is not possible to eliminate the existence of a small number of faulty points on the screen (even with maximum care while in production). These faulty pixels are not considered faults in terms of guarantee conditions if their extent is not greater than the boundaries defined by the DIN norm.
- The manufacturer cannot be held responsible, or be liable, for customer service-related issues related to the third party content or services. Any questions, comments, or service-related inquiries relating to the third party content or service should be made directly to the applicable content or service provider.
- There are a variety of reasons you may be unable to access content or services from the device unrelated to the device itself, including, but not limited to, power failure, the Internet connection, or failure to configure your device correctly. UMC Poland, its directors, officers, employees, agents, contractors, and affiliates shall not be liable to you or any third party with respect to such failures or maintenance outages, regardless of the cause or whether or not it could have been avoided.
- All third party content or services accessible via this device are provided to you on an "as-is" and "as available" basis and UMC Poland and its affiliates make no warranty or representation of any kind to you, either express or implied, including, without limitation, any warranties of merchantability, non-infringement, fitness for a particular purpose or any warranties of suitability, availability, accuracy, completeness, security, title, usefulness, lack of negligence or error-free or uninterrupted operation or use of the content or services provided to you or that the content or services will meet your requirements or expectations.
- 'UMC Poland' is not an agent of and assumes no responsibility for the acts or omissions of third-party content or service providers, nor any aspect of the content or service related to such third-party providers.
- In no event will 'UMC Poland' and/or its affiliates be liable to you or any third party for any direct, indirect, special, incidental, punitive, consequential or other damages, whether the theory of liability is based on contract, tort, negligence, breach of warranty, strict liability or otherwise and whether or not UMC Poland and/or

its affiliates have been advised of the possibility of such damages.

- **This product contains technology subject to certain intellectual property rights of Microsoft. Use or distribution of this technology outside of this product is prohibited without the appropriate license(s) from Microsoft.**
- **Content owners use Microsoft PlayReady™ content access technology to protect their intellectual property, including copyrighted content. This device uses PlayReady technology to access PlayReady-protected content and/or WMDRM-protected content. If the device fails to properly enforce restrictions on content usage, content owners may require Microsoft to revoke the device's ability to consume PlayReady-protected content. Revocation should not affect unprotected content or content protected by other content access technologies. Content owners may require you to upgrade PlayReady to access their content. If you decline an upgrade, you will not be able to access content that requires the upgrade.**

Important information regarding the use of video games, computers, captions, and other fixed image displays.

- The extended use of fixed image program material can cause a permanent "shadow image" on the LCD screen (this is sometimes incorrectly referred to as "burnout to the screen"). This shadow image is then permanently visible on the screen in the background. It is irreversible damage. You can avoid such damage by following the instructions below:
- Reduce the brightness/contrast setting to a minimum viewing level.
- Do not display the fixed image for a long period of time. Avoid displaying:
 - » Teletext time and charts,
 - » TV/DVD menu, e.g. DVD contents,
 - » In the „Pause“ mode (hold): Do not use this mode for a long time, e.g. while watching a DVD or a video.
 - » Turn off the appliance if you are not using it.

Batteries

- Observe the correct polarity when inserting the batteries.
- Do not expose batteries to high temperatures and do not place them in locations where the temperature might increase quickly, e.g. near the fire or in the direct sunshine. Do not expose batteries to excessive radiant heat, do not throw them into the fire, do not disassemble them, and do not try to recharge un-rechargeable batteries. They could leak or explode.
 - » Never use different batteries together or mix new and old ones.
 - » Dispose of batteries in an environmentally friendly way.
 - » Most of the EU countries regulate the disposal of batteries by law.

Disposal

- Do not dispose of this TV as unsorted municipal waste. Return it to a designated collection point for the recycling of WEEE. By doing so, you will help to conserve resources and protect the environment. Contact your retailer or local authorities for more information.



CE Statement:

Hereby, UMC Poland Sp. z o.o. declares that this LED TV is in compliance with the essential requirements and other relevant provisions of RED Directive 2014/53/EU.

The full text of the EU declaration of conformity is available by following the link www.sharpconsumer.eu/documents-of-conformity/

This equipment may be operated in all EU countries.

The 5 GHz WLAN(Wi-Fi) function of this equipment may only be operated indoors.

Wi-Fi max transmitter power:

100 mW at 2,412 GHz – 2,472 GHz

100 mW at 5,150 GHz – 5,350 GHz

100 mW at 5,470 GHz – 5,725 GHz

BT max transmitter power: 10 mW at 2,402 GHz – 2,480 GHz.

What is included in the box

The supply of this TV includes the following parts:

• 1x TV	• 1x TV stand installation packet
• 1x Remote control	• 1x Quick Start Guide
• 2x AAA batteries	• 1x Wall mount set (4x M6x35 screw and 4x plastic spacer)*

* – Available only for 50" models


Attaching the Stand

Please follow the instructions in the Technical leaflet, located in the accessories bag.

Wall mounting the TV

1. Remove the four screws that are supplied in the wall mounting holes.
2. The wall mount can now be easily attached to the mounting holes on the rear of the TV.
3. Install the wall mounting bracket to the television as advised by the bracket manufacturer.

When attaching wall mount brackets on the 50" model, instead of screws provided in TV wall mounting holes, we recommend the use of longer screws and spacers included in the accessory pack. Please put spacers into TV wall mounting holes, located on the back of the TV, then put wall brackets onto them. Attach brackets and spacers to TV using longer screws as shown below:



1. TV
2. SPACER
3. SCREW

NOTE: The TV and the wall bracket type shown in the diagram are for illustration purposes only.

Connections

Connecting external devices see the last page in this IM.

Getting started – initial setup

1. Using the RF cable, connect the TV to the TV Aerial wall socket.
2. For connecting to the Internet with a wired connection connect a Cat 5/Ethernet cable (not included) from the TV to your broadband modem/router.
3. Insert the batteries supplied into the Remote control.
4. Connect the power cable to the Electrical outlet.
5. Then press Standby button to power on the TV.
6. After turning the TV on, you will be welcomed to the **First Time Installation menu**.
7. Please select language for the TV menu.
8. Please set desired settings in the remaining screens of the First installation menu.

TV buttons*

Vol+ Volume up and menu right
Vol- Volume down and menu left
CH+ Programme/Channel up and menu up
CH- Programme/Channel down and menu down
MENU Displays Menu/OSD
SOURCE Displays the input source menu
STANDBY Standby Power On/Off

* – for TV with buttons

TV Control Stick*

The TV control stick is located on the lower-left corner of the backside of the TV. You can use it instead of remote control to control most of the functions of your TV.

While TV is in standby mode:

- a short press of control stick – Power On

While watching TV:

- RIGHT/LEFT – volume up/volume down
- UP/DOWN – changes channel up/down
- short press – Displays Menu
- long press – Standby Power Off

While in the menu:


- RIGHT/LEFT/UP/DOWN – navigation of cursor in on-screen menus
- short press – OK/Confirm selected item
- long press – Back to the previous menu

* – for TV with the control stick

Choosing Mode Input/Source

To switch between the different input/connections.

a) Using the buttons on the remote control:

1. Press [SOURCE/ ] – The source menu will appear.
2. Press [▲] or [▼] to select the input you require.
3. Press [OK].

b1) Using the buttons* on the Television:

1. Press [SOURCE].
2. Scroll up/down using CH+ / CH- buttons to the input/source you require.
3. Press [VOL+] to change the input/source to the one selected.

b2) Using the TV control stick*:

1. Shortly press control stick to enter the menu.
2. Press control sticks down and navigates the cursor to SOURCES menu.
3. Shortly press the control stick to enter the SOURCES menu.
4. With control, stick choose the input/source you require.
5. By the short pressing the control stick, you will change the input/source to the one selected.

* – optional

TV Menu navigation

Use the (▲/▼/◀/▶) buttons to focus on the desired item.

Press the OK button to select the item currently in focus.

Press the BACK button to go back one step in the menu.

Press the EXIT button to leave the menu.

Press the HOME button to enter the TV Home menu.

To enter the Live TV menu, press the TV button and then press the MENU button.

Electronic instruction manual

Find more useful information directly from your TV.


To launch the online manual, press the HOME button, select Apps from the Home menu, and select “E-instruction Manual” from the apps list.

NOTE: An Internet connection is required to use this electronic manual.

Remote control

See in On Screen Manual in TV

Connecting external devices



SHA/QSG/0122




UMC Poland Sp. z o.o.
Ostaszewo 57B, 87-148 Łysomice,
Poland

Assembled in Poland

www.sharpconsumer.eu

SHARP

Documents / Resources

	<p>SHARP 65BL2EA Android TV [pdf] User Guide 65BL2EA, Android TV, 65BL2EA Android TV</p>
--	--

References

- [Patents - DTS](#)
- [Sharp Consumer Products Europe - Sharp Europe](#)
- [Sharp Consumer Products Europe - Sharp Europe](#)
- [Sharp Consumer Products Europe - Sharp Europe](#)