



SHARP PS-929 Party Speaker System User Manual

[Home](#) » [Sharp](#) » SHARP PS-929 Party Speaker System User Manual 

SHARP PS-929 Party Speaker System













Contents

- 1 Important safety instructions
 - 1.1 Maintenance
 - 1.2 Power Adapter
 - 1.3 Built-in Battery Care
 - 1.4 Battery warning!
 - 1.5 How to remove the battery for disposal
 - 1.6 Disposal of this equipment and Batteries
 - 1.7 CE and UKCA statement:
- 2 What is included in the box
- 3 Panels & Controls
 - 3.1 TOP VIEW
 - 3.2 REAR VIEW
- 4 Operation instruction
 - 4.1 Power Connection
 - 4.2 Turning On
 - 4.3 Controlling the master Volume
 - 4.4 Bass Boost
 - 4.5 EQ Mode select
 - 4.6 Set lighting effect
 - 4.7 Connect Bluetooth audio output device
 - 4.8 AUX-IN OPERATION
 - 4.9 USB OPERATION
 - 4.10 USB Charge
 - 4.11 Connect guitar
 - 4.12 TWS/ True wireless Stereo – Duo Mode
- 5 Technical specification
- 6 Documents / Resources
 - 6.1 References
- 7 Related Posts

Important safety instructions



Please, read these safety instructions and respect the following warnings before the appliance is operated:

	The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated “dangerous voltage” within the product’s enclosure that may be of sufficient magnitude as to constitute a risk of electric shock to persons.
	The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.
	Use only power supply listed in the user manual.
	This symbol means that the product should be disposed of in an environmentally friendly manner and not with general household waste
	AC voltage
	DC voltage
	Class II equipment
	For indoor use only
	Energy efficiency marking with level VI
	Polarity of d.c. power connector



Warning:

- Always follow basic safety precautions when using this appliance, especially when children are present.
- Children should be supervised to ensure that they do not play with the appliance.
- Do not damage the power cord, neither do not place any heavy objects on it, do not stretch it or bend it. Also do not attach extension cables. Damage to the power cord may occur fire or electric shock.
- If the supply cord is damaged, it must be replaced by the manufacturer, a service agent or similarly qualified persons in order to avoid a hazard
- Ensure that the unit is plugged into an AC 220-240V 50Hz power outlet. Using higher voltage may cause the unit to malfunction or even fire catching.
- If the power plug does not fit into your outlet, do not force the plug into an electrical socket if it does not fit.
- Turn off the unit before unplugging it from power source to completely switch it off.
- Do not disconnect or connect the power cord with wet hands. It may cause an electric shock.
- NOTE: To disconnect the system completely if it not to be used for a long time, remove the AC power plug from

the wall outlet.

- Ensure that the mains plug is always easily accessible. · This product does not contain any parts that are serviceable by the user. In case of a fault, contact the manufacturer or authorised service department.
Exposing the internal parts inside the device may endanger your life. The manufacturers guarantee does not extend to faults caused by repairs carried out by unauthorised third parties.
- Do not use this product immediately after unpacking. Wait until it warms up to room temperature before using it.
- Ensure this product is used in moderate climates only (not in tropical/ subtropical climates).
- Place product on a flat, stable surface that is not subject to vibrations. · Ensure the product and its parts is not overhanging the edge of the supporting furniture.
- To reduce the risk of fire, electric shock or damage to this product, do not expose it to direct sunlight, dust, rain and moisture. Never expose it to dripping or splashing and do not place objects filled with liquids on or near the product.
- Do not place objects filled with liquids, such as vases, on the apparatus.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Do not place the product where the humidity is high and ventilation is poor.
- Don't mount this product on a wall or ceiling.
- Do not place the unit near TVs, speakers and other objects that generate strong magnetic fields.
- Do not leave the unit unattended when it is in use.
- Allow at least 30 cm clearance from the rear and the top of the unit and 5 cm from each side. Do not block any ventilation openings of this product. Always ensure that the ventilation openings are not covered with items such as newspapers, table-cloths, curtains, etc.
- NEVER let anyone, especially children, push anything into holes, slots or any other openings in the unit's casing as this could result in a fatal electric shock.
- Storms are dangerous for all electric appliances. If the mains or aerial wiring is struck by lightning, the appliance might get damaged, even if it is turned off. You should disconnect all the cables and connectors of the appliance before a storm.

Maintenance

- Unplug the power cable from the power source before cleaning the appliance.
- Use a soft and clean rag to clean the outside of the unit. Never clean it with chemicals or detergent.

Power Adapter

- To disconnect the unit from the mains supply, unplug the lead from the mains socket.
- Only use the supplied mains adaptor as failure to do this may result in a safety risk and/or damage to the unit.

Built-in Battery Care

- Your product is powered by a built-in rechargeable battery.
- The battery can be charged and discharged hundreds of times, but will eventually wear out.
- Unplug the charger from the electrical plug and the product when not in use.
- Do not leave a fully charged battery connected to a charger, since overcharging may shorten its lifetime.

- If left unused, a fully charged battery will lose its charge over time.
- Leaving the product in hot or cold places, such as in a closed car in the summer and winter conditions, will reduce the capacity and life time of the battery.
- Always try to keep your device in a cool, moisture-free environment that's less than 32°C.
- A product with a hot or cold battery may not work temporarily, even when the battery is fully charged. Battery performance is particularly limited in temperatures well below freezing
- If you plan to store your device for longer than six months, charge the battery to 50% every six months to keep it fresh. Store the device at temperatures between 5 °C and 20 °C.

Battery warning!

- The battery used in this product may present a risk of fire or chemical burn if mistreated.
- Do not attempt to open the product or replace the battery. It is built-in and not changeable. Use of other batteries may present a risk of fire or explosion and the warranty will be terminated.
- Dispose of batteries according to local regulations. Please recycle when possible. Do not dispose as household waste or in a fire as they may explode.
- Batteries may explode if damaged.
- Charging the battery using supplied charger or under the charging condition specified in user manual. Charging the battery under any other conditions may cause the battery to overheat, emit hydrogen gas, leak, ignite or burst.

CAUTION!

1. Important safety considerations

- Do not expose batteries to high temperatures and do not place them on locations where the temperature might increase quickly, e.g. near the fire or on the direct sunshine.
- Do not expose batteries to excessive radiant heat, do not throw them into the fire, do not disassemble them and do not try to recharge un rechargeable batteries. They could leak or explode.

2. To prevent deterioration or damage to the battery

- Do not drop or subject to strong physical shock.

3. To ensure long battery life

- Do not discharge completely.

How to remove the battery for disposal

RISK OF INJURY. WEAR GLOVES WHEN WORKING! The battery should be removed by an authorized Sharp service centre. Not doing so will invalidate any guarantees and warranties on your device.

Step 1: Remove 6 screws on the front grill.

Step 2: Remove the grill.

Step 3: Remove 11 screws on the front cabinet.

Step 4: Remove the front cabinet.

Step 5: On the battery remove 4 screws holding battery in a place.

Step 6: Remove the soldering points between the battery and the wires.

Step 7: Remove the battery from the battery case.

Disposal of this equipment and Batteries

- Do not dispose of this product or its batteries as unsorted municipal waste. Return it to a designated collection point for the recycling of WEEE in accordance with local law. By doing so, you will help to conserve resources and protect the environment.



- Most of the EU countries regulate the disposal of batteries by law. Contact your retailer or local authorities for more information.



- The shown above appears on electrical and electronic equipment and batteries (or the packaging) to remind users of this. If "Hg" or 'Pb' appears below the symbol, this means that the battery contains traces of mercury (Hg) or lead (Pb), respectively.
- Users are requested to use existing return facilities for used equipment and batteries.


CE and UKCA statement:

- Hereby, Sharp Consumer Electronics Poland sp. z o.o. declares that this audio device is in compliance with the essential requirements and other relevant provisions of RED Directive 2014/53/EU and UK Radio Equipment Regulations 2017.
- The full text of the EU declaration of conformity is available by following the link www.sharpconsumer.com and then entering download section of your model and choosing "CE Statements".

What is included in the box


- 1 x PS-929
- 1 x Power Adapter
- 1 x Microphone
- 1 x User Manual
- 1 x Quick start guide
- 1 x Warranty Card
- 4 x spare foot pads

Panels & Controls



TOP VIEW

1. LED display
2. SUPER BASS – BASS BOOST/TWS
3. MIC/GUITAR VOL – Microphone/Guitar volume controller
4. /MODE – Mode select/STANDY ON/OFF
5. EQ/ECHO – EQ MODE/Microphone echo effect on/of
6. LIGHT – LED speaker lights control
7. * / >> || PLAY/PAUSE/PAI
8. <<< Play previous trac
9. >>> Play next trac
10. VOLUME – Master volume



REAR VIEW

1. USB – USB port for playback
2. 5V/1A – 5V 1A USB charger
3. MIC IN – Microphone input
4. GT.IN – Guitar input
5. AUX.IN – Aux input (3.5mm)
6. 15V.IN – DC power 15V input
7. Power switch – Switch device on/off

Operation instruction

Power Connection

Connect the small plug from the supplied AC/DC Adaptor to the DC 15V (In) Jack on the rear of unit then plug the AC/DC Adaptor to a AC wall outlet having AC 100-240V~; 50/60Hz.

Turning On

Switch the POWER switch on the rear of the speaker to the ON position. Then press and hold the /MODE button for 2 seconds to switch on. To turn the speaker off, press the /MODE button for a few seconds.

Controlling the master Volume

Rotate the VOLUME knob to select the desired master volume level.

Bass Boost

Press the SUPER BASS button to have extra bass effect, press again to turn off.

EQ Mode select

Press the EQ/ECHO Button on the unit o to activate and set the equalizer effect that best matches the music style: FLAT/CLASSIC/ROCK/POP/JAZZ/ LIVE/CLUB/DANCE/HALL/SOFT

Set lighting effect

Press the LIGHT button repeatedly to choose one of the following light effect settings for speakers & ring lights


Screen display	Blink effect
L-01	Multiple colour change
L-02	Red light (in time with music rhythm)
L-03	Green light (in time with music rhythm)
L-04	Blue light (in time with music rhythm)
L-05	Yellow (in time with music rhythm)
L-06	Purple (in time with music rhythm)
L-07	Cyan (in time with music rhythm)
L-08	OFF

A long press the LIGHT button will turn the speakers & strobe lights on and off.

Connect Bluetooth audio output device

To connect a Bluetooth audio output device (e.g. smart phone or tablet PC), proceed as follows:

–Switch the speaker on.

–Press the /MODE button once or repeatedly until the screen shows `bt` to switch to the Bluetooth mode. The

speaker is now in pairing mode. During this time, “BT LOGO” flashes on the display screen. The party speaker will then attempt to automatically connect itself to the last audio output device connected via Bluetooth. If this is not possible, the speaker sends its device identification via Bluetooth and ‘bt’ flashes on the screen. –Switch on the Bluetooth function on your audio output device and enable search mode. On your audio output device select your speaker “**SHARP PS-929**” from the list of available devices and connect the devices. You may find more information about the Bluetooth function of your playback device in its operating instructions.


- Input the password 0000 if required. Once successfully connected, there will be a prompt sound and the “BT LOGO” on the screen will be solid.

You can control tracks being played back and the volume of the party speaker on your external device. The functions available when using an audio playback device on the party speaker will depend on your external device and the software used. Press and hold button (for 3sec.) to disconnect the current Bluetooth connection. The PS-929 will prompt “disconnected”. Then other Bluetooth devices can find and pair with the “SHARP PS-929”.

AUX-IN OPERATION

You can use the AUX IN connection to connect an external playback device (for example a CD player or MP3 player).

- Connect your audio device to the AUX IN JACK on the rear panel of the unit with an AUX IN cable. (not supplied with the device)



- Press the /MODE button several times until you see AUX in the display.

The audio signal from your external device will now be played back. The track being played back is controlled via the external device. The volume can be controlled both on your external device and the party speaker

USB OPERATION

- This unit provides two USB ports, one for playback, and another for charging. Insert the USB drive into the USB slot 1 on the rear panel of the party speaker.

- It will enter to USB mode, the USB will appear on the display. And it will play the songs from the USB immediately.

- Press  or  button to select the previous or next track

- Due to the numerous different file systems and file formats, compatibility with the connected memory media cannot be guaranteed. Depending on the size of the data medium, it may take some time for the system to be detected.

- The supported file format is MP3/WAV/FLAC.

- External hard disks are not supported.

- supports USB memory key up to 128GB.

USB Charge

The unit has a built-in 5V 1A charger, to charge an external USB Device:

1. Connect the USB plug from the external USB Device to 5V 1A port on the top of unit.
2. Power on the main unit, then the charging will automatically start.

Connect guitar

The guitar can be used in any operating mode. To connect the guitar, proceed as follows:

- Insert the connection cord (6.3 mm cinch) for the guitar into the guitar plug **GT.IN**.

- Connect the guitar with the connection cord. Use the **MIC/GUITAR** VOL knob to select the desired guitar volume

Connecting a microphone

- Insert the cord of the microphone supplied into the **MIC.IN** plug on the rear of the speaker.
- Use the **MIC/GUITAR VOL** knob to select the desired microphone volume.
- Long press the **EQ/ECHO** button to turn on/off echo effect.


TWS/ True wireless Stereo – Duo Mode

- This allows for two PS-929 party speakers to be connected together as a left and right stereo speakers for a real stereo experience. The first connected speaker is the primary one and the second the secondary.
- Press and hold the SUPER BASS button on the first speaker until the speaker says “Duo Mode pairing” then release the buttons.
- Ensure the second speaker is in Bluetooth mode, did not connect to any devices and ready for pairing.
- Please wait until both speaker says “Duo Mode connected”. The speakers are now connected to each other.
- The speaker that display “BT-L” (left speaker) is the primary speaker and this is the speaker that you should pair with your phone.
- For Bluetooth pairing to a Bluetooth-out enabled smart device search for “SHARP PS-929” on your device and pair.
- When in Duo Mode and you Power off one speaker both speakers will power off.
- When you Power on the speakers, they need to be turned on individually.
- When both speakers are powered on Duo Mode will automatically reconnect and you will hear “Duo Mode connected”.
- To disconnect Duo Mode press and hold SUPER BASS button until you hear “Duo Mode disconnected”.

Technical specification

Model	PS-929
Rated Power Consumption	20W
Standby Power Consumption	<0.5W
Output Power	2 x 25 W (RMS)
Total max power output	180 W
Frequency Response	40Hz-15KHz
Battery	Built-in lead-acid battery, DC 12V, 54Wh, 4,5Ah
Bluetooth	
Version	V5.0
Maximum power transmitted	
Frequency bands	2402 MHz ~ 2480 MHz
Power Adapter	
Model name	CW1502500RE
Input	AC100-240V ~ 50/60Hz, 1,2A Max
Output	DC 15V 2,5A
Manufacturer	Shenzhen Cenwell Technology CO., LTD Address:3F, Building C, Shengshun industrial park, Junxin Road, NiuHu, Guanlan, Shenzhen Tel: 86-0755-84160040

NOTE: Specifications are subject to change for continuous improvement without prior notice






Sharp Consumer Electronics Poland sp. z o.o. Ostaszewo 57B, 87-148 Łysomice, Poland

www.sharpconsumer.eu

SHARP

Documents / Resources

	<p>SHARP PS-929 Party Speaker System [pdf] User Manual PS-929, Party Speaker System</p>
	<p>SHARP PS-929 Party Speaker System [pdf] User Manual PS929, LMZ-PS929, LMZPS929, PS-929 Party Speaker System, PS-929, Party Speaker System</p>
	<p>SHARP PS-929 Party Speaker System [pdf] User Manual PS-929, Party Speaker System, PS-929 Party Speaker System, Speaker System, PS-929 Party Speaker</p>

References

- [S Domain Details Page](#)
- [S Sharp Consumer Products Europe - Sharp Europe](#)
- [S Sharp Consumer Products Europe - Sharp Europe](#)