



SHARP SMD2440JS Microwave Drawer Oven User Guide

[Home](#) » [Sharp](#) » SHARP SMD2440JS Microwave Drawer Oven User Guide 

SHARP® SMD2440JS Microwave Drawer Oven User Guide



MODEL
SMD2440JS
STAINLESS STEEL

Contents

- 1 CUSTOMER ASSISTANCE
- 2 IMPORTANT SAFETY INSTRUCTIONS
- 3 IMPORTANT INFORMATION
- 4 PART NAMES
- 5 BEFORE OPERATING
- 6 MICROWAVE COOKING
- 7 MICROWAVE COOKING
- 8 OTHER FEATURES
- 9 BEFORE YOU CALL FOR SERVICE
- 10 AUTO-TOUCH GUIDE
- 11 Documents / Resources
 - 11.1 References
- 12 Related Posts

CUSTOMER ASSISTANCE

REGISTER YOUR PRODUCT

Registering your new product is easy and offers benefits that help you get the most out of your Sharp product including:

- ✓ Convenience: If you ever need warranty support, your product information is already on file.
- ✓ Communication: Stay up to date with important notifications and special offers from SHARP.
- ✓ Support: Quickly access support content including Owner's Manuals, FAQ's, How-to Videos, and much more.

3 EASY WAYS TO REGISTER TODAY!

SCAN Use the camera or QR code scanning application on your mobile device	ONLINE Visit our sites to learn more about your product at sharpusa.com and sbl.sharpusa.com	CALL US US 800-BE-SHARP 800-237-4277 Mon-Fri: 7am-7pm CST Sat-Sun: 9 am-7pm CST
		
https://DELIVR.COM/2SGTH-QR	Visit http://www.sharpusa.com/register	Contact a Sharp Advisor on the phone

PRODUCT SUPPORT




If you have questions about the setup or operation of your product, please refer to the corresponding section within this manual.

Additionally, visit www.sharpusa.com/support to access exclusive content about your product including:

- FAQ's and How-To Videos
- Find or Request Service
- Extended Warranty Options
- Downloads including the Installation Guide, Spec Sheet, and Owner's Manual

CONTACT US

If at any time you have questions or comments concerning your SHARP product, please contact the SHARP Customer Assistance Center. We are available to assist you through multiple contact methods for your convenience:

EMAIL Available 24/7 US: sharpusa.com	CHAT ONLINE Mon-Fri: 7am-7pm CST Sat-Sun: 9am-7pm CST	CALL US US 800-BE-SHARP 800-237-4277 Mon-Fri: 7am-7pm CST Sat-Sun: 9am-7pm CST
		
See the Contact Us section on our sites	U.S. www.sharpusa.com/support	Contact a Sharp Advisor on the phone

PRECAUTIONS TO AVOID POSSIBLE EXPOSURE TO EXCESSIVE MICROWAVE ENERGY

- (a) Do not attempt to operate this oven with the door open since open-door operation can result in harmful exposure to microwave energy. It is important not to defeat or tamper with the safety interlocks.
- (b) Do not place any object between the oven front face and the door or allow soil or cleaner residue to accumulate on sealing surfaces.
- (c) Do not operate the oven if it is damaged. It is particularly important that the oven door close properly and that there is no damage to the: (1) door (bent), (2) hinges and latches (broken or loosened), (3) door seals and sealing surfaces.
- (d) The oven should not be adjusted or repaired by anyone except properly qualified service personnel.

US CONSUMER LIMITED WARRANTY

SHARP ELECTRONICS CORPORATION ("Sharp") warrants to the first consumer purchaser ("Purchaser") that this SHARP brand product ("Product"), when shipped in its original container and sold or distributed in the United States by Sharp or an authorized Sharp dealer or reseller, will be free from defective workmanship and materials, and agrees that it will, at its option, either repair the defect or replace the defective Product or part thereof with a new or remanufactured equivalent at no charge to the Purchaser for parts or labor for the period(s) set forth below.

This limited warranty does not apply to any appearance items of the Product nor to the additional excluded item(s) set forth below nor to any Product the exterior of which has been damaged or defaced, which has been subjected to misuse, abnormal service or handling, or which has been altered or modified in design or construction.

In order to enforce the rights under this limited warranty, the Purchaser should follow the steps set forth below and provide proof of purchase to the servicer.

The limited warranty described herein is in addition to whatever implied warranties may be granted to Purchasers by law. ALL IMPLIED WARRANTIES INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS FOR USE ARE LIMITED TO THE PERIOD(S) FROM THE DATE OF PURCHASE SET FORTH BELOW. Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you. Neither the sales personnel of the seller nor any other person is authorized to make any warranties other than those described herein, or to extend the duration of any warranties beyond the time period described above on behalf of Sharp.

The warranties described herein shall be the sole and exclusive warranties granted by Sharp and shall be the sole and exclusive remedy available to the Purchaser. Correction of defects, in the manner and for the period of time described herein, shall constitute complete fulfillment of all liabilities and responsibilities of Sharp to the Purchaser with respect to the Product, and shall constitute full satisfaction of all claims, whether based on contract, negligence, strict liability or otherwise. In no event shall Sharp be liable, or in any way responsible, for any damages or defects in the Product which were caused by repairs or attempted repairs performed by anyone other than an authorized servicer. Nor shall Sharp be liable or in any way responsible for any incident or consequential economic or property damage. Some states do not allow the exclusion of incidental or consequential damages, so the above exclusion may not apply to you.

THIS LIMITED WARRANTY IS VALID ONLY IN THE FIFTY (50) UNITED STATES, THE DISTRICT OF COLUMBIA AND PUERTO RICO.

IMPORTANT SAFETY INSTRUCTIONS

IMPORTANT Read all instructions carefully before installation and operation. Keep this Operation Manual for future use. Sharp Microwave Drawer™ Oven is manufactured in compliance with the relevant safety standard.



WARNING Failure to follow these warnings could result in a fire or explosion causing property damage, personal injury or death. To reduce the risk of fire, electric shock, exposure to excessive microwave energy or injury, use only as intended and take the following precautions.

SAFETY PRECAUTIONS WARNING

When using electrical appliances, take safety precautions, including the following:

1. Install or locate this unit only in accordance with the provided installation instructions.
2. Read all instructions before using Sharp Microwave Drawer™ Oven.
3. Read and follow specific PRECAUTIONS TO AVOID POSSIBLE EXPOSURE TO EXCESSIVE MICROWAVE ENERGY on page 2.
4. Do not store or use this appliance outdoors or in areas near water, such as near a kitchen sink, in a wet basement, near a swimming pool or similar locations.
5. Do not immerse the cord in water. Keep the cord away from heated surfaces.
6. To prevent accidents and achieve optimal ventilation, ensure sufficient space around the cooking area.
7. Do not block or cover any openings on this appliance.
8. Use the Sharp Microwave Drawer Oven only for its intended purpose as described in this manual. This appliance is designed for built-in household use only. Do not use outdoors. Do not use to heat a room. Do not use corrosive chemicals or vapors in this appliance. This appliance is specifically designed to heat, cook or dry food. It is not designed for industrial or laboratory use.™
9. Do not store or use flammable or combustible materials, gasoline or other flammable vapors and liquids in the vicinity of this appliance.
10. Use caution when removing hot items.
11. Teach children to not play with the appliance, its controls or any other part of the appliance. Hot contents can cause severe burns. Do not allow children to use the microwave oven.
12. Use only dry potholders. Moist or damp potholders on hot surfaces may cause burns from steam. Do not let potholders touch hot surfaces or radiant surface units. Do not use towels or other bulky cloth.
13. Keep fingers and clothes clear of drawer guides when the drawer is opened or closed. Fingers or clothes could be caught in the guides when the drawer is closed.
14. Have the installer identify the location of the circuit breaker or fuse. Mark it for easy reference.
15. Before performing any service, disconnect the appliance power supply at the household distribution panel by

removing the fuse or switching off the circuit breaker.


16. Do not repair or replace any part of Sharp Microwave Drawer™ Oven unless specifically recommended in this manual. All other servicing should be referred to a qualified technician.
17. Some products in sealed containers, such as whole eggs and closed glass jars, can explode and should not be heated in the Sharp Microwave Drawer™ Oven.
18. To reduce risk of fire in the oven cavity, take the following precautions.
 - Do not overcook food. Carefully attend the appliance when paper, plastic or other combustible materials are used to facilitate cooking in the Sharp Microwave Drawer™ Oven.
 - Remove wire twist-ties from paper or plastic bags before placing bag in oven cavity.
 - If materials inside the Sharp Microwave Drawer™ Oven ignite, keep the drawer closed, turn off the appliance and shut off power at the fuse or circuit breaker panel.
 - Do not use Sharp Microwave Drawer™ Oven for storage Do not leave paper products, cooking utensils or food in the oven cavity when not in use.
19. Food and containers must be shorter in height than the drawer. Refer to the height of the side walls of the drawer.
20. Use only mild, nonabrasive soaps or detergents applied with a sponge or soft cloth when cleaning the sealing surfaces that come together on closing the drawer. See CLEANING AND CARE on page 21.
21. Liquids, such as water, coffee or tea, can be overheated beyond the boiling point without appearing to boil, due to surface tension of the liquid. Visible bubbling or boiling when the container is removed from the Sharp Microwave Drawer™ Oven is not always present. This could result in VERY HOT LIQUIDS suddenly boiling over when a spoon or other utensil is inserted into the liquid.
 - To reduce the risk of injury to persons when heating liquids:
 - Do not overheat liquids.
 - Stir liquids both before and halfway through heating.
 - Do not use straight-sided containers with narrow necks. Use wide-mouthed containers.
 - After heating allow the container to stand in the Sharp Microwave Drawer™ Oven for at least 20 seconds before
 - Use extreme care when inserting a spoon or other utensil into liquids after heating.
22. If the Sharp Microwave Drawer™ Oven light fails, consult a Sharp Authorized Servicer. Only qualified service personnel should service Sharp Microwave Drawer™ Oven. Contact 1-800-BE-SHARP for the nearest Sharp Authorized Servicer for evaluation, repair and/or adjustment.

IMPORTANT INFORMATION

UNPACK THE APPLIANCE

Remove all packing materials from inside the appliance. Remove the protective film from the touch control area. Additionally, remove the feature sticker, if there is one, from outside of the Sharp Microwave Drawer Oven. Check the drawer for any damage, such as misaligned or bent drawer, damaged drawer seals and sealing surfaces, broken or loose drawer guides and dents inside the cavity or on the front side of the drawer. If there is any damage, do not operate the Sharp Microwave Drawer™ Oven and contact your dealer or a Sharp Authorized Servicer.

IMPORTANT: DO NOT REMOVE THE WAVEGUIDE COVER LOCATED ON THE TOP OF THE OVEN CAVITY.



BEFORE OPERATING

- Read and understand all instructions in this Operation Manual.
- Ensure the appliance is properly installed and connected to power according to all instructions in the included Installation Manual.
- Ensure all protective packaging materials and tape have been completely and correctly removed.


CONDITION OF UNIT Do not operate any appliance with a damaged cord or after the appliance malfunctions or has been damaged in any manner. Return the appliance to the nearest authorized service facility for examination, repair or adjustment.

SERVICE AND REPAIR WARNING

Do not repair or replace any part of the Sharp Microwave Drawer Oven. If the display, oven or touch controls fail, consult a Sharp Authorized Servicer. TM RADIO OR TV INTERFERENCE If any interference to your radio or TV is caused by the Sharp Microwave Drawer Oven, check if the appliance is on a different electrical circuit, relocate the radio or TV as far away from the appliance as feasible or check position and signal of receiving antenna.

GROUNDING INSTRUCTIONS

This appliance must be grounded. The Sharp Microwave DrawerTM Oven is equipped with a cord having a grounding wire with a grounding plug. It must be plugged into a wall receptacle that is properly installed and grounded in accordance with the National Electrical Code and local codes and ordinances. In the event of an electrical short circuit, grounding reduces risk of electric shock by providing an escape wire for the electric current.




CONDENSATION IS NORMAL

It is normal for microwave use to produce condensation, the amount of which is related to food moisture content and room humidity.

DO NOT BLOCK VENT

NEVER cover or obstruct the vent over and under the Sharp Microwave Drawer Oven. During microwave use, steam may come from the left side lower vent. Check the vent area after each use and wipe it down if needed.



MAGNETRON CYCLING IS NORMAL

The magnetron can be heard cycling on and off during microwave use with power levels below 100%. ABOUT MICROWAVE COOKING

ARRANGE FOOD CAREFULLY

Place the thickest parts of the food toward the outside of the dish.

WATCH COOKING TIME

When following recipes or package instructions, check food for doneness a minute or two before the minimum time and add time as needed.

COVER FOODS WHILE COOKING

Covers prevent spattering and help foods cook evenly. Check cookbooks and recipes for cover suggestions, such as paper towels, wax paper, microwave-safe plastic wrap or lids. See ABOUT MICROWAVE UTENSILS on page 8.

STIR FOODS REGULARLY

Stir foods once or twice during microwaving. Whenever possible, stir from the outside to the center of the dish.

TURN OVER FOODS

Turn over foods such as chicken and hamburgers at least once during microwaving to speed cooking. Large items like roasts must be turned over at least once.

REARRANGE FOODS

Rearrange foods such as meatballs halfway through microwaving by moving pieces from top to bottom and from left to right.

ADD STANDING TIME

Standing time allows cooking to finish without overcooking food. After microwave cooking, remove food, stir if possible and cover for standing time.

CHECK FOR DONENESS

Look for signs indicating the cooking temperature has been reached. Doneness signs include:

- food steams throughout, not just at edges
- center of the dish's underside is very hot to the touch
- poultry thigh joints move easily
- meat and poultry show no pinkness
- fish is opaque and flakes easily with a fork

Use a meat thermometer to check if foods are cooked to the safe temperature. See ABOUT FOOD SAFETY on page 8.

ABOUT MICROWAVE SAFETY



WARNING HOT CONTENTS CAN CAUSE SEVERE BURNS. DO NOT ALLOW CHILDREN TO USE THE MICROWAVE OVEN. Use caution when removing hot items.

To avoid spills and burns, anyone using the Sharp Microwave Drawer

Oven must be able to reach it comfortably. Anyone using the Sharp Microwave Drawer™

Oven can do so safely if they understand and take safety precautions, including the following.

ALWAYS USE POTHOLDERS

Use potholders to prevent burns when handling utensils in contact with hot food. Enough heat from the food can transfer through utensils to cause skin burns.

AVOID STEAM BURNS

Direct steam away from the face and hands. Slowly lift the farthest edge of a dish covering and carefully open cooking bags and popcorn bags away from the face.

MONITOR COOKING

Stay near the appliance when it is in use and check progress frequently to avoid overcooking food.

HANDLE FOOD CAREFULLY

Select, store and handle food carefully to preserve its high quality and minimize the spread of foodborne bacteria.

NOT FOR STORAGE


NEVER use the Sharp Microwave Drawer™ Oven for storing cookbooks or other items.

ABOUT FOOD IN THE MICROWAVE

FOODS		DO		DO NOT
eggs, sausages, fruits and	•	Puncture egg yolks before cooking to prevent bursting.	•	DO NOT cook eggs in shells. DO NOT reheat whole eggs.
vegetables	•	Pierce skins of potatoes, apples, squash, hot dogs and sausages so steam escapes.	•	DO NOT dry nuts or seeds in shells.
popcorn	•	Use popcorn specially packaged for microwave cooking.	•	DO NOT pop corn in regular brown paper bags or glass bowls.
	•	Listen for the popping of corn to slow to 1 or 2 seconds between pops to avoid overcooking.	•	DO NOT exceed the maximum cooking time listed in the package instructions.
	•	Use the special Popcorn feature by touching the		
		POPCORN pad.		
baby food	•	Transfer baby food to a small dish and heat carefully-	•	DO NOT heat disposable bottles.
		fully, stirring often.	•	DO NOT heat bottles with nipples attached.
	•	Check temperature before serving. Test temperature of bottles on your wrist before serving.	•	DO NOT heat baby food in original jars.
	•	Attach nipples to bottles AFTER heating. Shake well before serving.		
general	•	Cut filled baked goods after heating to release steam.	•	DO NOT heat or cook in closed glass jars or airtight containers.
	•	Stir liquids briskly before and after heating to avoid eruption.	•	DO NOT use the microwave for canning, as harmful bacteria may not be destroyed.
	•	Use a deep bowl when cooking liquids and cereals	•	DO NOT deep-fat fry in the microwave.
		to prevent boil-overs. Refer to the height of the side walls of the Sharp Microwave Drawer Oven.	•	DO NOT dry wood, gourds, herbs or wet papers.

PART NAMES

SHARP MICROWAVE DRAWER OVEN



1. Control panel & keysheet
2. Waveguide cover DO NOT REMOVE
3. Name plate: open the drawer fully. The label is beyond the back wall of the microwave cavity facing up from the flat surface.
4. Drawer sealing surfaces
5. Drawer light
6. Drawer guides
7. Vent
8. Menu label
9. Built-in flush mount



Numbers next to the keysheet illustration indicate pages containing feature descriptions and usage information.

SENSOR COOK	DEFROST	ROLLS/MUFFINS	BEVERAGE	MELT/SOFTEN
1 Fresh Vegetables: Quick 5 Ground Meat 2 Fresh Vegetables: Longer 6 Fish/Seafood 3 Frozen Vegetables 7 White Rice 4 Sweet Potatoes 8 Brown Rice	1 Ground Meat 2 Steaks/Chops 3 Boneless Poultry 4 Bone-in Poultry 5 Roast 6 Casserole or Soup	1 Fresh Rolls/Muffins 2 Frozen Rolls/Muffins	1 Beverage Reheat 2 Hot Water 3 Hot Cereal	Melt 1 Butter 2 Chocolate
				Soften 3 Ice Cream 4 Cream Cheese
				Warm 5 Syrup 6 Dessert Toppings

BEFORE OPERATING

BEFORE USE

1. Plug in the Sharp Microwave Drawer™ Oven. ENJOY YOUR MICROWAVE TOUCH CLEAR AND TOUCH CLOCK appears on the display.
2. Touch STOP/CLEAR pad. : appears on the display.

SET THE CLOCK

1. Touch Timer/Clock pad. TO SET TIMER TOUCH 1 TO SET CLOCK TOUCH 2 appears on the display.
2. Touch 2 pad to set clock. ENTER TIME appears on the display.
3. Use number pads to enter time of day. TOUCH CLOCK appears on the display.
4. Touch Timer/Clock pad to accept entered time of day.

TIMER

To set the timer:

1. Touch Timer/Clock pad. TO SET TIMER TOUCH 1 TO SET CLOCK TOUCH 2 appears on the display.
2. Touch 1 pad to set the timer. ENTER TIME appears on the display.
3. Use number pads to enter time. TOUCH TIMER appears on the display. The time counts down.
4. Touch STOP/CLEAR pad to cancel the timer. An audible signal will sound when the countdown completes.
STOP/CLEAR

Touch STOP/CLEAR pad to:

- erase a mistake
- cancel the timer
- pause heating
- return the time of day to the display
- cancel a program
- cancel timed cooking

OPEN/CLOSE

IMPORTANT Do not pull the drawer open by hand except in the case of emergency such as power failure. If necessary, push or pull the drawer gently and slowly.


TO OPEN MICROWAVE DRAWER

- Touch OPEN/CLOSE pad on the glass touch control.
TO CLOSE MICROWAVE DRAWER
- Touch OPEN/CLOSE pad on the glass touch control OR gently push on the drawer.


CONTROL LOCK

The Control Lock prevents unwanted operation such as by small children. The Sharp Microwave Drawer Oven can be set so the control panel and the automatic drawer mechanism are deactivated or locked.

TO LOCK CONTROL PANEL

- Touch and hold  pad for 3 seconds. LOCK ON appears on the display.

TO UNLOCK CONTROL PANEL

- Touch and hold  pad for 3 seconds. LOCK OFF appears on the display.

NOTE: If the electrical power to the appliance or home is interrupted, the Control Lock is NOT activated when power is restored.

When power to the oven is restored, re-lock the control panel.

POWER OUTAGE

If the electrical power supply to the appliance is interrupted, after power is reinstated, ENJOY YOUR MICROWAVE TOUCH CLEAR AND TOUCH CLOCK intermittently appears on the display. If power is lost during cooking, the programming and the time of day are erased. Touch STOP/CLEAR pad, reset the clock and re-program the appliance.

MICROWAVE COOKING

TIME COOKING

The Sharp Microwave Drawer™ Oven can be programmed for cooking times up to 99 minutes 99 seconds (99.99). Always enter the seconds after the minutes; if there are no seconds in the cooking time, enter two zeros (for three minutes, touch number pads to enter 3-0-0).

TO MICROWAVE COOK

Suppose you want to cook for 5 minutes at 100% power.

1. Touch number pads to enter cooking time 5-0-0. 5.00 TOUCH START OR TOUCH POWER LEVEL appears on the display.
2. Touch START/+30 SEC pad for 100% power. The timer on the display counts down.

NOTE: For best cooking results and to avoid spatters, some foods should be covered. See MICROWAVE COVERINGS on page 8 and refer to hints by touching the Help/Settings pad for recommendations. Always allow steam to escape away from face and hands when removing any covering.

POWER LEVEL

There are eleven preset power levels. Using lower power levels increases the required cooking time, which is recommended for foods such as cheese and milk and long, slow cooking of meats. Consult a microwave cookbook or recipes for specific recommendations.

TO SET POWER LEVEL

- Suppose you want to heat for 8 minutes at 30% power.
 - 1 Touch number pads to enter time 8-0-0. 8.00 TOUCH START OR TOUCH POWER LEVEL appears on the display.
 - 2 Touch POWER LEVEL pad eight times. P – 30 appears on the display for 30% microwave power.
 - 3 Touch START/+30 SEC pad.

POWER LEVEL CHART

POWER LEVEL	TOUCH POWER LEVEL PAD	RECOMMENDED USE
100%	1 time	brown foods, boil liquids or cook fish, ground meats, bacon and vegetables
90%	2 times	
80%	3 times	
70%	4 times	cook meats and poultry gently, bake casseroles and convenience foods, sauté or reheat foods
60%	5 times	
50%	6 times	slow-cook or braise foods
40%	7 times	
30%	8 times	defrost foods, simmer liquids or cook delicate sauces
20%	9 times	
10%	10 times	heat breads or soften butter, cheese or chocolate
0%	11 times	

SENSOR SETTINGS



The Sensor Cook center includes many Smart & Easy™ settings to cook the most popular microwaved foods without the need to calculate cooking time or power level. Sharp's Sensor is a semi-conductor device that detects vapor (moisture and humidity) emitted from food as it heats.

ABOUT SENSOR COOKING

- Wait two minutes after initially plugging in the appliance before using a Sensor setting.
- Wipe off any moisture from the exterior of the food container and the interior of the microwave cavity before using a Sensor setting.
- The sensor works with foods at normal storage temperature.
For example, popcorn would be at room temperature.
- Foods of different quantities than listed on the menu label can be cooked manually according to instructions found in any microwave cookbook.
- During the first part of sensor use, the food name appears on the display. Do not open the Sharp Microwave Drawer™ Oven or touch STOP/CLEAR during this part of the cycle, as the measurement of vapor will be interrupted. If the cycle is interrupted, ERROR appears on the display. To continue cooking, touch STOP/CLEAR pad and cook manually.
- When the sensor detects vapor emitted from food, the remaining cooking/reheating time appears on the display. At this time, the Sharp Microwave Drawer™ Oven may be opened to allow for stirring or seasoning of food.
- If the sensor does not detect vapor properly when cooking foods (except popcorn), ERROR appears on the display. To continue cooking, touch STOP/CLEAR pad and cook manually.

- Check food temperature after cooking. If more time is needed, continue to cook manually.

COOKING HINT

Each Smart & Easy™ menu item has a cooking hint. To view the hint, touch Help/Settings pad when HELP appears on the display. Cooking hints include recommended coverings and quantity/weight ranges. For example, the cooking hint for Sweet Potatoes is:

- PIERCE SKIN
- PLACE ON PAPER TOWEL
- QTY RANGE 1 – 6 PIECES

MICROWAVE COOKING

SENSOR COOK

See ABOUT SENSOR COOKING on page 12 for more information.

1. Touch Cook pad. SEE LABEL SELECT FOOD NUMBER appears on the display.
2. Touch a number pad to select food item. The name of the food item and TOUCH START appear on the display.
3. Touch START/+30 SEC pad. The name of the food item and SENSOR COOK appear on the display during vapor measurement. Once the vapor has been measured, the cook time appears on the display and counts down.
4. Once cooking is complete, instructions such as STIR LET STAND COVERED appear on the screen, depending on the food item. See the chart below for more information.

SMART & EASY™ CHART

FOOD	AMOUNT	PROCEDURE
1 Fresh Vegetables: Quick <ul style="list-style-type: none"> • broccoli • brussels sprouts • cabbage • cauliflower (florets) • cauliflower (whole) • spinach • zucchini • baked apples 	0.25–2 lb 0.25–2 lb 0.25–2 lb 0.25–2 lb 1 med 0.25–2 lb 0.25–2 lb 2–4 med	Wash fresh vegetables and place in casserole dish. Add no water to freshly washed quick vegetables. For tender vegetables, cover with lid. For tender-crisp vegetables, cover with plastic wrap. <ul style="list-style-type: none"> • Touch COOK pad. • Touch 1 pad for Fresh Vegetables: Quick. • Touch START/+30 SEC. After cooking, stir, if possible, recover and let stand for 2 to 5 minutes.
2 Fresh Vegetables: Longer <ul style="list-style-type: none"> • carrots (sliced) • corn (on cob) • green beans • winter squash (diced) • winter squash (halves) 	0.25–1.5 lb 2–4 pieces 0.25–1.5 lb 0.25–1.5 lb 1–2 halves	Wash fresh vegetables and place in casserole dish. Add 1–4 tablespoons water. For tender vegetables, cover with lid. For tender-crisp vegetables, cover with plastic wrap. <ul style="list-style-type: none"> • Touch COOK pad. • Touch 2 pad for Fresh Vegetables: Longer. • Touch START/+30 SEC. After cooking, stir, if possible, recover and let stand for 2 to 5 minutes.

3 Frozen Vegetables	0.25–1.25 lb	Place frozen vegetables in casserole dish. Add no water to frozen vegetables. Cover with lid or plastic wrap. • Touch COOK pad. • Touch 3 pad for Frozen Vegetables. • Touch START/+30 SEC. After cooking, stir, if possible, recover and let stand for 3 minutes.
4 Sweet Potatoes	1–6 med	Pierce potatoes at least three times each on the top, bottom and sides to allow steam to escape. Place potatoes on paper towel. • Touch COOK pad. • Touch 4 pad for Sweet Potatoes. • Touch START/+30 SEC. After cooking, remove from oven, wrap in aluminum foil and let stand 5 to 10 minutes.
5 Ground Meat • patties • bulk	0.25–2 lb 0.25–2 lb	To cook ground meat patties, place patties on a microwave safe dish and cover with wax paper. To cook bulk ground meat to be added to dishes, place ground meat in casserole dish and cover with wax paper or plastic wrap. • Touch COOK pad. • Touch 5 pad for Ground Meat. • Touch START/+30 SEC. • When microwave pauses, turn over patties or stir bulk meat to break up large pieces. • Recover and touch START/+30 SEC. After cooking, leave meat covered and let stand for 2 to 3 minutes.
6 Fish/Seafood	0.25–2 lb	Arrange fish or seafood in a ring in a shallow glass dish (roll fillet edges underneath). Cover with vented plastic wrap. • Touch COOK pad. • Touch 6 pad for Fish/Seafood. • Touch START/+30 SEC. After cooking, leave covered and let stand for 3 minutes.
7 White Rice	0.5–2 cups	Place rice in a deep casserole dish and add double quantity of water. Cover with lid or plastic wrap. • Touch COOK pad. • Touch 7 pad for White Rice. • Touch START/+30 SEC. After cooking, stir, recover and let stand 3 to 5 minutes or until all liquid has been absorbed.
8 Brown Rice	0.5–2 cups	Place rice in a deep casserole dish and add double quantity of water. Cover with lid or plastic wrap. • Touch COOK pad. • Touch 8 pad for Brown Rice. • Touch START/+30 SEC. After cooking, stir, recover and let stand 3 to 5 minutes or until all liquid has been absorbed.

OTHER FEATURES

- If the electrical power supply to the Sharp Microwave Drawer™ HELP/SETTINGS Oven should be interrupted, after power is reinstated, ENJOY YOUR MICROWAVE TOUCH CLEAR AND TOUCH CLOCK flashes intermittently on the display, and any settings previously programmed are erased. To reprogram settings, touch STOP/CLEAR pad and reset.

- **AUDIBLE SIGNAL ELIMINATION**

At the end of timed cook, beeps will sound. The audible signal can be turned off if you prefer quiet operation.

TO TURN OFF SOUND

1. Touch Help/Settings pad. TOUCH AGAIN appears on the display.
2. Touch Help/Settings pad. SOUND OFF? TOUCH START appears on the display.
3. Touch START/+30 SEC pad. SOUND OFF appears on the display.

- **TO RESTORE SOUND**

1. Touch Help/Settings pad. TOUCH AGAIN appears on the display.
2. Touch Help/Settings pad. SOUND ON? TOUCH START appears on the display.
3. Touch START/+30 SEC pad. SOUND ON appears on the display.

- **END OF COOKING REMINDER**

At end of timed cooking, the microwave will signal every 10 seconds for the first minute, then every 3 minutes for up to an hour or until STOP/CLEAR pad is touched.

TO TURN OFF REMINDER

1. Touch Help/Settings pad. TOUCH AGAIN appears on the display.
2. Touch Help/Settings pad two times. REMIND SIGNAL OFF?
TOUCH START appears on the display.
3. Touch START/+30 SEC pad. REMIND SIGNAL OFF appears on the display.

- **TO TURN REMINDER SIGNAL BACK ON**

1. Touch Help/Settings pad. TOUCH AGAIN appears on the display.
2. Touch Help/Settings pad two times. REMIND SIGNAL ON?
TOUCH START appears on the display.
3. Touch START/+30 SEC pad. REMIND SIGNAL ON appears on the display.

- **AUTO START**

To delay the start of cooking, use Auto Start to set the time of day you want cooking to start.

Do not let food sit in oven for more than one hour before or after cooking. Doing so can result in risk of food poisoning or sickness.

1. Touch Help/Settings pad. TOUCH AGAIN appears on the display.
2. Touch Help/Settings pad three times. AUTO START TOUCH START appears on the display.
3. Touch START/+30 SEC pad. ENTER START TIME appears on the display.
4. Touch number pads to enter start time. TOUCH CLOCK appears on the display.
5. Touch Timer/Clock pad. ENTER COOKING TIME appears on the display.
6. Touch number pads to enter cooking time. TOUCH START OR TOUCH POWER LEVEL appears on the display.

7. Touch Power Level pad to adjust power level, if necessary.

TOUCH START appears on the display.

8. Touch START/+30 SEC pad. AUTO START, followed by the entered start time and ON appear on the display.
To cancel Auto Start, simply touch STOP/CLEAR pad.

• **DEMONSTRATION MODE**

In Demo Mode, the magnetron tube does not function and the display counts down quickly. This mode is used during sales or to explore the unit without heating. All displays operate and light normally, and the drawer opens and closes by use of the OPEN/CLOSE keypad.

TO SET DEMO MODE

1. Touch Help/Settings pad. TOUCH AGAIN appears on the display.
2. Touch Help/Settings pad four times. DEMO ON? HOLD START 3 SEC appears on the display.
3. Touch and hold START/+30 SEC pad for three seconds.
DEMO ON appears on the display.
4. Until Demo Mode is turned off, DEMO appears on the display.

• **TO TURN OFF DEMO MODE**

1. Touch Help/Settings pad. TOUCH AGAIN appears on the display.
2. Touch Help/Settings pad four times. DEMO OFF? TOUCH START appears on the display.
3. Touch START/+30 SEC pad. DEMO OFF appears on the display.

• **CLEANING AND CARE**

• **EXTERIOR**

The outside surface is precoated metal and plastic. Clean the outside with mild soap and water, then rinse and dry with a soft cloth. Do not use any type of household or abrasive cleaner.

STAINLESS STEEL SURFACE

The exterior should be wiped often with a damp soft cloth and polished with a dry soft cloth to maintain its beauty. There is also a variety of products designed especially for cleaning and shining the stainless exterior of the oven. We recommend the cleaner be applied to a soft cloth and then carefully used on the stainless exterior rather than sprayed directly on to it. Follow package directions carefully.

FRONT SIDE OF THE DRAWER

Wipe the window on both sides with a damp soft cloth to remove any spills or spatters. Metal parts will be easier to maintain if wiped frequently with a damp soft cloth. Avoid the use of spray and other harsh cleaners, as they may stain, streak or dull the drawer surface.

TOUCH CONTROL PANEL

The touch-pads may be deactivated before cleaning the control panel. To lock the control panel, touch and hold pad for 3 seconds. LOCK ON appears on the display.

Wipe the panel with a soft cloth slightly dampened with water only, then wipe dry with a dry soft cloth. Do not scrub or use any sort of chemical cleaners.

To unlock the control panel, Touch and hold pad for 3 seconds.

LOCK OFF appears on the display. Touch STOP/CLEAR pad.

INTERIOR

Cleaning the interior is easy because no heat is generated to interior surfaces, thus there is no baking and setting of spills or spattering. To prevent the drawer closing and opening during cleaning, lock the control panel.

To clean interior surfaces, including drawer sealing surfaces, wipe with a damp soft cloth. For heavier soil, use mild soap and wipe clean with a damp soft cloth.

IMPORTANT: DO NOT USE ABRASIVE OR HARSH CLEANERS, CHEMICAL OVEN CLEANERS OR SCOURING PADS.

• DRAWER GUIDES

Remove the food crumbs from the drawer guides. Wipe with a dry soft cloth keep the Sharp Microwave Drawer Oven opening and closing smoothly.

WAVEGUIDE COVER

ATTENTION

The waveguide cover, located on the inside top of the Sharp Microwave Drawer™ Oven area, is made from mica, so it requires special care. Keep the waveguide cover clean to assure good microwave performance. Use a damp soft cloth to carefully wipe any food spatters from the surface of the cover immediately after they occur. Built-up splashes may overheat and cause smoke or catch fire. Do not remove the waveguide cover.

ODOR REMOVAL

Occasionally, a cooking odor may remain in the Sharp Microwave Drawer™ Oven. To remove odor, combine 1 cup water, grated peel and juice of one lemon and several whole cloves in a 2-cup glass microwave-safe measuring cup. Boil for several minutes using 100% power. Leave in the Sharp Microwave Drawer™ Oven until water cools. Wipe interior with a soft cloth.

BEFORE YOU CALL FOR SERVICE

Please check the following before calling for service. It may save you time and expense.

PROBLEM	POSSIBLE CAUSE	SOLUTION
1 Part or all of Sharp Microwave Drawer Oven does not operate.	• Power cord is not completely connected to the electrical outlet.	• Make sure the power cord is tightly connected to the outlet.
	• Power outage.	• Check house lights to be sure. Call your local electric company for service.
	• Fuse/circuit breaker at home doesn't work.	• Replace the fuse or reset the circuit breaker.
	• Oven is in Demo Mode.	• See page 19.
2 Food in Sharp Microwave Drawer Oven is not heated.	• No power to the appliance.	• See SOLUTION for PROBLEM 1.
	• Drawer controls improperly set.	• Check if the controls have been properly set.
	• Drawer is in Demo Mode.	• See page 19.
3 Sharp Microwave Drawer Oven light does not work.	• Light bulb is loose or burned out.	• Call for service.
4 Touch controls will not operate.	• Control Lock is on.	• See page 20.
5 Display flashes.	• Power failure.	• Touch STOP/CLEAR pad and reset the clock. If the oven displays error code, reset the cooking function.
6 Steam from the vent	• During microwaving, steam may come from the right side of the vent.	• This is normal.

AUTO-TOUCH GUIDE

For more complete information and safety precautions, refer to your Operation Manual.

SET THE CLOCK

1. Touch Timer/Clock pad.
2. Touch 2 pad to set clock.
3. Use number pads to enter time of day.
4. Touch Timer/Clock pad to accept entered time of day.

KEEP WARM

Use the Keep Warm feature to keep food warm for up to 30 minutes. The feature can be used directly or in sequence with timed cooking.

DIRECT USE

5. Touch Keep Warm pad.
6. Touch number pads to enter desired warming time in minutes and seconds. To warm for 30 minutes, touch 3-0-0-0.
7. Touch START/+30 SEC pad. The oven will start, and the display will show the timer counting down with KEEP WARM appearing intermittently during count down.

KEEP WARM AFTER TIMED COOK

1. Touch number pads to enter cook time in minutes and seconds.
2. If necessary, set the power level by touching Power Level pad repeatedly until the correct level is displayed.
3. Touch Keep Warm pad.
4. Touch number pads to enter desired warming time in minutes and seconds.
5. Touch START/+30 SEC pad. The timed cooking will start.

When cooking is complete, a long tone will sound and the Keep Warm feature will start. The display will show the timer counting down with KEEP WARM appearing intermittently during count down.

TIMER

To set the timer:

1. Touch Timer/Clock pad.
2. Touch 1 pad to set the timer.
3. Use number pads to enter time. The time counts down.
4. Touch STOP/CLEAR pad to cancel the timer. An audible signal will sound when the countdown completes.

CONTROL LOCK

The Control Lock prevents unwanted drawer operation such as by small children. The Sharp Microwave Drawer™ Oven can be set so the control panel and the automatic door mechanism are deactivated or locked.

TO LOCK

Touch and hold  pad for 3 seconds.
TO UNLOCK

Touch and hold  pad for 3 seconds.

HELP/SETTINGS

Check operation manual for specific details.

Touch Help/Settings pad:

- 2 times for Sound Off/On.
- 3 times for End of Cooking Reminder.
- 4 times for Auto Start.
- 5 times for Demonstration Mode.

TIME COOKING

HIGH POWER COOKING

1. Touch number pads to enter cooking time.
2. Touch START/+30 SEC pad for 100% power. The timer on the display counts down VARIABLE POWER COOKING
 - 1 Touch number pads to enter time.
 - 2 Touch POWER LEVEL pad repeatedly to select power level.
 - 3 Touch START/+30 SEC pad.

SENSOR COOK

See ABOUT SENSOR COOKING on page 13 for more information.

1. Touch Cook pad.
2. Touch a number pad to select food item.
3. Touch START/+30 SEC pad.
4. Once cooking is complete, instructions such as STIR LET STAND COVERED appear on the screen, depending on the food item.

See the chart below for more information.

MELT/SOFTEN

1. Touch Melt/Soften pad.
2. Touch a number pad to select food item.
3. Repeat touching the same number pad to select quantity.
4. Touch START/+30 SEC pad.


DEFROST

The Defrost feature uses lower power level to gently defrost foods shown on the menu label.

1. Touch Defrost pad.
2. Touch number pads to select food number.
3. Touch number pads to enter weight.
4. Touch START/+30 SEC pad.
5. The oven will pause so the food can be checked. Open the Sharp Microwave Drawer™ Oven and follow instructions on the display.
6. Touch START/+30 SEC pad.
7. After each audible signal, turn the food over and touch START/+30 SEC pad again.

SHARP
SHARP ELECTRONICS CORPORATION
 100 Paragon Drive
 Montvale, New Jersey 07645

Documents / Resources

 <p>SHARP SMD2440JS Microwave Drawer Oven</p>	<p>SHARP SMD2440JS Microwave Drawer Oven [pdf] User Guide SMD2440JSS, SMD2440JS, SMD2440JS Microwave Drawer Oven, Microwave Drawer Oven, Drawer Oven, Oven</p>
--	---

References

- [Simply Better Living – SHARP | Simply Better Living](#)
- [Sharp Electronics | SharpUSA](#)
- [Sharp Electronics | SharpUSA](#)

-  [Sharp Electronics - Sign in](#)
-  [Support](#)