




SHOWVEN Sparkular Triple 3-Way Nozzle Cold Spark Machine User Manual

[Home](#) » [Showven](#) » SHOWVEN Sparkular Triple 3-Way Nozzle Cold Spark Machine User Manual 

Contents

- [1 SHOWVEN Sparkular Triple 3-Way Nozzle Cold Spark Machine](#)
- [2 Safety Considerations](#)
- [3 Feature](#)
- [4 Operation Panel](#)
- [5 Control button area](#)
- [6 Radio frequency identification area](#)
- [7 Interface](#)
- [8 Error information](#)
- [9 Advanced menu](#)
- [10 Warranty instructions](#)
- [11 Warranty card](#)
- [12 Documents / Resources](#)
- [13 Related Posts](#)

SHOWVEN®

SHOWVEN Sparkular Triple 3-Way Nozzle Cold Spark Machine



Safety Considerations

- Never touch the nozzle of SPARKULAR TRIPLE, danger of getting burnt.
- Never touch the sparks which shooting out from the nozzle.
- Cover of nozzle of SPARKULAR TRIPLE is prohibited.
- Keep audience, animals or flammable objects at a minimum distance of 3m (for front and rear side) and 5m (for left and right side) from SPARKULAR TRIPLE. Make sure sparks shoot out from SPARKULAR TRIPLE can NOT touch any objects in the air.
- Ensure that children, animals and unauthorized persons don't have access to the SPARKULAR TRIPLE!
- Unauthorized repair are prohibited, it may cause serious incident.
- Keep SPARKULAR TRIPLE dry and do NOT use in rain or snow.
- Make sure lid of feeding hopper are well covered when use SPARKULAR TRIPLE. Accidentally burn-ing of Composite Ti can only use sands to extinguish. Composite Ti should keep away from moisture and stored in a dry sealed environment.
- Clear material is necessary both before and after the show. Please check nozzle of SPARKULAR TRIPLE after each show, if there are consumable agglomerated in the nozzle, please clear it with screwdriver, otherwise it will affect the sparks effects and even damage the machine.
- Maximum cascade of SPARKULAR TRIPLE is 2 units with one standard power cable. Otherwise it may damage the machine and even cause fire.
- For better heat dissipation, block the air intake and air outlet is prohibited.

Model: BT51/BT52



Parameters

Dimension	400×290×270mm
Weight	20kg
Input	BT51:AC200-240V, 50/60Hz BT52:AC100-120V, 50/60Hz
Work power	1500w
Working Temperature	-10°C~ 50 °C
Casing	Metal
Effect height	2.0-4.0m adjustable (HC8200 MEDIUM) 2.0-5.0m adjustable (HC8200 LARGE)
Hopper capacity	160g * 3
HC8200 consumption	17g/min * 3

Feature

- Triple heads, multi effect
- Each nozzle can be controlled separately
- Faster response, stronger bursts
- RDMX function, status can be monitored by original host controller


Operation Panel

LED display area:



READY1, READY2, READY3 shows the status of 3 heads respectively; After turn on, the machine pre-heating automatically, pre-heating time is around 5min. When “READY” turns from flashing into long on, indicates that the machine is ready to work. DMX: Flashing shows that DMX signal is connected, otherwise is without signal

Control button area



- MENU: Short press to switch interface, press for 3 seconds can switch to the advanced setup interface.
- DOWN: Parameters down
- UP: Parameters up
- ENTER: Confirm and save parameters

Radio frequency identification area



Please note that granules RFID card can increase the single machine specific working time. The card is disposable, can only use once.

Interface

Main Interface:

580	580	580
DMX	1	10.22

First line: temp. and error info. of each nozzle of machine Left shows nozzle 3, middle shows nozzle 2, right show nozzle 1. Second line: shows DMX address, and remaining working time 10min 22seconds

Error information

Error information	Explanation
E0 System IC	System error.
E2 Temp. Sensor	Temperature sensor was damaged.
E3 P Temp. Over	Machine stops working due to the chassis temperature is too high
E4 Time Remain	Insufficient granules or remaining time, please swiping RFID card.
E5 K Temp. Over	Machine stops working due to the inner core temperature is too high
E6 Heat Fail	Heating failed.

Setting interface

Press “MENU” to enter the Setting interface, press the “MENU” button to enter different options until you return to the main interface.

Options	Range	Instructions
Set DMX Address	1-512	Set the DMX address.
Manual Fountain	ON/OFF	Manual fountain switch, for testing purpose only.
Fountain Height	1-10	Manual fountain, set shooting height, for testing purpose only.

Advanced menu

Press “MENU” 3 seconds to enter the advanced setup interface, press MENU key to enter different options, wait 3 seconds to return to the main interface.

Options	Range	Explanation
Set Temperature	500-610	Setup inner Core temperature. Please don't change default value without engineer's suggestion from SHOWVEN.
Auto Heat	ON/OFF	Auto preheat function switch after turning on machine
Density	70-100	Adjust the sparks density. Please don't change default value without engineer's suggestion from SHOWVEN.
Mode Selection	Factory Mode/ User Mode	Factory Mode is factory debugging mode, User Mode is using mode
Default Parameter Mode		Press “ENTER” to restore all parameters to the factory settings.
Standby Switch	On/Off	When it's on, the machine can only generate spark when pre-heating finish.

When using the DMX controller, the system takes 6 channels, each nozzle takes 2 channels.

First channel (nozzle 1)	Functions
0-15	Fountain OFF
16-255	Fountain ON, Height adjustable
Second Channel (nozzle 1)	Functions
60-80	Clear Material
20-40	Emergency Stop
0-10	Pre-heat OFF Disable in Auto-heat
240-255	Pre-heat ON Disable in Auto-heat

Please set DMX address following the below rules when connecting with the SHOWVEN host controller.

SPARKULAR TRIPLE No.	1	2	3	4	5	6
DMX Address	1	7	13	19	25	31

Note: Wrong DMX address setting may cause uncontrolled shooting of SPARKULAR TRIPLE.

Warranty instructions

- Sincere thanks for your choosing our products, you will receive quality service from us.
- The product warranty period is one year, If there is any quality problems, we can exchange brand new same model machine to you within seven days after receiving the product.
- We will offer free of charge maintenance service for machines which with hardware malfunction (except for the instrument damage caused by human factors) in the warranty period. Please don't repair the machine without factory permission.

Below situation NOT included in warranty service:

1. Damage caused by improper transportation, using, management, and maintenance, or damage caused by human factors;
2. Disassemble, modified or maintain products without Showven's permission;
3. Damage caused by external reasons (lightning strike, power supply etc);
4. Damage caused by improper installation or use; For product damage not included in the warranty range, we can provide paid service. An invoice and warranty card are necessary when asking for service from SHOWN

Warranty card

Product Name:		Serial NO.	
Purchase Date:			
Contact Number:			
Address:			
Customer Feedback Information:			
Actual malfunction:			
Maintenance details:			
Maintenance person:		Maintenance Date:	


Showven Technologies Co., Ltd

Add: Building B1, Changsha E Center No.18, Xiangtai Road, Liuyang Economic Development Zone, Changsha

City, 410300, Hunan Province, P.R.China.

- Tel: +86-731-83833068
- Web: www.showven.cn
- E-mail: info@showven.cn

Documents / Resources

	<p>SHOWVEN Sparkular Triple 3-Way Nozzle Cold Spark Machine [pdf] User Manual Sparkular Triple 3-Way Nozzle Cold Spark Machine, Sparkular Triple</p>
---	--