




SMARTBCON192 DMX 512 Metal Controller for Professional Show Lighting Control User Manual

[Home](#) » [SMARTBCON192](#) » SMARTBCON192 DMX 512 Metal Controller for Professional Show Lighting Control User Manual 

SMARTBCON 192 DMX 512 CONTROLLER



USER MANUAL

Contents

- [1 BEFORE YOU BEGIN](#)
- [2 INTRODUCTION](#)
- [3 OPERATING INSTRUCTIONS](#)
- [4 APPENDIX](#)
- [5 Documents / Resources](#)

BEFORE YOU BEGIN

1.1 What are included

1. DMX-512 Controlle
2. DC 9-12V 500mA, 90V~240V Power Adapter

3. Manual

1.2 Unpacking Instructions

Immediately upon receiving a fixture, carefully unpack the carton, check the contents to ensure that all parts are present, and have been received in good condition. Notify the shipper immediately and retain packing material for inspection if any parts appear damaged from shipping or the carton itself shows signs of mishandling. Save the carton and all packing materials. In the event that a fixture must be returned to the factory, it is important that the fixture be returned in the original factory box and packing.

1.3 Safety Instructions



Please read these instructions carefully, which includes important information about the installation, usage and maintenance .

- Please keep this User Guide for future consultation. If you sell the unit to another user, be sure that they also receive this instruction booklet.
- Always make sure that you are connecting to the proper voltage and that the line voltage you are connecting to is not higher than that stated on decal or rear panel of the fixture.
- This product is intended for indoor use only!
- To prevent risk of fire or shock, do not expose fixture to rain or moisture. Make sure there are no flammable materials close to the unit while operating.
- The unit must be installed in a location with adequate ventilation, at least 50cm from adjacent surfaces. Be sure that no ventilation slots are blocked.
- Always disconnect from power source before servicing or replacing lamp or fuse and be sure to replace with same lamp source.
- In the event of serious operating problem, stop using the unit immediately. Never try to repair the unit by yourself. Repairs carried out by unskilled people can lead to damage or malfunction. Please contact the nearest authorized technical assistance center. Always use the same type spare parts.
- Don't connect the device to a dimmer pack.
- Make sure power cord is never crimped or damaged.
- Never disconnect power cord by pulling or tugging on the cord.
- Do not operate this device under 113 F ambient temperature conditions.

INTRODUCTION

2.1 Features


- DMX512/1990 Standard
- Controls 12 intelligent lights of up to 16 channels, totally 192 channels
- 23 banks, each with 8 scenes; 6 chase, each with up to 184 scenes
- Record up to 6 chases with fade time and speeds
- 16 sliders for direct control of channels
- MIDI control over banks, chases and blackout
- Built-in microphone for music mode
- Black out
- 4 digital LED display. 1st chases, 2nd scenes, 3rd & 4th banks
- Auto mode program controlled by fade time sliders

- DMX in/out: 3 pin XRL
- Plastic end housing
- Auto-save last running program when switch off/power off and continue to run last running program while switch ON or power ON again.

2.2 General Overview


- The Controller is a universal intelligent lighting controller. It allows to control 12 fixtures composed of 16 channels each and up to 184 programmable scenes. Six chase banks can contain up to 184 steps composed of the saved scenes and in any order. Programs can be triggered by music, midi, automatically or manually. All chases can be executed at the same time.
- On the surface you will find various programming tools such as 8 universal channel sliders, quick access scanner and scene buttons, and an LED display indicator for easier navigation of controls and menu functions.

2.3 Product Overview (front)



| ITEM | Button or Fader | Function |
|------|------------------------|--|
| 1 | Scanner select buttons | Fixture selection |
| 2 | Scanner indicator LEDS | Indicates the fixtures currently selected |
| 3 | Scene select buttons | Universal bump buttons representing scene location for storage and selection |
| 4 | Channel faders | For adjusting DMX values, Ch 1~8 can be adjusted immediately after pressing the respective scanner select button, CHL 9-16 after pressing the Page select button |
| 5 | Program button | Used to enter programming mode |
| 6 | Music/Bank Copy button | Used to activate Music mode and as the copy command during programming |
| 7 | LED display window | Status window displays pertinent operation data |
| 8 | Mode Indicator LEDS | Provides operating mode status, (manual, music or auto) |
| 9 | Bank Up button | Function button to traverse Scene/Steps in banks or chases |
| 10 | Bank Down button | Function button to traverse Scene/Steps in banks or chases |
| 11 | Tap Display button | Sets the chase speed by tapping, and toggles between values and percentages. |
| 12 | Blackout button | Sets the shutter or dimmer value of all fixtures to 0 Causing all light output to cease |
| 13 | Midi/ADD button | Activates MIDI external control and also used to confirm the record/save process |
| 14 | Auto/Del button | Used to activate Auto mode and as the delete function key during programming |
| 15 | Chaser buttons | Chase memory 1 ~ 6 |
| 16 | Speed fader | This will adjust the hold time of a scene or a step within a chase |
| 17 | Fade-Time fader | Also considered a cross-fade, sets the interval time between two scenes in a chase |
| 18 | Page A Indicator LED | Represents Ch 1~8 range selected, |
| 19 | Page B Indicator LED | Represents Ch 9~16 range selected |
| 20 | Page select button | In manual mode, press to toggle between pages of control. |

2.3 Product Overview (front)



| ITEM | Button or Fader | Function |
|------|----------------------|---|
| 21 | MIDI input port | For external triggering of Banks and Chases using a MIDI device |
| 22 | DMX output connector | DMX control signal |
| 23 | DC Input jack | Main power feed |
| 24 | USB Lamp socket | |
| 25 | ON/OFF power switch | Turns the controller on and off |

2.5 Common Terms

The following are common terms used in intelligent light programming.

Blackout is a state by where all lighting fixtures light output are set to 0 or off, usually on a temporary basis

DMX-512 is an industry standard digital communication protocol used in entertainment lighting equipment. For more information read Sections DMX Primer and DMX Control Mode in the Appendix.

Fixture refers to your lighting instrument or other device such as a fogger or dimmer of which you can control.

Programs are a bunch of scenes stacked one after another. It can be programmed as either a single scene or multiple scenes in sequence

Scenes are static lighting states.

Sliders also known as faders.

Chases can also be called programs. A chase consists of a bunch of scenes stacked one after another.

Scanner refers to a lighting instrument with a pan and tilt mirror; however, in the ILS-CON controller it can be used to control any DMX-512 compatible device as a generic fixture.

MIDI is a standard for representing musical information in a digital format. A MIDI input would provide external triggering of scenes using midi device such as a midi keyboard.

Stand Alone refers to a fixture s ability to function independently of an external controller and usually in sync to music, due to a built in microphone.

Fade slider is used to adjust the time between scenes within a chase.

Speed slider affects the amount of time a scene will hold its state. It is also considered a wait time.

Shutter is a mechanical device in the lighting fixture that allows you to block the lights path. It is often used to lessen the intensity of the light output and to strobe.

Patching refers to the process of assigning fixtures a DMX channel or.

Playbacks can be either scenes or chases that are directly called to execution by the user. A playback can also be considered program memory that can be recalled during a show.

OPERATING INSTRUCTIONS

3.1 Setup

3.1.1 SETTING UP THE SYSTEM

1. Plug the AC to DC power supply to the system back panel and to the mains outlet.
2. Plug in your DMX cable(s) to your intelligent lighting as described in the fixtures respective manual. For a quick Primer on DMX see the“DMX Primer” section in the Appendix of this manual.

3.1.2 FIXTURE ADDRESSING

The Controller is programmed to control 16 channels of DMX per fixture, therefore the fixtures you wish to control with the corresponding SCANNER buttons on the unit, must be spaced 16 channels apart.

| FIXTURE OR SCANNER # | DEFAULT DMX STARTING ADDRESS | BINARY DIPSWITCH SETTINGS SWITCH TO THE ON POSITION |
|----------------------|------------------------------|---|
| 1 | 1 | 1 |
| 2 | 17 | 1,5 |
| 3 | 33 | 1,6 |
| 4 | 49 | 1,5,6 |
| 5 | 65 | 1,7 |
| 6 | 81 | 1,5,7 |
| 7 | 97 | 1,6,7 |
| 8 | 113 | 1,5,6,7 |
| 9 | 129 | 1,8 |
| 10 | 145 | 1,5,8 |
| 11 | 161 | 1,6,8 |
| 12 | 177 | 1,5,6,8 |

Please refer to your individual fixture's manual for DMX addressing instructions.

The table above refers to a standard 9 dipswitch binary configurable device.

3.1.3 PAN AND TILT CHANNELS ASSIGNMENT

Because not all intelligent lighting fixtures are alike or share the same control attributes, the Controller allows the user to assign the wheel the correct pan and tilt channel for every individual fixture

Action :

1. Press and hold PROGRAM & TAPSYNC/DISPLAY button at the same time to access the number and are labeled on the surface of the channel assignment mode.
2. Press a SCANNER button that represents the fixture whose faders you would like to re-assign.
3. Press the TAPSYNC DISPLAY button to select pan / tilt.
4. Move one fader of 1-8 or 9-16 channel at different page to select the target PAN/ tilt channel you wish be assigned to. LED display 1st & 2nd show X channel number and 3rd & 4th indicate Y channel number you set
5. Press and hold PROGRAM & TAPSYNC DISPLAY buttons to exit and save setting. All LEDs will blink.
6. Press page button to choose channel you need at different page)

Notes :

All pan/tilt can be reassigned to output on a different DMX channel.

Press AUTO/DEL buttons to delete the channel assignment mode.

3.1.4 RESETTING THE SYSTEM

Warning:

This will reset the controller to its factory defaults.

This will erase all programs and settings.

Action :

1. Turn off the unit.
2. Press and hold BANK UP and AUTO/DEL.
3. Turn on power to the unit (while still holding BANK UP and AUTO/DEL).

Notes :**3.1.5 COPY SCANNER**

Example: Copying Scanner 1 into Scanner 2

Action :

1. Press and hold SCANNER button # 1.
2. While holding button # 1 press SCANNER button # 2.
3. Release SCANNER button # 1 first before releasing SCANNER button # 2.
4. All SCANNER LED indicators will flash to confirm successful copy.

Notes :

To save time, you can copy the settings of one Scanner button to another.

3.1.6 FADE TIME ASSIGN

You can choose whether the fade time during scene execution is implemented broadly to all output channels or only to the Pan & Tilt movement channels. This is relevant because often you will want gobos and colors to change quickly while not affecting the movement of the light.

Action :

1. Turn OFF the controller.
2. Hold the BLACKOUT and TAPSYNC DISPLAY buttons simultaneously.
3. Turn ON the controller.
4. Press the TAPSYNC DISPLAY button to toggle between the two modes. Either all channels(A) or select channel Pan & Tilt only (P)
5. Press BLACKOUT and TAPSYNC DISPLAY to save settings. All LEDs will blink to confirm.

Notes :

A: All channels

P: Only Pan & Tilt

3.2 Operation**3.2.1 MANUAL MODE**

The manual mode allows direct control of all scanners. You are able to move them and change attributes by using the channel faders.

Action :

1. Press the AUTO DEL button repeatedly until the MANUAL LED is lit.
2. Select a SCANNER button.
3. Move faders to change fixture attributes.

TAPSYNC DISPLAY button: Press to toggle the output indicator on the LED display between DMX values (0-255) and percentage (0-100)

Notes :

All changes made while in Manual Mode are temporary and will not be recorded.

3.2.2 REVIEW SCENE OR CHASE

This instruction assumes that you have already recorded scenes and chases on the controller. Other wise skip section and go to programming.

Action : (SCENE Review)

1. Press the AUTO DEL button repeatedly until the MANUAL LED is lit.
2. All AUTO Trigger led and Music Trigger led OFF. Move all sliders at bottom
3. Select any one of the 23 banks by pressing the BANK UP/DOWN buttons.
4. Select a SCENE button (1~8) to review.
5. Move faders to change fixture attributes.

Action : (CHASE Review)

1. Keep pressing PROGRAM button 2 seconds to enter program mode and the indicated led will lit..
2. Press any one of the 6 CHASE buttons.
3. Press the TAPSYNIC/DISPLAY button to view the step number on the display.
4. Press the BANK UP/DOWN buttons review all scenes in the chase.

Notes :

Make sure you are still in MANUAL Mode.

3.3 Programming

A program (bank) is a sequence of different scenes (or steps) that will be called up one after another. In the controller 23 programs can be created of 8 scenes in each.

3.3.1 ENTERING PROGRAM MODE

1. Press the Program button around 2 seconds until the LED blinks.

3.3.2CREATE A SCENE :

A scene is a static lighting state. Scenes are stored in banks. There are 23 bank memories on the controller and each bank can hold 8 scene memories. The controller can save 184 scenes total.

Action :

1. Press the PROGRAM button until the LED blinks to enter program mode.
2. Select the SCANNERS you wish to include in your scene.
3. Compose the effect by moving the sliders.The relative DMX value will be displayed on led display
4. Tap MIDI/ADD button to save setting.
5. Choose a bank by BANK UP/DOWN (01~23) to save it to your target BANK.
6. Select a SCENES button to store. All LED blinks once data are saved.
7. Repeat steps 2 through 6 as need. 8 scenes can be recorded in a Program
8. Press the PROGRAM button until the LED OFF to quite program mode

Notes :

Deselect Blackout if LED is lit.

You can select more than one fixture.

There are 8 scenes available in every bank.

All LEDs will flash to confirm. The LED display will now indicate the Scene number and Bank number used.

3.3.3 RUNNING A CHASE

Action :

1. Press AUTO/DEL to enter auto running mode and AUTO indicated led ON.
2. Press target run CHASE number button and tap the TAPSYNC DISPLAY button twice to run it. Multi chases could be selected at the same time to run in cycle.
3. Use BANK UP/DOWN buttons to change Program banks if there is no chase.
4. Adjust the PROGRAM speed via the SPEED fader and the loop rate via the FADE TIME fader. The time between two taps sets the time between SCENES (up to 10 minutes).

Notes :

Deselect Blackout if LED is lit.
Also called a Tap-Sync.

3.3.4 CHECK A BANK

Action :

1. Press and hold the PROGRAM button until the LED blinks.
2. Use the BANK UP/DOWN buttons to select the PROGRAM bank to review.
3. Press the SCENES buttons to review each scene individually.

Notes :

3.3.5 EDITING A PROGRAM

Scenes will need to be modified manually.

Action :

1. Press and hold the PROGRAM button until the LED blinks.
2. Use BANK UP/DOWN buttons to change Program banks if need.
3. Select the targeted fixture via the SCANNERS button .
4. Adjust and change fixture attributes using the channel faders and wheel.
5. Press the MIDI/ADD button to prepare the save.
6. Select the desired SCENES button to save.

Notes :

Deselect Blackout if LED is lit.

3.3.6 COPY A BANK

Action :

1. Press and hold the PROGRAM button until the LED blinks.
2. Use BANK UP/DOWN buttons to select the PROGRAM bank you will copy.
3. Press the MIDI/ADD button to prepare the copy.
4. Use BANK UP/DOWN buttons to select the destination PROGRAM bank.
5. Press the MUSIC BANK COPY button to execute the copy. All LEDs on the controller will blink.

Notes :

All 8 scenes in a Program Bank will be copied.

3.4 Chase Programming

A chase be created by using previously created scenes. Scenes become steps in a chase and can be arranged in any order you choose. It is highly recommended that prior to programming chases for the first time; you delete all chases from memory.

See Delete All Chases for instructions.

3.4.1 CREATE A CHASE

A Chase can contain 184 scenes as steps. The term steps and scenes are used interchangeably.

Action :

1. Press the PROGRAM button until the LED blinks.
2. Press the CHASE (1~6) button you wish to program.
3. Change BANK if necessary to locate a scene.
4. Select the SCENE to insert.
5. Tap the MIDI/ADD button to store.
6. Repeat steps 3 ~ 5 to add additional steps in the chase. Up to 240 steps can be recorded.
7. Press and hold the PROGRAM button to save the chase.

Notes :

3.4.2 RUNNING A CHASE

Action :

1. Press AUTO/DEL to enter auto running mode and AUTO indicated led ON.
2. Press target run CHASE number button and tap the TAPSYNC DISPLAY button twice to run it. Multi chases could be selected at the same time to run in cycle.
3. Adjust the PROGRAM speed via the SPEED fader and the loop rate via the FADE TIME fader

Notes :

The time between 2 taps will set the chase speed (up to 10 minutes)

3.4.3 CHECKING A CHASE

Action :

1. Press and hold the PROGRAM button until the LED is light.
2. Select the target CHASE button.
3. Press the TAPSYNC/DISPLAY button to check steps on display.
4. Review each scene/step individually by using the BANK UP/DOWN buttons.

Notes :

3.4.4 EDIT CHASE (COPY BANK INTO CHASE

Action:

1. Press and hold the PROGRAM button to enter programming mode.
2. Press the desired CHASE button.
3. Select the BANK to be copied using the BANK UP/DOWN button
4. Press MUSIC/BANK COPY button one time to prepare copy.

5. Press MIDI/ADD button again to copy the bank.

All LEDs will blink.

Notes:

3.4.5 EDIT CHASE (COPY SCENE INTO CHASE)

Action :

1. Press and hold the PROGRAM button to enter programming mode.
2. Press the desired CHASE button.
3. Select the BANK that contains the scene to be copied using the BANK UP/DOWN buttons.
4. Press the SCENE button that corresponds to the scene to be copied.
5. Press MIDI/ADD button to copy the scene.

All LEDs will blink.

Notes :

3.4.6 EDIT CHASE (INSERT SCENE INTOACHASE)

Action :

1. Press and hold the PROGRAM button to enter programming mode.
2. Press the desired CHASE button.
3. Press the TAPSYNC DISPLAY to switch the LED display to steps view.
4. Use the BANK UP/DOWN buttons to navigate steps and locate the insert point of the new scene. The display will read the step number.
5. Press MIDI/ADD button to prepare the insert.
6. Use the BANK UP/DOWN button to locate the SCENE.
7. Press the SCENE button that corresponds to the scene to be inserted.
8. Press MIDI/ADD button to insert the scene. All LEDs will blink.

Notes :

I.e. To insert a scene between Steps 05 and 06 navigate using BANK buttons until the display reads STEP05. The display will show STEP006 at this time.

3.4.7 DELETE A SCENE IN A CHASE

Action :

1. Press and hold the PROGRAM button to enter programming mode.
2. Press the desired CHASE button that contains the scene to be delete
3. Press the TAPSYNC DISPLAY button to switch the LED display to steps
4. Select the scene/step to be deleted using the BANK UP/DOWN buttons
5. Press AUTO DEL button to delete the step/scene. All LEDs will blink.

Notes :

3.4.8 DELETE A CHASE

Action:

1. Press and hold the PROGRAM button to enter program edit mode.
2. Press the CHASE button (1~6) to be deleted.
3. Press and hold AUTO DEL button and the selected CHASE button to delete the chase.

All LEDs will blink

Notes:**3.4.9 DELETE ALL CHASE PROGRAMS**

CAUTION! This procedure will result in irrevocable loss of chase step memory. The individual scenes and program banks will be preserved.

Action :

1. Turn OFF power of controller.
2. Press and hold the BANK DOWN button and the AUTO DEL button while turning ON the controller.
3. All LEDs will blink.

Notes :**3.5 Scene Programming (Steps)****3.5.1 INSERT A SCENE****Action :**

1. Press and hold the PROGRAM button to enter programming mode.
2. Press the desired CHASE button.
3. Press the TAPSYNC DISPLAY to switch the LED display to steps view.
4. Use the BANK UP/DOWN buttons to navigate steps and locate the insert point of the new scene. The display will read the step number.
5. Press MIDI/ADD button to prepare the insert.
6. Use the BANK UP/DOWN button to locate the SCENE.
7. Press the SCENE button that corresponds to the scene to be inserted.
8. Press MIDI/ADD button to insert the scene. All LEDs will blink.

Notes :

I.e. To insert a scene between Steps 05 and 06 navigate using BANK buttons until the display reads STEP05. The display will show STEP006 at this time.

3.5.2 COPY A SCENE**Action :**

1. Press and hold the PROGRAM button to enter programming mode.
2. Select the BANK that contains the scene to be copied using the BANK UP/DOWN buttons.
3. Press the SCENE button that corresponds to the scene to be Copied.
4. Press MIDI/ADD button to copy the scene.
5. Select the destination BANK that contains the scene memory to record onto using the BANK UP/DOWN buttons

6. Press the desired SCENE button to complete copy. All LEDs will blink

Notes :

3.5.3 DELETE A SCENE

Action :

1. Press and hold the PROGRAM button to enter programming mode.
2. Select the BANK that contains the scene to be deleted by using the BANK UP/DOWN buttons.
3. Press and hold the AUTO DEL button.
4. Press the SCENE button that corresponds to the scene you want to delete. All LEDs will blink.

Notes :

When deleting a scene the physical location is not removed, however, all 384 DMX channels available to the scene will be set to value 0.

3.5.4 DELETE ALL SCENES

Action :

1. Press and hold the PROGRAM button and the BANK DOWN button while switching off power to the controller.
2. Turn the controller back on.

Notes :

CAUTION!

This process is irreversible. All scenes with data will be set to 0.

3.6 Playback

3.6.1 RUNNING IN SOUND-MODE

Action :

1. Press the MUSIC BANK COPY button until the MUSIC LED turns on.
2. Select the program BANK to run in sound active mode using the BANK UP/DOWN buttons.
3. Alternatively you can press a single CHASE button(1~6) or several CHASE buttons in sequence and all selected chases will loop in the order selected.
4. You can adjust the duration time using the FADE TIME fader.

Notes :

In the Sound mode, programs will be triggered by the sound using its built-in microphone. Multiple chases selected will loop and run in the order originally selected.

3.6.2 RUNNING IN AUTO-MODE

Action :

1. Press the AUTO DEL button until the AUTO LED turns on.
2. If a CHASE button is not pressed the controller will automatically run a BANK program.
3. Change BANK programs by using BANK UP/DOWN buttons.
4. Alternatively you can press a single CHASE button(1~6) or several CHASE buttons in sequence and all selected chases will loop in the order selected.

5. You can adjust the time between steps by moving the SPEED fader and the duration of the step by moving the FADE TIME fader

Notes :

In the Auto mode, programs will be triggered by controllers fade and speed time as set on the faders. Multiple chases selected will loop and run in the order originally selected.

3.6.3BLACKOUT

The Blackout button brings all lighting output to 0 or off.

3.7MidOperation

The controller will only respond to MIDI commands on the MIDI channel is set to full stop. All MIDI control is performed using Note on commands. All other MIDI instructions are ignored. To stop a chase, send the blackout on note.

Action :

1. Press and hold the MIDI/ADD button for about 2 seconds.
2. Select the MIDI control channel (1~16) via the BANK UP/DOWN buttons to set.
3. Press and hold the MIDI/ADD button for 3 seconds to save settings.
4. To release MIDI control, press any other button except the BANK buttons during step 2.

Notes :

This is the Channel that the controller will receive MIDI note commands.

| MIDI Value | FUNCTION (TURN ON/OFF) |
|------------|------------------------|
| 00 to 07 | Scenes 1~8 in BANK 1 |
| 08 to 15 | Scenes 1~8 in BANK 2 |
| 16 to 23 | Scenes 1~8 in BANK 3 |
| 24 to 31 | Scenes 1~8 in BANK 4 |
| 32 to 39 | Scenes 1~8 in BANK 5 |
| 40 to 47 | Scenes 1~8 in BANK 6 |
| 48 to 55 | Scenes 1~8 in BANK 7 |
| 56 to 63 | Scenes 1~8 in BANK 8 |
| 64 to 71 | Scenes 1~8 in BANK 9 |
| 72 to 79 | Scenes 1~8 in BANK 10 |
| 80 to 87 | Scenes 1~8 in BANK 11 |
| 88 to 95 | Scenes 1~8 in BANK 12 |
| 96 to 103 | Scenes 1~8 in BANK 13 |
| 104 to 111 | Scenes 1~8 in BANK 14 |
| 112 to 119 | Scenes 1~8 in BANK 15 |
| 120 | Chase 1 |
| 121 | Chase 2 |
| 122 | Chase 3 |
| 123 | Chase 4 |
| 124 | Chase 5 |
| 125 | Chase 6 |
| 126 | BLACKOUT |

APPENDIX

4.1 DMX Primer



There are 512 channels in a DMX-512 connection. Channels may be assigned in any manner. A fixture capable of receiving DMX 512 will require one or a number of sequential channels. The user must assign a starting address on the fixture that indicates the first channel reserved in the controller. There are many different types of DMX controllable fixtures and they all may vary in the total number of channels required. Choosing a start address should be planned in advance. Channels should never overlap. If they do, this will result in erratic operation of the fixtures whose starting address is set incorrectly. You can however, control multiple fixtures of the same type using the same starting address as long as the intended result is that of unison movement or operation. In other words, the fixtures will be slaved together and all respond exactly the same.

DMX fixtures are designed to receive data through a serial Daisy Chain. A Daisy Chain connection is where the DATA OUT of one fixture connects to the DATA IN of the next fixture. The order in which the fixtures are connected is not important and has no effect on how a controller communicates to each fixture. Use an order that provides for the easiest and most direct cabling. Connect fixtures using shielded two conductor twisted pair cable with three pin XLR male to female connectors. The shield connection is pin 1, while pin 2 is Data Negative (S-) and pin 3 is


Data positive (S+).

4.2 FIXTURE LINKING


Occupation of the XLR-connection:

| DMX-OUTPUT XLR mounting-socket: | DMX-OUTPUT XLR mounting-plug: |
|--|--|
|  1- Ground 2 – Signal (-) 3 – Signal (+) |  1- Ground 2 – Signal (-) 3 – Signal (+) |

Caution: At the last fixture, the DMX-cable has to be terminated with a terminator. Solder a 120 resistor between Signal (-) and Signal (+) into a 3-pin XLR-plug and plug it in the DMX-output of the last fixture. In the Controller mode, at the last fixture in the chain, the DMX output has to be connected with a DMX terminator. This prevents electrical noise from disturbing and corrupting the DMX control signals. The DMX terminator is simply an XLR connector with a 120W (ohm) resistor connected across pins 2 and 3, which is then plugged into the output socket on the last projector in the chain. The connections are illustrated below.



If you wish to connect DMX-controllers with other XLR-outputs, you need to use adapter cables. The transform of the controller line of 3 pins and 5 pins (plug and socket)




4.3 DMX Dipswitch Quick Reference Chart

| DMX Address Quick Reference Chart | | | | | | | | | | | | | | | | | | | | |
|---|----|----|----|----|----|----|----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|
| Dip Switch Position | | | | | | | | | | | | | | | | | | | | |
| DMX DIP SWITCH SET O=FF 1=ON X=OFF or ON | #9 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | |
| | #8 | 0 | 0 | 0 | 0 | 1 | 1 | 1 | 1 | 0 | 0 | 0 | 0 | 1 | 1 | 1 | 1 | 1 | 1 | |
| | #7 | 0 | 0 | 1 | 1 | 0 | 0 | 1 | 1 | 0 | 0 | 1 | 1 | 0 | 0 | 1 | 1 | 1 | 1 | |
| | #6 | 0 | 1 | 0 | 1 | 0 | 1 | 0 | 1 | 0 | 1 | 0 | 1 | 0 | 1 | 0 | 1 | 0 | 1 | |
| #1 | #2 | #3 | #4 | #5 | | | | | | | | | | | | | | | | |
| 0 | 0 | 0 | 0 | 0 | | 32 | 64 | 96 | 128 | 160 | 192 | 224 | 256 | 288 | 320 | 352 | 384 | 416 | 448 | 480 |
| 1 | 0 | 0 | 0 | 0 | 1 | 33 | 65 | 97 | 129 | 161 | 193 | 225 | 257 | 289 | 321 | 353 | 385 | 417 | 449 | 481 |
| 0 | 1 | 0 | 0 | 0 | 2 | 34 | 66 | 98 | 130 | 162 | 194 | 226 | 258 | 290 | 322 | 354 | 386 | 418 | 450 | 482 |
| 1 | 1 | 0 | 0 | 0 | 3 | 35 | 67 | 99 | 131 | 163 | 195 | 227 | 259 | 291 | 323 | 355 | 387 | 419 | 451 | 483 |
| 0 | 0 | 1 | 0 | 0 | 4 | 36 | 68 | 100 | 132 | 164 | 196 | 228 | 260 | 292 | 324 | 356 | 388 | 420 | 452 | 484 |
| 1 | 0 | 1 | 0 | 0 | 5 | 37 | 69 | 101 | 133 | 165 | 197 | 229 | 261 | 293 | 325 | 357 | 389 | 421 | 453 | 485 |
| 0 | 1 | 1 | 0 | 0 | 6 | 38 | 70 | 102 | 134 | 166 | 198 | 230 | 262 | 294 | 326 | 358 | 390 | 422 | 454 | 486 |
| 1 | 1 | 1 | 0 | 0 | 7 | 39 | 71 | 103 | 135 | 167 | 199 | 231 | 263 | 295 | 327 | 359 | 391 | 423 | 455 | 487 |
| 0 | 0 | 0 | 1 | 0 | 8 | 40 | 72 | 104 | 136 | 168 | 200 | 232 | 264 | 296 | 328 | 360 | 392 | 424 | 456 | 488 |
| 1 | 0 | 0 | 1 | 0 | 9 | 41 | 73 | 105 | 137 | 169 | 201 | 233 | 265 | 297 | 329 | 361 | 393 | 425 | 457 | 489 |
| 0 | 1 | 0 | 1 | 0 | 10 | 42 | 74 | 106 | 138 | 170 | 202 | 234 | 266 | 298 | 330 | 362 | 394 | 426 | 458 | 490 |
| 1 | 1 | 0 | 1 | 0 | 11 | 43 | 75 | 107 | 139 | 171 | 203 | 235 | 267 | 299 | 331 | 363 | 395 | 427 | 459 | 491 |
| 0 | 0 | 1 | 1 | 0 | 12 | 44 | 76 | 108 | 140 | 172 | 204 | 236 | 268 | 300 | 332 | 364 | 396 | 428 | 460 | 492 |
| 1 | 0 | 1 | 1 | 0 | 13 | 45 | 77 | 109 | 141 | 173 | 205 | 237 | 269 | 301 | 333 | 365 | 397 | 429 | 461 | 493 |
| 0 | 1 | 1 | 1 | 0 | 14 | 46 | 78 | 110 | 142 | 174 | 206 | 238 | 270 | 302 | 334 | 366 | 398 | 430 | 462 | 494 |
| 1 | 1 | 1 | 1 | 0 | 15 | 47 | 79 | 111 | 143 | 175 | 207 | 239 | 271 | 303 | 335 | 367 | 399 | 431 | 463 | 495 |
| 0 | 0 | 0 | 0 | 1 | 16 | 48 | 80 | 112 | 144 | 176 | 208 | 240 | 272 | 304 | 336 | 368 | 400 | 432 | 464 | 496 |
| 1 | 0 | 0 | 0 | 1 | 17 | 49 | 81 | 113 | 145 | 177 | 209 | 241 | 273 | 305 | 337 | 369 | 401 | 433 | 465 | 497 |
| 0 | 1 | 0 | 0 | 1 | 18 | 50 | 82 | 114 | 146 | 178 | 210 | 242 | 274 | 306 | 338 | 370 | 402 | 434 | 466 | 498 |
| 1 | 1 | 0 | 0 | 1 | 19 | 51 | 83 | 115 | 147 | 179 | 211 | 243 | 275 | 307 | 339 | 371 | 403 | 435 | 467 | 499 |
| 0 | 0 | 1 | 0 | 1 | 20 | 52 | 84 | 116 | 148 | 180 | 212 | 244 | 276 | 308 | 340 | 372 | 404 | 436 | 468 | 500 |
| 1 | 0 | 1 | 0 | 1 | 21 | 53 | 85 | 117 | 149 | 181 | 213 | 245 | 277 | 309 | 341 | 373 | 405 | 437 | 469 | 501 |
| 0 | 1 | 1 | 0 | 1 | 22 | 54 | 86 | 118 | 150 | 182 | 214 | 246 | 278 | 310 | 342 | 374 | 406 | 438 | 470 | 502 |
| 1 | 1 | 1 | 0 | 1 | 23 | 55 | 87 | 119 | 151 | 183 | 215 | 247 | 279 | 311 | 343 | 375 | 407 | 439 | 471 | 503 |
| 0 | 0 | 0 | 1 | 1 | 24 | 56 | 88 | 120 | 152 | 184 | 216 | 248 | 280 | 312 | 344 | 376 | 408 | 440 | 472 | 504 |
| 1 | 0 | 0 | 1 | 1 | 25 | 57 | 89 | 121 | 153 | 185 | 217 | 249 | 281 | 313 | 345 | 377 | 409 | 441 | 473 | 505 |
| 0 | 1 | 0 | 1 | 1 | 26 | 58 | 90 | 122 | 154 | 186 | 218 | 250 | 282 | 314 | 346 | 378 | 410 | 442 | 474 | 506 |
| 1 | 1 | 0 | 1 | 1 | 27 | 59 | 91 | 123 | 155 | 187 | 219 | 251 | 283 | 315 | 347 | 379 | 411 | 443 | 475 | 507 |
| 0 | 0 | 1 | 1 | 1 | 28 | 60 | 92 | 124 | 156 | 188 | 220 | 252 | 284 | 316 | 348 | 380 | 412 | 444 | 476 | 508 |
| 1 | 0 | 1 | 1 | 1 | 29 | 61 | 93 | 125 | 157 | 189 | 221 | 253 | 285 | 317 | 349 | 381 | 413 | 445 | 477 | 509 |
| 0 | 1 | 1 | 1 | 1 | 30 | 62 | 94 | 126 | 158 | 190 | 222 | 254 | 286 | 318 | 350 | 382 | 414 | 446 | 478 | 510 |
| 1 | 1 | 1 | 1 | 1 | 31 | 63 | 95 | 127 | 159 | 191 | 223 | 255 | 287 | 319 | 351 | 383 | 415 | 447 | 479 | 511 |

Dip Switch Position

DMX Address


4.4 Technical Specifications



| | |
|-----------------------------|------------------------------------|
| Dimensions | 482 X133 X82 mm |
| Weight | 2.0 Kg |
| Operating Range | DC 9V-12V 500mA min |
| Maximum ambient temperature | 45°C |
| Data input | locking 3-pin XLR male socket |
| Data output | locking 3-pin XLR female socket |
| Data pin configuration | pin 1 shield, pin 2 (-), pin 3 (+) |
| Protocols | DMX-512 USITT |

DMX 512 CONTROLLER SERIES

Documents / Resources

| | |
|--|--|
|  | <p>SMARTBCON192 DMX 512 Metal Controller for Professional Show Lighting Control [pdf] User Manual DMX 512 Metal Controller for Professional Show Lighting Control, DMX 512, Metal Controller for Professional Show Lighting Control, Professional Show Lighting Control, Show Lighting Control, Lighting Control</p> |
|--|--|

[Manuals+](#)