



SONBEST SM3720V Pipeline Temperature and Humidity Sensor User Manual

[Home](#) » [SONBEST](#) » SONBEST SM3720V Pipeline Temperature and Humidity Sensor User Manual 

Contents

- 1 SONBEST SM3720V Pipeline Temperature and Humidity Sensor
- 2 Technical Parameters
 - 2.1 Product Selection
 - 2.2 Product Size
 - 2.3 Application solution
- 3 Communication Protocol
 - 3.1 Read Data (Function id 0x03)
 - 3.2 Data Address Table
 - 3.3 read and modify device address
 - 3.4 Read and Modify Baud Rate
 - 3.5 Read Correction Value
- 4 Documents / Resources
 - 4.1 References
- 5 Related Posts



SONBEST SM3720V Pipeline Temperature and Humidity Sensor



Technical Parameters


Technical parameter	Parameter value
Brand	SONBEST
Temperature measuring range	-30°C~80°C
Temperature measuring accuracy	±0.5°C @25°C
Humidity measuring range	0~100%RH
Humidity accuracy	±3%RH @25°C
Interface	RS485/4-20mA/DC0-5V/DC0-10V
Power	DC12~24V 1A
Running temperature	-40~80°C
Working humidity	5%RH~90%RH

Product Selection

Product DesignRS485,4 DesignRS485,4-20mA,DC0 DC0-5V,DC0 DC0-10VMultiple output methods, the products are divided into the following models depending on the output method.

Product model	output method
SM3720B	RS485
SM3720M	4-20mA
SM3720V5	DC0-5V
SM3720V10	DC0-10V

Product Size



How to wiring?

SM3720B T&H RS485(No DIP)		SM3700B Only T RS485(No DIP)	
A+	RS485 A+	A+	RS485 A+
B-	RS485 B-	B-	RS485 B-
V-	PWR-	V-	PWR-
V+	PWR+	V+	PWR+
SM3720V T&H 0~5/0~10V		SM3700V Only T 0~5/0~10V	
VH	H Signal output	V-	PWR-
V-	PWR-	V+	PWR+
V+	PWR+	VT	T Signal output
VT	T Signal output		


SM3720M T&H 4~20mA (Three-wire system)	SM3700M Only T 4~20mA (Three-wire system)
H/A+ H Signal output GND PWR- V+ PWR+ T/B- T Signal output	GND PWR- V+ PWR+ T/B- T Signal output
SM3720M T&H 4~20mA (Two-wire system)	SM3700M Only T 4~20mA (Two-wire system)
VT+ T PWR+ VT- T PWR- VH- H PWR+ VH+ H PWR-	VT+ T PWR+ VT- H PWR-


※Note: When wiring, the positive and negative poles of the power supply are connected first, and then the signal line; models that are not marked with "no dialing code" have dialing codes included.

DIP Setting		
1	2	Range
OFF	OFF	0~50°C
OFF	ON	-20~80°C
ON	OFF	-40~60°C
ON	ON	CUSTOM

※The temperature range can be adjusted by dialing code on site, the default temperature range is 0~50°C, RS485 has no dialing function, it needs to be set in the software.

Application solution





How to use?



Communication Protocol

The product uses RS485 MODBUS RTU standard protocol format, all operation or reply commands are hexadecimal data. The default device address is 1 when the device is shipped, the default baud rate is 9600, 8, n, 1

Read Data (Function id 0x03)

Inquiry frame (hexadecimal), sending example: Query 1# device 1 data, the host computer sends the command: 01 03 00 00 00 02 C4 0B .

Device ID	Function id	Start Address	Data Length	CRC16
01	03	00 00	00 02	C4 0B

For the correct query frame, the device will respond with data: 01 03 04 00 7A 00 00 DB EA , the response format is parsed as follows:

Device ID	Function id	Data Length	Data 1	Data 2	Check Code
01	03	04	00 79	00 7A	DB EA

Data Description: The data in the command is hexadecimal. Take data 1 as an example. 00 79 is converted to a decimal value of 121. If the data magnification is 100, the actual value is 121/100=1.21. Others and so on.

Data Address Table

Address	Start Address	Description	Data type	Value range
40001	00 00	temperature	Read Only	0~65535
40002	00 01	humidity	Read Only	0~65535
40101	00 64	model code	read/write	0~65535
40102	00 65	total points	read/write	1~20
40103	00 66	Device ID	read/write	1~249
40104	00 67	baud rate	read/write	0~6
40105	00 68	mode	read/write	1~4
40106	00 69	protocol	read/write	1~10

read and modify device address

1. Read or query device address

If you don't know the current device address and there is only one device on the bus, you can use the command FA 03 00 64 00 02 90 5F Query device address.

Device ID	Function id	Start Address	Data Length	CRC16
FA	03	00 64	00 02	90 5F

FA is 250 for the general address. When you don't know the address, you can use 250 to get the real device address, 00 64 is the device model register.

For the correct query command, the device will respond, for example the response data is: 01 03 02 07 12 3A 79, the format of which is as shown in the following table:

Device ID	Function id	Start Address	Model Code	CRC16
01	03	02	55 3C 00 01	3A 79

2. Change device address

For example, if the current device address is 1, we want to change to 02, the command is: 01 06 00 66 00 02 E8 14 .

Device ID	Function id	Start Address	Destination	CRC16
01	06	00 66	00 02	E8 14

After the change is successful, the device will return information: 02 06 00 66 00 02 E8 27 , its format is parsed as shown in the following table:

Device ID	Function id	Start Address	Destination	CRC16
01	06	00 66	00 02	E8 27

Response should be in the data, after the modification is successful, the first byte is the new device address. After the general device address is changed, it will take effect immediately. At this time, the user needs to change the query command of the software at the same time.

Read and Modify Baud Rate

1. Read baud rate

The device default factory baud rate is 9600. If you need to change it, you can change it according to the following table and the corresponding communication protocol. For example, read the current device's baud rate ID, the command is: 01 03 00 67 00 01 35 D5, its format is parsed as follows.

Device ID	Function id	Start Address	Data Length	CRC16
01	03	00 67	00 01	35 D5

Read the baud rate encoding of the current device. Baud rate encoding: 1 is 2400; 2 is 4800; 3 is 9600; 4 is 19200; 5 is 38400; 6 is 115200. For the correct query command, the device will respond, for example the response data is: 01 03 02 00 03 F8 45, the format of which is as shown in the following table:

Device ID	Function id	Data Length	Rate ID	CRC16
01	03	02	00 03	F8 45

coded according to baud rate, 03 is 9600, ie the current device has a baud rate of 9600.

2. Change the baud rate

For example, changing the baud rate from 9600 to 38400, ie changing the code from 3 to 5, the command is: 01 06 00 67 00 05 F8 16 01 03 00 66 00 01 64 15.

Device ID	Function id	Start Address	Target Baud Rate	CRC16
01	03	00 66	00 01	64 15

Change the baud rate from 9600 to 38400, changing the code from 3 to 5. The new baud rate will take effect immediately, at which point the device will lose its response and the baud rate of the device should be queried accordingly. Modified.

Read Correction Value

1. When there is an error between the data and the reference standard, we can reduce the display error by adjusting the correction value. The correction difference can be modified to be plus or minus 1000, that is, the value range is 0 1000 or 64535 65535. For example, when the display value is too small, we can correct it by adding 100. The command is: 01 03 00 6B 00 01 F5 D6 . In the command 100 is hex 0x64 If you need to reduce, you can set a negative value, such as 100, corresponding t correction value starts from 00 6B. We take the first parameter as an example. The correction value is read an d modified in the same way for multiple parameter

Device ID	Function id	Start Address	Data Length	CRC16
01	03	00 6B	00 01	F5 D6

For the correct query command, the device will respond, for example the response data is: 01 03 02 00 64 B9 AF, the format of which is as shown in the following table:

Device ID	Function id	Data Length	Data value	CRC16
01	03	02	00 64	B9 AF

In the response data, the first byte 01 indicates the real address of the current device, and 00 6B is the first state quantity correction value register. If the device has multiple parameters, other parameters operate in this way. The same, the general temperature, humidity have this parameter, the light generally does not have this item.

Change correction value

For example, the current state quantity is too small, we want to add 1 to its true value, and the current value plus 100 correction operation command is:01 06 00 6B 00 64 F9 FD .

Device ID	Function id	Start Address	Destination	CRC16
01	06	00 6B	00 64	F9 FD

1. temperature and current computing relationship

For example, the range is 30~80 °C°C, the analog output is 4~20mA current signal, temperature and current
The calculation relationship is as shown in the formula: $C = (A2 - A1) * (X - B1) / (B2 - B1) + A1$, where A2 is temperature range upper limit, A1 is the lower limit of the range, B2 is current output range upper limit, B1 is the lower limit, X is the currently read temperature value, and C is the calculated current value. The list of commonly used values is as follows:

DC0-5Vvoltage(V)	temperature Value (°C)	Calculation Process
0	-30	$(80-(-30))*(0-0)\div(5-0)+-30$
1	-8	$(80-(-30))*(1-0)\div(5-0)+-30$
2	14	$(80-(-30))*(2-0)\div(5-0)+-30$
3	36	$(80-(-30))*(3-0)\div(5-0)+-30$
4	58	$(80-(-30))*(4-0)\div(5-0)+-30$
5	80	$(80-(-30))*(5-0)\div(5-0)+-30$

2. humidity and current computing relationship

For example, the range is 0~100%RH, the analog output is 4~20mA current signal, humidity and current The calculation relationship is as shown in the formula: $C = (A2 - A1) * (X - B1) / (B2 - B1) + A1$, where A2 is humidity range upper limit, A1 is the lower limit of the range, B2 is current output range upper limit, B1 is the lower limit, X is the currently read humidity value, and C is the calculated current value. The list of commonly used values is as follows:

DC0-5Vvoltage(V)	humidity Value (%RH)	Calculation Process
0	0.0	$(100-0)*(0-0)\div(5-0)+0$
1	20.0	$(100-0)*(1-0)\div(5-0)+0$
2	40.0	$(100-0)*(2-0)\div(5-0)+0$
3	60.0	$(100-0)*(3-0)\div(5-0)+0$
4	80.0	$(100-0)*(4-0)\div(5-0)+0$
5	100.0	$(100-0)*(5-0)\div(5-0)+0$

As shown in the above formula, when measuring 2.5V, current DC0 5Vvoltage is 50%RH

1. Temperature and DC0 10Vvoltage computing relationship

For example, the range is -30~80°C, the analog output is 0~10V DC0-10Vvoltage signal, temperature and DC0-10Vvoltage The calculation relationship is as shown in the formula: $C = (A2 - A1) * (X - B1) / (B2 - B1) + A1$, where A2 is temperature range upper limit, A1 is the lower limit of the range, B2 is DC0-10Vvoltage output range upper limit, B1 is the lower limit, X is the currently read temperature value, and C is the calculated DC0-10Vvoltage value. The list of commonly used values is as follows:

DC0-10Vvoltage(V)	temperature Value (°C)	Calculation Process
0	-30	$(80 - (-30)) * (0 - 0) \div (10 - 0) + -30$
1	-19	$(80 - (-30)) * (1 - 0) \div (10 - 0) + -30$
2	-8	$(80 - (-30)) * (2 - 0) \div (10 - 0) + -30$
3	3	$(80 - (-30)) * (3 - 0) \div (10 - 0) + -30$
4	14	$(80 - (-30)) * (4 - 0) \div (10 - 0) + -30$
5	25	$(80 - (-30)) * (5 - 0) \div (10 - 0) + -30$
6	36	$(80 - (-30)) * (6 - 0) \div (10 - 0) + -30$
7	47	$(80 - (-30)) * (7 - 0) \div (10 - 0) + -30$
8	58	$(80 - (-30)) * (8 - 0) \div (10 - 0) + -30$
9	69	$(80 - (-30)) * (9 - 0) \div (10 - 0) + -30$
10	80	$(80 - (-30)) * (10 - 0) \div (10 - 0) + -30$

2. humidity and DC0 5Vvoltage computing relationship

For example, the range is 0~100%RH, the analog output is 0~5V DC0 5Vvoltage signal, humidity and DC0 5Vvoltage The calculation relationship is as shown in the formula: $C = (A2 - A1) * (X - B1) / (B2 - B1) + A1$, where A2 is humidity range upper limit, A1 is the lower limit of the range, B2 is DC0 5Vvoltage output range upper limit, B1 is the lower limit, X is the currently read humidity value, and C is the calculated DC0 5Vvoltage value. The list of commonly used values is as follows:

DC0-10Vvoltage(V)	humidity Value (%RH)	Calculation Process
0	0.0	$(100-0)*(0-0) \div (10-0) + 0$
1	10.0	$(100-0)*(1-0) \div (10-0) + 0$
2	20.0	$(100-0)*(2-0) \div (10-0) + 0$
3	30.0	$(100-0)*(3-0) \div (10-0) + 0$
4	40.0	$(100-0)*(4-0) \div (10-0) + 0$
5	50.0	$(100-0)*(5-0) \div (10-0) + 0$
6	60.0	$(100-0)*(6-0) \div (10-0) + 0$
7	70.0	$(100-0)*(7-0) \div (10-0) + 0$
8	80.0	$(100-0)*(8-0) \div (10-0) + 0$
9	90.0	$(100-0)*(9-0) \div (10-0) + 0$
10	100.0	$(100-0)*(10-0) \div (10-0) + 0$

it value, and C is the calculated DC0-10Vvoltage value. The list of commonly used values is as follows: As shown in the above formula, when measuring 5V, current DC0 -10Vvoltage is 50%RH

Disclaimer

This document provides all information about the product, does not grant any license to intellectual property, does not express or imply, and prohibits any other means of granting any intellectual property rights, such as the statement of sales terms and conditions of this product, other issues. No liability is assumed. Furthermore, our company makes no warranties, express or implied, regarding the sale and use of this product, including the suitability for the specific use of the product, the marketability or the infringement liability for any patent, copyright or other intellectual property rights, etc. Product specifications and product descriptions may be modified at any time without notice.

Contact Us

Company: Shanghai Sonbest Industrial Co., Ltd


Address: Building 8, No. 215 North East Road, Baoshan District, Shanghai, China Web: <http://www.sonbest.com>

Web: <http://www.sonbus.com> SKYPE: soobuu

Email: sale@sonbest.com

Tel: 86-021-51083595 / 66862055 / 66862075 / 66861077

Documents / Resources

	<p>SONBEST SM3720V Pipeline Temperature and Humidity Sensor [pdf] User Manual SM3720V, Pipeline Temperature and Humidity Sensor, SM3720V Pipeline Temperature and Humidity Sensor</p>
-----------------------------------------------------------------------------------	------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

References

- [Home-ä Šæµ·æœåšá@žă šæœ%œé™ă...-ă](#)
- [Home-SONBEST -SONBUS.COM| THE SENSOR COMPANY](#)
- [Home-SONBEST -SONBUS.COM| THE SENSOR COMPANY](#)

Manuals+.