



SONY Service Procedure Panel Board and Software Change User Guide

Home » Sony » SONY Service Procedure Panel Board and Software Change User Guide The Control of the Panel Board and Software Change User Guide The Control of the Panel Board and Software Change User Guide The Control of the Panel Board and Software Change User Guide The Control of the Panel Board and Software Change User Guide The Panel Board And Softwa



Contents

- 1 SONY Service Procedure Panel Board and Software
- **2 Product Information**
- **3 Product Usage Instructions**
- **5 Service Procedure for Panel**
- **6 INFORMATION**
- 7 LCD Model
- 8 Appendix
- 9 Documents / Resources
 - 9.1 References

SONY.

SONY Service Procedure Panel Board and Software Change



Product Information

· Specifications:

Model: Sony GR1VH and GN6VH Chassis

Version: 1Date: 2021.06Subject: 1st issue

Product Usage Instructions

- Section 1: Replacing Service Parts for GR1VH Series
 - After replacing the B** board, Panel, or T-Con, you need to upgrade the software using USB memory.
 Upgrade the software even if replacing the Panel only.
 - Before upgrading the software, ensure to disconnect all cables.
 - After upgrading the version, confirm the NVM Version, Model Name, Software version, and Serial
 Number from the Service menu. Incorrect settings can affect the set's capabilities.
 - When upgrading software, make sure to download the most recent version. If the software on the repair board is already newer than the upgraded version, the software will not be upgraded.
- Section 2: USB Memory Format
 - There is no special restriction on USB memory. If the USB memory is recognized when connected to a computer, it can be used. The USB memory should be formatted in FAT32.
 - USB Recommendation: USB media must be a Sony product and have a capacity of more than 2GB (4GB or higher recommended).
- Section 3: USB Update File Preparation
 - Procedure:
 - Obtain the correct and latest SW PKG (atvota file).
 - Unzip atvota file (e.g., sony_atvotafull_20xx_zzzzzzzzzzyyy_auth.zip).

 - Copy this zip file to the root of your USB pen drive.

FAQs

- Q: What should I do if the software upgrade does not work?
 - A: If the software upgrade does not work, ensure that you have followed all steps correctly and that you
 are using the correct software version for your device. If issues persist, contact customer support for
 further assistance.

Service Procedure for Panel

Service Procedure for Panel, Board and Software Change / Upgrade

- Version / Date / Subject
 - 1 /2021. 06 /1st issue

Conditions of Use:

- 1. Please use this information only to perform repair, maintenance and/or configuration services of the Sony products (hereinafter the "Repair services") under the service agreement entered into with the Sony group company (hereinafter the "Service agreement"). Using this information for any purpose other than the purpose described foregoing is forbidden.
- 2. Only the Authorized Servicer's officers, employees or subcontractors (including their officers and employees) whose duties justify a need-to-know and who have agreed to hold confidential this information (collectively hereinafter the "Permitted users") are permitted to access and use this information. To disclose or disseminate to any person other than the Permitted users is forbidden.
- 3. Destroy or erase any portion of this information promptly in an irrecoverable and secure fashion after achieving the purpose described in Section (1) above.
- 4. Do not copy, replicate, reproduce, alter, translate, transmit, sell, lease, or distribute this information in whole or in part without the prior written permission of the author. (Notwithstanding the foregoing, it is permitted to copy and distribute this information to the Permitted users.)
- 5. Please notify immediately of any leakage, loss, theft, misappropriation, or other misuse of this information by email to the following address: somk-gcs-tissnexim-adm@jp.sony.com.
- 6. In addition to the above, the terms and conditions of the Service agreement shall be applied to using this information.

Revision of Information:

- This information may be changed or updated at any time without any prior notice.
- Please confirm that this information is up-to-date before using it.

INFORMATION

NOTES


Replacing Service Parts for GR1VH Series


- 1. After replacing the B board, Panel, or T-Con you need to upgrade Software by using the USB memory. (Upgrade Software even if replacing the Panel only.)
- 2. Before upgrading the Software, be sure to disconnect all cables.
- 3. After upgrading the version, you need to confirm the NVM Version, Model Name, Software version and Serial Number from the Service menu. (Incorrect settings affect the set's capabilities.)
- 4. When upgrading Software, be sure to download the most recent version. (If the version of Software already on the repair board is newer than the version of Software for upgrade, Software is not upgraded.)
 - Remark: List of (B** Board); please refer to each segment Service Manual for details.

USB Memory Format.

1. There is no special restriction on USB memory. If you connect the USB memory to the computer and it is recognized, you can use it.

2. The USB memory should be formatted in FAT32.





USB Format


3. USB recommendation:

- USB media must be Sony product
- And the capacity must be more than
- 2GB. (4GB or higher is recommended.)




USB Update file Preparation Procedure

- 1. Obtain the correct and the latest SW PKG. (atvotafile)
- 2. Unzip atvotafile. (sony_atvotafull_20xx_zzzzzzzzzzyyy_auth.zip)
 - Note: fine name may differ depending on the destination
- 4. Copy this zip file to the root of your USB pen drive.




LCD Model


APH/APHB, AX/AXB, AR/ARB, AG, AQ, NX2 segment (LCD Model) Service Procedure for B-board Replacement




Service Procedure for T-con Replacement




Service Procedure for Panel Replacement




AS, AT segment (OLED Model) Service Procedure for B-board Replacement




Service Procedure for Panel Replacement



Appendix





- Sony EMCS (Malaysia) Sdn. Bhd. HES-M
- GR1VH CHASSIS
- · AG, AQ, AS, AT Segment
- APH/APHB, AR/ARB, AX/AXB Segment
- GN6VH CHASSIS
- NX2 Segment
- 2021/09/17 23:25:00 (GMT+09:00)

Documents / Resources



SONY Service Procedure Panel Board and Software Change [pdf] User Guide

Service Procedure Panel Board and Software Change, Procedure Panel Board and Software Change, Board and Software Change, Change

References

- S Sony Group Portal Home
- The domain name ver.info is for sale | Dan.com
- User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.