



# Spectrum DG500 Digital Keypad and Proximity Reader User Manual

[Home](#) » [SPECTRUM](#) » Spectrum DG500 Digital Keypad and Proximity Reader User Manual 

## Contents


- 1 [Spectrum -DG500 -Digital -Keypad- and -Proximity -Reader](#)
- 2 [Digital Keypad & Proximity Reader](#)
- 3 [KEY FEATURES](#)
- 4 [DG500 KEYPAD PROGRAMMING INSTRUCTIONS](#)
- 5 [OTHER INSTRUCTIONS YOU MAY NEED](#)
- 6 [LOCK STRIKE & AUXILIART RELAY CODE ASSIGNMENT](#)
- 7 [PROGRAMMING CARD & PIN FACILITY](#)
- 8 [TO SWITCH KEYPAD FROM NORMAL MODE TO SECURE MODE](#)
- 9 [Latching Wiring](#)
- 10 [MAGNET WIRING](#)
- 11 [WIRING FAIL SECURE](#)
- 12 [Documents / Resources](#)
- 13 [Related Posts](#)



## Spectrum -DG500 -Digital -Keypad- and -Proximity -Reader



### Digital Keypad & Proximity Reader



### KEY FEATURES

- Built in Proximity Reader
- Built in Keypad for Code entry
- 500 user codes
- Illuminated Keys
- Auxiliary Input & Auxiliary Output
- Individually programmable Output
- 12vDC operation
- 2 Open door Modes (code only – card only)
- 1 Secure door mode (card & pin)
- Internal & external use

- Metal case construction

### Technical Specification

- Operating Voltage: 12vDC
- Current: 130mA
- **Built –in Proximity reader**
- Compatible Cards All 26-Bit EM Cards.















#### Size

- 120 Long x 76 Wide x 27 High Dim in mm















### DG500 KEYPAD PROGRAMMING INSTRUCTIONS

### (How to programme 4 digit PIN NUMBER)

LED Sequence	
Apply 12vDC LH Green -----	 
Press # (2 seconds) RH light turns Red -----	 
Enter 1234 RH lights turns-----	 
Enter 7 RH light turns -----	 
Create a user code 3 figures (001 to 500) LH flashing (Green) RH (Red)	 
Create a pin for user LH turns Green RH turns Red -----	 
Press # (2 seconds) LH turns Green -----	 

### (How to Delete Pin)

LED Sequence	
Keypad powered with 12vDC LH light Green -----	 
Press # (2 seconds) RH light turns Red -----	 
Enter 1234 LH light turns Green -----	 
Enter 8 Both LH & RH lights turn Red -----	 
Enter 3 digit user code (one to be removed) LH flashing Red	 
Enter 1234 to confirm LH light turns Green -----	 

# Index

LED out -----



LED Green solid -----



LED Green flashing --

















LED Red solid -----















LED Red flashing -----








## (How to Insert Proximity Card EM Type)











	LED Sequence
Apply 12vDC LH Green -----	 
Press # (2 seconds) RH light turns Red -----	 
Enter 1234 RH lights turns Green -----	 
Enter 7 RH light turns Red -----	 
Create a user code 3 figures (001 to 500) LH flashing (Green) RH (Red)	 
Show EM Card to Keypad LH Green RH Red -----	 
Press # (2 seconds) LH light turns Green -----	 

## (How to Delete Card)











	LED Sequence
Keypad powered with 12vDC LH light Green -----	 
Press # (2 seconds) RH light turns Red -----	 
Enter 1234 LH light turns Green -----	 
Enter 8 Both LH & RH lights turn Red -----	 
Enter 3 digit user code (one to be removed) LH flashing Red	 
Enter 1234 to confirm LH light turns Green -----	 

Index	
LED out -----	
LED Green solid -----	
LED Green flashing --	
LED Red solid -----	
LED Red flashing -----	


## How to change Relay One


	LED Sequence	
Apply 12vDc – LH Green -----		
Press # (2 Seconds) RH turns Red-----		
Enter 1234 RH turns green -----		
Enter 6 LH flashes Green RH Green -----		
Enter 00 + 01-99 sec bleeps twice LH turns green -----		
00 denotes relay 1 next 2 digits sets time in seconds		

## How to change Relay Two

	LED Sequence	
Apply 12vDc – LH Green -----		
Press # (2 Seconds) RH turns Red-----		
Enter 1234 RH turns green -----		
Enter 6 LH flashes Green RH Green -----		
Enter 10 + 01-99 sec bleeps twice LH turns green -----		
10 denotes relay 2 next 2 digits sets time in seconds		


## Index

LED out ----- 

LED Green solid ----- 











LED Green flashing -- 

LED Red solid ----- 

LED Red flashing ----- 











## OTHER INSTRUCTIONS YOU MAY NEED






### FACTORY RESET

	LED Sequence	
Apply 12vDC LH LED is Green -----		
Enter # (2 seconds) RH LED turns RED -----		
Enter 1234 RH LED turns Green -----		
Enter 0 LH & RH LED turn RED both flashing-----		
Enter 1234 LH LED turns Green -----		



## LOCK STRIKE & AUXILIARY RELAY CODE ASSIGNMENT















	LED Sequence	
Apply 12vDc – LH Green -----		
Press # (2 Seconds) RH turns Red-----		
Enter 1234 RH turns green -----		
Enter 9 LH flashes Green RH Green -----		
Enter 3 digit user code you need to assign too -----		
Enter assignment digit for current User Slot		
( 1 ) lock strike relay		
( 2 ) Auxiliary relay		
( 3 ) lock & Auxiliary		

Index	
LED out -----	
LED Green solid -----	
LED Green flashing --	
LED Red solid -----	
LED Red flashing -----	















## PROGRAMMING CARD & PIN FACILITY

PLEASE NOTE CARD AND PIN WILL ONLY WORK IN SECURE MODE

## (How to Insert Proximity Card EM Type)

	LED Sequence	
Apply 12vDC LH Green -----		
Press # (2 seconds) RH light turns Red -----		
Enter 1234 RH lights turns Green -----		
Enter 7 RH light turns Red -----		
Create a user code 3 figures (001 to 500) LH flashing (Green) RH (Red)		
Show EM Card to Keypad LH Green RH Red -----		
Press # (2 seconds) LH light turns Green -----		

## (How to programme 4 digit PIN NUMBER)

	LED Sequence	
Apply 12vDC LH Green -----		
Press # (2 seconds) RH light turns Red -----		
Enter 1234 RH lights turns-----		
Enter 7 RH light turns -----		
Create a user code 3 figures (001 to 500) LH flashing (Green) RH (Red)		
Create a pin for user LH turns Green RH turns Red -----		
Press # (2 seconds) LH turns Green -----		


## TO SWITCH KEYPAD FROM NORMAL MODE TO SECURE MODE






**Keypad in normal mode**

**#3838#**


**revert back to normal mode**

**#3838#**




Index	
LED out -----	
LED Green solid -----	
LED Green flashing --	
LED Red solid -----	
LED Red flashing -----	

Programme DG500 latching mode. To use latching mode you must use Auxiliary relay2 Stage1 # for 2 seconds till red light comes on 1234 7 Create user code 3 figures (001 to 500) Create pin for user 4 digit (not 1234)# till red light goes off Stage 2 # for 2 seconds till red light comes on 1234 9 Enter user code 3 figure number in stage 1 2 # till red light goes off Stage 3 # till red light comes on 1234 6 2000 # till red light goes off When 4 figure number is put into key pad relay 2 opens Relay is closed by putting on 4 figure number in again.




## Latching Wiring




Latching mode only through  
relay 2.

## MAGNET WIRING



## WIRING FAIL SECURE



## Documents / Resources



[Spectrum DG500 Digital Keypad and Proximity Reader \[pdf\] User Manual](#)  
DG500, Digital Keypad and Proximity Reader