



swift EB137CD 40V Lithium-Ion Cordless Lawn Mower User Manual

[Home](#) » [Swift](#) » swift EB137CD 40V Lithium-Ion Cordless Lawn Mower User Manual 




40V LITHIUM-ION CORDLESS LAWN MOWER
Model: EB137CD

Contents

- [1 EB137CD 40V Lithium-Ion Cordless Lawn Mower](#)
- [2 SYMBOLS](#)
- [3 Safety Instructions](#)
- [4 PRODUCT SPECIFICATIONS](#)
- [5 ASSEMBLY AND OPERATION](#)
- [6 PARTS LIST](#)
- [7 MAINTENANCE AND CARE](#)
- [8 Documents / Resources](#)
- [9 Related Posts](#)

EB137CD 40V Lithium-Ion Cordless Lawn Mower



Operations Manual

SYMBOLS

General Safety Warnings



1. After releasing the On/Off switch, the cutter bar continues running briefly.
Risk of injury!
2. To protect against injury from the cutter blade, have a specialist garage perform all work such as replacing or regrounding the cutter blade (special tools required).
3. Before performing any maintenance and cleaning work on the garden tool, remove the battery.
4. Protect the battery contacts when the battery is not being used. Loose metal parts may short-circuit the contacts – Explosion and fire hazard!




Before using the tool, read the operating manual. Read all safety warnings and all instructions including the currently valid site rules and regulations for the prevention of accidents. Failure to follow the warnings and instructions may result in electric shock, fire, and/or serious injury.



Remove the safety key before carrying out any work on the unit and before leaving the unit.



Sharp cutting tool! Keep hands and feet away from the cutter bar! Wear protective gloves if possible.



Do not throw batteries and other electrical products into the household waste, fire, or water.



Recycle to protect the environment.



Do not expose to rain or wet conditions.



Protective goggles/visor, protective helmet & hearing protection.

Safety Instructions

User

This garden tool is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge unless they have been given supervision or instruction concerning the use of the machine by a person responsible for their safety.

Never allow children or people unfamiliar with these instructions to use the garden tool. Supervise children. This will ensure that children do not play with the unit.

Intended Use

This garden tool is intended exclusively to mow lawns according to the descriptions and safety instructions indicated in this operating manual.

Any other use is not as intended. Improper use is not covered by the warranty and the manufacturer will reject any liability. The user is liable for all injuries to third parties and damage to their property.

Operate the unit only in the technical condition as stipulated and delivered by the manufacturer. Arbitrary changes to the unit will exclude the manufacturer from any liability for resulting injury and/or damage.



Preparation

1. Familiarize yourself with the unit and its functions as well as its controls.
2. Inspect the lawnmower before switching it on and check for signs of wear and damage. Never use the lawnmower with damaged or missing guards, e.g. dis-charge flap and/or grass catcher, housing, etc.
3. Has the damage been repaired by a qualified technician or the service center?
4. Do not use a unit that has a defective switch and can no longer be switched on or off.
5. When working with or on the unit, always wear sturdy footwear and long trousers. Do not operate the unit when barefoot or wearing sandals.
6. Check the terrain on which the unit will be used and remove any stones, sticks, wires, bones, and other foreign objects, which could be picked up by the unit, to avoid endangering people.

During Operation

1. Do not switch on the unit if there are persons (particularly children) or animals in the immediate vicinity.
2. Ensure that children do not play with the unit.
3. Interrupt working if you notice that persons (particularly children) or pets are nearby.
4. Working on steep slopes can be dangerous.
5. Ensure that you have a firm footing and mow slowly.

6. Always mow across the slope and not up and down.
7. Be particularly careful when changing direction. There is a risk of tripping!
8. Do not mow on steep slopes.
9. Be particularly careful when mowing backward and pulling the lawnmower towards yourself.
10. Do not tilt the lawnmower when switching on the motor.
11. Maintain a safe distance as provided by the handle frame.
12. Do not switch on the motor until your feet are at a safe distance from the cutter bar.
13. Be careful and do not reach into the rotating cutter bar.
14. Switch the lawnmower off before tilting or transporting it, e.g. from/to the lawn or over paths.
15. Never run over gravel while the motor is running. There is a risk of being hit by stones!
16. Before lifting or transporting the lawn mower, switch the motor off, pull out the safety key, and wait until the cutter bar has come to a standstill.
17. Do not adjust the cutting height until the motor has been switched off and the cutter bar has come to a standstill.
18. Never open the discharge flap while the motor is running.
19. Before removing the grass catcher, switch the motor off and wait until the cutter bar has come to a standstill.
After emptying the grass catcher, carefully re-attach it and ensure that the grass catcher is attached securely to the lawnmower.
20. If possible, do not mow wet grass.
21. Do not work with the garden tool in a potentially explosive environment in which there are flammable liquids, gases, or dust.
22. When interrupting work, never leave the unit unattended and keep it in a safe place.

For The Battery Charger

1. Do not place any objects on the battery charger and do not place the battery charger on soft surfaces.
2. Please read the safety instructions for Li-ion batteries. There is a risk of explosion.
3. Liquid ejected from the battery may cause irritation or burns.
4. If other batteries are used, e.g. imitations, reconditioned batteries, or third-party products, there is a risk of injuries as well as damage caused by exploding batteries.
5. A charger that is suitable for one type of battery pack may create a risk of fire when used with another battery pack. This may cause an internal short-circuit and the battery to burn, smoke, explode or overheat.

General Power Tool Safety Warnings




The term “power tool” in the warnings refers to your mains operated (corded) power tool or battery-operated (cordless) power tool.

Work Area Safety


1. **Keep the work area clean and well-lit.** Cluttered or dark areas invite accidents.

2. **Do not operate power tools in explosive atmospheres, such as in the presence of flammable liquids, gases, or dust.** Power tools create sparks that may ignite dust or fumes.
3. **Keep children and bystanders away while operating a power tool.** Distractions can cause you to lose control.

Electrical Safety

1. **Power tool plugs must match the outlet. Never modify the plug in any way. Do not use any adapter plugs with earthed (grounded) power tools.** Unmodified plugs and matching outlets will reduce the risk of electric shock.
2. **Avoid body contact with earthed or grounded surfaces, such as pipes, radiators, ranges, and refrigerators.** There is an increased risk of electric shock if your body is earthed or grounded.
3. **Do not expose power tools to rain or wet conditions.** 
Water entering a power tool will increase the risk of electric shock.
4. **Do not abuse the cord. Never use the cord for carrying, pulling, or unplugging the power tool.** Keep the cord away from heat, oil, sharp edges, or moving parts. Damaged or entangled cords increase the risk of electric shock.
5. **When operating a power tool outdoors, use an extension cord suitable for outdoor use.** The use of a cord suitable for outdoor use reduces the risk of electric shock.
6. **If operating a power tool in a damp location is unavoidable, use a residual current device (RCD) protected supply.** The use of an RCD reduces the risk of electric shock.

Personal Safety

1. **Stay alert, watch what you are doing, and use common sense when operating a power tool. Do not use a power tool while you are tired or under the influence of drugs, alcohol, or medication.** A moment of inattention while operating power tools may result in serious personal injury.
2. **Use personal protective equipment.** Always wear eye protection. Protective equipment such as dust masks, non-skid safety shoes, hard hats, or hearing protection used for appropriate conditions will reduce the risk of injury. 
3. **Prevent unintentional starting. Ensure the switch is in the off-position before connecting to the power source and/or battery pack, picking up, or carrying the tool.** Carrying power tools with your finger on the switch or power tools that have been turned on invites accidents.
4. **Remove any adjusting key or wrench before turning the power tool on.** A wrench or a key left attached to a rotating part of the power tool may increase the risk of injury.
5. **Do not overreach. Keep proper footing and balance at all times.** This enables better control of the power tool in unexpected situations.
6. **Dress properly. Do not wear loose clothing or jewelry. Keep your hair, clothing, and gloves away from moving parts.** Loose clothes, jewelry, or long hair can be caught by moving parts.
7. **If devices are provided for the connection of dust extraction and collection facilities, ensure that these are connected and properly used.** The use of dust collection can reduce dust-related hazards.

Power Tool Use And Care

1. **Do not force the power tool. Use the correct power tool for your application.** The correct power tool will do the job better and safer at the rate for which it is designed.
2. **Do not use the power tool if it can't be turned on and off by its switch.** Any power tool that cannot be controlled with the switch is dangerous and must be repaired.
3. **Disconnect the plug from the power source and/or the battery pack from the power tool before making** any adjustments, changing accessories, or storing the power tool. Such preventive safety measure reduces the risk of starting the power tool accidentally.
4. **Store idle power tools out of the reach of children and do not allow persons unfamiliar with the power tool or these instructions to operate it.** Power tools are dangerous in the hands of untrained users.
5. **Maintain the power tools. Check for misalignment or binding of moving parts, breakage of parts, and any other condition that may affect the power tool's operation.** If damaged, have the power tool repaired before use. Many accidents are caused by poorly maintained power tools.
6. **Keep cutting tools sharp and clean.** Properly maintained cutting tools with sharp cutting edges are less likely to bind and are easier to control.
7. **Use the power tool, accessories and tool bits, etc.** in accordance with these instructions, taking into account the working conditions and the work to be performed. Use of the power tool for operations different from those intended could result in a hazardous situation.

Battery Tool Use And Care

1. **Recharge only with the charger specified by the manufacturer.** A charger that is suitable for one type of battery pack may create a risk of fire when used with another battery pack.
2. **Use power tools only with specifically designated battery packs.** The use of any other battery packs may create a risk of injury and fire.
3. **When the battery pack is not in use, keep it away from other metal objects like paper clips, coins, keys, nails, screws, or other small metal objects that can make a connection from one terminal to another.** Shorting the battery terminals together may cause burns or fire.
4. **Under abusive conditions, liquid may be ejected from the battery; avoid contact.** If you accidentally contact the battery liquid, flush it with water. If the battery liquid contacts the eyes seek medical help as soon as possible. Liquid ejected from the battery may cause irritation or burns.

Service

Have your power tool serviced by a qualified repair professional using only the identical replacement parts. This will ensure that the safety of the power tool is maintained.

PRODUCT SPECIFICATIONS

Type	EB137CD	
Nominal voltage	V	40
Cutting Width	inch	15
Cutting height	inch	0.98-2.95
Capacity grass catcher	gal.	10.5
Idle speed	r.p.m.	4000
Sound power level LwA	dB(A)	96
Weight (without battery)	Lbs	34.17
Battery (EB20)	Ah	2
Charger (EBC05)	V	40

ASSEMBLY AND OPERATION

Before Initial Operation

Unpack the garden tool and accessories and check that no parts are missing or damaged.

NOTE: The batteries (optional; depending on delivery scope) are not fully charged on delivery. Prior to the initial operation, charge the batteries fully. See the user manual of the battery charger.

Safety Key




The unit has a security key. The key is located under the battery cover. By removing the key, the power supply to the motor is interrupted.

Remove the safety key:

- a.) if the unit is left unattended;
- b.) before checking, cleaning, or performing other work on the unit;
- c.) before removing blockages;
- d.) if a foreign object is hit;
- e.) if the unit starts vibrating excessively.

Check the lawnmower for damage, and have any damage repaired by a qualified technician or a service center.

To remove the key, press the lock (1) and pull out the safety key (2).





To insert the safety key, press down the key until it clicks.

Assembly


Attaching The Handle Bar

CAUTION: When collapsing or unfolding the handlebar, the cable may be damaged. Ensure that the cable is not kinked

1. Unfold the upper handlebar upwards (1). And tighten the knobs between the upper and lower handlebars as illustrated.




2. Insert the lower handle into slot (2).
3. Align the holes on the handlebar and the machine.
Insert the bolts through the holes and tighten up (3&4).




Assembling the Grass Catcher

1. Insert the two lower parts together until it clicks (1).
2. Turn in the two screws at the bottom (2).




3. Put on the upper part and press it together until it clicks. (3).



Attaching the Grass Catcher


1. Lift the discharge flap (1).
2. Hook the grass catcher bag into the lawnmower (2).
3. Fold the discharge flap down (3).



Adjusting the Cutting Height

The cutting height can be adjusted from 0.98" to 2.95".


1. Pull the handle outwards slightly.
2. Set the required cutting height.
3. Release the lever again.



Inserting/Replacing the Battery


Ensure that the battery is fully charged before inserting it into the tool.

1. Open the battery cover (1).
2. Press the charged battery into the power tool until it clicks into place (2).
3. Close the battery cover (3).



Removing the Battery

1. Press the release button (1).
2. Pull out the battery (2).




GENERAL SAFETY WARNING #4!

CAUTION: Protect the battery contacts when the battery is not being used. Loose metal parts may short-circuit the contacts – **Explosion and fire hazard!**

Switching the Power Tool On

1. Press the switch interlock and hold down (1).
2. Pull back the On/Off switch towards the handle (2).
3. The motor runs.



Switching the Power Tool Off


1. Release the On /Off switch (2).



GENERAL SAFETY WARNING #1!

Removing and Emptying the Grass Catcher


1. If the grass catcher bag is full and should be emptied immediately.



2. Switch the motor off.
3. Wait until the cutter bar stops.
4. Lift the discharge flap.
5. Remove the grass catcher.
6. Lower the discharge flap down again.
7. Empty the grass catcher.
8. Before hooking, remove any obstructions from the cutting area.

Working Without the Grass Catcher

When working without the grass catcher, the mowed grass is ejected directly downwards.



Charging the Battery

1. Plug the charger into an AC outlet 100-250V (normal household voltage).
2. Insert the battery into the slots of the charger and slide into place until the battery locks into place
3. The LED will flash green while the battery is charging.
 - Once the battery is fully charged, the LED indicator will show a steady green light.
 - Remove the battery by pressing and holding the latch button and sliding out of the charger. Lithium Ion batteries have no memory effect – a partial charge will not damage your battery.


TIPS ON LAWN CARE

Here are some tips to help you keep your lawn looking healthy and ensure uniform growth:

Lawns consist of various grass types. Frequent mowing promotes the growth of grass, resulting in strong roots and a firm sward. If you seldom cut the grass, you will enhance the development of high-growing types of grass and other weeds, such as clover, and daisies). The normal height of a lawn is approx. 4–5 cm. Only one-third of

the total height should be mown; therefore cut 7–8 cm long grass to normal height.

PARTS LIST



- | | |
|---|--|
| <ul style="list-style-type: none">1. Upper Handle2. Fasten Screw3. Lower Handle4. Grass Catcher5. Battery6. Wheels | <ul style="list-style-type: none">7. Switch Interlock8. Foam Pipe9. On/Off Switch10. Plastic Stopper11. Safety Key |
|---|--|

MAINTENANCE AND CARE



1. Switch the unit off, remove the safety key and remove the battery from the mower then place the unit in a safe location.
2. Do not keep the unit within the reach of children.
3. Ensure that the ventilation slots in the unit are clean.
4. Keep all nuts, bolts, and screws tight to be sure that the lawnmower is in safe working condition.
5. Check the grass catcher frequently for wear or damage.
6. Use only the cutter bar, which is intended for this lawnmower.

7. Please follow the supplied installation instructions and remove the battery beforehand.
8. Have repairs carried out exclusively by a qualified technician or at a service center.

Cleaning Lawn Mower

1. Do not use water or liquid detergents.
2. Whenever possible, always clean the unit directly after mowing.
3. Remove the battery.
4. Remove the grass catcher.
5. After mowing, always clean the lawnmower with a hand brush.
6. Remove grass residues carefully out of the cutting area. Remove stuck clipping deposits using a stick.
7. Keep the ventilation slits clean and dust-free.

Grass Catcher

For thorough cleaning, the grass catcher can be cleaned with a hose

Storage


1. Remove the safety key and remove the battery from the mower before storing
2. Store the unit in a dry and frost-free place (50-77 °F).
3. Store the battery and the unit separately.
4. Charge the battery before storing the unit in winter.
5. Keep the unit, in particular its plastic components, away from brake fluids, petrol, petroleum products, penetrating oil, etc. They contain chemical substances which may damage, attack or destroy the plastic components of the unit.

Folding the Lawn Mower

The handlebar can be folded down to facilitate storage and transport. Loosen the screws of the triangle knob on the upper handle and move the handle backward.

Replacing/Regrinding The Cutter Blade

 **GENERAL SAFETY WARNING #2!**



Spare parts must conform to the requirements specified by the manufacturer. Therefore use original spare parts only or spare parts authorized by the manufacturer.

Repair

Check the unit for damage. Repairs may be earned out by an authorized customer service center only.

DISPOSAL INFORMATION



Recycle raw materials instead of disposing of the waste.

Devices, accessories, and packaging should be recycled in an environmentally friendly manner. Plastic parts are identified for recycling according to material type. For EU countries only:

Do not throw electric power tools into the household waste! In accordance with the European Directive 2012/19/EC on Waste Electrical and Electronic Equipment and transposition into national law, used electric power tools must be collected separately and recycled in an environmentally friendly manner.

GUARANTEE/WARRANTY

This product has been manufactured to the highest quality standards. When a new product is purchased, it is guaranteed a 24-month (lawnmower) and 12-month (battery) manufacturer's warranty which comes into force on the date the product was purchased.

The guarantee covers only the defects which can be attributed to a material and/or production fault as well as nonperformance of warranted characteristics.

When making a claim under the guarantee, enclose the original sales receipt with the purchase date. Repairs under the guarantee may be carried out only by workshops or service centers authorized by the manufacturer.


A claim may be made under the guarantee only if the power tool has been used as intended.

This warranty is invalid where defects are caused by or result from:

- misuse, abuse, or neglect;
- commercial use (industry, craft, rental)
- repairs attempted by unauthorized repair centers
- damage caused by external effects, foreign objects, substances, or accidents.



Documents / Resources

	swift EB137CD 40V Lithium-Ion Cordless Lawn Mower [pdf] User Manual EB137CD 40V Lithium-Ion Cordless Lawn Mower, EB137CD, 40V Lithium-Ion Cordless Lawn Mower, Cordless Lawn Mower, Lawn Mower, Mower, Cordless Mower
---	--