


TCHELICON Voicetone Harmony-G Xt User Guide

Home » TCHELICON » TCHELICON Voicetone Harmony-G Xt User Guide 🖺

Quick Start Guide
VOICETONE HARMONY-G XT



(1) Input knob

Adjust the input gain so that the adjacent LED lights green while you sing, and occasionally lights orange during the loudest peaks.

(2) Tone button

A single press activates or deactivates AdaptiveTone to make your voice smoother and brighter, indicated by a solid LED when engaged. A double click activates or deactivates auto-chromatic pitch correction to provide subtle pitch support, indicated by a periodic flash of the LED when engaged. When both effects are engaged, the LED will light solid except for periodically flashing off.

(3) Guitar knob

Controls the guitar volume when the THRU jack is not used. The far left `Auto' position automatically balanced your guitar volume with your voice. Just above the `Auto' setting is an `Off' setting that mutes the guitar.

(4) FX knob

Adjusts the mix level of the effect selected with the FX button.

(5) Harmony knob

Adjusts the mix level of the harmony and double effects.

(6) Preset button

Press to cycle through the 5 presets shown in the display. Hold the Preset button to save changes made to the current preset.

(7) **48V LED**

Hold the Manual and Double buttons for 2 seconds to engage phantom power for use with condenser microphones.

(8) Manual button

Press to allow the guitar signal to dictate the harmonies. Details of this function are discussed in the full manual.

(9) Double button

Press to simulate the sound of two of you singing in unison.

(10) Voice 1/2 buttons

Press either of the Voice buttons to select a harmony interval. Details of this function are discussed in the full manual. Hold both buttons to select stereo or mono operation.

(11) FX button

Press to cycle through the available effect styles for the current preset. When no LEDs are lit, the effects are bypassed.

(12) Preset A/B footswitch

Tapping the footswitch will toggle between the presets assigned to slot A and B. Hold the footswitch to enter Preset Select mode for the current slot (A or B), which allows the footswitch to cycle through all 5 saved presets.

(13) On/Bypass footswitch

Tapping the footswitch engages or disengages the doubling and harmony effects in the current preset, leaving the reverb/delay effects active. Holding the footswitch will enter Tuner/Bypass mode, which mutes the guitar signal and bypasses all vocal effects except for Tone.

(14) USB port

Connect to a computer for firmware updates and support.

(15) Power input

Connect the included power adapter. (12 V DC, 300 mA, tip negative)

(16) OUTPUTS

Connect to a mixer via XLR cables.

(17) INST IN/THRU

Connect your guitar to the IN jack, then connect the THRU to other guitar pedals or an amplifier.

(18) MIC INPUT

Connect your microphone via XLR cable.

(19) GND

If you hear a buzz when you plug in a cable from the THRU to your amp or PA, press this button in. If the THRU jack is not used and your guitar sound is routed internally, the Ground Lift switch should be left out.

Visit tc-helicon.com to download the full manual

LEGAL DISCLAIMER

Music Tribe accepts no liability for any loss which may be suffered by any person who relies either wholly or in part upon any description, photograph, or statement contained herein. Technical specifications, appearances and other information are subject to change without notice. All trademarks are the property of their respective owners. Midas, Klark Teknik, Lab Gruppen, Lake, Tannoy, Turbosound, TC Electronic, TC Helicon, Behringer, Bugera and Coolaudio are trademarks or registered trademarks of Music Tribe Global Brands Ltd. © Music Tribe Global Brands Ltd. 2019 All rights reserved.

LIMITED WARRANTY

For the applicable warranty terms and conditions and additional information regarding Music Tribe's Limited Warranty, please see complete details online at musictribe.com/warranty.

Zhongshan Eurotec Electronics Limited


No. 10 Wanmei Road, South China Modern Chinese Medicine Park, Nanlang Town, 528451, Zhongshan City, Guangdong Province, China

Contents

- 1 Documents / Resources
 - 1.1 References
- 2 Related Posts



Documents / Resources



TCHELICON Voicetone Harmony-G Xt [pdf] User Guide Voicetone Harmony-G Xt

References

• TC Helicon | Home

Manuals+,