



TEAC TD-SC1 Setup Instruction Manual

[Home](#) » [TEAC](#) » TEAC TD-SC1 Setup Instruction Manual 

Contents

- 1 [TEAC TD-SC1 Setup](#)
- 2 [Overview](#)
 - 2.1 [Introduction](#)
 - 2.2 [Features](#)
- 3 [Program installation](#)
 - 3.1 [Recommended computer system for TD-SC1 Setup](#)
 - 3.2 [Installing TD-SC1 Setup](#)
- 4 [Program operation](#)
 - 4.1 [Launching and closing the program](#)
 - 4.2 [Calibrating](#)
 - 4.3 [Making condition settings](#)
 - 4.4 [Making comparison/hold settings](#)
 - 4.5 [Making system settings](#)
 - 4.6 [Changing setting memories](#)
 - 4.7 [Monitoring](#)
- 5 [Documents / Resources](#)
 - 5.1 [References](#)
- 6 [Related Posts](#)

TEAC

TEAC TD-SC1 Setup



Thank you very much for using the TD-SC1 Setup Program. Read this manual before using it.
After reading it, keep it in a safe place for future reference.

Revision history

Revision	Date	Description
1.0.0	Oct. 2020	First edition
1.1.0	Dec. 2020	Support for linearization calibration and input/output tests

Note

Any data, including, but not limited to information, described herein are intended only as illustrations of such data and/or information and not as the specifications for such data and/or information. TEAC CORPORATION disclaims any warranty that any use of such data and/or information shall be free from infringement of any third party's intellectual property rights or other proprietary rights, and further, assumes no liability of whatsoever nature in the event of any such infringement, or arising from or connected with or related to the use of such data and/or information.

- Microsoft and Windows are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.
- Intel and Intel Core are trademarks of Intel Corporation or its subsidiaries.

- Other company names, product names and logos in this document are the trademarks or registered trademarks of their respective owners.
- The contents of this document could be changed without warning in the future.

Any Software is protected by applicable copyright acts and international treaties. Unauthorized reproduction or distribution of the SOFTWARE, or any portion of it, may constitute infringement of rights under applicable civil codes, and further criminal behavior, which may result in criminal penalties or damages claimed. This SOFTWARE is licensed on the condition that YOU agree to all terms and condition of the following End User License Agreement.

End User License Agreement

This End User License Agreement is an agreement between YOU and TEAC Corporation (hereinafter referred to as "TEAC") regarding the software, including computer programs, online or electronic documents, and if provided, any related record media, printed materials, and any software TEAC may provide as the updates, additions or customizations for specific individual customers (hereinafter collectively referred to as "SOFTWARE"). By installing the SOFTWARE, it is deemed that YOU have agreed to be bound by the terms of this Agreement. If you do not agree to the terms of this Agreement, YOU may not be allowed to use the SOFTWARE.

1. GRANT OF LICENSE.

TEAC grants YOU the right to use the SOFTWARE for the product that YOU possess (hereinafter referred to as "PRODUCT"). YOU may produce one set of a duplicate of the SOFTWARE for the purpose of backup.

2. RESTRICTIONS.

- YOU may not delete the copyright notices or any other proprietary legends on the SOFTWARE, when YOU produce a duplicate of the SOFTWARE;
- YOU may not copy or distribute the SOFTWARE to any third party;
- YOU may not modify, reverse engineer, decompile, or disassemble the SOFTWARE;
- YOU may not rent or lease the SOFTWARE to any third party; and
- Only in case YOU transfer the SOFTWARE together with PRODUCT to the transferee perpetually, YOU may transfer YOUR rights under this Agreement to the transferee of the SOFTWARE, provided that the transferee agrees to comply with the terms and conditions of this Agreement.

3. TERMINATION.

Without prejudice to any rights or claims to YOU, TEAC may revoke YOUR rights under this Agreement if YOU breach this Agreement. In such event, YOU must immediately cease using the SOFTWARE, and must completely delete them. Without prejudice to any rights or claims to YOU, TEAC may revoke YOUR rights under this Agreement if YOU breach this Agreement. In such event, YOU must completely delete the SOFTWARE including any duplicate.

4. COPYRIGHT

Any and all titles and copyrights in and to the SOFTWARE including any duplicate are reserved to TEAC or the third parties who granted license to TEAC (hereinafter referred to as "SUPPLIER"), and are protected by applicable copyright acts, intellectual property rights regulations, and international treaties.

5. LIMITATION OF WARRANTY

YOU ACKNOWLEDGE AND AGREE THAT ALL INFORMATION SUPPLIED BY TEAC UNDER THIS AGREEMENT, INCLUDING WITHOUT LIMITATION, THE SOFTWARE, IS PROVIDED BY TEAC "AS IS" AND WITHOUT WARRANTY OF ANY KIND. TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, TEAC HEREBY DISCLAIMS ALL WARRANTIES, EXPRESS OR IMPLIED, WITH RESPECT TO THE SOFTWARE AND ANY MODIFICATION THEREOF BY YOU, INCLUDING BUT NOT LIMITED TO ANY

WARRANTIES OF DESIGN, MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, NON-INFRINGEMENT, OR WARRANTIES ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE. TEAC DOES NOT WARRANT THAT THE FUNCTIONS CONTAINED IN THE SOFTWARE WILL MEET YOUR REQUIREMENTS, OR THAT OPERATION OF THE SOFTWARE WILL BE UNINTERRUPTED OR ERROR-FREE, OR THAT DEFECTS IN THE SOFTWARE WILL BE CORRECTED, OR THAT YOU WILL HAVE OUR SUPPORT FOR YOUR USE OF THE SOFTWARE. TEAC SHALL HAVE NO RESPONSIBILITY OR LIABILITY FOR ERRORS OR PRODUCT MALFUNCTION RESULTING FROM YOUR USE, MODIFICATION, COPYING, OR DISTRIBUTION OF THE SOFTWARE. YOU assume complete responsibility for decisions made or actions taken based on information obtained using the Software. Any statements concerning the utility of the Software are not to be construed as expressed or implied warranties.

6. NO LIABILITY FOR CONSEQUENTIAL DAMAGES TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT SHALL TEAC AND THE SUPPLIER BE LIABLE FOR ANY SPECIAL, INCIDENTAL, INDIRECT, OR CONSEQUENTIAL DAMAGES WHATSOEVER (INCLUDING, WITHOUT LIMITATION, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, DAMAGES FROM LOSS OF OR NON-OBTAINING OF BUSINESS INFORMATION OR DATA, OR ANY OTHER PECUNIARY LOSS) ARISING OUT OF THE USE OF OR INABILITY TO USE THE SOFTWARE, EVEN IF TEAC HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. IN CASE ANY LAWS OR REGULATIONS IN SOME JURISDICTIONS DO NOT ALLOW THE EXCLUSION OR LIMITATION OF LIABILITY FOR CONSEQUENTIAL OR INCIDENTAL DAMAGES, THE LIMITATION WILL NOT APPLY TO YOU.

7. MAXIMUM LIABILITY

TEAC's maximum liability you can claim, if any, under this Agreement shall, in no event, exceed the purchase amount of the SOFTWARE paid by YOU.

8. MISCELLANEOUS

This Agreement shall be construed in accordance with the laws of Japan. All disputes arising in connection with this Agreement shall be submitted to the exclusive jurisdiction of the Tokyo District Court of Japan.

Should you have any questions concerning this Agreement, or if you desire to contact TEAC for any reason, please write to the address or visit our website set forth below:

TEAC CORPORATION

1-47 Ochiai, Tama-shi, Tokyo 206-8530, Japan

TEAC Load Cell site (Inquiry Form)

<https://loadcell.jp/en/inquiry/>

Tel. +81-42-356-9161

Fax. +81-42-356-9185

Manual overview

This manual explains operation procedures for TD-SC1 Setup, which is a Windows PC setup program designed for use with the TD-SC1. Read the Instructions for Use for the TD-SC1 thoroughly before operating this program.

Conventions used in this manual

Items and messages shown in the program are indicated with quotation marks, for example "MENU" and "Are you sure?"

Control buttons and selection items in the program are indicated with brackets, for example, [REC].

Overview

Introduction

TD-SC1 Setup is a set up program designed for TD-SC1 digital indicators.

Features

By connecting to a TD-SC1 by USB, the following operations are possible with that TD-SC1.

- Importing and exporting TD-SC1 setting values
- Loading and saving TD-SC1 setting value files
- Digitally displaying current TD-SC1 values

Program installation

Recommended computer system for TD-SC1 Setup

- CPU: 6th generation Intel® Core™ i5, 2.4 GHz or faster
- OS: Windows 10
- Memory: 4 GB or more
- Hard drive open space: 10 GB or more
- USB 2.0 1 or more ports
- Screen resolution: 1024×768 pixels or more
- Net Framework 4.7.2

Installing TD-SC1 Setup

1. Double-click the TD-SC1 Setup installer (Setup.exe) to launch it.
Click [Next >] to open the next screen.



2. Select the installation folder. Click [Browse...] to change the folder.
Click [Next >] to open the next screen.



3. A message to confirm the start of installation will appear.

Click [Next >] to start program installation



4. When program installation completes, the next message will appear.

Click [Close] to close the dialog.



Program operation


Launching and closing the program

In the Start menu at the bottom left of the screen, click [TEAC] > [TD-SC1 Setup] to launch the TD-SC1 Setup program.




When running, it will always try to connect with the TD-SC1.

When not connected, “TD-SC1 Setup – file version [OFF LINE]” will appear in the window title bar.



Click at the top right of the main window to close the program.

The following menu will open before closing.



Click “Yes” to save to the unit’s ROM. By doing this, the settings will be retained even if the unit is turned off. (Clicking “Update ROM” at the bottom of the main window has the same effect. “Update ROM” becomes available when settings have been changed.)

Calibrating

Make the “Calibration” tab active. (Click the “Calibration” tab if another tab is active.)



- Calibration Lock Remove the check to enable setting of the calibration items. (Remote Sense, Excitation Voltage, Rated Output, Rated Capacity, Zero Balancing, Actual Load Cal., TEDS Cal., Min. Grid, Disp. Times, Sensor Input Logic)
- Remote Sense Turn Remote Sense on/off.
- Excitation Voltage Set the excitation voltage.
- Rated Output [mV/V] Use when conducting equivalent input calibration. Click the field showing the value to open a setting dialog. Click "Set" change the setting.



- Rated Capacity Use when conducting equivalent input calibration and actual load calibration. Click the field showing the value to open a setting dialog. Click "Set" change the setting.
- Zero Balancing Click the "Execute" button to conduct zero balancing. Always conduct this with no load immediately after equivalent input calibration or TEDS calibration, as well as immediately before actual load calibration.
- Actual Load Cal. Click the "Execute" button to conduct actual load calibration. Always conduct this with the rated capacity load that was set in advance.
- TEDS Cal. Click "Exeter cute" button to conduct TEDS calibration.
- Linearize Cal. Click the "Linearize Cal. " button to open a dialog.


Check “Enable” to conduct linearization calibration for up to three points.

From the left, each point has an on/off checkbox, an output value (mV/V) and a capacity value. Set the output value (mV/V) first. Click the “Actual Load Cal. ” button if actual load calibration is necessary.



- Min. Grid Set the minimum digital change of the indicator value.
- Disp. Times Set the number of times that the indicator value is shown per second.
- Max. Disp. Set the highest indicator value.
Click the field showing the value to open a setting dialog.
Click “Set” change the setting.
- Sensor Input Logic The sensor input logic can be reversed artificially. Normally, “Standard” should be used.
- TEDS Disp. This writes the current rated output, rated capacity and calibration date to the TEDS memory.
Click the “TEDS Disp.” button to open the setting dialog.

The left side shows the current TEDS memory values and the right side shows the current rated output, rated capacity and calibration date. Click the “TEDS Write” button to open a request for the write password. Input “000015”. When writing succeeds, a “Succeeded” message will appear.



- TEDS Restore Restore calibration values that were changed using “TEDS Write” to product factory defaults. (If writing has not been conducted once, restoring will fail.) Click the “TEDS Restore” button to open a request for the restore password. Input “000015”. When restoring succeeds, a “Succeeded” message will appear.

Enabled only for D/A models

- Output Mode Set this to voltage output or current output.
- Max. Voltage When using output voltage, set the maximum voltage from 1–10 V.
- Zero Set the indicator value output for 0V voltage or 4mA current.

- Full Scale Set the indicator value output for maximum voltage or 20mA current.
- Cal. Input When the CAL button is pressed, voltage equivalent to the value input for this setting is output.
(This is also output during input/output tests.)

Conducting equivalent input calibration

1. Disable calibration locking (uncheck the box.)
2. Set the Remote Sense and Excitation Voltage.
3. Set the Rated Output value (with up to 3 decimal places.)
4. Set the Rated Capacity value. Set the number of digits after the decimal place accurately (0–4 digits can be set).
5. With no load, execute Zero Balancing.
6. Set the Min. Grid, Disp. Times, Max. Disp. and Sensor Input Logic.
7. Enable calibration locking (check the box.)

The screenshot shows the 'TD-6C1 Setup - 1.1.1.0' window with the 'Calibration' tab selected. The 'Setting Memory1' dropdown is at the top. The 'Calibration' tab contains the following settings:

- ☐ Calibration Lock (labeled ① ⑦)
- Remote Sense: OFF (labeled ①)
- Excitation Voltage: 5 V (labeled ②)
- Rated Output[mV]: 3.000 (labeled ③)
- Rated Capacity: 100.00 (labeled ④)
- Zero Balancing: Execute (labeled ⑤)
- Min. Grid: 1 (labeled ⑥)
- Disp. Times: 4 (labeled ⑥)
- Max. Disp.: 110.00
- Sensor Input Logic: Standard

On the right side of the Calibration tab, there are buttons for 'TEDS Cal.', 'Actual Load Cal.', 'Linearize Cal.', 'TEDS Disp.', and 'TEDS Restore'. An 'Execute' button is next to the 'Rated Output' and 'Rated Capacity' fields.

The 'D/A' section at the bottom contains the following settings:

- Output Mode: Voltage
- Max. Voltage: 10 V
- Zero: 0.00
- Full Scale: 100.00
- Cal. Input: 1.0 mV/V


An 'Update ROM' button is located at the bottom of the window.

- Calibration will change the following items, so check them beforehand.
 - D/A Zero, Full Scale
- Moreover, decimal point position changes will be applied to the following items.

- Condition Motion Detect Width, Zero Tracking Width, Digital Zero Limit Value, Digital Zero Offset
- Comparison Comparison Values (HI, LO), Hysteresis, Bar Meter Zero Position

Conducting actual load calibration


1. Disable calibration locking (uncheck the box.)
2. Set the Remote Sense and Excitation Voltage.
3. Set the rated capacity value of the actual load. Set the number of digits after the decimal place accurately (
4. With no load, execute Zero Balancing.
5. With the actual load, execute Actual Load Calibration.
6. Set the Min. Grid, Disp. Times, Max. Disp. and Sensor Input Logic.
7. Enable calibration locking (check the box.)



- Calibration will change the following items, so check them beforehand.
 - D/A Zero, Full Scale
- Moreover, decimal point position changes will be applied to the following items.
- Condition Motion Detect Width, Zero Tracking Width, Digital Zero Limit Value, Digital Zero Offset
 - Comparison Comparison Values (HI, LO), Hysteresis, Bar Meter Zero Position

Conducting TEDS calibration

1. Disable calibration locking (uncheck the box.)
2. Set the Remote Sense to OFF and set the Excitation Voltage.
3. Execute TEDS Calibration.
4. With no load, execute Zero Balancing.
5. Set the Min. Grid, Disp. Times, Max. Disp. and Sensor Input Logic.
6. Enable calibration locking (check the box.)



- Calibration will change the following items, so check them beforehand.
- D/A Zero, Full Scale
- Moreover, decimal point position changes will be applied to the following items.
- Condition Motion Detect Width, Zero Tracking Width, Digital Zero Limit Value, Digital Zero Offset
- Comparison Comparison Values (HI, LO), Hysteresis, Bar Meter Zero Position

Making condition settings

Make the "Condition" tab active. (Click the "Condition" tab if another tab is active.)



- **LPF** Set the low pass filter cutoff frequency.
- **Moving Aver.** Set the moving average number.
Click the field showing the value to open a setting dialog.
Click "Set" to change the setting.
- **Auto Digital Filter** Turn Auto Digital Filter ON/OFF
- **Motion Detect** Set the Time (s) and Width used to detect stability.
Click the field showing the value to open a setting dialog.
Click "Set" to change the setting.
- **Zero Tracking** Set the Time (s) and Width used to automatically track and correct drift and other gradual changes to the zero point. Click the field showing the value to open a setting dialog.
Click "Set" to change the setting.
- **Digital Zero** Turn Digital Zero ON/OFF.
Click the field showing the Limit Value used for the Digital Zero function to open a setting dialog.
Click "Set" to change the setting.
- **Digital Zero Offset** The set value is subtracted from the measured value.
Click the field showing the value to open a setting dialog.
Click "Set" to change the setting.
- **D/A Data Output** Set whether to link D/A output to display or input.

Making comparison/hold settings

Make the “Comparison/Hold” tab active. (Click the “Comparison/Hold” tab if another tab is active.)



- **Comp. Value** Set the high limit and low limit values, compare them with indicator values, and turn judgment output ON for each one.

Click the field showing the value to open a setting dialog.

“Set Click ” to change the setting.

- **Comp. Pattern** Set the comparison judgment OK pattern for the set comparison values.
- **Comp. Mode** Set the conditions for conducting comparison judgment.
- **Hysteresis** Set the width for switching judgment output.
Click the field showing the value to open a setting dialog.
Click “Set” to change the setting.
- **Comp. Output Pattern** Set judgment output operation to Standard Output or Area Output.
- **Bar Meter Zero Position** Set the range in which indicator values are evaluated as being nearly zero.
Click the field showing the value to open a setting dialog.
Click “Set” to change the setting.

- **Hold Mode** Set the indicator value hold condition.
- **External Hold Mode** Set the control input terminal HOLD signal format.
- **CLEAR Signal** Set whether control input terminal CLEAR signals are enabled (ON) or disabled (OFF).
- **Zone Definition** When set to ON, the indicator value will continue to be shown after the hold ends. Use a

control input terminal CLEAR signal to stop showing it.

- Auto Zero Set whether or not to automatically execute a Digital Zero when a hold starts (ON/OFF).

Making system settings

Make the “System” tab active. (Click the “System” tab if another tab is active.)

- Calibration Lock Remove the check to enable setting of the calibration items.
(Remote Sense, Excitation Voltage, Rated Output, Rated Capacity, Zero Balancing, Actual Load Cal., TEDS Cal., Min. Grid, Disp. Times, Sensor Input Logic)
- Setting Lock Remove the check to enable setting D/A, Condition, Comparison and System items.
(All D/A items, all Condition items, all Comparison/Hold settings, Unit Information Number)
- Operation Lock This shows the panel lock status of the unit. If the box is unchecked, it is unlocked.
- Unit Information This shows the model name, firmware version and communication option setting.
The option mode can be changed when offline.
- Number This sets the identification number of the unit. Click the field showing the value to open a setting dialog.
Click “Set” to change the setting.

Enabled only for RS-485 models ID

- Transmission mode Set the RS-485 COM port number.
- Baud Rate Set the RS-485 transmission mode.
- Bit Length Set the RS-485 baud rate.
- Parity Set the RS-485 bit length.
- Stop Bit Set the RS-485 parity bit.
- Delimiter Set the RS-485 stop bit.
- Initialize Settings Initialize the settings.
Initialization will not be executed if calibration or setting values are locked.
- Load Settings Load settings saved in a file.
Initialization will not be executed if calibration or setting values are locked
- Save Settings Save the current settings.

Changing setting memories

Setting Memories 1–4 can be changed, and the current Setting Memory can be set.

TD-SC1 Setup - 1.1.1.0

Setting Memory1
Setting Memory1
Setting Memory2
Setting Memory3
Setting Memory4

Remote Sense	OFF		
Excitation Voltage	5 V		
Rated Output[mV/V]	5.000	TEDS Cal.	Execute
Rated Capacity	100.00		
Zero Balancing	Execute	Actual Load Cal.	Execute
Min. Grid	1		Linearize Cal.
Disp. Times	4		
Max. Disp.	110.00		TEDS Disp.
Sensor Input Logic	Standard		TEDS Restore

D/A

Output Mode	Voltage	Cal. Input	1.0 mV/V
Max. voltage	10 V		
Zero	0.00		
Full Scale	100.00		


Update ROM

Monitoring

Make the "Monitor" tab active. (Click the "Monitor" tab if another tab is active.)



- Indicator Value The current indicator value is shown.
- SETUP (number) This shows the current setting memory number.
- LO/OK/HI/FULL This shows the comparison judgment.
- ZERO This appears when the indicator value is nearly zero.
- STB This appears when the indicator value is stable.
- HOLD This appears when the indicator value is held.
- ZERO button Click to execute the Digital Zero function.
- HOLD ON/OFF button Click to turn hold on/off.
- HOLD CLEAR button Click to clear a hold.
- STRAIN button Click to show/hide static strain.
- TEST button Execute an input/output test. When Input is ON (LOW), it becomes light blue. Click an Output button to switch it on/off. (Light blue is on.)



Documents / Resources

	<p>TEAC TD-SC1 Setup [pdf] Instruction Manual TD-SC1 Setup, TD-SC1, Setup</p>
---	---

References

- 📄 [Inquiry Form - Load Cell site | TEAC](#)