


TELTONIKA TFT100 Geofence Settings



TELTONIKA TFT100 Geofence Settings Instructions

[Home](#) » [teltonika](#) » TELTONIKA TFT100 Geofence Settings Instructions 

Contents

- [1 TELTONIKA TFT100 Geofence Settings](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
- [4 Manual Geofence Settings](#)
- [5 Manual Geofence Map](#)
- [6 Documents / Resources](#)
 - [6.1 References](#)
- [7 Related Posts](#)

TELTONIKA

TELTONIKA TFT100 Geofence Settings

Auto Geofence

Scenario Settings

Disable
Low Priority

High Priority
Panic Priority

Eventual Records

Disable
Enable

Generate Event

On Exit
On Entrance

On Both

Activation Timeout (s)
60

Radius (m)
100

Deactivate By

Power Voltage
Digital Input 1

Engine RPM

Send SMS To

SMS Text
AutoGeofence

Product Information

Specifications

- Model: TFT100
- Max Geofence Zones: 50
- Event Generation: Triggered when crossing defined zone border

Product Usage Instructions

Manual Geofence Selection:

The TFT100 can support up to 50 configurable Geofence zones. These Geozones can generate an event when a defined zone border is crossed.

Manual Geofence Settings:

Manual geofence settings can be configured only when OverSpeeding is not detected anywhere. It's important to note that regular OverSpeeding and geozones' OverSpeeding function independently.

Max Allowed Speed: Set the maximum allowed speed in the geozone.

Manual Geofence Map

Coordinates for the Geozone can be described using coordinate systems or by utilizing the drag & drop feature on the map for each selected zone. Please note that only one figure can be set on one geozone.

FAQ (Frequently Asked Questions):

- **Q: How many Geofence zones can the TFT100 support?**

A: The TFT100 can support up to 50 configurable Geofence zones.

- **Q: Can geozones generate events when crossing a defined zone border?**

A: Yes, Geozones can generate an event when a defined zone border is crossed.

https://wiki.teltonika-gps.com/view/TFT100_Manual_Geofence_settings

TFT100 Manual Geofence settings


Main Page > E-Mobility Trackers > TFT100 > TFT100 Configuration > TFT100 Manual Geofence settings

Contents

- 1 Manual Geofence Settings
 - 1.1 Manual Geofence Selection
 - 1.2 Manual Geofence Settings
- 2 Manual Geofence Map

Manual Geofence Settings

Manual Geofence Selection



The image shows a web interface for 'Manual geofence selection'. It features a dropdown menu with a light blue border. The text 'Manual geofence selection' is written in blue above the dropdown. The dropdown itself is white and contains the text '1 geozone' in a dark font, with a small downward-pointing chevron icon on the right side.

TFT100 can have up to 50 configurable Geofence zones. As well Geozones can generate an event when a defined zone border is crossed.

Manual Geofence Settings

Manual geofence 1

Feature	
<input type="button" value="Disable"/>	<input type="button" value="Low Priority"/>
<input type="button" value="High Priority"/>	<input type="button" value="Panic Priority"/>
Generate Event	
<input type="button" value="No Event"/>	<input type="button" value="On Exit"/>
<input type="button" value="On Entrance"/>	<input type="button" value="On Both"/>
Eventual Records	
<input type="button" value="Disable"/>	<input type="button" value="Enable"/>
Frame Border	<input type="text" value="1"/>
Shape Type	
<input type="button" value="Circle"/>	<input type="button" value="Rectangle"/>
Latitude (Y1)	<input type="text" value="0.0"/>
Longitude (X1)	<input type="text" value="0.0"/>
Latitude (Y2)	<input type="text" value="0.0"/>
Longitude (X2)	<input type="text" value="0.0"/>
Overspeeding	
<input type="button" value="Disable"/>	<input type="button" value="Enable"/>
Max Allowed Speed (km/h)	<input type="text" value="90"/>
Send SMS To	<input type="text" value=""/>
SMS Text	<input type="text" value="Geozone Zone 1"/>

- **Feature** – The priority of Geofence event is categorized into low, High or Panic levels. These levels define the priority of event information that is sent to the server. For more details about priorities look in here.
 - Generate event allows to choose when record will be generated.
 - **Eventual** records – controls where scenario status value appears: when disabled it will exist in each AVL record and when enabled the value will be appended only to eventual records.
 - **Frame** border – is an additional border around Geofence zone used to prevent false events when object stops on the border of the area and as a result records are made inside and outside the defined area because of GNSS errors. The event is generated only when both (Geofence and frame) borders are crossed. See figure to the right for details. Blue track is considered to have entered the area whereas red track is not.
 - **Shape** type – it is possible to have a rectangle or a circle as it is defined by the user. Radius – is used to set circle radius in meters when Circular zone is used.
 - **Latitude** Y1 – is used to set Y coordinate (latitude).
 - **Longitude** X1 – is used to set geofence zone left bottom corner X coordinate (longitude). Latitude Y2 – is used to set geofence zone upper right corner Y coordinate (latitude) for a Rectangular zone.
 - **Longitude** X2 – is used to set accordingly geofence zone upper right corner X coordinate (longitude) when Rectangular zone is used or circle radius when Circular zone is used.
 - **Over** Speeding – helps to configure Over Speeding scenarios separately for each different Geozone. If digital output control is enabled in a regular OverSpeeding scenario, geozones' OverSpeeding scenario will control it too i.e when the device is in more than one geozone and OverSpeeding is detected in any zone then the digital output turns on. Digital output turns off only when OverSpeeding is not detected anywhere.
- Note!** Regular OverSpeeding and geozones' OverSpeeding function independently.

Max Allowed Speed – Max allowed speed in the geozone.

Manual Geofence Map

Coordinates for the Geozone can be described not only with coordinate system but by drag & drop principle on the map in each selected geozone.

Note! Only one figure can be set on one geozone.



Documents / Resources

<p>TELTONIKA TFT100 Manual Geofence settings</p> <p>Contents</p> <p>Manual Geofence Settings</p>	<p>TELTONIKA TFT100 Geofence Settings [pdf] Instructions TFT100 Geofence Settings, Geofence Settings, Settings</p>
--	--

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.