

[Skip to content](#)

Manuals+

User Manuals Simplified.



THUNDERSTRUCK MOTORS JLD404 Programmable Battery Meter User Manual

[Home](#) » [THUNDERSTRUCK MOTORS](#) » THUNDERSTRUCK
MOTORS JLD404 Programmable Battery Meter User Manual 

Contents

- [1 THUNDERSTRUCK MOTORS JLD404 Programmable Battery Meter](#)
- [2 Thunderstruck Motors JLD404 Manual](#)
- [3 Simplified Wiring Diagram](#)
- [4 Features](#)
- [5 Specification](#)
- [6 Panel](#)
- [7 Key setting](#)
- [8 Setting](#)
- [9 Setup](#)
- [10 Documents / Resources](#)
- [11 Related Posts](#)

THUNDERSTRUCK

THUNDERSTRUCK MOTORS JLD404 Programmable Battery Meter



Thunderstruck Motors JLD404 Manual

Thank you for purchasing a JLD404 battery meter. You have made a wise choice to monitor the status of your batteries. Before installing your meter, please read this entirely and see the included wiring diagram.

It should be apparent from the drawing that your high-current load does not go through the meter. Instead, it is sensed via the shunt at 9 and 10 (notice that 10 is closest to the battery). If you have any questions about the legitimacy of your wiring, feel free to take a photo of it and shoot us an email; we'll gladly look it over for you. To get your meter to function to its fullest, you may need to establish a few parameters. Your meter should already be set up for your battery pack, in that it is programmed to accept a voltage range from 0-100V or from 0-500V. Be sure to use the appropriate terminal (5 or 6) for your application. If you want to change this setting, you'll have to swap terminals, and change settings for both the v-Sn (voltage input) and vPvH (full-scale voltage) to match your choice.

To make programming changes like those mentioned above, see the included manufacturer's manual for details. Simply put, you hit SET and choose 0036, and scroll through the choices. To make changes to the output relay settings, you hit SET and

Simplified Wiring Diagram



- ## Specification

- Input range: Current: 0-9999A(need a DC shunt): +/-
- 0.56FS+3d; 0-500VDCc (0.5% FS+3d)
- Input mode: Common Ground
- Sampling: 3times/sec
- Overload: "EEEE" or "-EEE"
- Expandable(need a proper DC shunt, programmable)
- Power 0.001W-9999Kw
- DC Accuracy: +/- 1%
- LED Display: Power (Blue/0.56")

- Operating Power: DC8-30V/2W
- Temperature: 0~ +50'C
- Humidity: <<85% RH
- Relay: AC220V/BA
- Relay Life Span: 10s
- Dimension: 96*48*82(mm), Mounting hole: 92*44(mm)



Panel

1. Display
2. Watt indicator
3. alam indicator
4. Current indicator
5. Selection key
6. Increment parameter down
7. KiloWat indicator
8. larm indicator
9. Voltage indicator
10. Set Confirm
11. decrement/parameter up

Key setting

During the stage of measuring, Press to select the reading from P(wat), V, and I(amp). Press for over 3 's, it will display P,V,I in sequence. Press again will cancel it. Parameter setup: Press,enter passcode: 0036

Fig 1

Full scale value	Decimal point	Display	Resolution
0500	2	5.00	10mA
5000	3	5.000	1mA

Fig2

0	1	2	3
---	---	---	---



Setting

- Pressto enter programming mode
- Input Password using
- Press O to set parameters
- Measurement setup

Symbol	Name	Definition	Selection/Range	Default	Remark
<i>A-Sn</i>	A-Sn	Input Current Sets	5A/1A/75mV	5A	1
<i>APvL</i>	APvL	"Zero A input" display	-1999~9999	0.000	2
<i>APvH</i>	APvH	Full scale display (A)	-1999~9999	5.000	3
<i>Adot</i>	Adot	Decimal point pos. (A)	0-3	3	4
<i>U-Sn</i>	U-Sn	Input Voltage Sets	500V/100V	500V	5
<i>UPvL</i>	UPvL	"Zero V input" display	-1999~9999	000.0	
<i>UPvH</i>	UPvH	Full scale display (V)	-1999~9999	500.0	
<i>Udot</i>	Udot	Decimal point pos. (V)	0-3	1	
<i>FILt</i>	FILt	Digital filtering index	0-3	0	6
<i>End</i>	End	End of setup			

1. Current Input (A-Sn): Input range 5A (-1A-5A), 1A(-0.2-1A). 75mV(shunt value: -15-75mV). Default: 5A
2. Zero current input(APvL): Setup the meter how to display when the input current is "0.0A". It serves as offset adjustment. Default: "0000"
3. Full-scale current display: (APvH): To display value when input current is at max. Resolution varies with this setting.
4. Decimal point position: Can be set arbitrary
5. Voltage Input(V-Sn): Voltage input range 500V (-100-500V);
6. Digital filtering Index: Range: 0,1,2,3 where 0 means no filtering. 1=weak, 2=medium, 3=strong. The higher the index, the more stable of the display but w/ slower refresh 100V(-20100V) rate

Power Alarm Parameters(Press, enter password "0001")


Symbol	Name	Definition	Range	Default	Remark
<i>AH1</i>	AH1	Relay J1 latched	0~9999KW	0200W	7
<i>AL1</i>	AL1	Relay J1 unlatched	0~9999KW	0100W	
<i>AH2</i>	AH2	Relay J2 latched	0~9999KW	0200W	
<i>AL2</i>	AL2	Relay J2 unlatched	0~9999KW	0100W	
<i>End</i>	End	End of setting			

Note:

The position of the decimal point changes automatically when displaying the power. To setup the alarm value or the decimal position Press the decimal point blink, press or to set the value.

The setting of the alarm is similar to the setting of the measurement 7 Alarm/relay(J1,J2) operation AH1 & AH2 are the latched value, where AL1 & AL2 are unlatched value

1. Set AH1=AL1(AH2=AL2), relay disable Set AH1>AL1(AH2>AL2), when measured value 2 AH1, the relay will latch; when AL1 2 measured value, relay unlatched.
2. This is for 'upper limited' configuration. See Fig 1.
3. Set AH1<AL1(AH2<AL2), when AH1 2 measured value, the relay will latch; when measured value 2 AH1, the relay unlatched. This is for the "lower limited" configuration. See Eio




Transmission Output (Press, enter code: 0042)(note: this function does not apply to all models. It's optional)

Symbol	Name	Definition	Range	Default	Remark
<i>o b t y</i>	obty	Output mode	0~20/4~20	4~20	8
<i>o b L</i>	obL	Output(lower)	0~9999KW	0000W	9
<i>o b H</i>	obH	Output(upper)	0~9999KW	0200W	10
<i>E n d</i>	End	End of setting			


1. Table of transmission parameters
2. Procedures of setting up Transmission is similar to the measurement setup
3. Parameters definition: 8 Transmission mode(obty): Output selection either in 0-20mA or 4-20mA
4. Transmission lower limit(obL): output is either in 0mA or 4mA
5. Transmission upper limit(obH): output is 20mA. Resolution varies depends on the obH setting. The smaller value of obH, the
6. lower the resolution is. To set the decimal point, press or for W or KW selection

Setup Procedures:

1. Pressto enter the programming stage
2. Use O to enter the password
3. Use to set value




4. Press to confirm and save



Example: Monitoring a DC motor (Power: 100W; DC24V, <5A or equal Condition requirement

1. when power go over 110W, relay J1 latched to set off alarm
2. Convert 0-100W to 4-20mA for transmission output
3. Power is DC24V To full this requirement, the meter must be equipped with "Transmission output and "relay output" functions. * Never jump short cable between #1 and #6. Doing so the meter will not read properly



Setup

1. Enter password: 0036
Current mode: A-Sn = 5A, Current “zero input” APvL: 0.000;
Current full scale APvH: 5.000; Decimal point dot=3 (0.000-5.000A))
Voltage mode U-Sn: 100V; Voltage “zero input” UpvL= 000.0;
Voltage full scale: UpvH=100.0; Decimal point dot=2 (0.0-100.0V)
2. Enter password: 0001, set alarm
Set current upper limit J1 latched value(AH1)= 110.0W
Set current lower limit J1 unlatched value(AL1) = 109.5W
Set voltage upper limit J2 (AH2) =200W;
Set voltage lower limit J2 (AL2) =200W; (AH2=AL2, disable J2)
3. Enter password: 0042
Set obty=4-20mA, set obl = 0000W, set obH= 0100W

Documents / Resources

Thunderbolt Model JLD40 Model

Thank you for purchasing a JLD40 heater. Here are some useful hints to increase the life span of your heater. Before starting your new heater and while it is running, please observe the following:

- It is strongly recommended for the heater that you high-grade fuel oil and use it through the heater. Instead, it is advised you use #2 fuel oil. If you cannot use #2 fuel oil, please use #1 fuel oil. The heater is designed for #2 fuel oil. If you use a lower grade of fuel oil, your heater will gradually lose its heat.
- Get your water meter checked in 1 to 2 days if you are going to establish a new water line. Your water meter should be set up for your heating pipes. If the meter is programmed to read a rotating clock hand, it will read 0.8 or 0.9. The scale on the meter should be 1.0. If the meter is not set up properly, it will not read the actual amount of water being used. This will cause the water meter to read incorrectly and cause the water bill to be incorrect.
- The water-pumping equipment (water pump, water control valve, etc.) are also checked. The water pump should be set up for your heating pipes. The water pump should be checked to make certain it is working properly. The water pump will be checked through the heater. To make certain, you will need to verify through the water meter and the water pump.
- To avoid a fire hazard, never use oil and water in the heater. The heater is designed for #2 fuel oil. If you use a lower grade of fuel oil, your heater will gradually lose its heat. If you use a lower grade of fuel oil, your heater will gradually lose its heat. If you use a lower grade of fuel oil, your heater will gradually lose its heat.

Please do not touch the heater or any of its components or accessories with your hands and do not touch the heater or any of its components or accessories with your hands.

Thunderbolt's Mission

over 12/2003

THUNDERSTRUCK MOTORS JLD404 Programmable Battery Meter [pdf] User Manual
JLD404, Programmable Battery Meter