


toPARC SAM-1A Gateway PLC or Automated Network Instruction Manual

[Home](#) » [toPARC](#) » toPARC SAM-1A Gateway PLC or Automated Network Instruction Manual 

toPARC SAM-1A Gateway PLC or Automated Network



Contents

1 GENERAL INFORMATION
2 WARNINGS – SAFETY REGULATIONS
2.1 GENERAL ADVICE
2.2 ELECTRICAL SAFETY
2.3 ELECTROSTATIC DAMAGE WARNING
3 PRODUCT OVERVIEW
3.1 INTRODUCTION
4 CONTENTS / SPARE PARTS
4.1 Electronic board support brackets
4.2 Connector support plates:
4.3 Connector cover plate:
5 SETTING UP THE DEVICE
5.1 INSTALLATION
5.2 SWO FEATURE (SAFE WELDING OFF)
6 INPUT/OUTPUT ASSIGNMENTS
6.1 CONNECTOR X20 TECHNICAL SPECIFICATIONS%
6.2 Analogue inputs/outputs
6.3 DIP 2 settings
7 WELDING PROCESSES
8 MAINTENANCE
8.1 DEFECTS LIST
8.2 ELECTRONIC BOARD
8.3 WARRANTY CONDITIONS FRANCE
9 Digital inputs/outputs for NEOPULSE/PULSEMIG machines
10 NEOPULSE/PULSEMIG analogue inputs/outputs
11 Where to find the JOB number?
12 Where to find the synergy values?
13 How to change the management mode to find the min./max. values?
14 The TITAN/TITANIUM'S DIGITAL INPUTS/OUTPUTS
15 The TITAN/TITANIUM'S ANALOGUE INPUTS/OUTPUTS
16 Where to find the JOB number?
17 CUSTOMER SUPPORT
18 Documents / Resources
19 Related Posts

GENERAL INFORMATION

Review	Date	Modification	SAM firmware version
1.0	01/04/2022	Design	1.0
2.0	27/02/2023	Modification	1.0

WARNINGS – SAFETY REGULATIONS

GENERAL ADVICE

This user's manual contains information on the operation of the device and the precautions to be taken for the safety of the user.

Please read it carefully before using the machine for the first time and keep it for future reference.

These instructions must be read and understood before any operation.

Any modification or maintenance not specified in the manual must not be undertaken.

The manufacturer shall not be liable for any damage to persons or property arising from use not in accordance

with the instructions in this manual.

If you have any problems or uncertainties, please consult a qualified person to handle the appliance correctly. This device may only be used for ticket printing and/or data transmission within the limits indicated on the device and in the manual. The safety instructions must be observed. In case of improper or dangerous use, the manufacturer cannot be held responsible.

The device is intended for indoor use. It should not be exposed to rain.

Regulation :

The device complies with the European directives. The declaration of conformity is available on our website (see cover page).

Material conforms to UK requirements. The UK Declaration of Conformity is available on our website (see cover page).

This material is subject to separate collection in accordance with the European Directive 2012/19/EU. Do not dispose of in domestic waste!

A recyclable product that is subject to sorting instructions.

ELECTRICAL SAFETY

When working on the product, be sure to secure the area by not allowing anyone who is not familiar with the safety instructions in this user manual to enter the area. This device should preferably be installed by a professional according to the installation rules in force in the particular country. If this is not possible, it is recommended that you read these rules before proceeding.

ELECTROSTATIC DAMAGE WARNING

Static electricity can damage electronic equipment. Use an earthed, antistatic wrist strap, ankle strap or equivalent safety device to prevent electrostatic discharges (ESD) when installing this product.

Electrostatic damage can irreparably impair the power source and/or the entire product. To protect electronic components from electrostatic damage, place this product on an antistatic surface, such as an antistatic discharge mat, antistatic bag or disposable antistatic mat

PRODUCT OVERVIEW

This document contains information on how to set up and connect the SAM-1A gateway in a PLC or automated network.

The Smart Automation Module (SAM-1A) is a communication tool between compatible GYS welding power sources and programmable logic controllers (PLCs).

A SAM-1A connection converts GYS devices' internal communication language into digital or analogue input/output signals.

The settings can be changed by using pre-loaded JOBS saved in the power source.

The power source/SAM-1A module assembly can be reassigned to a new system without requiring any modifications to the system (integrating it into a new machine, replacing a PLC or automating a process, etc.).

INTRODUCTION


The SAM-1A (PN. 071940) enables additional applications on compatible power sources. The module allows access to parameters of the welding generator for control by the PLC or robot.

The following products are compatible:

MIG/MAG	NEOPULSE 320 C PULSEMIG 320 C	062474 062641
	NEOPULSE 400 CW PULSEMIG 400 CW	062061 062658
	NEOPULSE 400 G PULSEMIG 400 G	014497 062665
	NEOPULSE 500 G PULSEMIG 500 G	014503 062672
TIG	TITAN 400 DC	013520
	TITANIUM 400 AC/DC IMS TITANIUM 400 AC/DC	013568 037830

CONTENTS / SPARE PARTS

- Electronic board E0101C



- Cable bundle 300 mm F0035



- RJ45 cables 300 mm 21574 750 mm 21575




- Connectors 20 points 63851 4 points 53115




Electronic board support brackets

- NEOPULSE 320 C / 400 CW
PULSEMIG 320 C / 400 CW



98129


- NEOPULSE 400 G / 500 G
PULSEMIG 400 G / 500 G



K0539Z


Connector support plates:

- NEOPULSE 320 C / 400 CW
PULSEMIG 320 C / 400 CW
EXAGON 400 FLEX
GENIUS 400 FLEX




K0535GF

- NEOPULSE 400 G / 500 G
PULSEMIG 400 G / 500 G



K0536GF4


- TITAN 400
TITANIUM 400



98116


Connector cover plate:

- NEOPULSE 400 G / 500 G
PULSEMIG 400 G / 500 G



99089GF

- TITAN 400
TITANIUM 400



K0537G


Some configurations do not require all the kit's items.

SETTING UP THE DEVICE

INSTALLATION



WARNING
ELECTRIC SHOCKS CAN BE FATAL



Only experienced personnel authorised by the manufacturer may install the equipment. During installation, ensure that the power source is disconnected from the mains.

Videos on how to set up the kit:

NEOPLUSE 320 C
PULSEMIG 320 C

NEOPULSE 400 CW
PULSEMIG 400 CW

NEOPULSE 400 G / 500 G
PULSEMIG 400 G / 500 G

TITAN 400 DC
TITANIUM 400 AC/DC

Access to internal areas beyond those outlined in this video manual is prohibited and voids the warranty as well as all other forms of support. Indeed, these interventions can be damaging to the power source's internal electronic parts and/or components.

SWO FEATURE (SAFE WELDING OFF)


The «Safe Welding Off» function mainly prevents the current or voltage source from starting. It acts directly on the power source in a very short time.

This function is also used to safely stop the power source in the event of an emergency stop. This avoids a sudden power supply interruption to the power source if a problem arises. It should be remembered that a break in the power supply downstream of a loaded power source is dangerous and can damage the equipment.

1. Electrical safety


The «Safe Welding Off» function does not offer electrical isolation; therefore, before any work is carried out on the power source, it must be electrically isolated by switching off the power supply and locally isolating the power source (padlock procedure).

2. Schematic diagram of how the safety system work



3. Activating the 'Safe Welding Off' (SWO) function (Hard)


A switch (DIP 1), located on the SAM-1A board (see electronic board on page 11), is fitted to the equipment to provide a robust safety feature. Simply switch both switches to ON.



4. SWO (Safe Welding Off) wiring and feedback

If switch 1 (DIP 1) is set to the ON position and switch 2 (DIP 1) to the OFF position, the safety device must be wired.

A dedicated terminal block (X5) is available on the SAM-1A circuit board (see circuit board on page 11).



5. Electrical characteristics of terminal block X5 inputs/outputs

		OUTPUT (feedback)	INPUT
Insulation type		Dry contact	Relay
Connection		3- S13 contact NO 4- S14 Vcc	1- AU_A2 : Earth 2- AU_A2 : VCC
Voltage range		20 – 30 VDC	20 – 30 VDC 15 VDC logic threshold Maximum low voltage at 3 V
Current rating at 24 VDC		Max. 2 A	10 mA
Current rating	response time	8 ms	4 ms
	max. time	16 ms	8 ms
Test pulse train			
< 1 ms at frequencies below 100 Hz		No response	No response


6. Activating the SWO function (Soft)

A switch (DIP 2), located on the SAM-1A board (see page 11), provides the user with a way to set the various SAM-1A board functions. In order to activate the safety feature, switch 3 must be set to ON.

Button Icon

INPUT/OUTPUT ASSIGNMENTS

CONNECTOR X20 TECHNICAL SPECIFICATIONS



Power supply


The inputs/outputs (24 V) can be supplied either internally by the SAM-1A or by an external, 24 V power supply. The SAM-1A is set up for an internal power supply as standard. To use an external power supply, simply switch

the jumper on the three-pin power connector (see electronic board on page 11) and apply 24 V to the X20 connector (pin 10).


Internal power supply		External 24 V power supply	
Rated voltage	Rated current	Maximum voltage	Maximum current
24 V	100 mA	24 V	2 A
		10 V	20 mA

Digital inputs/outputs

Digital inputs



Digital inputs Digital outputs




SAM digital input/output overview and technical data:


	Output	Input
Insulation type	DRY contact 24 VDC 1 – 24 VDC 2 -5 – DO1 – DO4 (NO)	500 VDC isolation photocoupler 6-9 – DI1 – DI4 (NO) 10 – Earth (0 V)
ON Voltage V_{min}/V_{max}	+20 – +30 V	15 – 28 VDC
OFF Voltage V_{min}/V_{max}		0 – 5 VDC
Rated current at +24 V	Max. 2 A	5 mA

Analogue inputs/outputs

Analogue inputs



Analogue outputs



	Output	Input
Voltage	0 – 10 V	0 – 10 V
Current	100 μ A	1 mA

DIP 2 settings

	Description		MIG		TIG	
			JOB	Manual	JOB	CC Tracking
DIP Switch	SWITCH-1	OFF	JOB Mode		JOB Mode	
		ON		Manual Mode		Tracking Mode
	SWITCH-2	ON	Weld_Current			
		OFF	Wire_Speed			
	SWITCH-3	OFF	Safety disabled			
		ON	Safety activated			
	SWITCH-4	OFF	Job Lock		Job Lock	
		ON	Job Unlock		Job Unlock	

WELDING PROCESSES

This chapter contains diagrams of different welding processes.


A) SCHEMATIC DIAGRAM OF THE WELDING CYCLE

Job Mode init




B) SCHEMATIC DIAGRAM OF A WELDING CYCLE IN TRACKING MODE

Tracking Mode TIG




Welding cycle



C) SCHEMATIC DIAGRAM IN CASE OF AN ERROR

Error




MAINTENANCE

Before using the product for the first time, it is recommended to check whether a new software update is available on the GYS after-sales service site (customer code required).



A single update allows the user to update all connected products (power source, remote control, wire-feed reel and SAM, etc).

1. Disconnect all devices from the network.
2. Connect a USB key containing the latest updates to the specific USB port and start the device.



3. The screen comes on if a new software version is detected. Wait until the step is complete and restart the product after having disconnected the USB key.

System Update - V1.02
Please Wait ...
AutoPulse328_Full.egf
Check File Integrity




! Before upgrading, check the changes made by the new firmware update. In the event of a major software update, changes may be required to the PLC's software programming.

DEFECTS LIST

Please refer to the after-sales section of the website www.gys.fr.

ELECTRONIC BOARD



1	X20
2	Power supply
3	DIP 2
4	X5
5	DIP 1

WARRANTY CONDITIONS FRANCE

The warranty covers any defects or manufacturing faults for two years from the date of purchase (parts and labour).

The warranty does not cover:

- Any damage caused by transporting the device.
- The normal wear and tear of the parts (e.g. : cables and clamps, etc.).
- Incidents due to misuse (incorrect wire feeding, dropping or dismantling the machine, etc.).
- Environmental failures (pollution, rust or dust, etc).

In the event of a breakdown, return the appliance to your distributor, enclosing:

- a dated proof of purchase (receipt or invoice, etc.)
- a note explaining the breakdown

Digital inputs/outputs for NEOPULSE/PULSEMIG machines

a) Digital inputs

The SAM-1A has four digital inputs as detailed below:

		Status	
	Pin Connector	0	1
MMI_LOCK	X20-18	Current-Voltage multimeter mode	Accessing the power source settings
Start_Process	X20-19	Stopping the welding process	Starting the welding cycle
Start_Gaz	X20-20	GAS solenoid valve closed	GAS solenoid valve open
Wire_Feed (only in MIG)	X20-16	Wire stopped	Unwinding the wire

b. Digital outputs

As well as the following four digital outputs

		Status	
	Pin Connector	0	1
Error	X20-6	No error	Error detected
Authorised_Start	X20-7	Welding prohibited	Welding permitted
Arc_Detect	X20-14	Arc not detected	Arc detected
Welding_Process	X20-8	No welding in progress	Welding in progress
Main_Current	X20-13	Outside the main welding phase	In the main welding phase

NEOPULSE/PULSEMIG analogue inputs/outputs

a. Analogue outputs

The SAM-1A has two analogue outputs providing voltage- and current-measurement information as follows:
Voltage measurement (M_Weld_Voltage, X20-5): varies from 0 – 10 V and covers a measurement range of 0 – 50 V.
Current measurement (M_Weld_Current, X20-15): varies from 0 – 10 V and covers a measurement range of 0 – 500 A.

b) Analogue input functions

I. JOB mode – Without settings

All parameter settings stored in JOB mode are used (the values of inputs 1, 2 and 3 are, therefore, not taken into account).

DIP2-SWITCH 1 = OFF (Mode: JOB)

DIP2-SWITCH 2 = OFF

DIP2-SWITCH 4= OFF (JOB LOCK)

Button Icon

Table of adjustable values:

SAM-1A input	Pin Connector	Setting	Value
INPUT_1	X20-1	–	–
INPUT_2	X20-2	–	–
INPUT_3	X20-4	–	–
INPUT_4	X20-3	JOB number	between 1 – 20

II. JOB mode – Current settings

The current parameter setting values, Arc_LEN, Self and Weld_Current in JOB mode are disregarded (the values are taken from the SAM-1A inputs).

DIP2-SWITCH 1 = OFF (Mode: JOB)

DIP2-SWITCH 2 = OFF (Management: Current)

DIP2-SWITCH 4 = ON (JOB UNLOCK)

Button Icon

Table of adjustable values:

SAM-1A input	Pin Connector	Setting	Value
INPUT_1	X20-1	ARC_LEN	0 V = -6 5 V = 0 10 V = +6
INPUT_2	X20-2	WELD_CURRENT	0 V = minimum synergy value 10 V = maximum synergy value
INPUT_3	X20-4	SELF	0 V = -4 5 V = 0 10 V = +4
INPUT_4	X20-3	JOB number	between 0 – 20

III. JOB mode – Wire-speed settings

The parameter setting values, Arc_LEN, Self and Wire_Weld_Speed in JOB mode are disregarded (the values are taken from the SAM-1A inputs).

DIP2-SWITCH 1 = OFF (Mode: JOB)

DIP2-SWITCH 2 = ON (Management: Wire speed)

DIP2-SWITCH 4 = ON (JOB UNLOCK)

Button Icon

Table of adjustable values:

SAM-1A input	Pin Connector	Setting	Value
INPUT_1	X20-1	ARC_LEN	0 V = -6 5 V = 0 10 V = +6
INPUT_2	X20-2	WIRE_WELD_SPEED	0 V = minimum synergy value 10 V = maximum synergy value
INPUT_3	X20-4	SELF	0 V = -4 5 V = 0 10 V = +4
INPUT_4	X20-3	JOB number	between 0 – 20

IV. MANUAL Mode

DIP2-SWITCH 1 = ON (Mode: MANUAL)


Button Icon

Table of adjustable values:

SAM-1A input	Pin Connector	Setting	Value
INPUT_1	X20-1	WELD_VOLTAGE	0 V = 0 V 10 V = 50 V
INPUT_2	X20-2	WIRE_WELD_SPEED	0 V = minimum synergy value 10 V = maximum synergy value
INPUT_3	X20-4	CHOKE	0 V = -4 5 V = 0 10 V = +4
INPUT_4	X20-3	–	–


Where to find the JOB number?

On the product's man machine interface (MMI), complete the following steps:





Where to find the synergy values?

From the product's MMI, the MIN. and MAX. synergy values are indicated on the left-hand cursor.



How to change the management mode to find the min./max. values?

From the JOB menu on the product's MMI



The TITAN/TITANIUM'S DIGITAL INPUTS/OUTPUTS

a) Digital inputs

The SAM-1A has four digital inputs as detailed below:

		Status	
	Pin Connector	0	1
MMI_LOCK	X20-18	Current-Voltage multimeter mode	Accessing the power source settings
Start_Process	X20-19	Stopping the welding process	Starting the welding cycle
Start_Gaz	X20-20	GAS solenoid valve closed	GAS solenoid valve open
Wire_Feed (only in MIG)	X20-16	Wire stopped	Unwinding the wire

b) Digital outputs

As well as the following four digital outputs:

		Status	
	Pin Connector	0	1
Error	X20-6	No error	Error detected
Authorised_Start	X20-7	Welding prohibited	Welding permitted
Arc_Detect	X20-14	Arc not detected	Arc detected
Welding_Process	X20-8	No welding in progress	Welding in progress
Main_Current	X20-13	Outside the main welding phase	In the main welding phase

The TITAN/TITANIUM'S ANALOGUE INPUTS/OUTPUTS

a) Analogue outputs

The SAM-1A has two analogue outputs providing voltage- and current-measurement information as follows:

Voltage measurement (M_Weld_Voltage, X20-5): varies from 0 – 10 V and covers a measurement range of 0 – 50 V.

Current measurement (M_Weld_Current, X20-15): varies from 0 – 10 V and covers a measurement range of 0 – 500 A.

b) Analogue input functions

I. JOB mode – Without settings

All parameter settings stored in JOB mode are used (the values of inputs 1, 2 and 3 are, therefore, not taken into account).

DIP2-SWITCH 1 = OFF (Mode: JOB)

DIP2-SWITCH 4 = OFF (JOB LOCK)

Button Icon

Table of adjustable values:

SAM-1A input	Pin Connector	Setting	Value
INPUT_1	X20-1	–	–
INPUT_2	X20-2	–	–
INPUT_3	X20-4	Current type (Titanium only)	<5 V = DC >5 V = AC
INPUT_4	X20-3	JOB number	between 0 – 20

II. JOB mode – SAM-1A settings

The welding current value (JOB mode's Weld_Current parameter) is disregarded (the value is taken from the SAM-1A's input). DIP2-SWITCH 1 = OFF (Mode: JOB)

DIP2-SWITCH 4 = ON (JOB UNLOCK)

Button Icon

Table of adjustable values:

SAM-1A input	Pin Connector	Setting	Value
INPUT_1	X20-1	ARC_LEN	0 V = -6 5 V = 0 10 V = +6
INPUT_2	X20-2	WELD_CURRENT	0 V = minimum power source value 10 V = maximum power source value
INPUT_3	X20-4	Current type (Titanium only)	<5 V = DC >5 V = AC
INPUT_4	X20-3	JOB number	between 0 – 20

III. TRACKING Mode

DIP2-SWITCH 1 = ON (Mode: TRACKING)


Button Icon

Table of adjustable values:

SAM-1A input	Pin Connector	Setting	Value
INPUT_1	X20-1	–	–
INPUT_2	X20-2	WELD_CURRENT	0 V = minimum power source value 10 V = maximum power source value
INPUT_3	X20-4	Current type	DC
INPUT_4	X20-3	Arc_Initiation	< 1 V = HF 1 – 2 V = Lift 2 – 3 V = Touch_HF

Where to find the JOB number?

On the product's man machine interface (MMI), complete the following steps:



CUSTOMER SUPPORT

JBDC
 1, rue de la Croix des Landes
 CS 54159
 53941 SAINT-BERTHEVIN Cedex
 France



Documents / Resources

	<p>toPARC SAM-1A Gateway PLC or Automated Network [pdf] Instruction Manual SAM-1A, Gateway PLC or Automated Network, SAM-1A Gateway PLC or Automated Network, Electronic board E0101C</p>
--	---