

uni SD Reader Troubleshooting Instructions

Home » uni » uni SD Reader Troubleshooting Instructions



Contents

- 1 uni SD Reader Troubleshooting Instructions
- 2 SD Reader Troubleshooting
- 3 1. Can't Read My Cards:
- 4 2. Failed to Transfer Large Files:
- 5 3. My Card Got Stuck/ Slot is Too Tight:
- 6 Can't find Your question?
- 7 Read More About This Manual & Download PDF:
- 8 Documents / Resources
 - 8.1 References
- 9 Related Posts





SD Reader Troubleshooting

1. Can't Read My Cards:

- a. Check if the otg setting is enabled.
- b. Check if the sd card is healthy, or try a different SD card.
- c. Check if the card file format is FAT32/EXFAT instead of NTFS.
- d. Try another phone or laptop.
- e. If you're using an iPad Pro 2018, check if the pic is camera RAW format (e.g.
- *.CR2 for Canon / *.NEF for Nikon) and saved in a folder exact same as the original camera folder.

2. Failed to Transfer Large Files:

- a. Try to format the SD/Micro SD cards to the right format for your devices. (*Back up your files first)
- b. Recommend using MS-DOS(FAT) for 32GB or smaller cards, and EXFAT for 64GB cards

3. My Card Got Stuck/ Slot is Too Tight:


- a. Please make sure to insert the card correctly.
- b. Use a tweezer to remove it first, then try to insert this card to another standard card slot, see if it gets stuck.
- d. If not suck, the spring-loaded mechanism must be fails, please contact us via hello@uniaccessories.io for a free replacement.

Can't find Your question?

We are always here to help: hello@uniaccessories.io www.uniaccessories.io/support

Read More About This Manual & Download PDF:

Documents / Resources



References

- wi uniAccessories American Express Apple Pay Mastercard PayPal Visa
- O Contact us uniAccessories Help Center American Express Apple Pay Mastercard PayPal Visa

Manuals+, home privacy