

unitronics US5-B5-B1 Built-in UniStream User Guide

Home » UNITRONICS » unitronics US5-B5-B1 Built-in UniStream User Guide 1





US5-B5-B1 Built-in UniStream User Guide

Contents

- 1 US5-B5-B1 Built-in
- **UniStream**
- **2 General Features**
- 3 Product Diagram
- **4 Technical Specifications**
- 5 Documents / Resources
 - **5.1 References**
- **6 Related Posts**

US5-B5-B1 Built-in UniStream

UniStream® Built-in

User Guide

US5-B5-B1, US5-B10-B1, US5-B5-TR22, US5-B10-TR22, US5-B5-T24, US5-B10-T24, US5-C5-B1, US5-C10-B1, US5-C5-TR22, US5-C10-TR22, US5-C5-T24, US5-C10-T24

US7-B5-B1, US7-B10-B1, US7-B5-TR22, US7-B10-TR22, US7-B5-T24, US7-B10-T24, US7-C5-B1, US7-C10-B1, US7-C5-TR22, US7-C10-TR22, US7-C5-T24, US7-C10-T24

US10-B5-B1, US10-B10-B1, US10-B5-TR22, US10-B10-TR22, US10-B5-T24, US10-B10-T24, US10-C5-B1, US10-C10-B1, US10-C5-TR22, US10-C10-TR22, US10-C5-T24, US10-C10-T24

This guide provides basic installation information for specific UniStream® models with built-in I/O.

Technical specifications may be downloaded from the Unitronics website.

General Features

Unitronics' UniStream® Built-in series are PLC+HMI All-in-One programmable controllers that comprise a built-in

CPU, an HMI panel, and built-in I/Os.

The series is available in two versions: UniStream Built-in and UniStream Built-in Pro.

Note that a model number that includes:

- B5/C5 refers to UniStream Built-in
- B10/C10 refers to UniStream Built-in Pro. These models offer additional features, detailed below.

НМІ	Resistive Color Touch-screens Rich graphic library for HMI design
Power Features	 Built-in Trends and Gauges, auto-tuned PID, data tables, data sampling, and Recipes UniApps™: Access & edit data, monitor, troubleshoot & debug and more – via HMI or remo tely via VNC Security: Multi-level password protection Alarms: Built-in system, ANSI/ISA standards
I/O Options	 Built-in I/O configuration, varies according to model Local I/O via UAG-CX series I/O expansion adapters and standard UniStream Uni-I/O™ modules Remote I/O using UniStream Remote I/O or via EX-RC1
COM Options	 Built-in ports: 1 Ethernet, 1 USB host, 1 Mini-B USB device port Serial and CANbus ports may be added via UAC-CX modules
COM Protocols	 Fieldbus: CANopen, CAN Layer2, MODBUS, EtherNetIP and more. Implement any serial R S232/485, TCP/IP, or CANbus third-party protocols via Message Composer Advanced: SNMP Agent/Trap, e-mail, SMS, modems, GPRS/GSM, VNC Client, FTP Serve r/Client
Programming S oftware	All-in-One software for hardware configuration, communications, and HMI /PLC applications, available as a free download from Unitronics.

Comparison tabl	Feature	B5/C5	B10/C10 (Pro)
	System Memory	3GB	6GB
	Audio Jack	No	Yes
	Video/RSTP Support	No	Yes
	Web Server	No	Yes
	SQL Client	No	Yes

Before You Begin

Before installing the device, the user must:

- Read and understand this document.
- Verify the Kit Contents.

Alert Symbols and General Restrictions

When any of the following symbols appear, read the associated information carefully.

Symb ol	Meaning	Description
\triangle	Danger	The identified danger causes physical and property damage.
\triangle	Warning	The identified danger could cause physical and property damage.
Cautio n	Caution	Use caution.

- All examples and diagrams are intended to aid understanding, and do not guarantee operation. Unitronics acc epts no responsibility for actual use of this product based on these examples.
- Please dispose of this product according to local and national standards and regulations.
- This product should be installed only by qualified personnel.



- Failure to comply with appropriate safety guidelines can cause severe injury or property damage.
- Do not attempt to use this device with parameters that exceed permissible levels.
- Do not connect/disconnect the device when power is on.

Environmental Considerations

- Ventilation: 10mm space is required between the device top/bottom edges and the enclosure's walls
- Do not install in areas with: excessive or conductive dust, corrosive or flammable gas, moisture or rain, excessive heat, regular impact shocks or excessive vibration, in accordance with the standards and limitations given in the product's technical specification sheet.
- Do not place in water or let water leak onto the unit.
- Do not allow debris to fall inside the unit during installation.
- Install at maximum distance from high-voltage cables and power equipment.

UL Compliance

The following section is relevant to Unitronics' products that are listed with the UL.

The following models are UL listed for Hazardous Locations: US5-B5-B1, US5-B10-B1, US7-B5-B1 and US7-B10-B1

The following models are UL listed for Ordinary Location:

- USL followed by -, followed by 050 or 070 or 101, followed by B05
- US followed by 5 or 7 or 10, followed by -, followed by B5 or B10 or C5 or C10, followed by -, followed by B1 or TR22 or T24 or RA28 or TA30 or R38 or T42

Models from series US5, US7 and US10 that include "T10" or "T5" in the model name are suitable for mounting on the flat surface of Type 4X enclosure. For examples: US7-T10-B1, US7-T5-R38, US5-T10RA22 and US5-T5-T42.

UL Ordinary Location

In order to meet the UL ordinary location standard, panel-mount this device on the flat surface of Type 1 or 4X enclosures

UL Ratings, Programmable Controllers for Use in Hazardous Locations, Class I, Division 2, Groups A, B, C and D

These Release Notes relate to all Unitronics products that bear the UL symbols used to mark products that have been approved for use in hazardous locations, Class I, Division 2, Groups A, B, C and D.

Caution

This equipment is suitable for use in Class I, Division 2, Groups A, B, C and D, or Nonhazardous locations only.



- Input and output wiring must be in accordance with Class I, Division 2 wiring methods and in accordance with the authority having jurisdiction.
- WARNING—Explosion Hazard—substitution of components may impair suitability for Class I, Division 2.
- WARNING EXPLOSION HAZARD Do not connect or disconnect equipment unless power has been switched off or the area is known to be non-hazardous.
- WARNING Exposure to some chemicals may degrade the sealing properties of material used in Relays.
- This equipment must be installed using wiring methods as required for Class I, Division 2 as per the NEC and/or CEC.

Panel-Mounting

For programmable controllers that can be mounted also on panel, in order to meet the UL Haz Loc standard, panel-mount this device on the flat surface of Type 1 or Type 4X enclosures.

Communication and Removable Memory Storage


When products comprise either USB communication port, SD card slot, or both, neither the SD card slot nor the USB port are intended to be permanently connected, while the USB port is intended for programming only.

Removing / Replacing the battery

When a product has been installed with a battery, do not remove or replace the battery unless the power has been switched off, or the area is known to be non-hazardous.

Please note that it is recommended to back up all data retained in RAM, in order to avoid losing data when changing the battery while the power is switched off. Date and time information will also need to be reset after the procedure.

Product Diagram



Front and Rear View

1	Screen Protection	A plastic sheet attached to the screen for protection. Remove it during installation of the HMI Panel.
2	Battery Cover	The battery is supplied with the unit, but must be installed by the user.
3	Power Supply Inpu	Connection point for the controller power source. Connect the Terminal Block supplied with the kit to the end of the power cable.
4	microSD Slot	Supports standard microSD cards.
5	USB Host port	Provides the interface for external USB devices.
6	Ethernet port	Supports high-speed Ethernet communications.
7	USB Device	Use for application download and direct PC-UniStream communication.
8	I/O Expansion Jac k	Connection point for an I/O Expansion Port. Ports are supplied as part of I/O Expansion Model Kits. Kits are available by separate order. Note that UniStream® Built-in is compatible only with adapters from the series UA G-CX.
9	Audio Jack	Pro models only. This 3.5mm Audio jack enables you to connect external audio equipment.
10	Built-in I/O	Model-dependent. Present in models with built-in I/O configurations.
11	Uni-COM™ CX Mo dule Jack	Connection point for up to 3 stack-on modules. These are available by separate ord er.


Installation Space Considerations


Allocate space for:

- the controller
- any modules that will be installed
- access to ports, jacks, and the microSD card slot


For exact dimensions, please refer to the Mechanical Dimensions shown below.

Mechanical Dimensions






UniStream 7"



UniStream 10.1"



NOTE Allow space for modules to be snapped onto the back of the controller, if required by your application. Modules are available by separate order.


Panel Mounting

NOTE

- Mounting panel thickness must be less or equal to 5mm (0.2").
- Ensure that the space considerations are met.
- 1. Prepare a panel cut-out according to the dimensions as shown in the previous section.
- 2. Slide the controller into the cut-out, ensuring that the Panel Mounting Seal is in place as shown below.
- 3. Push the mounting brackets into their slots on the sides of the panel as shown below.
- 4. Tighten the bracket screws against the panel. Hold the brackets securely against the unit while tightening the screws. The torque required is 0.35 N·m (3.1 in-lb).
 - When properly mounted, the panel is squarely situated in the panel cut-out as shown below.

Caution

• Do not apply torque exceeding 0.35 N·m (3.1 in-lb) of torque to tighten the bracket screws. Using excessive force to tighten the screw can damage this product.




Battery: Back-up, First Use, Installation, and Replacement Back-up

In order to preserve back-up values for RTC and system data in the event of power off, the battery must be connected.

First Use


The battery is protected by a removable cover on the side of the controller.

The battery is supplied installed inside the unit, witha plastic tab preventing contact which must be removed by the user.




A Battery Installation and Replacement

- Use proper precautions to prevent Electro-Static Discharge (ESD) while servicing the battery. Caution
- To preserve back-up values for RTC and system data during battery replacement, the controller must be
- Note that disconnecting the battery halts the preservation of back-up values and causes them to be deleted.
- 1. Remove the battery cover from the controller as shown in the accompanying figure:
 - Press the tab on the module to disengage it.
 - Slide it up to remove it.
- 2. If you are replacing the battery, remove the battery from its slot on the side of the controller.
- 3. Insert the battery, ensuring that the polarity is aligned with the polarity marking as shown in the accompanying figure.
- 4. Replace the battery cover.
- 5. Dispose of the used battery according to local and national standards and regulations.



Panel Support Installation

- Insert the Panel Support tabs into their location.
 Note that the exact location varies according to the panel model.
- 2. Pull on the Panel Support until it locks (clicks) into it's place.



Wiring

- This equipment is designed to operate only at SELV/PELV/Class 2/Limited Power environments.
- All power supplies in the system must include double insulation. Power supply outputs must be rated as SELV/PELV/Class 2/Limited Power.
- Do not connect either the 'Neutral' or 'Line' signal of the 110/220VAC to device's 0V point.

- · Do not touch live wires.
- · All wiring activities should be performed while power is OFF.
- Use over-current protection, such as a fuse or circuit breaker, to avoid excessive currents into the power supply connection point.
- Unused points should not be connected (unless otherwise specified). Ignoring this directive may damage the
 device.
- Double-check all wiring before turning on the power supply.

Caution

- To avoid damaging the wire, use a maximum torque of 0.5 N·m (4.4 in-lb).
- Do not use tin, solder, or any substance on stripped wire that might cause the wire strand to break.
- Install at maximum distance from high-voltage cables and power equipment.

Wiring Procedure

Use crimp terminals for wiring; use 26-12 AWG wire (0.13 mm2–3.31 mm2)

- 1. Strip the wire to a length of 7±0.5mm (0.250–0.300 inches).
- 2. Unscrew the terminal to its widest position before inserting a wire.
- 3. Insert the wire completely into the terminal to ensure a proper connection.
- 4. Tighten enough to keep the wire from pulling free.

Wiring Guidelines

In order to ensure that the device will operate properly and to avoid electromagnetic interference:

- Use a metal cabinet. Make sure the cabinet and its doors are properly earthed.
- Use wires that are properly sized for the load.
- Use shielded twisted pair cables for wiring High Speed and Analog I/O signals.
 - In either case, do not use the cable shield as a signal common / return path.
- Route each I/O signal with its own dedicated common wire. Connect common wires at their respective common (CM) points at the controller.
- Individually connect each 0V point and each common (CM) point in the system to the power supply 0V terminal, unless otherwise specified.
- Individually connect each functional ground point () to the earth of the system (preferably to the metal cabinet chassis).
 - Use the shortest and thickest wires possible: less than 1m (3.3') in length, minimum thickness 14 AWG (2 mm²).
- Connect the power supply 0V to the earth of the system.
- Earthing the cables' shield:
- > Connect the cable shield to the earth of the system (preferably to the metal cabinet chassis). Note that the shield must be connected only at one end of the cable; it is recommended to earth the shield at the PLC-side.
- > Keep shield connections as short as possible.
- > Ensure shield continuity when extending shielded cables.

NOTE For detailed information, refer to the document System Wiring Guidelines, located in the Technical Library

in the Unitronics' website.




Wiring the Power Supply

The controller requires an external power supply.

• In the event of voltage fluctuations or non-conformity to voltage power supply specifications, connect the device to a regulated power supply.

Connect the +V and 0V terminals as shown in the accompanying figure.



Connecting Ports

Ethernet	CAT-5e shielded cable with RJ45 connector
• USB Device	Use the proprietary programming cable supplied with the device
• USB Host	Standard USB cable with Type-A plug


Connecting Audio

Audio-Out

Use 3.5mm stereo audio plug with shielded audio cable Note that only Pro models support this feature.

Audio Pinout

1.




Headphone Left Out (Tip)

- 2. Headphone Right Out (Ring)
- 3. Ground (Ring)
- 4. Don't connect (Sleeve)


Note that below, the letters "xx" that is used in the model numbers means that the section refers both to B5/C5 and B10/C10 models.

US5-xx-TR22, US5-xx-T24 US7-xx-TR22, US7-xx-T24 US10-xx-TR22, US10-xx-T24

US5-xx-TR22, US7-xx-TR22, US10-xx-TR22



US5-xx-T24, US7-xx-T24, US10-xx-T24



I/O Connection Points

The IOs for these models are arranged in two groups of fifteen points each, as shown in the figures to the right.

Top group

Input connection points


Bottom group

Output connection points

The function of certain I/Os may be adapted via wiring and software settings.

Wiring the Digital Inputs

All 10 digital inputs share the common point CM0. The digital inputs may be wired together as sink or source.




NOTE Use sink input wiring to connect a sourcing (pnp) device. Use source input wiring to connect a sinking (npn) device.

Wiring the Analog Inputs

Both inputs share the common point CM1.

NOTE

- The inputs are not isolated.
- Each input offers two modes: voltage or current. You can set each input independently.
- The mode is determined by the hardware configuration within the software application.
- Note that if, for example, you wire the input to current, you must also set it to current in the software application.




 To avoid risk of fire or property damage, always use a limited current source or connect a current limiting device in series with the relay contacts

The relay outputs are arranged in two isolated groups:

O0-O3 share the common return CM2.


O4-O7 share the common return CM3.




Increasing Contact Life Span

To increase the life span of the relay contacts and protect the controller from potential damage by reverse EMF, connect:

- a clamping diode in parallel with each inductive DC load,
- a RC snubber circuit in parallel with each inductive AC load




Wiring the Sink Transistor Outputs




- Connect a current limiting device in series with outputs O8 and O9. These outputs are not short-circuit protected.
- Outputs O8 and O9 can independently be configured as either normal digital outputs or as high speed PWM outputs.
- Outputs O8 and O9 share the common point CM4.

Normal Transistor Output

High Speed PWM Output






Wiring the Source Transistor Outputs (US5-xx-T24, US7-xx-T24, US10-xx-T24)

Output's power supply

The use of any of the outputs requires an external 24VDC power supply as shown in the accompanying figure.



Outputs

Connect the +VO and 0VO terminals as shown in the accompanying figure. O0-O11 share common return 0VO.

Installing Uni-I/O™ & Uni-COM™ Modules

Refer to the Installation Guides provided with these modules.

- Turn off system power before connecting or disconnecting any modules or devices.
- Use proper precautions to prevent Electro-Static Discharge (ESD).

Uninstalling the Controller

- 1. Disconnect the power supply.
- 2. Remove all wiring and disconnect any installed devices according to the device's installation guide.
- 3. Unscrew and remove the mounting brackets, taking care to support the device to prevent it from falling during


this procedure.

Technical Specifications

Unitronics' UniStream® Built-in series are PLC+HMI All-in-One programmable controllers that comprise built-in HMI and built-in I/Os.

UniStream connects directly to UniCloud, Unitronics' IIoT cloud platform using built-in UniCloud connectivity. More information about UniCloud is available at www.unitronics.cloud.

Model numbers in this document



Installation Guides are available in the Unitronics Technical Library at www.unitronicsplc.com.

Power Supply		USx-xx-B1	USx-xx-TR22	USx-xx-T24
Input voltage		12VDC or 24VDC	24VDC	24VDC
Permissible ra	ange	10.2VDC to 28.8VDC	20.4VDC to 28.8VDC	20.4VDC to 28.8VDC
Max. current consumptio n	US5	0.7A@12VDC 0.4A@24VDC	0.44A@24VDC	0.4A@24VDC
	US7	0.79A@12VDC 0.49A@24VDC	0.53A@24VDC	0.49A@24VDC
	US10	0.85A@12VDC 0.52A@24VDC	0.56A@24VDC	0.52A@24VDC
Isolation		None		

Display	UniStream 5″	UniStream 7″	UniStream 10.1″
LCD type	TFT		
Backlight type	White LED		
Luminous intensity (b rightness)	Typically 350 nits (cd/m2), at 25°C	Typically 400 nits (cd/m2), at 25°C	Typically 300 nits (cd/m2), at 25°C
Backlight longevity(1)	30k hours		
Resolution (pixels)	800 x 480 (WVGA)		1024 x 600 (WSVGA)
Size	5"	7"	10.1"
Viewing area	Width x Height (mm) 108 x 64.8	Width x Height (mm) 154.0 8 x 85.92	Width x Height (mm) 222.7 2 x 125.28
Color support	65,536 (16bit)		
Surface treatment	Anti-glare		
Touch screen	Resistive Analog		
Actuation force (min)	> 80 g (0.176 lb)		

General	
I/O support	Up to 2,048 I/O points
Built-in I/O	According to model
Local I/O expansion	To add local I/Os, use UAG-CX I/O Expansion Adapters (2). These adapters provide the connection point for standard UniStream Uni-I/O™ modules. You can connect up to 80 I/O modules to a single controller using these adapters.
Remote I/O	Up to 8 UniStream Remote I/O Adapters (URB)
Communication ports	
Built-in COM ports	Specifications are provided below in the section Communications
Add-on Ports	Add up to 3 ports to a single controller using Uni-COM™ UAC-CX Modules (3).

	Standard (B5/C5)	Pro (B10/C10)
Internal memory	RAM: 512MB ROM: 3GB system memory 1GB user me mory	RAM: 1GB ROM: 6GB system memory 2GB user me mory
Ladder memory	1 MB	
External memory	microSD or microSDHC card Size: up to 32GB, Data Speed: up to 200Mbps	
Bit operation	0.13 μs	
Battery	Model: 3V CR2032 Lithium battery (4) Battery lifetime: 4 years typical, at 25°C Battery Low detection and indication (via the HMI and via System Tag).	

Audio (Pro B10/C10 models only)	
Bit Rate	192kbps
Audio compatibility	Stereo MP3 files
Interface	3.5mm Audio-out jack – use shielded audio cable of up to 3 m (9.84 ft)
Impedance	16Ω, 32Ω
Isolation	None

Video (Pro B10/C10 models only)	
Supported Formats	MPEG-4 Visual , AVC/H.264

Communication (Built-in Ports)	
Ethernet port	
Number of ports	1
Port type	10/100 Base-T (RJ45)
Auto crossover	Yes
Auto negotiation	Yes
Isolation voltage	500VAC for 1 minute
Cable	Shielded CAT5e cable, up to 100 m (328 ft)
USB device (5)	
Number of ports	1
Port type	Mini-B
Data rate	USB 2.0 (480Mbps)
Isolation	None
Cable	USB 2.0 compliant; < 3 m (9.84 ft)
USB host	
Number of ports	1
Port type	Type A
Data rate	USB 2.0 (480Mbps)

Isolation	None
Cable	USB 2.0 compliant; < 3 m (9.84 ft)
Over current protecti on	Yes

Digital Inputs	Digital Inputs		
Number of inputs	10		
Туре	Sink or Source		
Isolation voltage			
Input to bus	500VAC for 1 minute		
Input to input	None		
Nominal voltage	24VDC @ 6mA		
Input voltage			
Sink/Source	On state: 15-30VDC, 4mA min. Off state: 0-5VDC, 1mA max.		
Nominal impedance	4κΩ		
Filter	6ms typical		

Analog Inputs							
Number of inputs	2						
	Input Type		Nominal	Nominal Values		Over-rang	e Values *
Input range (6) (7)	0 ÷ 10VDC		0 ≤ Vin ≤	10VDC		10 < Vin ≤	10.15VDC
input range (o) (7)	0 ÷ 20mA		0 ≤ lin ≤ 2	20mA		20 < lin ≤ 2	20.3mA
	* Overflow (8) is declared	d when an	input value ex	ceeds the Ove	er-range bou	ındary.
Absolute maximu m rating	±30V (Voltage	±30V (Voltage), ±30mA (Current)					
Isolation	None	None					
Conversion metho d	Successive approximation						
Resolution	12 bits						
Accuracy (25°C / - 20°C to 55°C)	±0.3% / ±0.9% of full scale						
Input impedance	541kΩ (Voltage), 248Ω (Current)						
Noise rejection	10Hz, 50Hz, 60Hz, 400Hz						
	Smoothing	Noise Re	jection Fr	equency			
		400Hz		60Hz	50Hz		10Hz
Step response (9) (0 to 100% of final value)	None	2.7ms		16.86ms	20.2ms		100.2ms
	Weak	10.2ms		66.86ms	80.2ms		400.2ms
	Medium	20.2ms		133.53ms	160.2ms		800.2ms
	Strong	40.2ms		266.86ms	320.2ms		1600.2ms

	Noise Rejection Frequency	Update Time	
	400Hz	5ms	
Update time (9)	60Hz	4.17ms	
	50Hz	5ms	
	10Hz	10ms	
Operational signal ran ge (signal + common mode)	Voltage mode – Alx: -1V ÷ 10.5V ; CM1: -1V ÷ 0.5V Current mode – Alx: -1V ÷ 5.5V ; C M1: -1V ÷ 0.5V (x=0 or 1)		
Cable	Shielded twisted pair		
Diagnostics (8)	Analog input overflow		

Relay Outputs (USx-xx-TR22)		
Number of outputs	8 (O0 to O7)	
Output type	Relay, SPST-NO (Form A)	
Isolation groups	Two groups of 4 outputs each	
Isolation voltage		
Group to bus	1,500VAC for 1 minute	
Group to group	1,500VAC for 1 minute	
Output to output with in group	None	
Current	2A maximum per output (Resistive load)	
Voltage	250VAC / 30VDC maximum	
Minimum load	1mA, 5VDC	
Switching time	10ms maximum	
Short-circuit protection	None	
Life expectancy (10)	100k operations at maximum load	

Sink Transistor Outputs (USx-xx-TR22)		
Number of outputs	2 (O8 and O9)	
Output type	Transistor, Sink	
Isolation		
Output to bus	1,500VAC for 1 minute	
Output to output	None	
Current	50mA max. per output	
Voltage	Nominal: 24VDC Range: 3.5V to 28.8VDC	
On state voltage dro	1V max	

Off state leakage cur rent	10μA max
Switching times	Turn-on: 1.6ms max.)4kΩ load, 24V) Turn-off: 13.4ms max.)4kΩ load, 24V)
High speed outputs	
PWM Frequency	0.3Hz min. 30kHz max.)4kΩ load(
Cable	Shielded twisted pair

Source Transistor Outputs (USx-xx-T24)		
Number of outputs	12	
Output type	Transistor, Source (pnp)	
Isolation voltage		
Output to bus	500VAC for 1 minute	
Output to output	None	
Outputs power suppl y to bus	500VAC for 1 minute	
Outputs power suppl y to output	None	
Current	0.5A maximum per output	
Voltage	See Source Transistor Outputs Power Supply specification below	
ON state voltage dro	0.5V maximum	
OFF state leakage c urrent	10μA maximum	
Switching times	Turn-on: 80ms maximum, Turn-off: 155ms maximum (Load resistance < 4kΩ(
PWM Frequency (11)	O0, O1: 3kHz max. (Load resistance < 4kΩ)	
Short-circuit protection	Yes	


Source Transistor Outputs Power Supply (USx-xx-T24)		
Nominal operating voltage	24VDC	
Operating voltage	20.4 – 28.8VDC	
Maximum current co nsumption	30mA@24VDC Current consumption does not include load current	


Environmental		
Protection	Front face : IP66, NEMA 4X Rear side: IP20, NEMA1	
Operating temperature	-20°C to 55°C (-4°F to 131°F)	

Storage temperature	-30°C to 70°C (-22°F to 158°F)
Relative Humidity (R H)	5% to 95% (non-condensing)
Operating Altitude	2,000 m (6,562 ft)
Shock	IEC 60068-2-27, 15G, 11ms duration
Vibration	IEC 60068-2-6, 5Hz to 8.4Hz, 3.5mm constant amplitude, 8.4Hz to 150Hz, 1G acceleration

Dimensions		
	Weight	Size
US5-xx-B1	0.31 Kg (0.68 lb)	
US5-xx-TR22	0.37 Kg (0.81 lb)	Refer to the images on page 7
US5-xx-T24	0.35 Kg (0.77 lb)	
US7-xx-B1	0.62 Kg (1.36 lb)	
US7-xx-TR22	0.68 Kg (1.5 lb)	Refer to the images on page 8
US7-xx-T24	0.68 Kg (1.5 lb)	
US10-xx-B1	1.02 Kg (2.25 lb)	
US10-xx-TR22	1.08 Kg (2.38 lb)	Refer to the images on page 8
US10-xx-T24	1.08 Kg (2.38 lb)	

UniStream 5"





Notes:

3.804

7.626

SHILL

1. The HMI panel's backlight longevity is the typical operating time after which the brightness drops to 50% of its original level.

Cut Out drawing

88 111111

[0.340]

8.6

DO HHHHR

SHILL GO SESSEE GO CHILLE

- 2. UAG-CX Expansion Adapter Kits comprise a Base unit, an End unit, and a connecting cable. You plug the Base Unit into the controller's I/O Expansion Jack and connect tandard UniStream UniI/O™ modules. For more information, refer to the product's installation guide and technical specifications.
- 3. Uni-COM[™] CX modules plug directly into the Uni-COM[™] CX Module Jack on the back of the controller. UAC-CX modules may be installed in the following configurations:
 - If a module comprising a serial port is snapped directly into to the back of UniStream, it may be followed only by another serial module, for a total of 2.
 - If your configuration includes a CANbus module, it must be snapped directly to the back of UniStream. The CANbus module may be followed by up to two serial modules, or a total of 3.
 - For more information, refer to the product's installation guide and technical specifications.
- 4. When replacing the unit's battery, make sure that the new one has environmental specifications that are similar or better than the one specified in this document.
- 5. The USB device port is used to connect the device to a PC.
- 6. The 4-20mA input option is implemented using 0-20mA input range.
- 7. The analog inputs measure values that are slightly higher than the nominal input range (Input Over-range). Note that when the input overflow occurs, it is indicated in the corresponding I/O Status tag while the input value is registered as the maximum permissible value. For xample, if the specified input range is 0 ÷ 10V, the Over-range values can reach up to 10.15V, and any input voltage higher than that will still register as 10.15V while the Overflow system tag is turned on.
- 8. The diagnostics results are indicated in the system tags and can be observed through the UniApps[™] or the online state of the UniLogic[™].
- 9. Step response and update time are independent of the number of channels that are used.
- 10. Life expectancy of the relay contacts depends on the application that they are used in. The product's installation guide provides procedures for using the contacts with long cables or with inductive loads.
- 11. Outputs O0 and O1 can be configured as either normal digital outputs or as PWM outputs. PWM outputs specifications apply only when outputs are configured as PWM outputs.

The information in this document reflects products at the date of printing. Unitronics reserves the right, subject to all applicable laws, at any time, at its sole discretion, and without notice, to discontinue or change the features, designs, materials and other specifications of its products, and to either permanently or temporarily withdraw any of the forgoing from the market. All information in this document is provided "as is" without warranty of any kind, either expressed or implied, including but not limited to any implied warranties of merchantability, fitness for a particular purpose, or non-infringement. Unitronics assumes no responsibility for errors or omissions in the information presented in this document. In no event shall Unitronics be liable for any special, incidental, indirect or consequential damages of any kind, or any damages whatsoever arising out of or in connection with the use or performance of this information.

The tradenames, trademarks, logos and service marks presented in this document, including their design, are the property of Unitronics (1989) (R"G) Ltd. or other third parties and you are not permitted to use them without the prior written consent of Unitronics or such third party as may own them.

Documents / Resources



<u>unitronics US5-B5-B1 Built-in UniStream</u> [pdf] User Guide US5-B5-B1 Built-in UniStream, US5-B5-B1, Built-in UniStream, UniStream

References

- ® UniCloud- IIoT Cloud Platform- by Unitronics
- <u>Unitronics- Programmable Logic Controller + Built-in HMI</u>
- <u>Unitronics- Programmable Logic Controller + Built-in HMI</u>

Manuals+,