



Home » UNITRONICS » Unitronics US5-B5-B1 Built In UniStream Programmable Logic Controller User Guide 75

Contents [hide]

- 1 Unitronics US5-B5-B1 Built-In UniStream Programmable Logic Controller
- 2 General Features
- 3 Before You Begin
- 4 UL Ordinary Location
- 5 Kit Contents
- 6 Product Diagram
- 7 Installation Space Considerations
- 8 Mechanical Dimensions
- 9 Panel Mounting
- 10 Battery: Back-up, First Use, Installation, and Replacement
- 11 Wiring
- 12 Technical Specifications
- 13 FAQ
- 14 Documents / Resources
 - 14.1 References



Unitronics US5-B5-B1 Built-In UniStream Programmable Logic Controller



This guide provides basic installation and technical specifications for the UniStream® models listed above.

General Features

- Unitronics' UniStream® Built-in series are PLC+HMI All-in-One programmable controllers that comprise a built-in CPU, an HMI panel, and built-in I/Os.
- The series is available in two versions: UniStream Built-in and UniStream Built-in Pro.

Note that a model number that includes:

- B5/C5 refers to UniStream Built-in
- B10/C10 refers to UniStream Built-in Pro. These models offer additional features, detailed below.

General Features

НМІ	§ Resistive Color Touch-screens § Rich graphic library for HMI design	
Power Features	§ Built-in Trends and Gauges, auto-tuned PID, data tables, data samp ling, and Recipes § UniApps™: Access & edit data, monitor, troubleshoot & debug and more — via HMI or remotely via VNC § Security: Multi-level password protection § Alarms: Built-in system, ANSI/ISA standards	
I/O Options	§ Built-in I/O configuration, varies according to model § Local I/O via UAG-CX series I/O expansion adapters and standard UniStream Uni-I/O™ modules § Remote I/O using UniStream Remote I/O or via EX-RC1 § US15 only – Integrate I/O into your system by using UAG-BACK-IO ADP, snap onto the panel for an all- in-one configuration	
COM Options	 § Built-in ports: 1 Ethernet, 1 USB host, 1 Mini-B USB device port (US B-C in US15) § Serial and CANbus ports may be added via UAC-CX modules 	
COM Protocols	§ Fieldbus: CANopen, CAN Layer2, MODBUS, EtherCAT (US15 models only), EtherNetIP and more. Implement any serial RS232/485, TCP/IP, or CANbus third-party protocols via Message Composer § Advanced: SNMP Agent/Trap, e-mail, SMS, modems, GPRS/GSM, VNC Client, FTP Server/Client, MQTT, REST API, Telegram, etc.	

Programmin	All-in-One software for hardware configuration, communications, and			
g Software	HMI /PLC applications, available as a free download from Unitronics.			
Comparison table	Feature B5/C5 B10/C10 (Pro)			
	System Memory 3GB 6GB			
	Audio Jack No Yes		Yes	
	Video/RSTP Suppor t	No	Yes	
	Web Server	No	Yes	
	SQL Client	No	Yes	

Before You Begin

Before installing the device, the user must:

Read and understand this document.

- Verify the Kit contents.
- Alert Symbols and General Restrictions

When any of the following symbols appear, read the associated information carefully.

Sy mb ol	Meaning	Description
À	Danger	The identified danger causes physical and property damage.
À	Warning	The identified danger could cause physical and property dam age.

Ca		
uti	Caution	Use caution.
on		

- All examples and diagrams are provided to assist with understanding and do not guarantee operation. Unitronics accepts no responsibility for the actual use of this product based on these examples.
- Please dispose of this product according to local and national standards and regulations.
- This product should be installed only by qualified personnel.
- If the equipment is used in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired.
- Failure to comply with appropriate safety guidelines can cause severe injury or property damage.
- Do not attempt to use this device with parameters that exceed permissible levels.
- Do not connect/disconnect the device when power is on.

Environmental Considerations

- Ventilation: 10mm space is required between the device top/bottom edges and the enclosure's walls
- Do not install in areas with excessive or conductive dust, corrosive or flammable gas, moisture or rain, excessive heat, frequent impact shocks or excessive vibration, in accordance with the standards and limitations given in the product's technical specification sheet.
- Do not submerge the unit in water or allow water to leak onto it.
- Do not allow debris to fall inside the unit during installation.
- Install the unit as far as possible from high-voltage cables and power equipment.

UL Compliance

- The following section is relevant to Unitronics' products that are listed with the UL.
- The following models are UL listed for Hazardous Locations: US5-B5-B1, US5-B10-B1, US7-B5-B1 and US7-B10-B1

The following models are UL listed for Ordinary Location:

- USL followed by -, followed by 050 or 070 or 101, followed by B05
- US followed by 5 or 7 or 10, followed by -, followed by B5 or B10 or C5 or C10, followed by -, followed by B1 or TR22 or T24 or RA28 or TA30 or R38 or T42

Models from series US5, US7 and US10 that include "T10" or "T5" in the model name are suitable for mounting on the flat surface of Type 4X enclosure. For examples: US7-T10-B1, US7-T5-R38, US5-T10-RA22 and US5-T5-T42.

UL Ordinary Location

In order to meet the UL ordinary location standard, panel-mount this device on the flat surface of Type 1 or 4X enclosures

UL Ratings, Programmable Controllers for Use in Hazardous Locations, Class I, Division 2, Groups A, B, C and D

These Release Notes relate to all Unitronics products that bear the UL symbols used to mark products that have been approved for use in hazardous locations, Class I, Division 2, Groups A, B, C and D.

Caution: This equipment is suitable for use in Class I, Division 2, Groups A, B, C and D, or Non-hazardous locations only.

- Input and output wiring must be in accordance with Class I, Division 2 wiring methods and in accordance with the authority having jurisdiction.
- WARNING—Explosion Hazard—substitution of components may impair suitability for Class I, Division 2.
- WARNING EXPLOSION HAZARD Do not connect or disconnect equipment unless power has been switched off or the area is known to be non-hazardous.
- WARNING Exposure to some chemicals may degrade the sealing properties of material used in Relays.
- This equipment must be installed using wiring methods as required for Class I,
 Division 2 as per the NEC and/or CEC.

Panel-Mounting

For programmable controllers that can be mounted also on panel, in order to meet the UL Haz Loc standard, panel-mount this device on the flat surface of Type 1 or Type 4X enclosures.

Communication and Removable Memory Storage

When products comprise either USB communication port, SD card slot, or both, neither the SD card slot nor the USB port are intended to be permanently connected, while the USB port is intended for programming only.


Removing / Replacing the battery

When a product has been installed with a battery, do not remove or replace the battery unless the power has been switched off, or the area is known to be non-hazardous. Please note that it is recommended to back up all data retained in RAM, in order to avoid losing data when changing the battery while the power is switched off. Date and time information will also need to be reset after the procedure.

Kit Contents

- 1 PLC+HMI controller
- 4,8,10 mounting brackets (US5/US7, US10, US15)
- 1 panel mounting seal
- 2 panel supports (US7/US10/US15 only)
- 1 power terminal block
- 2 I/O terminal blocks (provided only with models comprising built-in I/Os)
- 1 Battery

Product Diagram



Front and Rear View

1	Screen Protection	A plastic sheet attached to the screen for protection. Remove it during installation of the HMI Panel.
2	Battery Cover	The battery is supplied with the unit but must be installed by the user.
3	Power Supply Input	Connection point for the controller power source. Connect the Terminal Block supplied with the kit to the end of the power cable.
4	MicroSD Slot	Supports standard microSD cards.
5	USB Host Por	Provides the interface for external USB devices.
6	Ethernet Port	Supports high-speed Ethernet communications.

7	USB Device	Use for application download and direct PC-UniStream commun ication.
8	I/O Expansion Jack	Connection point for an I/O Expansion Port. Ports are supplied as part of I/O Expansion Model Kits. Kits are available by separate order. Note that UniStream® Built-in is compatible only with adapters from the series UAG-CX.
9	Audio Jack	Pro models only. This 3.5mm Audio Jack enables you to connec t external audio equipment.
10	Built-in I/O	Model-dependent. Present in models with built-in I/O configurations.
11	Uni-COM™ C X Module Jac k	Connection point for up to 3 stack-COM modules. These are av ailable by separate order.
12	UAG-BACK-I OADP Adapter Jack	Connection point to UAG-BACK-IO-ADP Jack. Adapter is availa ble by separate order.

Installation Space Considerations


Allocate space for:

- the controller
- any modules that will be installed
- access to ports, jacks, and the microSD card slot


For exact dimensions, please refer to the Mechanical Dimensions shown below.


Mechanical Dimensions

UniStream 5"



UniStream 7"





NOTE

Allow space for modules to be snapped onto the back of the controller, if required by your application. Modules are available by separate order.

Panel Mounting

NOTE


- Mounting panel thickness must be less or equal to 5mm (0.2").
- Ensure that the space considerations are met.
- 1. Prepare a panel cut-out according to the dimensions as shown in the previous section.
- 2. Slide the controller into the cut-out, ensuring that the Panel Mounting Seal is in place as shown below.
- 3. Push the mounting brackets into their slots on the sides of the panel as shown below.
- 4. Tighten the bracket screws against the panel. Hold the brackets securely against the unit while tightening the screws. The torque required is 0.6 N·m (5 in-lb).

When properly mounted, the panel is squarely situated in the panel cut-out as shown below.


Caution: Do not apply torque exceeding 0.6 N·m (5 in-lb) of torque to tighten the bracket screws. Using excessive force to tighten the screw can damage this product.


UniStream 5"







UniStream 7"






UniStream 10.1"





UniStream 15.6"



Battery: Back-up, First Use, Installation, and Replacement


Back-up

In order to preserve back-up values for RTC and system data in the event of power off, the battery must be connected.

First Use

- The battery is protected by a removable cover on the side of the controller.
- The battery comes pre-installed inside the unit with a plastic tab preventing contact.

 This tab must be removed by the user before use.




Battery Installation and Replacement

Use proper precautions to prevent Electro-Static Discharge (ESD) while servicing the battery.

Caution

- To preserve back-up values for RTC and system data during battery replacement, the controller must be powered.
- Note that disconnecting the battery halts the preservation of back-up values and causes them to be deleted.
- 1. Remove the battery cover from the controller as shown in the accompanying figure:
 - Press the tab on the module to disengage it.
 - Slide it up to remove it.
- 2. If you are replacing the battery, remove the battery from its slot on the side of the controller.
- 3. Insert the battery, ensuring that the polarity is aligned with the polarity marking as shown in the accompanying figure.
- 4. Replace the battery cover.
- 5. Dispose of the used battery according to local and national standards and regulations.



Wiring

 This equipment is designed to operate only at SELV/PELV/Class 2/Limited Power environments.

- All power supplies in the system must include double insulation. Power supply outputs must be rated as SELV/PELV/Class 2/Limited Power.
- Do not connect either the 'Neutral' or 'Line' signal of the 110/220VAC to device's 0V point.
- Do not touch live wires.
- All wiring activities should be performed while power is OFF.
- Use over-current protection, such as a fuse or circuit breaker, to avoid excessive currents into the power supply connection point.
- Unused points should not be connected (unless otherwise specified). Ignoring this
 directive may damage the device.
- Double-check all wiring before turning on the power supply.

Caution

- Do not use tin, solder, or any substance on stripped wire that might cause the wire strand to break.
- Wire and cable should have a temperature rating of minimum 75°C.
- Install at maximum distance from high-voltage cables and power equipment.

Wiring Procedure

Use crimp terminals for wiring; use 26-12 AWG wire (0.13 mm2 –3.31 mm2)

- 1. Strip the wire to a length of 7±0.5mm (0.250–0.300 inches).
- 2. Unscrew the terminal to its widest position before inserting a wire.
- 3. Insert the wire completely into the terminal to ensure a proper connection.
- 4. Tighten enough to keep the wire from pulling free.

Wiring Guidelines

In order to ensure that the device will operate properly and to avoid electromagnetic interference:

- Use a metal cabinet. Make sure the cabinet and its doors are properly earthed.
- Use wires that are properly sized for the load.
- Use shielded twisted pair cables for wiring High Speed and Analog I/O signals.
- In either case, do not use the cable shield as a signal common / return path.

- Route each I/O signal with its own dedicated common wire. Connect common wires at their respective common (CM) points at the controller.
- Individually connect each 0V point and each common (CM) point in the system to the power supply 0V terminal, unless otherwise specified.
- Individually connect each functional ground point () to the earth of the system (preferably to the metal cabinet chassis). Use the shortest and thickest wires possible: less than 1m (3.3') in length, minimum thickness 14 AWG (2 mm2).
- Connect the power supply 0V to the earth of the system.


• Earthing the cables' shield:

- Connect the cable shield to the earth of the system (preferably to the metal cabinet chassis). Note that the shield must be connected only at one end of the cable; it is recommended to earth the shield at the PLC-side.
- Keep shield connections as short as possible.
- Ensure shield continuity when extending shielded cables.

Wiring the Power Supply

The controller requires an external power supply.

In the event of voltage fluctuations or non-conformity to voltage power supply specifications, connect the device to a regulated power supply. Connect the +V and 0V terminals as shown in the accompanying figure.



Connecting Ports

Ethernet

CAT-5e shielded cable with RJ45 connector

USB Device

Standard USB cable with Mini-B USB plug (USC-C plug in US15)

USB Host

Standard USB device with Type-A plug


Connecting Audio

Audio-Out

Use a 3.5mm stereo audio plug with shielded audio cable. Note that only Pro models support this feature.

Audio Pinout

- 1. Headphone Left Out (Tip)
- 2. Headphone Right Out (Ring
- 3. Ground (Ring
- 4. Don't connect (Sleeve)



Note that the letters "xx" in the model numbers indicate that the section applies to both B5/C5 and B10/C10 models.

- US5 -xx-TR22, US5-xx-T24 US7-xx-TR22, US7-xx-T24
- US10 -xx-TR22, US10-xx-T24 I/O Connection Points

The IOs for these models are arranged in two groups of fifteen points each, as shown in the figures to the right.

Top group


Input connection points

• Bottom group


Output connection points

The function of certain I/Os may be adapted via wiring and software settings.

US5-xx-TR22, US7-xx-TR22, US10-xx-TR22





US5-xx-T24, US7-xx-T24, US10-xx-T24



Wiring the Digital Inputs

All 10 digital inputs share the common point CM0. The digital inputs may be wired together as sink or source.





NOTE

Use sink input wiring to connect a sourcing (pnp) device. Use source input wiring to connect a sinking (npn) device.


Wiring the Analog Inputs

Both inputs share the common point CM1.


NOTE

- The inputs are not isolated.
- Each input offers two modes: voltage or current. You can set each input independently.

- The mode is determined by the hardware configuration within the software application.
- Note that if, for example, you wire the input to current, you must also set it to current in the software application.



4-wire




Wiring the Relay Outputs (US5 -xx-TR22, US7-xx-TR22, US10-xx-TR22)

To avoid risk of fire or property damage, always use a limited current source or connect a current limiting device in series with the relay contacts

The relay outputs are arranged in two isolated groups:

- O0-O3 share the common return CM2.
- O4-O7 share the common return CM3.




Increasing Contact Life Span


To increase the life span of the relay contacts and protect the controller from potential damage by reverse EMF, connect:

- a clamping diode in parallel with each inductive DC load,
- a RC snubber circuit in parallel with each inductive AC load

DC Load




AC Load




Wiring the Sink Transistor Outputs (US5-xx-TR22, US7-xx-TR22, US10-xx-TR22)

- Connect a current limiting device in series with outputs O8 and O9. These outputs are not short-circuited protected.
- Outputs O8 and O9 can independently be configured as either normal digital outputs or as high speed PWM outputs.
- Outputs O8 and O9 share the common point CM4.

Normal Transistor Output



High Speed PWM Output




Wiring the Source Transistor Outputs (US5-xx-T24, US7-xx-T24, US10-xx-T24)

• Output's power supply

The use of any of the outputs requires an external 24VDC power supply as shown in the accompanying figure.

Outputs

Connect the +VO and 0VO terminals as shown in the accompanying figure. O0-O11 share common return 0VO.



Installing Uni-I/O™ & Uni-COM™ Modules

Refer to the Installation Guides provided with these modules.

- Turn off system power before connecting or disconnecting any modules or devices.
- Use proper precautions to prevent Electro-Static Discharge (ESD).

Uninstalling the Controller


- 1. Disconnect the power supply.
- 2. Remove all wiring and disconnect any installed devices according to the device's installation guide.
- 3. Unscrew and remove the mounting brackets, taking care to support the device to prevent it from falling during this procedure.
 - The information in this document reflects products at the date of printing. Unitronics
 reserves the right, subject to all applicable laws, at any time, at its sole discretion, and
 without notice, to discontinue or change the features, designs, materials and other
 specifications of its products, and to either permanently or temporarily withdraw any of
 the forgoing from the market.
 - All information in this document is provided "as is" without warranty of any kind, either expressed or implied, including but not limited to any implied warranties of merchantability, fitness for a particular purpose, or non-infringement. Unitronics assumes no responsibility for errors or omissions in the information presented in this document. In no event shall Unitronics be liable for any special, incidental, indirect or consequential damages of any kind, or any damages whatsoever arising out of or in connection with the use or performance of this information.
 - The tradenames, trademarks, logos and service marks presented in this document, including their design, are the property of Unitronics (1989) (R"G) Ltd. or other third

parties and you are not permitted to use them without the prior written consent of Unitronics or such third party as may own them

Technical Specifications

- Unitronics' UniStream® Built-in series are PLC+HMI All-in-One programmable controllers.
- UniStream connects directly to UniCloud, Unitronics' IIoT cloud platform using built-in UniCloud connectivity. More information about UniCloud is available at www.unitronics.cloud.

Model numbers in this document



- No built-in I/Os
- 10 x Digital inputs, 24VDC, sink/source
- 2 x Analog inputs, 0÷10V / 0÷20mA, 12 bits
- 2 x Transistor outputs, npn, including 2 High speed PWM output channels
- 8 x Relay outputs
- 10 x Digital inputs, 24VDC, sink/source

- 2 x Analog inputs, 0÷10V / 0÷20mA, 12 bits
- 12 x Transistor outputs, pnp, including 2 PWM output channels

Standard

Pro, offers additional features, detailed below

With UniCloud enabled functionality

With built-in 5 years UniCloud start-up subscription with no additional payment required for this period.

- 5" 800×480 (WVGA) display
- 7" 800×480 (WVGA) display
- 10.1" 1024×600 (WSVGA) display
- 15.6" 1366 x 768 (HD) display

Installation Guides are available in the Unitronics Technical Library at www.unitronicsplc.com.

Power Supply		USx-xx-B1	USx-xx-TR22	USx-xx-T24
Input volta	ge	12VDC or 24VDC	24VDC	24VDC
Permissible rang		10.2VDC to 28.8VD	20.4VDC to 28.8VD	20.4VDC to 28.8VD
	US5	0.7A@12VDC 0.4A@24VDC	0.44A@24VDC	0.4A@24VDC
Max. current consump tion	US7	0.79A@12VDC 0.49A@24VDC	0.53A@24VDC	0.49A@24VDC
	US1 0	0.85A@12VDC 0.52A@24VDC	0.56A@24VDC	0.52A@24VDC

	US1 5	2.2A@12VDC 1.1A@24VDC	None	None
Isolation		None		

Display	UniStream 5″	UniStream 7"	UniStream 10.	UniStream 15.6"
LCD type	TFT			
Backlight ty	White LED			
Luminous i ntensity (br ightness)	Typically 350 ni ts (cd/m2), at 2 5°C	Typically 400 n its (cd/m2), at 25°C	Typically 300 ni ts (cd/m2), at 2 5°C	Typically 400 nits (cd/m2), at 25°C
Backlight lo ngevity	30k hours			
Resolution (pixels)	800 x 480 (WVGA)		1024 x 600 (W SVGA)	1366 x 768 (HD)
Size	5"	7"	10.1″	15.6"
Viewing ar ea	Width x Height (mm) 108 x 64.	Width x Height (mm) 154.08 x 85.92	Width x Height (mm) 222.72 x 125.28	Width x Height (m m) 344.23 x 193.5
Color supp ort	65,536 (16bit)			16M (24bit)

Surface tre atment	Anti-glare
Touch scre	Resistive Analog
Actuation f orce (min)	> 80 g (0.176 lb)

General		
I/O support	Up to 2,048 I/O points	
Built-in I/O	According to model	
Local I/O expans ion	To add local I/Os, use UAG-CX I/O Expansion Adapters. These ad apters provide the connection point for standard UniStream Uni-I/O ™ modules. You can connect up to 80 I/O modules to a single controller using t hese adapters. US15 only − Integrate I/O into your system by using UAG-BACK-IO ADP adapter, snap onto the panel for an all-in-one configuration.	
Remote I/O	Up to 8 UniStream Remote I/O Adapters (URB)	

Communication Ports		
Built-in COM por ts Specifications are provided below in the section Communications		
Add-on Ports	Add up to 3 ports to a single controller using Uni-COM™ UAC-CX Modules	

	Standard (B5/C5)	Pro (B10/C10)	
Internal memory	RAM: 512MB	RAM: 1GB	
	ROM: 3GB system memory 1G B user memory	ROM: 6GB system memory 2G B user memory	
Ladder memory	1 MB		
External memor	microSD or microSDHC card Size: up to 32GB, Data Speed: up to 200Mbps		
Bit operation	0.13 μs		
Battery	Model: 3V CR2032 Lithium battery Battery lifetime: 4 years typical, at 25°C Battery Low detection and indication (via the HMI and via System Tag).		

Audio (Pro B10/C10 models only)		
Bit Rate	192kbps	
Audio compatibility	Stereo MP3 files	
Interface	3.5mm Audio-out jack – use shielded audio cable of up to 3 m (9.84 ft)	
Impedance	16Ω, 32Ω	
Isolation	None	

Video (Pro B10/C10 models only)

Communication (Built-in Ports)	US5, US7, US10	US15
Ethernet port		
Number of ports	1	2
Port type	10/100 Base-T (RJ45)	
Auto crossover	Yes	
Auto negotiation	Yes	
Isolation voltage	500VAC for 1 minute	
Cable	Shielded CAT5e cable, up to 100 m (328 ft)	
USB device		
Port type	Mini-B	USB-C
Data rate	USB 2.0 (480Mbps)	
Isolation	None	
Cable	USB 2.0 compliant; < 3 m (9.84 ft)	
USB host		
Over current protection	Yes	

Digital Inputs (T24, TR22 models)	
Number of input	10

Туре	Sink or Source
Isolation voltag	
Input to bus	500VAC for 1 minute
Input to input	None
Nominal voltage	24VDC @ 6mA
Input voltage	
Sink/Source	On state: 15-30VDC, 4mA min. Off state: 0-5VDC, 1mA max.
Nominal imped ance	4kΩ
Filter	6ms typical

Analog Inputs (T24, TR22 models)			
2			
Input Type	Nominal Values	Over-range Value s *	
0 ÷ 10VDC	0 ≤ Vin ≤ 10VDC	10 < Vin ≤ 10.15V DC	
0 ÷ 20mA	0 ≤ lin ≤ 20mA	20 < lin ≤ 20.3mA	
* Overflow (7) is declared when an input value exceeds the Over-ran ge boundary.			
	Input Type 0 ÷ 10VDC 0 ÷ 20mA * Overflow (7) is defined to the second control of the	Input Type Nominal Values 0 ÷ 10VDC 0 ≤ Vin ≤ 10VDC 0 ÷ 20mA 0 ≤ lin ≤ 20mA * Overflow (7) is declared when an input value ex	

Absolute maximum rati ng	±30V (Voltage), ±30mA (Current)				
Isolation	None				
Conversion method	Successive	Successive approximation			
Resolution	12 bits				
Accuracy (25°C / -20°C to 55°C)	±0.3% / ±0.9% of full scale				
Input impeda	541kΩ (Voltage), 248Ω (Current)				
Noise rejectio	10Hz, 50Hz, 60Hz, 400Hz				
	Smoothi ng Noise Rejection Frequency				
Step respons		400Hz	60Hz	50Hz	10Hz
e (8)	None	2.7ms	16.86ms	20.2ms	100.2ms
(0 to 100% of final value)	Weak	10.2ms	66.86ms	80.2ms	400.2ms
ina value)	Medium	20.2ms	133.53ms	160.2ms	800.2ms
	Strong	40.2ms	266.86ms	320.2ms	1600.2m s

	Noise Rejection Frequenc	Update Time
	400Hz	5ms
Update time (8)	60Hz	4.17ms
	50Hz	5ms
	10Hz	10ms
Operational sign al range (signal + common mod e)	Voltage mode — Alx: -1V ÷ 10.5V ; CM1: -1V ÷ 0.5V Current mode — Alx: -1V ÷ 5.5V ; CM1: -1V ÷ 0.5V (x=0 or 1)	
Cable	Shielded twisted pair	
Diagnostics (7)	Analog input overflow	

Relay Outputs (USx-xx-TR22)	
Number of outp	8 (O0 to O7)
Output type	Relay, SPST-NO (Form A)
Isolation groups	Two groups of 4 outputs each
Isolation voltag	
Group to bus	1,500VAC for 1 minute
Group to group	1,500VAC for 1 minute
Output to output within group	None

Current	2A maximum per output (Resistive load)
Voltage	250VAC / 30VDC maximum
Minimum load	1mA, 5VDC
Switching time	10ms maximum
Short-circuit protection	None
Life expectancy (9)	100k operations at maximum load

Sink Transistor Outputs (USx-xx-TR22)		
Number of outp	2 (O8 and O9)	
Output type	Transistor, Sink	
Isolation		
Output to bus	1,500VAC for 1 minute	
Output to outpu	None	
Current	50mA max. per output	
Voltage	Nominal: 24VDC Range: 3.5V to 28.8VDC	
On state voltag	1V max	

Off state leakag e current	10μA max
Switching times	Turn-on: 1.6ms max.)4k Ω load, 24V) Turn-off: 13.4ms max.)4k Ω load, 24V)
High speed out puts	
PWM Frequenc	0.3Hz min. 30kHz max.)4kΩ load(
Cable	Shielded twisted pair

Source Transistor Outputs (USx-xx-T24)	
Number of outp	12
Output type	Transistor, Source (pnp)
Isolation voltag	
Output to bus	500VAC for 1 minute
Output to outpu	None
Outputs power supply to bus	500VAC for 1 minute
Outputs power supply to output	None

Current	0.5A maximum per output
Voltage	See Source Transistor Outputs Power Supply specification below
ON state voltag e drop	0.5V maximum
OFF state leakage current	10μA maximum
Switching times	Turn-on: 80ms maximum, Turn-off: 155ms maximum $(\mbox{Load resistance} < 4 \mbox{k} \Omega ($
PWM Frequenc y (10)	O0, O1: 3kHz max. (Load resistance < 4kΩ)
Short-circuit protection	Yes

Source Transistor Outputs Power Supply (USx-xx-T24)	
Nominal operating voltage	24VDC
Operating volta	20.4 – 28.8VDC
Maximum curre nt consumption	30mA@24VDC Current consumption does not include load current

Environmental	US5, US7, US10	US15
Protection	Front face: IP66, NEMA 4X Rear side: IP20, NEMA1	

Operating temp erature	-20°C to 55°C (-4°F to 131°F)	0°C to 50°C (32°F to 122°F)
Storage temper ature	-30°C to 70°C (-22°F to 158° F)	-20°C to 60°C (-4°F to 140°F)
Relative Humidi ty (RH)	5% to 95% (non-condensing)	
Operating Altitu	2,000 m (6,562 ft)	
Shock	IEC 60068-2-27, 15G, 11ms duration	
Vibration	IEC 60068-2-6, 5Hz to 8.4Hz, 3.5mm constant amplitude, 8.4Hz to 150Hz, 1G acceleration	

Dimensions	Weight	Size
US5-xx-B1	0.31 Kg (0.68 lb)	
US5-xx-TR22	0.37 Kg (0.81 lb)	Refer to the images on page 7
US5-xx-T24	0.35 Kg (0.77 lb)	
US7-xx-B1	0.62 Kg (1.36 lb)	
US7-xx-TR22	0.68 Kg (1.5 lb)	Refer to the images on page 8
US7-xx-T24	0.68 Kg (1.5 lb)	
US10-xx-B1	1.02 Kg (2.25 lb)	
US10-xx-TR22	1.08 Kg (2.38 lb)	Refer to the images on page 8
US10-xx-T24	1.08 Kg (2.38 lb)	
US15-xx-B1	2.68Kg (5.9 lb)	Refer to the images on page 9

Notes:

- 1. The typical backlight lifespan of the HMI panel is the time after which its brightness decreases to 50% of its original level.
- 2. UAG-CX Expansion Adapter Kits consist of a Base unit, an End unit, and a connecting cable. The Base Unit connects to the controller's I/O Expansion Jack and allows for the connection of standard UniStream Uni-I/O™ modules. For more details, refer to the product's installation guide and technical specifications.
- 3. Uni-COM™ CX modules are plugged directly into the Uni-COM™ CX Module Jack on the back of the controller. UAC-CX modules can be installed in the following configurations:
 - 1. If a serial port module is attached directly to the back of UniStream, it can only be followed by another serial module, for a total of two modules.
 - 2. If the configuration includes a CANbus module, it must be connected directly to the back of UniStream and can be followed by up to two serial modules, for a total of three modules. For additional information, refer to the product's installation guide and technical specifications.
- 4. When replacing the unit's battery, ensure that the new battery meets or exceeds the environmental specifications outlined in this document.
- 5. The USB device port is used to connect the device to a PC.
- 6. The 4-20mA input option is implemented using the 0-20mA input range. The analog inputs measure values slightly above the nominal input range (Input Over-range). When an input overflow occurs, the corresponding I/O Status tag indicates this, while the input value is recorded as the maximum allowable value. For example, if the input range is 0 to 10V, Over-range values can reach up to 10.15V, and any input voltage above that will still register as 10.15V, with the Overflow system tag activated.
- 7. Diagnostic results are displayed in system tags and can be viewed through UniApps™ or the online state of UniLogic™.
- 8. Step response and update time are independent of the number of channels that are used.
- The life expectancy of relay contacts varies depending on the application. The
 product's installation guide provides guidelines for using the contacts with long cables
 or inductive loads.
- 10. Outputs O0 and O1 can be configured as either standard digital outputs or as PWM

outputs. PWM outputs specifications apply only when outputs are configured as PWM outputs.

- The information in this document reflects products at the date of printing. Unitronics
 reserves the right, subject to all applicable laws, at any time, at its sole discretion, and
 without notice, to discontinue or change the features, designs, materials and other
 specifications of its products, and to either permanently or temporarily withdraw any of
 the forgoing from the market.
- All information in this document is provided "as is" without warranty of any kind, either expressed or implied, including but not limited to any implied warranties of merchantability, fitness for a particular purpose, or non-infringement. Unitronics assumes no responsibility for errors or omissions in the information presented in this document. In no event shall Unitronics be liable for any special, incidental, indirect or consequential damages of any kind, or any damages whatsoever arising out of or in connection with the use or performance of this information.
- The tradenames, trademarks, logos and service marks presented in this document, including their design, are the property of Unitronics (1989) (R"G) Ltd. or other third parties and you are not permitted to use them without the prior written consent of Unitronics or such third party as may own them.

FAQ

Q: Can I install the unit in an area with high humidity?

A: It is not recommended to install the unit in areas with excessive moisture. Ensure to follow the specified environmental considerations.

Q: What programming software is compatible with the device?

A: The device is compatible with the all-in-one software available as a free download from Unitronics for hardware configuration, communications, and HMI/PLC applications.

Documents / Resources



<u>Unitronics US5-B5-B1 Built In UniStream Programmable Logic Controller</u> [pdf] User Guide

US5-B5-B1, US5-B5-B1 Built In UniStream Programmable Logic Controller, Built In UniStream Programmable Logic Controller, UniStream Programmable Logic Controller, Programmable Logic Controller, Logic Controller

References

- <u>UniCloud- IIoT Cloud Platform- by Unitronics</u>
- <u>Lunitronics- Programmable Logic Controller + Built-in HMI</u>
- User Manual
- **■** UNITRONICS
- Built In UniStream Programmable Logic Controller, Logic Controller, Programmable Logic Controller, UniStream
 Programmable Logic Controller, UNITRONICS, US5-B5-B1, US5-B5-B1 Built In UniStream Programmable Logic Controller
 —Previous Post

Unitronics UAG-BACK-IOADP UniStream Platform User Guide

Leave a comment

Your email address will not be published. Required fields are marked*	
Comment *	
Name	
Email	

Website	
☐ Save my name, email, and website in this browser for the next time I comment.	
Post Comment	

Search:

e.g. whirlpool wrf535swhz

Search

Manuals+ | Upload | Deep Search | Privacy Policy | @manuals.plus | YouTube

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.