



# UNITRONICS V570-57-T20B Vision OPLC Programmable Controllers User Guide

[Home](#) » [UNITRONICS](#) » UNITRONICS V570-57-T20B Vision OPLC Programmable Controllers User Guide 

## UNITRONICS V570-57-T20B Vision OPLC Programmable Controllers User Guide



### Contents

- [1 General Description](#)
- [2 Standard Kit Contents](#)
- [3 Danger Symbols](#)
- [4 Environmental Considerations](#)
- [5 UL Compliance](#)
- [6 Inserting the Battery](#)
- [7 Mounting](#)
- [8 Wiring](#)
- [9 Power Supply](#)
- [10 Communication Ports](#)
- [11 Technical Specifications](#)
- [12 Documents / Resources](#)
- [13 Related Posts](#)

### General Description

V570 OPLCs are programmable logic controllers that comprise a built-in operating panel containing a 5.7" Color

Touchscreen which displays a virtual keyboard when the application requires the operator to enter data.

## Communications

- 2 isolated RS232/RS485 ports
- USB programming port (Mini-B)
- Isolated CANbus port
- The user can order and install an Ethernet port
- Communication Function Blocks include: SMS, GPRS, MODBUS serial/IP Protocol FB enables PLC to communicate with almost any external device, via serial or Ethernet communications

## I/O Options



V570 supports digital, high-speed, analog, weight and temperature measurement I/Os via:

- Snap-in I/O Modules  
Plug into the back of the controller to provide an onboard I/O configuration
- I/O Expansion Modules  
Local or remote I/Os may be added via expansion port or CANbus.

Installation instructions and other data may be found in the module's technical specification sheet.

## Information Mode

This mode enables you to:

- Calibrate the touchscreen
- View & Edit operand values, COM port settings, RTC and screen contrast/brightness settings
- Stop, initialize, and reset the PLC

To enter Information Mode, press the button for several seconds.

## Programming Software, & Utilities

The Unitronics Setup CD contains VisiLogic software and other utilities

- VisiLogic

Easily configure hardware and write both HMI and Ladder control applications; the Function Block library simplifies complex tasks such as PID. Write your application, and then download it to the controller via the programming cable included in the kit.

- Utilities

These include UniOPC server, Remote Access for remote programming and diagnostics, and DataXport for run-time data logging.

To learn how to use and program the controller, as well as use utilities such as Remote Access, refer to the VisiLogic Help system.

## **Removable Memory Storage**

SD card: store datalogs, Alarms, Trends, Data Tables; export to Excel; backup Ladder, HMI & OS and use this data to 'clone' PLCs.

For more data, refer to the SD topics in the VisiLogic Help system.

## **Data Tables**





Data tables enable you to set recipe parameters and create datalogs.

Additional product documentation is in the Technical Library, located at [www.unitronicsplc.com](http://www.unitronicsplc.com). Technical support is available at the site, and from [support@unitronics.com](mailto:support@unitronics.com).



## **Standard Kit Contents**

- Vision controller
- 3 pin power supply connector
- 5 pin CANbus connector
- CANbus network termination resistor
- Battery (not installed)
- Mounting brackets (x4)
- Rubber seal

## **Danger Symbols**

Symbol	Meaning	Description
	Danger	The identified danger causes physical and property damage.
	Warning	The identified danger could cause physical and property damage.
Caution	Caution	Use caution.
<ul style="list-style-type: none"> <li>• Before using this product, the user must read and understand this document.</li> <li>• All examples and diagrams are intended to aid understanding, and do not guarantee operation. Unitronics accepts no responsibility for actual use of this product based on these examples.</li> <li>• Please dispose of this product according to local and national standards and regulations.</li> <li>• Only qualified service personnel should open this device or carry out repairs.</li> </ul>		
	Failure to comply with appropriate safety guidelines can cause severe injury or property damage.	
	<ul style="list-style-type: none"> <li>• Do not attempt to use this device with parameters that exceed permissible levels.</li> <li>• To avoid damaging the system, do not connect/disconnect the device when power is on.</li> </ul>	

## Environmental Considerations

	<ul style="list-style-type: none"> <li>• Do not install in areas with: excessive or conductive dust, corrosive or flammable gas, moisture or rain, excessive heat, regular impact shocks or excessive vibration, in accordance with the standards given in the product's technical specification sheet.</li> </ul>
	<ul style="list-style-type: none"> <li>• Ventilation: 10mm space required between controller's top/bottom edges &amp; enclosure walls.</li> <li>• Do not place in water or let water leak onto the unit.</li> <li>• Do not allow debris to fall inside the unit during installation.</li> <li>• Install at maximum distance from high-voltage cables and power equipment.</li> </ul>

## UL Compliance

The following section is relevant to Unitronics' products that are listed with the UL.

The following models: V570-57-T20B, V570-57-T20B-J are UL listed for Hazardous Locations.



The following models: V570-57-T20B, V570-57-T20B-J are UL listed for Ordinary Location.

### UL Ordinary Location

In order to meet the UL ordinary location standard, panel-mount this device on the flat surface of Type 1 or 4 X

### **UL Ratings, Programmable Controllers for Use in Hazardous Locations, Class I, Division 2, Groups A, B, C and D**

These Release Notes relate to all Unitronics products that bear the UL symbols used to mark products that have been approved for use in hazardous locations, Class I, Division 2, Groups A, B, C and D.

Caution	This equipment is suitable for use in Class I, Division 2, Groups A, B, C and D, or Non- hazardous locations only.
	<ul style="list-style-type: none"><li>• Input and output wiring must be in accordance with Class I, Division 2 wiring methods and in accordance with the authority having jurisdiction.</li></ul>
	<ul style="list-style-type: none"><li>• WARNING—Explosion Hazard—substitution of components may impair suitability for Class I, Division 2.</li><li>• WARNING – EXPLOSION HAZARD – Do not connect or disconnect equipment unless power has been switched off or the area is known to be non-hazardous.</li><li>• WARNING – Exposure to some chemicals may degrade the sealing properties of material used in Relays.</li><li>• This equipment must be installed using wiring methods as required for Class I, Division 2 as per the NEC and/or CEC.</li></ul>

### **Panel-Mounting**

For programmable controllers that can be mounted also on panel, in order to meet the UL Haz Loc standard, panel-mount this device on the flat surface of Type 1 or Type 4X enclosures.

### **Communication and Removable Memory Storage**

When products comprise either USB communication port, SD card slot, or both, neither the SD card slot nor the USB port are intended to be permanently connected, while the USB port is intended for programming only.

### **Removing / Replacing the battery**

When a product has been installed with a battery, do not remove or replace the battery unless the power has been switched off, or the area is known to be non-hazardous.

Please note that it is recommended to back up all data retained in RAM, in order to avoid losing data when changing the battery while the power is switched off. Date and time information will also need to be reset after the procedure.

### **Inserting the Battery**


In order to preserve data in case of power-off, you must insert the battery.

The battery is supplied taped to the battery cover on the rear of the controller.

1. Remove the battery cover shown on page 6. The polarity (+) is marked on the battery holder and on the battery.
2. Insert the battery, ensuring that the polarity symbol on the battery is:
  - facing up
  - aligned with the symbol on the holder
3. Replace the battery cover.

## Mounting

### Dimensions




Note that the LCD screen may have a single pixel that is permanently either black or white.

### Panel Mounting


Before you begin, note that the mounting panel cannot be more than 5 mm thick.

1. Make a panel cut-out according to the dimensions in the figure to the right.


2. Slide the controller into the cutout, ensuring that the rubber seal is in place.
3. Push the 4 mounting brackets into their slots on the sides of the controller as shown in the figure to the right.





4. Tighten the bracket screws against the panel. Hold the bracket securely against the unit while tightening the screw.



5. When properly mounted, the controller is squarely situated in the panel cut-out as shown below.



## Wiring

	<ul style="list-style-type: none"><li>• Do not touch live wires.</li></ul>
	<ul style="list-style-type: none"><li>• Install an external circuit breaker. Guard against short-circuiting in external wiring.</li><li>• Use appropriate circuit protection devices.</li><li>• Unused pins should not be connected. Ignoring this directive may damage the device.</li><li>• Double-check all wiring before turning on the power supply</li></ul>
Caution	<ul style="list-style-type: none"><li>• To avoid damaging the wire, do not exceed a maximum torque of 0.5 N·m (5 kgf·cm).</li><li>• Do not use tin, solder, or any substance on stripped wire that might cause the wire strand to break.</li><li>• Install at maximum distance from high-voltage cables and power equipment.</li></ul>

### Wiring Procedure


Use crimp terminals for wiring; use 26-12 AWG wire (0.13 mm 2–3.31 mm<sup>2</sup> ).



1. Strip the wire to a length of 7±0.5mm (0.250–0.300 inches).
2. Unscrew the terminal to its widest position before inserting a wire.
3. Insert the wire completely into the terminal to ensure a proper connection.
4. Tighten enough to keep the wire from pulling free.

## Power Supply

V570-57-T20B & V570-57-T20B-J requires either an external 12 or 24VDC power supply.  
Permissible input voltage range: 10.2-28.8VDC, with less than 10% ripple.





	<ul style="list-style-type: none"> <li>• A non-isolated power supply can be used if a 0V signal is connected to the chassis</li> </ul>
	<ul style="list-style-type: none"> <li>• Install an external circuit breaker. Guard against shortcircuiting in external wiring.</li> <li>• Double-check all wiring before turning on the power supply.</li> <li>• Do not connect either the 'Neutral' or 'Line' signal of the 110/220VAC to device's 0V pin.</li> <li>• In the event of voltage fluctuations or non-conformity to voltage power supply specifications, connect the device to a regulated power supply.</li> </ul>

### **Earthing the Power Supply**


To maximize system performance, avoid electromagnetic interference by:

- Mounting the controller on a metal panel.
- Earthing the controller's power supply: connect one end of a 14 AWG wire to the chassis signal; connect the other end to the panel.

**Note: If possible, the wire used to earth the power supply should not exceed 10 cm in length. However, it is recommended to earth the controller in all cases.**

### **Communication Ports**

This series comprises a USB port, 2 RS232/RS485 serial ports and a CANbus port

	<ul style="list-style-type: none"> <li>• Turn off power before making communications connections.</li> </ul>
Caution	<ul style="list-style-type: none"> <li>• Always use the appropriate port adapters.</li> </ul>

The USB port may be used for programming, OS download, and PC access.

Note that **COM port 1 function is suspended when this port is physically connected to a PC.**

The serial ports are type RJ-11 and may be set to either RS232 or RS485 via DIP switches, in accordance with the table shown below.


Use RS232 to download programs from a PC, and to communicate with serial devices and applications, such as SCADA.

Use RS485 to create a multi-drop network containing up to 32 devices.

The pinouts below show PLC port signals.

To connect a PC to a port that is set to RS485, remove the RS485 connector, and connect the PC to the PLC via the programming cable. Note that this is possible only if flow control signals are not used (which is the standard case).

RS232	
Pin #	Description
1	DTR signal
2	0V reference
3	TXD signal
4	RXD signal
5	0V reference
6*	DSR signal

RS485**		Controller Port
Pin #	Description	
1	A signal (+)	
2	(RS232 signal)	
3	(RS232 signal)	
4	(RS232 signal)	
5	(RS232 signal)	
6	B signal (-)	

\*Standard programming cables do not provide connection points for pins 1 and 6.

\*\*When a port is adapted to RS485, Pin 1 (DTR) is used for signal A, and Pin 6 (DSR) signal is used for signal B.

### **RS232 to RS485: Changing DIP Switch Settings**


The ports are set to RS232 by factory default.

To change the settings, first remove the Snap-in I/O Module, if one is installed, and then set the switches according to the following table.

### **RS232/RS485: DIP Switch Settings**

The settings below are for each COM port.

	Switch Settings					
	1	2	3	4	5	6
<b>RS232*</b>	<b>ON</b>	<b>ON</b>	<b>ON</b>	OFF	<b>ON</b>	OFF
<b>RS485</b>	OFF	OFF	OFF	<b>ON</b>	OFF	<b>ON</b>
<b>RS485 with termination**</b>	<b>ON</b>	<b>ON</b>	OFF	<b>ON</b>	OFF	<b>ON</b>





\*Default factory setting

\*\*Causes the unit to function as an end unit in an RS485 network

### **Removing a Snap-in I/O Module**



1. Locate the four buttons on the sides of the controller, two on either side.
2. Press the buttons and hold them down to open the locking mechanism.
3. Gently rock the module from side to side, easing the module from the controller



### **Re-installing a Snap-in I/O Module**

1. Line the circular guidelines on the controller up with the guidelines on the Snap-in I/O Module as shown below.
2. Apply even pressure on all 4 corners until you hear a distinct 'click'. The module is now installed.

Check that all sides and corners are correctly aligned.



### **CANbus**

These controllers comprise a CANbus port. Use this to create a decentralized control network using one of the following CAN protocols:

- CANopen: 127 controllers or external devices
- CANLayer 2
- Unitronics' proprietary UniCAN: 60 controllers, (512 data bytes per scan)

The CANbus port is galvanically isolated.

### **CANbus Wiring**

Use twisted-pair cable. DeviceNet® thick shielded twisted pair cable is recommended.


Network terminators: These are supplied with the controller. Place terminators at each end of the CANbus network.

Resistance must be set to 1%, 121Ω, 1/4W.

Connect ground signal to the earth at only one point, near the power supply.

- The network power supply need not be at the end of the network.

## CANbus Connector



## Technical Specifications

<b><u>Power Supply</u></b>	
Input voltage	12 or 24VDC
Permissible range	10.2-28.8VDC with less than 10% ripple
Max. current consumption	540mA@12VDC 270mA@24VDC
<b><u>Battery</u></b>	
Back-up	7 years typical at 25°C, battery back-up for RTC and system data, including variable data.
Replaceable	Yes, without opening the controller.
<b><u>Graphic Display Screen</u></b>	See Note 1
LCD Type	TFT

Illumination backlight	White LED
Display resolution, pixels	320×240 (QVGA)
Viewing area	5.7"
Colors	65,536 (16-bit)
Touchscreen	Resistive, analog
'Touch' indication	Via buzzer
Screen brightness	Via software (Store value to SI 9).
Keypad	Displays virtual keyboard when the application requires data entry.
<p><b><u>Notes:</u></b></p> <p>1. Note that the LCD screen may have a single pixel that is permanently either black or white.</p>	

### **Program**

Memory size Application Logic – 2MB, Images – 12MB, Fonts – 1MB

Operand type	Quantity	Symbol	Value
Memory Bits	8192	MB	Bit (coil)
Memory Integers	4096	MI	16-bit
Long Integers	512	ML	32-bit
Double Word	256	DW	32-bit unsigned
Memory Floats	64	MF	32-bit
Timers	384	T	32-bit
Counters	32	C	16-bit

#### Data Tables

120K dynamic RAM data (recipe parameters, datalogs, etc.)

Up to 256K Flash data

#### HMI displays

Up to 1024

#### Program scan time

9 µsec per 1K of typical application

### **Removable Memory**

#### SD card

Compatible with fast SD cards; store datalogs, Alarms, Trends, Data Tables, backup Ladder, HMI, and OS. See Note 2

#### **Notes:**

User must format via Unitronics SD tools utility.

### **Communication**

Serial ports	2. See Note 3&4
RS232	
Galvanic isolation	Yes
Voltage limits	±20VDC absolute maximum
Baud rate range	300 to 115200 bps
Cable length	Up to 15m (50')
RS485	
Galvanic isolation	Yes
Voltage limits	-7 to +12VDC differential maximum
Baud rate range	300 to 115200 bps
Nodes	Up to 32
Cable type	Shielded twisted pair, in compliance with EIA RS485



Cable length	1200m maximum (4000')	
USB	See Note 4	
Port type	Mini-B	
Galvanic isolation	No	
Specification	USB 2.0 compliant; full speed	
Baud rate range	300 to 115200 bps	
Cable	USB 2.0 compliant; up to 3m	
CANbus port	1. See Note 5	
Nodes	CANopen	Unitronics' CANbus protocols
	127	60
Power requirements	24VDC ( $\pm 4\%$ ), 40mA max. per unit	
Galvanic isolation	Yes, between CANbus and controller	

Cable length/baud rate See Note 3	25 m 100 m 250 m 500 m 500 m 1000 m* 1000 m*	1 Mbit/s 500 Kbit/s 250 Kbit/s 125 Kbit/s 100 Kbit/s 50 Kbit/s 20 Kbit/s	* If you require cable lengths over 500 meters, contact technical support.
Optional port	User may install a single Ethernet port, or an RS232/RS485 port. Available by separate order.		
<b>Notes:</b>			
<ul style="list-style-type: none"><li>3. The standard for each port is set to either RS232/RS485 according to DIP switch settings. Refer to the Installation Guide.</li><li>4. The USB port may be used for programming, OS download, and PC access. Note that COM port 1 function is suspended when this port is physically connected to a PC.</li><li>5. V570-57-T20B &amp; V570-57-T20B-J supports both 12 and 24VDC CANbus power supply, (±4%), 40mA maximum per unit. Note that if 12 VDC is used, the maximum cable length is 150 meters.</li></ul>			

<b>I/Os</b>	
	Number of I/Os and types vary according to module. Supports up to 1024 digital, high-speed, and analog I/Os.
Snap-in I/O modules	Plugs into rear port to create self-contained PLC with up to 62 I/Os.
Expansion modules	<u>Local adapter</u> (P.N. EX-A2X), via I/O Expansion Port. Integrate up to 8 I/O Expansion Modules comprising up to 128 additional I/Os. <u>Remote adapter</u> (P.N. EX-RC1), via CANbus port. Connect up to 60 adapters; connect up to 8 I/O expansion modules to each adapter.
Exp. port isolation	Galvanic

Dimensions

Size  
197X146.6X68.5mm )7.75" X 5.77" X2.7"). See Note 6  
Weight  
750 gm (26.4 oz)

Notes:

6. For exact dimensions, refer to the product’s Installation Guide-

Mounting	
Panel-mounting	Via brackets


Environment		
Inside cabinet	IP20 / NEMA1 (case)	
Panel mounted	V570-57-T20B	V570-57-T20B-J
	IP65/NEMA4X (front panel)	IP65/66/NEMA4X (front panel)
Operational temperature	0 to 50°C (32 to 122°F)	
Storage temperature	-20 to 60°C (-4 to 140°F)	
Relative Humidity (RH)	5% to 95% (non-condensing)	

The information in this document reflects products at the date of printing. Unitronics reserves the right, subject to all applicable laws, at any time, at its sole discretion, and without notice, to discontinue or change the features, designs, materials and other specifications of its products, and to either permanently or temporarily withdraw any of the forgoing from the market.

All information in this document is provided “as is” without warranty of any kind, either expressed or implied, including but not limited to any implied warranties of merchantability, fitness for a particular purpose, or non-infringement. Unitronics assumes no responsibility for errors or omissions in the information presented in this document. In no event shall Unitronics be liable for any special, incidental, indirect or consequential damages of any kind, or any damages whatsoever arising out of or in connection with the use or performance of this information.

The tradenames, trademarks, logos and service marks presented in this document, including their design, are the property of Unitronics (1989) (R”G) Ltd. or other third parties and you are not permitted to use them without the prior written consent of Unitronics or such third party as may own them.

Documents / Resources

	<a href="#">UNITRONICS V570-57-T20B Vision OPLC Programmable Controllers</a> [pdf] User Guide V570-57-T20B, V570-57-T20B-J, Vision OPLC, Programmable Controllers, Vision OPLC Programmable Controllers, V570-57-T20B Vision OPLC Programmable Controllers
---	---

