



vttech Phones Manuals: Expandable Cordless Phone User Guide

[Home](#) » [vttech](#) » **vttech Phones Manuals: Expandable Cordless Phone User Guide**

This page provides a user guide for the vttech Expandable Cordless Phone, which is a versatile and convenient device for home or office use. The guide includes basic installation and usage instructions, as well as a detailed overview of the handset and telephone base features. The guide covers topics such as battery installation and charging, handset and telephone base overview, using the menu, telephone settings, telephone operation, intercom, push-to-talk (PTT), directory, speed dial, caller ID, and caller ID log. The guide is designed to help users get started with their vttech Expandable Cordless Phone quickly and easily. It provides step-by-step instructions and helpful tips to ensure that users can take full advantage of the phone's features and capabilities. Whether you are a first-time user or an experienced phone user, this guide will help you get the most out of your vttech Expandable Cordless Phone.

Contents [[hide](#)]

- [1 vttech Expandable Cordless Phone](#)
- [2 Introduction](#)
- [3 Battery installation and charging](#)
- [4 Handset overview](#)
- [5 Telephone base overview](#)
- [6 Using the menu](#)
- [7 Answering system operation](#)
- [8 Access the answering system remotely](#)
- [9 SPECIFICATION](#)
- [10 FAQs](#)
- [11 Documents / Resources](#)
 - [11.1 References](#)
- [12 Related Posts](#)




vtech Expandable Cordless Phone




Introduction

This quick start guide provides you with the basic installation and use instructions. A limited set of features are described in abbreviated form. Please refer to the user's manual for complete installation and operation instructions.





Install the battery as shown below. Once you have installed the battery, you may be able to make and receive short calls. For best performance, charge the handset battery continuously for at least 10 hours

1. Plug the battery connector securely into the socket inside the handset battery compartment, matching the color-coded label.
2. Place the battery with the label **THIS SIDE UP** facing up and the wires inside the battery compartment.



3. Slide the battery compartment cover towards the center of the handset until it clicks into place.
4. Place the handset in the telephone base or charger to charge.



Handset overview

CHARGE light

On when the handset is charging.

VOLUME

Review the directory when the telephone is not in use. Scroll up while in a menu. Increase the listening volume during a call or message playback. Move the cursor to the right when entering numbers or names in the directory.

MUTE/DELETE

Mute the microphone during a call. Delete the displayed entry while in the directory, caller ID log or redial list.

Silence the ringer temporarily while the handset is ringing.

Delete digits or characters while using the dialing keys.

FLASH

Make or answer a call. Answer a call waiting call during a call.

Press repeatedly to add or remove 1 in front of the caller ID log entry before dialing or saving it to the directory.

Switch to tone dialing temporarily while on a call.

SPEAKER

Make or answer a call using the handset speakerphone. Switch between the speakerphone and the handset during a call.

REDIAL/PAUSE

Press to review the redial list. Press and hold to insert a dialing pause while entering numbers in the directory.

CID//VOLUME

Review the caller ID log when the telephone is not in use. Scroll down while in a menu. Decrease the listening volume during a call or message playback. Move the cursor to the left when entering numbers or names.

MENU/SELECT

Show the menu. Choose an item, or save an entry or setting while in a menu.

PUSH TO TALK (PTT)

Begin a one-to-one or one-to-group broadcast.

OFF/CANCEL

Hang up a call. Silence the ringer temporarily while the handset is ringing. Press and hold to delete the missed call indicator while the telephone is not in use. Press to return to the previous menu, or press and hold to return to

idle mode without making changes.

Dialing keys

Enter numbers or characters.

(pound key)

Press repeatedly to show other dialing options when reviewing a caller ID log entry. Switch the name order when saving the caller ID log entries to the directory.

EQ

Change the audio quality to best suit your hearing during an outside call, intercom call, message or announcement playback.

Telephone base overview

IN USE light

Flashes when there is an incoming call, or another telephone sharing the same line is in use.

Flashes when the handsets are being deregistered.

On when the handset is in use, or the answering system is answering a call.

On when a handset is being registered.

📞/FIND HANDSET

Page all system handsets.

⏮️/REPEAT

Repeat a message or press twice to play the previous message.

X/DELETE

Delete the message currently playing.

Press twice to delete all old messages when the telephone is not in use.

Message window

Shows the number of messages and other answering system information.

⏭️/SKIP

Skip to the next message.


🔌/ANS ON/OFF

Turn the answering system on or off.

▶️/PLAY/STOP

Play messages.

Stop message playback.



Using the menu

To enter the handset menu:

1. Press MENU/SELECT when the telephone is not in use.
2. Press or until the screen displays the desired feature menu.
3. Press MENU/SELECT to enter that menu.
 - To return to the previous menu, press OFF/CANCEL
 - To return to idle mode, press and hold OFF/CANCEL.

Telephone settings

Default settings are indicated by asterisks (*).

Screen display	Function	Options
LCD language	Set the screen display language.	English* Français Español
Annc Caller ID	Enable the telephone base and/or the handset to announce the incoming caller ID information.	On* Off
Clr voicemail	Turn off the voicemail indicators.	Turn off indicator?
Rename handset	Change the name of each registered handset.	HANDSET_____
Key tone	Adjust the key tone volume whenever a key is pressed, or turn it off.	* Off
CID time sync	Enable the date and time to be set by incoming caller ID information.	On* Off
Home area code	Enter your home area code if you dial only seven digits for local calls.	— — —
Dial mode	Set the telephone to be tone or pulse dialing.	Tone* Pulse

Telephone operation

Make a call

Press /FLASH or /SPEAKER, and then dial telephone number.

-OR-

Predial by first dialing the telephone number and then press /FLASH or /SPEAKER.

Answer a call

Press /FLASH, /SPEAKER or any dialing key (0-9, TONE or #).

End a call

Press OFF/CANCEL or put the handset to the telephone base or charger.

Redial list

Each handset stores the last 10 telephone numbers dialed.

1. To review and dial numbers from the redial list:
2. Press REDIAL/PAUSE when the handset is not in use.
3. Press , REDIAL/PAUSE repeatedly until the desired entry displays.
4. Press /FLASH or /SPEAKER to dial.

To delete a redial entry:

When the desired redial entry displays, press MUTE/DELETE.

Intercom

Use the intercom feature for conversation between two system handsets. Only one intercom call can be established with two handsets at a time. If there is an incoming call while the originating handset is making an intercom request, the intercom request will be stopped.

To initiate an intercom call:

When the handset is not in use, press MENU/SELECT. Scroll to >Intercom, then press MENU/SELECT. If you have more than two handsets, scroll to select a destination handset, or use the dialing keys to enter a handset number.

To answer an intercom call:

Press /FLASH, /SPEAKER or any of the dialing keys on the destination handset.

To end an intercom call:

Press OFF/CANCEL or place the handset back in the telephone base or charger.

Push-to-talk (PTT)

You can directly broadcast messages from one handset to the speakerphone of one or multiple handsets. Press and hold PUSH TO TALK to begin two-way communication.

When the connection is made, both the caller and the destination handsets display Press and hold [PTT] to talk and beep once. Only one handset can talk at a time. To do so, press and hold **PUSH TO TALK**

Directory

The directory can store up to 50 entries, which are shared by all system handsets.

To add a directory entry:

1. Press MENU/SELECT when the handset is not in use.
2. Scroll to >Directory, then press MENU/SELECT.
3. Scroll to >Add contact, then press MENU/SELECT.
4. Use the dialing keys to enter the phone number (up to 30 digits).
-OR- Copy a number from the redial list by pressing REDIAL/PAUSE and then press , or REDIAL/PAUSE repeatedly to select a number. Press MENU/SELECT.
5. Press MENU/SELECT to move to the name.
6. Use the dialing keys to enter the name (up to 15 characters). Additional key presses show other characters of that particular key.
7. Press MENU/SELECT to store the entry.

While entering names and numbers, you can:

- Press MUTE/DELETE to backspace and erase a digit or character.
- Press and hold MUTE/DELETE to erase the entire entry.
- Press and hold REDIAL/PAUSE to insert a dialing pause (for entering phone numbers only).
- Press ← or → to move the cursor to the left or right.
- Press 0 to add a space (for entering names only).

To review and dial from the directory:

1. Entries are sorted alphabetically.
2. Press / when the handset is not in use.
3. Scroll to browse through the directory, or use the dialing keys to start a name search.
4. When the desired entry appears, press /FLASH or /SPEAKER to dial.

To edit a directory entry:

1. When the desired entry displays, press MENU/SELECT.
2. When the screen displays EDIT NUMBER, use the dialing keys to edit.
3. Press MENU/SELECT.
4. When the handset displays EDIT NAME, use the dialing keys to edit.
5. Press MENU/SELECT to save.
6. To delete a directory entry:
7. When the desired entry displays, press MUTE/DELETE.
8. When the handset displays Delete contact?, press MENU/SELECT.

Speed dial

You can copy up to 10 directory entries into the speed dial locations so that you can dial these numbers using fewer keys than usual.

To store a speed dial entry:

1. Press MENU/SELECT when the handset is not in use.
2. Scroll to >Directory, then press MENU/SELECT.
3. Scroll to >Speed dial, then press MENU/SELECT.
4. Scroll to a desired speed dial location, then press MENU/SELECT.
5. Scroll to a desired directory entry, then press MENU/SELECT to save.

To dial a speed dial entry:

Press and hold a speed dial key (0-9) of the desired entry when the handset is not in use, the number will be dialed automatically.

To delete a speed dial entry:

When the desired entry displays, press MUTE/DELETE.

Caller ID

This product supports caller ID services provided by most telephone service providers. Depending on your service subscription, you may see the caller's name, number, date and time of calls that are sent by your telephone

service provider after the first or second ring.

Caller ID log

The caller ID log stores up to 50 entries. If you answer a call before the caller information appears, it will not be saved in the caller ID log.

The handset displays XX Missed calls when there are calls that have not been reviewed in the caller ID log.

If you want to erase the missed call indicator, press and hold OFF/CANCEL on the idle handset.

To review and dial a number in the caller ID log:

1. Press CID/ when the handset is not in use.
2. Scroll to browse through the call log. When the desired entry appears:
3. Press # (pound key) repeatedly to show different dialing options.
4. Press 1 repeatedly to add or remove 1 in front of the telephone number.
5. Press /FLASH or /SPEAKER to dial the displayed number.

To delete the caller ID log entries:

Delete one entry: When the desired caller ID log entry displays, press MUTE/DELETE.

Delete all entries: Press MENU/SELECT when the handset is not in use. Scroll to >Caller ID log and then press MENU/SELECT. Scroll to >Del all calls and then press MENU/SELECT twice.

About answering system and voicemail

Your telephone has separate indicators for two different types of voice messages: those left on the built-in answering system and those left at your telephone service provider's voicemail. Each alerts you to new messages separately.

- If XX New messages and display on the handset and the message window on the telephone base flashes, there are messages recorded on the built-in answering system.
The total recording time is approximately 14 minutes. It can record and store up to 99 messages and the recording time of each message depends on the message length you set.
- If New Voicemail and display on the handset, your telephone service provider is indicating that it has new voicemail for you. Contact your telephone service provider for more information on how to access your voicemail.

Answering system settings

Default settings are indicated by asterisks (*).


Screen display	Function	Options
Call screening	Set whether you hear the callers while they are leaving messages to you.	On* Off
# of rings	Set the number of times the telephone rings before the answering system answers.	6; 5; 4*; 3; 2; Toll saver
Remote code	Set a two-digit security code to access the answering system remotely from any touch-tone telephone.	19*
Msg alert tone	Set to alert you when you have new messages.	On Off*
Recording time	Set the recording time for each incoming message.	3 minutes* 2 minutes 1 minute

Answering system operation

Turn the answering system on or off

The answering system must be turned on to answer and record messages. When it is turned on, the /ANS ON/OFF light on the telephone base turns on and ANS ON displays on the handset.

Press /ANS ON/OFF on the telephone base to turn the built-in answering system on or off.



Record your own announcement

You can use the preset announcement to answer calls, or replace it with your own recorded announcement. It can be up to 90 seconds in length.

1. Press MENU/SELECT when the handset is not in use.
2. Scroll to >Answering sys. Press MENU/SELECT twice.
3. Scroll to >Record annnc. Press MENU/SELECT. The system announces, "Record after the tone. Press 5 when you are done."
4. After the tone, speak towards the handset microphone. Press 5 when done. The answering system automatically plays back the newly recorded announcement, then returns to the previous menu.

Message playback

To play messages with the telephone base:

- Press /PLAY/STOP when the telephone is not in use.
- Options during playback:
 - Press /VOL or /VOL to adjust the speaker volume.
 - Press /SKIP to skip to the next message.
 - Press /REPEAT to repeat the message currently playing. Press /REPEAT twice to listen to the previous message.
 - Press X/DELETE to delete the current message. The system advances to the next message.
 - Press /PLAY/STOP to stop.
- To play messages with a handset:
 - Press MENU/SELECT twice when the telephone is not in use.

Options during playback:

- Press MENU/SELECT to pause the playback, and display the caller ID information if it is available, then press /FLASH or /SPEAKER to call back the caller. If you do not press /FLASH within 10 seconds, message playback resumes.
- Press /FLASH to stop the playback and the handset displays

- Call back? then press MENU/SELECT, /FLASH or /SPEAKER to call back the caller.
- Press /VOLUME or /VOLUME to adjust the speaker volume.
- Press EQ to adjust the handset message playback audio quality.
- Press 6 to skip to the next message.
- Press 4 to repeat the message currently playing. Press 4 twice to listen to the previous message.
- Press MUTE/DELETE to delete the current message. The system announces, "Message deleted," and advances to the next message.
- Press 5 to stop.

Delete all old messages

To delete all old messages at the telephone base:

1. Press X/DELETE twice when the telephone is not in use.
2. To delete all old messages with a handset:
3. Press MENU/SELECT when the handset is not in use.
4. Scroll to >Answering sys and then press MENU/SELECT.
5. Scroll to >Delete all old and then press MENU/SELECT twice.

Call screening

Call screening at the telephone base:

If the answering system and call screening are on, the announcement and the incoming message broadcast at the telephone base when a call is answered by the answering system.

Options while recording a message:

- Press /VOL or /VOL on the telephone base to adjust the call screening volume.
- Press /PLAY/STOP to temporarily silence the call screening.

Call screening at the handset:

If the answering system is on, the announcement and the incoming message broadcast at the telephone base when a call is answered by the answering system. The handset shows To screen call, press [SELECT]. Press MENU/SELECT to screen the call on your handset and the handset displays the caller ID information. If you do not subscribe to caller ID service, the handset shows Screening...

Call intercept

If you want to talk to the person whose message is being recorded, press /FLASH or /SPEAKER on the handset.

Access the answering system remotely

1. Dial your telephone number from any touch-tone telephone.
2. When the system plays your announcement, enter the two-digit remote code. The preset code is 19.
3. You can enter one of the following remote commands.

Command	Function
1	Play all messages.
2	Play new messages.
3	Delete a message (during playback).
33	Delete all old messages.
4	Repeat the current message (during playback).
44	Listen to the previous message (during playback).
5	Stop.
*5	Hear a list of remote commands.
6	Skip to the next message (during playback).
*7	Record a new announcement.
8	End the call.
0	Turn the answering system on or off.

4. Hang up or press 8 to end the call.

IMPORTANT!

If you have difficulty with your telephone, please refer to the user's manual for a full set of installation and operation instructions. For customer service, visit our website at www.vtechphones.com or call 1 (800) 595-9511. In Canada, go to www.vtechcanada.com or call 1 (800) 267-7377.

Disclaimer and Limitation of Liability

VTech Communications, Inc. and its suppliers assume no responsibility for any damage or loss resulting from the

use of this user's manual. VTech Communications, Inc. and its suppliers assume no responsibility for any loss or claims by third parties that may arise through the use of this product.

Company: VTech Communications, Inc.

Address: 9020 SW Washington Square Road – Ste 555 Tigard, OR 97223, United States

Phone: 1 (800) 595-9511 in the U.S. or 1 (800) 267-7377 in Canada

SPECIFICATION

Product Specifications	Description
Battery Installation and Charging	Charge the handset battery continuously for at least 10 hours for best performance
Handset Overview	Includes CHARGE light, VOLUME, MUTE/DELETE, FLASH, SPEAKER, REDIAL/PAUSE, CID/VOLUME, MENU/SELECT, PUSH TO TALK (PTT), OFF/CANCEL, and Dialing keys
Telephone Base Overview	Includes using the menu, telephone settings, telephone operation, intercom, push-to-talk (PTT), directory, speed dial, caller ID, and caller ID log
Telephone Settings	Includes screen display, LCD language, Ann. Caller ID, Clr voicemail, Rename handset, Key tone, CID time sync, Home area code, and Dial mode
Telephone Operation	Includes making a call, answering a call, ending a call, and redial list
Intercom	Use for conversation between two system handsets
Push-to-talk (PTT)	Broadcast messages from one handset to the speakerphone of one or multiple handsets
Directory	Stores up to 50 entries, can add, edit, and delete entries, and can review and dial from directory
Speed Dial	Can copy up to 10 directory entries into speed dial locations for faster dialing
Caller ID	Supports caller ID services provided by most telephone service providers
Caller ID Log	Stores up to 50 entries, can review and dial a number in the log, and can delete log entries

FAQS

How do I install the battery for the vtech Expandable Cordless Phone?

Plug the battery connector securely into the socket inside the handset battery compartment, matching the color-coded label. Place the battery with the label THIS SIDE UP facing up and the wires inside the battery compartment. Slide the battery compartment cover towards the center of the handset until it clicks into place.

How long should I charge the handset battery for best performance?

Charge the handset battery continuously for at least 10 hours for best performance.

How do I access the directory on the vtech Expandable Cordless Phone?

Press / when the handset is not in use. Scroll to browse through the directory, or use the dialing keys to start a name search. When the desired entry appears, press /FLASH or /SPEAKER to dial.

How many entries can the directory on the vtech Expandable Cordless Phone store?

The directory can store up to 50 entries, which are shared by all system handsets.

How do I add a directory entry on the vtech Expandable Cordless Phone?

Press MENU/SELECT when the handset is not in use. Scroll to >Directory, then press MENU/SELECT. Scroll to >Add contact, then press MENU/SELECT. Use the dialing keys to enter the phone number (up to 30 digits). Press MENU/SELECT to move to the name. Use the dialing keys to enter the name (up to 15 characters). Additional key presses show other characters of that particular key. Press MENU/SELECT to store the entry.

How do I delete a directory entry on the vtech Expandable Cordless Phone?

When the desired entry displays, press MUTE/DELETE. When the handset displays Delete contact?, press MENU/SELECT.

How do I access the speed dial feature on the vtech Expandable Cordless Phone?

Press MENU/SELECT when the handset is not in use. Scroll to >Directory, then press MENU/SELECT. Scroll to >Speed dial, then press MENU/SELECT.

How many speed dial entries can I store on the vtech Expandable Cordless Phone?

You can copy up to 10 directory entries into the speed dial locations so that you can dial these numbers using fewer keys than usual.

How do I dial a speed dial entry on the vtech Expandable Cordless Phone?

Press and hold a speed dial key (0-9) of the desired entry when the handset is not in use, the number will be dialed automatically.

How many entries can the caller ID log on the vtech Expandable Cordless Phone store?

The caller ID log stores up to 50 entries.

How do I review and dial a number in the caller ID log on the vtech Expandable Cordless Phone?

To review and dial numbers from the redial list, press REDIAL/PAUSE when the handset is not in use. Press , REDIAL/PAUSE repeatedly until the desired entry displays. Press /FLASH or /SPEAKER to dial.

How do I delete a caller ID log entry on the vtech Expandable Cordless Phone?

When the desired entry displays, press MUTE/DELETE.





[vtech Expandable Cordless Phone](#) [pdf] User Guide
Expandable Cordless Phone, LS6425, LS6425-2, LS6425-3, LS6425-4, LS6426-3, LS6426-4,
LS642V-1E, LS642V-1F, LS642V-1G

References

- **[V](#) [VTech Canada Official Site | Best Home Office & Business Phones](#)**
- **[v](#) [VTech Cordless Phones Official Site | Best Home Office & Business Phones](#)**