



wilo 2056576 Protect Module C Instruction Manual

[Home](#) » [wilo](#) » wilo 2056576 Protect Module C Instruction Manual 



Wilo-Protect-Modul C Installation and operating instructions





Fig.1




Fig.2a




Fig.2b




Fig.2c




Fig.2d




Fig.2e




Fig.2f




Fig.2g




Fig.3a




Fig.3b




Fig.3c




Fig.3d





Fig.3e



Contents

- 1 General
- 2 Safety
- 3 Transport and interim storage
- 4 Application
- 5 Product data
- 6 Description and function
- 7 Installation and electrical connection
- 8 Commissioning
- 9 Maintenance
- 10 Faults, causes, and remedies
- 11 Spare parts
- 12 Documents / Resources
 - 12.1 References
- 13 Related Posts

General

1.1 About this document

These Installation and Operating Instructions are an integral part of the product. They must be kept readily available at the place where the product is installed. Strict adherence to these instructions is a precondition for the proper use and correct operation of the product.

This Installation and Operating Instructions correspond to the relevant version of the product and the underlying safety standards valid at the time of going to print. These Installation and operating instructions are an addition to the Installation and operating instructions for glandless circulation pump type TOP-S/ TOP-SD/TOP-Z.

Safety

These operating instructions contain basic information which must be adhered to during installation and operation. For this reason, these operating instructions must, without fail, be read by the service technician and the responsible operator before installation and commissioning. It is not only the general safety instructions listed under the main point “safety” that must be adhered to but also the special safety instructions with danger symbols included under the following main points.

2.1 Designation of information in the operating instructions

Symbols:



General danger symbol



Danger due to electrical voltage



NOTE: ...

Signal words:

DANGER!

An acutely dangerous situation.

Non-observance results in death or the most serious of injuries.

WARNING!

The user can suffer (serious) injuries. 'Warning' implies that (serious) injury to persons is probable if this information is disregarded.

CAUTION!

There is a risk of damaging the pump/unit. 'Caution' implies that damage to the product is likely if the information is disregarded.

NOTE:

Useful information on using the product. It draws attention to possible problems.

2.2 Personnel qualifications

The installation personnel must have the appropriate qualification for this work.

2.3 Danger in event of non-observance of the safety instructions

Non-observance of the safety instructions can result in risk of injury to persons and damage to pump/unit. Non-observance of the safety instructions can result in the loss of any claims to damages.

In detail, non-observance can, for example, result in the following risks:

- Failure of important pump/unit functions,
- Failure of required maintenance and repair procedures
- Danger to persons from electrical, mechanical and bacteriological influences,
- Property damage

2.4 Safety instructions for the operator

The existing directives for accident prevention must be adhered to.

Danger from electrical current must be eliminated. Local directives or general directives [e.g. IEC, VDE, etc.] and local power supply companies must be adhered to.

2.5 Safety instructions for inspection and installation work

The operator must ensure that all inspection and installation work is carried out by authorized and qualified personnel, who are sufficiently informed from their own detailed study of the operating instructions.

Work to the pump/unit must only be carried out when at a standstill.

2.6 Unauthorised alteration and spare part production

Alterations to the pump/unit are only permissible after consultation with the manufacturer. Original spare parts and accessories authorized by the manufacturer ensure safety.

The use of other parts can nullify the liability from the results of their usage.

2.7 Unacceptable operating modes

The operating safety of the supplied pump/unit is only guaranteed for conventional use in accordance with Section 4 of the operating instructions. The limit values must on no account fall under or exceed those specified in the catalog/ datasheet.

Transport and interim storage

On receipt of the product, check it for any damage incurred in transit. In the event of damage in transit, the necessary steps must be taken with the carrier before the relevant deadlines.



CAUTION! The danger of damage to the module!

The danger of damage due to improper handling during transport and storage.

- The Protect-Module C must be protected during transport and storage from moisture, frost, and mechanical damage.
- It must not be exposed to any temperature outside the range – 10 °C to +70°C.

Application

The TOP series circulating pumps come equipped with a standard terminal box.

A retrofit plug-in module is available for the pump with the Protect-Module C (see title illustration). In addition to the pump functions, the Protect-Module C also enables further signals as well as the performance of control tasks. When the Protect-Module C is deployed, external contractors and supplementary switchgear are no longer required, with a corresponding effect on the complexity of the installation.

Product data

5.1 Type Key

Example: Wilo-Protect-Modul C Type 22 EM

Protect-Modul	Series designation
C	Comfort
Type 22	Type designation: 22 or 32-52
EM	For mains connection: EM = 1~230 V, 50 Hz (single-phase motor) DM = 3~400 V, 50 Hz (three-phase current motor)

5.2 Technical data

Connection current Type 22 EM Type 32-52 EM Type 22 DM Type 32-52 DM	1~230 V, $\pm 10\%$, 50 Hz 1~230 V, $\pm 10\%$, 50 Hz 3~400 V, $\pm 10\%$, 50 Hz 3~400 V, $\pm 10\%$, 50 Hz
Frequency	50 Hz
Terminal cross-section, all terminals	max. 2.5 mm
Temperature range of flow medium	-20 °C to +110 °C
Max. ambient temperature	+40 °C
Pump protection class	IP 44
Cable connections	4xPG9
Electromagnetic compatibility: Emitted interference Immunity to interference	EN 61000-6-3 EN 61000-6-2

5.3 Scope of supply

- Protect-Module C
- Plug strip control and signal terminals
- Plug strip mains connection terminals and connection terminals WSK/SSM with connection cables
- Fixing screws (4)
- Installation and operating instructions

Description and function

6.1 Description of the Protect-Module C

The functions of the pump housing in the terminal box (mains connection, thermal winding contact WSK or potential-free collective fault signal) are transferred to the terminal box when the Protect-Module C is installed. The fault acknowledgment button and the direction of the rotation control lamp, if fitted, as well as the manual speed stage switching of the standard terminal box continue to function when the Protect-Module C is installed. The Protect-Module C is fitted to the standard terminal box of the pump in place of the terminal box cover.

6.2 Functions and operation of the Protect-Module C

6.2.1 Light signals

There are three possible light signals on the display field:

- Operation light signal (figure 1, position 1)



WARNING! The danger of electric shock

Even when the operation light signal is off, the voltage may be present on the Protect-Module.

- Fault signal light "Stoppage" (figure 1, position 2)
- Fault signal light "Winding Overheat" (figure 1, position 3)

6.2.2 Fault acknowledgment buttons

- Fault acknowledgment button on the pump (figures 3b, 3d, position 4)
If fitted, this button is used to reset the response of the integrated full motor protection. This fault reset is done before the fault reset on the Protect-Module C.
- Fault acknowledgment button on Protect-Module C (figure 1, position 4)
- A fault displayed on the Protect-Module C is reset by briefly pressing this button (< 1s).
- Pressing and holding down the button (≥ 1s) triggers pump cycling in dual pump operation with integrated dual pump management.

6.2.3 Faults, light signals, signal contacts

- Single pump

The following table shows the links between possible faults and the reactions of light signals and signal contacts:

Operating element	Status	Possible causes
Operation light signal green	off	<ul style="list-style-type: none"> •No supply voltage. •Control input “Ext. Off” opened. •Fault is present and has not yet been acknowledged.
	flashing	<ul style="list-style-type: none"> •DP communication fault (only with a double pump).
Fault signal light “Stoppage” red	off	<ul style="list-style-type: none"> •No motor stoppage.
	on	<ul style="list-style-type: none"> •Motor stoppage recognized. •Mechanical blockage of pump •Winding fault
	flashing	<ul style="list-style-type: none"> •Motor stoppage acknowledged, the pump is in control loop 1).
Fault signal light “Winding Overheat” red	off	<ul style="list-style-type: none"> •No overheating.
	on	<ul style="list-style-type: none"> •Overheat recognized. •Pump overload •Winding fault •Unacceptable combination of medium temperature — ambient temperature
	flashing	<ul style="list-style-type: none"> •Overheat acknowledged, the pump is in control loop 1).
Operating signal contact	open	<ul style="list-style-type: none"> •No supply voltage. •Control input “Ext. Off” opened. •Fault is present and has not yet been acknowledged.
	closed	<ul style="list-style-type: none"> •Pump functioning, no-fault recognized.
Fault signal contact	open	<ul style="list-style-type: none"> •Fault is present. •Pump is still in control loop 1).
	closed	<ul style="list-style-type: none"> •Fault-free operation.
Fault signal light “Stoppage” red	off	<ul style="list-style-type: none"> •No motor stoppage.
	on	<ul style="list-style-type: none"> •Motor stoppage recognized. •Mechanical blockage of the pump. •Winding fault.

After acknowledging a fault, the Protect-Module C will be in a special control loop for up to 10 sec, depending on pump type and fault. If the fault is recognized again during this process, the pump returns to fault status.

Table 1

- Double pump:

The relationships between possible faults and the reactions of light signals and signal contacts depend on the following factors:

- Parametrization of signal contacts in individual operation/individual fault signal or joint operation/collective fault signal (function see Table 2)
- Allocation of "Ext. Off" control inputs to master and slave

6.2.4 Double pump operation

A Protect-Module C must be installed for each of the two pumps.

The double pump functions on the Protect-Module C are:

- Main/Reserve operation with automatic switching to the standby reserve pump after 24 hours of real running time, the external control command "Ext. Off" interrupts the running time counter.
- Switching takes place through an overlap, i.e. at the time of switching, both pumps run simultaneously (for approx. 10 sec.). This avoids pressure surges and undersupplies in cooling and air-conditioning systems for example.
- The DIP switch 1 (figure 2b, position 1) determines which pump is the master (MA) and which pump is the slave (SL) (function see Table 2).
- The DIP switch 2 (figure 2b, position 1) determines whether the signal contacts "SSM" and "SBM" are individual or collective signals (function see Table 2).
- In the case of a fault in the working pump, the system switches to the standby pump after approx. 3 sec.

Single pump	Double pump	
Master (MA)		Slave (SL)
DIP Switch1: MA DIP Switch2: I Allocate terminals to Ext. Off	DIP Switch1: MA DIP Switch2: Allocate terminals to Ext. Off	DIP Switch1: SL DIP Switch2: Bridge terminals to Ext. Off
DIP Switch1: MA DIP Switch2: I SSM: Collective fault signal for pump	DIP Switch1: MA DIP Switch2: I SSM: Individual fault signal for MA DIP Switch2: I + II SSM: Collective fault signal for MA + SL	DIP Switch1: SL DIP Switch2: SSM: Individual fault signal for SL DIP Switch2: SSM: Individual fault signal for SL
DIP Switch1: MA DIP Switch2: I SBM: Individual operating signal for pump	DIP Switch1: MA DIP Switch2: I SBM: Individual operating signal for MA DIP Switch2: I + II SBM: Collective operating signal for MA + SL	DIP Switch1: SL DIP Switch2: SBM: Individual operating signal for SL DIP Switch2: SBM: Individual operating signal for SL

-: Setting of DIP switch not relevant

Installation and electrical connection

Installation and the electrical connection must be carried out in accordance with local regulations and only by qualified personnel.



WARNING! The danger of personal injury

The applicable regulations on the prevention of accidents must be observed.



WARNING! The danger of electric shock

Potential dangers from electrical currents must be eliminated.

Local directives or general regulations [e.g. IEC, VDE, etc.] and those issued by the local power supply company must be adhered to.

7.1 Installation and electrical connection of mains cable

1. Switch off the power supply to the pump,



CAUTION! The danger of damage to Protect-Module C

The module may only be plugged in and unplugged when the pump has been completely disconnected.

2. Loosen the terminal box lid screws on the pump,
3. Remove terminal box lid,

4. Pinch off the power supply cable except for the protective lead PE: EM version (1~230V): L, N DM version (3~400V) L1, L2, L3 (figure 2a)
5. Remove plug strip with power supply terminals and connection terminals MP1/MP2 (figure 2b, position 5) with connection cables (figure 2b, position. 2.3) from the Protect-Module C. When removing, do not pull straight out, but begin at one corner of the plug strip,
6. Apply the plug strip cables to the corresponding terminals on the pump terminal box (figure 2c, figure 3),
7. Fit the power supply cable to the plug strip, Table 3 shows the allocation of module types to the terminal diagrams.

Protect-Module C	Terminal diagram
Type 22 EM	3a
Type 32-52 EM	3b
Type 22 DM	3c
Type 32-52 DM	3d

Table 3

8. Remove the plug strip with control and signal terminals (figure 2b, position 4) from the Protect-Module C. When removing, do not pull straight out, but begin at one corner of the plug strip,
 - 8.1 Dismantle cable connection (PG 9) of the Protect-Module C,
 - 8.2 Cut diaphragm seal,
 - 8.3 Thread individual parts of the cable connection onto the control cable (figure 2d),
- Pos. 1: Union connection
- Pos. 2: Seal
- Pos. 3: Strain relief
- 8.4 Insert control cable through cable connection into Protect-Module C,
- 8.5 Assemble cable connection, fastening union nuts tightly enough so that the cable can no longer be pulled out of the cable connection by hand.



CAUTION! The danger of damage to Protect-Module C

An incorrectly assembled cable connection may lead to a short-circuit in the module due to water penetration. This is a particular danger in cold water installations in which condensation constantly forms.

9. Fix the control cable to the plug strip (figure 2 e),
10. Plug the plug strip with the control cable to the corresponding place in the Protect-Module C,
11. Set DIP switch (figure 2b, position 1) in accordance with Table 2,
12. Plug the Protect-Module C onto the plug strip with the power connections (figure 2f),



Note: Arrange power cables and leads so that they cannot be crushed when finally tightening the module installation.

In DM versions, it is essential before the final tightening of the module installation to check the direction of rotation with the direction of the rotation control lamp in the pump terminal box (figures 3c, 3d, position 1).

13. Arrange the Protect-Module C over the terminal box structure and screw to the domes of the terminal box using the screws provided, tighten screws evenly diagonally (figure 2g).

• Stages 1 to 4 are not required for a new installation. Power connection is made directly on the corresponding

plug strip with power connection terminals and connection terminals MP1/MP2.

- For a double pump, as previously described, two Protect-Modules C must be fitted. For integrated dual pump management, the DP terminals of the two Protect-Modules C must be connected to each other, see also figure 3e.

7.2 Electrical connection of control and signal clamps

For connection to a remote control center or building automation, the following connections are provided:

- Ext. Off: Control input with “drive priority off” for potential-free normally closed contacts, contact charge 24V, 10 mA.

In dual pump operation, Ext. Off on the master must be assigned to a potential-free normally closed contact, and Ext. Off on the slave must remain bridged.

The Ext. Off of the master works on the entire double pump, i.e. master and slave.

- SBM: Programmable run signal, potential-free normally opened contact, maximum contact capacity 250 VAC, 1 A.
- SSM: Programmable fault signal, potential-free normally closed contact, maximum contact capacity 250 VAC, 1 A.

A serial interface is provided for integrated dual pump management:

- DP: Interface for integrated dual pump management, the connection terminals cannot be twisted. The connection cable (2 x 0.75 mm²) must be provided on-site. Wiring for all Protect-Modules is shown in the example in figure 3e.

Commissioning



CAUTION! The danger of damage to Protect-Module C

When commissioning, the Installation and operating instructions of the glandless circulation pump types TOP-S/TOP-SD/TOP-Z must be observed.



NOTE: Rotation control (only for three-phase motors)

In pumps with a three-phase connection, before the final tightening of the module installation, it is essential to check the direction of rotation with the direction of the rotation control lamp in the pump terminal box (figures 3c, 3d, position 1).

- When the Protect-Module C is fully installed, switch on the power supply.

Maintenance

Maintenance and repair work must only be carried out by professionally qualified personnel.



WARNING! The danger of electric shock

Potential dangers from electrical currents must be eliminated.

During all maintenance and repair work, the pump must be disconnected from the power supply and secured against possible unauthorized reconnection.

Faults, causes, and remedies

see paragraph 6.2

If an operating fault of the pump / the Protect-Module C / system cannot be corrected, please consult a

professional technician or contact your nearest Wilo Customer Service point or representative.

Spare parts

Spare parts may be ordered through local professional technicians and/or Wilo Customer Service. To avoid queries and order errors, all data on the rating plate must be given along with every order.

Subject to technical changes!

Wilo – International (Subsidiaries)

<p>Argentina WILO SALMSON Argentina S.A. C1295ABI Ciudad Autónoma de Buenos Aires T+ 54 11 4361 5929 info@salmson.com.ar</p> <p>Austria WILO Pumpen Österreich GmbH 1230 Wien T +43 507 507-0 office@wilo.at</p> <p>Azerbaijan WILO Caspian LLC 1065 Baku T +994 12 5962372 info@wilo.az</p> <p>Belarus WILO Bel OOO 220035 Minsk T +375 17 2503393 wilobel@wilo.by</p> <p>Belgium WILO SA/NV 1083 Ganshoren T +3224823333 info@wilo.be</p> <p>Bulgaria WILO Bulgaria Ltd. 1125 Sofia T +359 2 9701970 info@wilo.bg</p>	<p>Denmark WILO Danmark A/S 2690 Karlslunde T +45 70 253312 wilo@wilo.dk</p> <p>Estonia WILO Eesti OÜ 12618 Tallinn T +372 6509780 info@wilo.ee</p> <p>Finland WILO Finland OY 02330 Espoo T +358 207401540 wilo@wilo.fi</p> <p>France WILO S.A.S. 78390 Bois d'Arcy T +33 1 30050930 info@wilo.fr</p> <p>Great Britain WILO (U.K.) Ltd. DE14 2WJ Burton upon-Trent T +44 1283 523000 sales@wilo.co.uk</p> <p>Greece WILO Hellas AG 14569 Anixi (Attika) T +302 10 6248300 wilo.info@wilo.gr</p> <p>Hungary</p>	<p>Ireland WILO Engineering Ltd. Limerick T +353 61 227566 sales@wilo.ie</p> <p>Italy WILO Italia s.r.l. 20068 Peschiera Bo rronero (Milano) T +39 25538351 wilo.italia@wilo.it</p> <p>Kazakhstan WILO Central Asia 050002 Almaty T +7 727 2785961 in.pak@wilo.kz</p> <p>Korea WILO Pumps Ltd. 621-807 Gimhae Gyeongnam T +82 55 3405890 wilo@wilo.co.kr</p> <p>Latvia WILO Baltic SIA 1019 Riga T +371 67 145229 mail@wilo.lv</p> <p>Lebanon WILO SALMSON Lebanon 12022030 El Metn</p>	<p>Portugal Bombas Wilo-Salmson Portugal Lda. 4050-040 Porto T +351 22 2080350 bombas@wilo.pt</p> <p>Romania WILO Romania s.r.l. 077040 Com. Chiajna Jud. Ilfov T +40 21 3170164 wilo@wilo.ro</p> <p>Russia WILO Rus ooo 123592 Moscow T +7 495 7810690 wilo@wilo.ru</p> <p>Saudi Arabia WILO ME – Riyadh Riyadh 11465 T +966 1 4624430 wshoula@watanaiaind.com</p> <p>Serbia and Montenegro WILO Beograd d.o.o. 11000 Beograd T +381112851278 office@wilo.co.yu</p> <p>Slovakia WILO Slovakia s.r.o.</p>	<p>Sweden WILO Sverige AB 35246 Växjö T +46 470 727600 wilo@wilo.se</p> <p>Switzerland EMB Pumpen AG 4310 Rheinfelden T +41 61 83680-20 info@emb-pumpen.ch</p> <p>Taiwan WILO-EMU Taiwan Co. Ltd. 110 Taipei T +886 227 391655 nelson.wu@wiloemutaiwan.com.tw</p> <p>Turkey WILO Pompa Sistemleri San. ve Tic. A.Ş. 34530 Istanbul T +90 216 6610211 wilo@wilo.com.tr</p> <p>Ukraine WILO Ukraina t.o.w. 01033 Kiev T +38 044 2011870 wilo@wilo.ua</p> <p>United Arab Emirates Wilo Middle East FZ</p>
---	---	--	--	--

Canada WILO Canada Inc. Calgary, Alberta T2 A 5L4 T +1 403 2769456 bill.lowe@wilo-na.com China WILO China Ltd. 101300 Beijing T +861058041888 wilobj@wilo.com.cn Croatia WILO Hrvatska d.o.o. 10090 Zagreb T +38 51 3430914 wilo-hrvatska@wilo.hr Czech Republic WILO Praha s.r.o. 25101 Cestlice T +420 234 098711 info@wilo.cz	WILO Magyarország Kft 2045 Törökbálint (Budapest) T +36 23 889500 wilo@wilo.hu India WILO India Mather and Platt Pumps Ltd. Pune 411019 T +91 20 27442100 service@pun.matherplatt.co.in Indonesia WILO Pumps Indon esia Jakarta Selatan 121 40 T +62 21 7247676 citrawilo@cbn.net.id	T +961 4 722280 wsl@cyberia.net.lb Lithuania WILO Lietuva UAB 03202 Vilnius T +370 5 2136495 mail@wilo.lt The Netherlands WILO Nederland b.v. . 1551 NA Westzaan T +31 88 9456 000 info@wilo.nl Norway WILO Norge AS 0975 Oslo T +47 22 804570 wilo@wilo.no Poland WILO Polska Sp. z. o.o. 05-090 Raszyn T +48 22 7026161 wilo@wilo.pl	82008 Bratislava 28 T +421 2 45520122 wilo@wilo.sk Slovenia WILO Adriatic d.o.o. 1000 Ljubljana T +38615838130 wilo.adriatic@wilo.si South Africa Salmson South Afri ca 1610 Edenvale T +27 11 6082780 errol.cornelius@salmson.co.za Spain WILO Ibérica S.A. 28806 Alcalá de He nares (Madrid) T +34 91 8797100 wilo.iberica@wilo.es	E Jebel Ali – Dubai T +971 4 8864771 info@wilo.com.sa USA WILO-EMUUSA LL C Thomasville, Georgia 31792 T +1 229 5840097 info@wilo-emu.com WILO USA LLC Melrose Park, Illinoi s 60160 T +1708 3389456 mike.easterley@wilo-na.com Vietnam WILO Vietnam Co Lt d. Ho Chi Minh City, Vi etnam T +84 8 38109975 nkminh@wilo.vn
--	---	---	---	---





Wilo – International (Representation offices)

Algeria Bad Ezzouar, Dar El Beid a T +213 21 247979 Armenia 375001 Yerevan T +374 10 544336 Bosnia and Herzegovina 71000 Sarajevo T +387 33 714510	Georgia 0179 Tbilisi T +995 32 306375 Macedonia 1000 Skopje T +389 2 3122058 Mexico 07300 Mexico T +52 55 55863209	Moldova 2012 Chisinau T +373 2 223501 Rep. Mongolia Ulaanbaatar T +976 11 314843 Tajikistan 734025 Dushanbe T +992 37 2232908	Turkmenistan 744000 Ashgabad T +993 12 345838 Uzbekistan 100015 Tashkent T +998 71 1206774
---	---	--	---





WILO SE

Nortkirchenstraße 100
 44263 Dortmund
 Germany
 T 0231 4102-0
 F 0231 4102-7363

Documents / Resources

	wilo 2056576 Protect Module C [pdf] Instruction Manual 2056576, Protect Module C, 2056576 Protect Module C
	wilo 2056576 Protect Module [pdf] Instruction Manual 2056576, Protect Module, 2056576 Protect Module
	wilo 2056576 Protect Module [pdf] Instruction Manual 2056576, Protect Module, 2056576 Protect Module
	wilo 2056576 Protect Module [pdf] Instruction Manual 2056576, Protect Module, 2056576 Protect Module

References

-  [Commercial Distributor & Supply Company | North American](#)
-  [100% WIR | Crisol Holding GmbH](#)
-  [Wilo Corporate - Pioneering for You | WILO](#)
-  [Wilo - Pumpenhersteller in Ihrer Nähe seit 1872 | Wilo](#)